

REPAIR MANUAL 2008

690 SMC EU
690 SMC AUS/UK
690 SMC USA

Article no. 3206042en



KTM

Read this repair manual carefully and thoroughly before beginning work.

Only use **ORIGINAL KTM SPARE PARTS**.

The vehicle will only be able to meet the demands placed on it if the specified service work is performed regularly and properly.

This repair manual was written to correspond to the latest state of this series. We reserve the right to make changes in the interest of technical advancement without at the same time updating this manual.

We shall not provide a description of general workshop methods. Likewise, safety rules that apply in a workshop are not specified here. It is assumed that the repair work will be performed by a fully trained mechanic.

All specifications are non-binding. KTM Sportmotorcycle AG specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. KTM accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of delivery.

© 2010 KTM-Sportmotorcycle AG, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

According to the international quality management standard ISO 9001, KTM uses quality assurance processes that lead to the maximum possible quality of the products.

Issued by: TÜV Management Service

REG.NO. 12 100 6061

KTM-Sportmotorcycle AG
5230 Mattighofen, Austria









| | | | |
|---|----|---|----|
| MEANS OF REPRESENTATION | 5 | Filling the damper with nitrogen | 45 |
| IMPORTANT NOTES | 6 | Installing the spring | 45 |
| LOCATION OF SERIAL NUMBERS | 7 | 05/EXHAUST | 47 |
| Chassis number/type label (690 SMC EU, 690 SMC AUS/UK) | 7 | Removing the exhaust manifold | 47 |
| Chassis number/type label (690 SMC USA) | 7 | Installing exhaust manifold | 47 |
| Key number | 7 | Removing the main silencer | 48 |
| Engine number | 7 | Installing the main silencer | 49 |
| Fork part number | 8 | 06/AIR FILTER | 51 |
| Shock absorber part number | 8 | Removing the air filter | 51 |
| MOTORCYCLE | 9 | Installing the air filter | 51 |
| Raising the motorcycle with the rear wheel stand | 9 | Removing the air filter box | 51 |
| Taking the motorcycle off of the rear wheel stand | 9 | Installing the air filter box | 52 |
| Raising the motorcycle with the front wheel stand | 9 | 07/FUEL TANK, SEAT, TRIM | 54 |
| Taking the motorcycle off of the front wheel stand | 9 | Opening filler cap | 54 |
| Raising the motorcycle with the work stand | 10 | Closing filler cap | 54 |
| Removing the motorcycle from the work stand | 10 | Removing the seat | 54 |
| Starting | 11 | Mounting the seat | 54 |
| Starting the motorcycle to make checks | 11 | Taking off the side cover | 54 |
| 01/FORK, TRIPLE CLAMP | 12 | Mounting the side cover | 55 |
| Adjusting compression damping of fork | 12 | Checking the fuel pressure | 55 |
| Adjusting rebound damping of fork | 12 | Changing the fuel filter | 56 |
| Bleeding the fork legs | 12 | 09/FRONT WHEEL | 59 |
| Cleaning the dust boots of the fork legs | 13 | Removing front wheel | 59 |
| Removing the fork protector | 13 | Installing the front wheel | 59 |
| Installing the fork protector | 13 | Checking the tire air pressure | 60 |
| Removing fork legs | 14 | Checking the tire condition | 60 |
| Installing the fork legs | 15 | Checking the brake discs | 61 |
| Servicing the fork | 16 | 10/REAR WHEEL | 62 |
| Disassembling the fork legs | 17 | Removing rear wheel | 62 |
| Checking the fork legs | 20 | Installing the rear wheel | 62 |
| Assembling the fork legs | 21 | Checking the chain tension | 63 |
| Checking the steering head bearing play | 25 | Adjusting the chain tension | 63 |
| Adjusting the steering head bearing play | 26 | Adjusting chain guide | 64 |
| 02/HANDLEBAR, INSTRUMENTS | 27 | Checking the chain, rear sprocket and engine sprocket | 64 |
| Handlebar position | 27 | Cleaning the chain | 65 |
| Adjusting handlebar position | 27 | Checking the rear hub rubber dampers | 66 |
| Checking the play in the throttle cable | 27 | Checking the spoke tension | 66 |
| Adjusting the play in the throttle cable | 28 | Checking the rim run-out | 67 |
| 04/SHOCK ABSORBER, SWINGARM | 29 | 11/WIRING HARNESS, BATTERY | 68 |
| Adjusting the high-speed compression damping of the shock absorber | 29 | Removing the battery | 68 |
| Adjusting the low-speed compression damping of the shock absorber | 29 | Installing the battery | 68 |
| Adjusting the rebound damping of the shock absorber | 30 | Disconnecting the battery | 68 |
| Measuring the unloaded rear wheel sag | 30 | Connecting the battery | 69 |
| Checking the static sag of the shock absorber | 30 | Recharging the battery | 69 |
| Checking the riding sag of the shock absorber | 31 | Checking the charging voltage | 70 |
| Adjusting the spring preload of the shock absorber | 31 | Changing the main fuse | 70 |
| Adjusting the riding sag | 32 | Changing fuses of individual power consumers | 71 |
| Removing the shock absorber | 32 | Adjusting the engine characteristic | 72 |
| Installing the shock absorber | 33 | 13/BRAKE SYSTEM | 73 |
| Servicing the shock absorber | 34 | Checking the front brake linings | 73 |
| Removing the spring | 35 | Changing the front brake linings | 73 |
| Dismantling the damper | 35 | Adjusting the basic position of the hand brake lever | 74 |
| Disassembling the piston rod | 36 | Checking the front brake fluid level | 74 |
| Checking the damper | 37 | Adding front brake fluid | 75 |
| Removing the heim joint | 38 | Changing the front brake fluid | 75 |
| Installing the heim joint | 39 | Checking the rear brake linings | 76 |
| Assembling the piston rod | 40 | Changing rear brake linings | 77 |
| Assembling the damper | 41 | Checking the free travel of foot brake lever | 78 |
| Bleeding and filling the damper | 43 | Adjusting the basic position of the foot brake lever | 78 |
| | | Checking rear brake fluid level | 79 |
| | | Adding rear brake fluid | 79 |

| | | | |
|--|-----|--|-----|
| Changing the rear brake fluid..... | 80 | Measuring axial clearance of crankshaft and balancer shaft | 112 |
| 14/LIGHT SYSTEM, INSTRUMENTS | 82 | Cylinder - Nikasil® coating..... | 112 |
| Setting kilometers or miles | 82 | Checking/measuring the cylinder..... | 113 |
| Setting the clock | 82 | Checking/measuring the piston | 113 |
| Combination instrument - setting/resetting TRIP 1 | 82 | Checking piston ring end gap..... | 114 |
| Combination instrument - setting/resetting TRIP 2..... | 83 | Checking piston/cylinder mounting clearance | 115 |
| Combination instrument - setting the wheel circumference | 83 | Checking oil pumps for wear..... | 115 |
| Checking the headlight setting..... | 84 | Replacing autodecompressor | 115 |
| Adjusting the headlight range | 84 | Preparing timing chain tensioner for installation | 116 |
| Removing the headlight mask with the headlight | 84 | Checking timing assembly..... | 117 |
| Installing the headlight mask with the headlight..... | 85 | Removing rocker arm | 117 |
| Changing the parking light bulb | 85 | Changing camshaft bearing | 117 |
| Changing the headlight bulb..... | 86 | Removing valves..... | 118 |
| Changing the flasher bulb | 86 | Checking valves..... | 119 |
| 30/ENGINE..... | 88 | Checking valve springs..... | 119 |
| Removing the engine | 88 | Checking valve spring retainer | 119 |
| Installing the engine | 90 | Checking cylinder head | 119 |
| 30/DISASSEMBLING THE ENGINE..... | 94 | Installing valves | 120 |
| Clamping engine into engine work stand | 94 | Installing rocker arm | 121 |
| Draining the engine oil..... | 94 | Dismantling antihopping clutch | 121 |
| Removing starter motor | 94 | Checking the clutch..... | 122 |
| Removing valve cover..... | 94 | Preassembling antihopping clutch..... | 123 |
| Removing the alternator cover..... | 95 | Checking shift mechanism | 124 |
| Removing spacer | 95 | Preassembling shift shaft | 124 |
| Removing gear position sensor | 95 | Disassembling the main shaft | 125 |
| Removing oil filter | 95 | Dismantling countershaft | 125 |
| Removing thermostat | 96 | Checking the transmission..... | 126 |
| Setting engine to ignition top dead center..... | 96 | Assembling the main shaft | 127 |
| Removing water pump wheel | 96 | Assembling countershaft | 128 |
| Removing clutch cover..... | 97 | Checking electric starter drive..... | 129 |
| Removing spacer and spring..... | 97 | Removing freewheel..... | 129 |
| Removing spark plug | 97 | Checking freewheel..... | 130 |
| Removing timing chain tensioner | 98 | Installing freewheel | 130 |
| Removing camshafts..... | 98 | 30/ASSEMBLING THE ENGINE | 132 |
| Removing cylinder head | 98 | Installing transmission shafts | 132 |
| Removing piston..... | 98 | Installing crankshaft and balancer shaft..... | 133 |
| Removing rotor..... | 99 | Installing left engine case | 133 |
| Removing timing chain rails | 99 | Installing oil pumps..... | 134 |
| Removing timing chain and timing chain sprocket | 100 | Installing locking lever | 134 |
| Removing crankshaft position sensor | 100 | Installing shift drum locating..... | 134 |
| Removing clutch cage..... | 100 | Installing shift shaft..... | 135 |
| Removing primary gear..... | 102 | Installing starter drive | 135 |
| Removing starter drive | 102 | Installing primary gear | 135 |
| Removing shift shaft | 102 | Installing clutch cage..... | 136 |
| Removing shift drum locating | 102 | Installing crankshaft position sensor..... | 137 |
| Removing locking lever | 103 | Installing timing chain and timing chain sprocket..... | 137 |
| Removing oil pumps | 103 | Installing timing chain rails | 138 |
| Removing left engine case..... | 103 | Installing rotor..... | 138 |
| Removing crankshaft and balancer shaft..... | 104 | Adjusting crankshaft position sensor distance..... | 138 |
| Removing transmission shafts..... | 104 | Setting engine to top dead center..... | 139 |
| 30/ENGINE - WORK ON INDIVIDUAL PARTS..... | 106 | Installing piston | 139 |
| Work on the right section of the engine case | 106 | Installing cylinder head | 140 |
| Work on the left section of the engine case | 107 | Installing camshafts | 141 |
| Work on the clutch cover..... | 108 | Installing timing chain tensioner | 141 |
| Removing crankshaft bearing inner ring | 109 | Checking valve clearance | 142 |
| Removing balancer shaft drive wheel | 109 | Adjusting valve clearance | 142 |
| Changing the conrod bearing | 109 | Installing spark plug | 143 |
| Checking crankshaft run-out at bearing pin | 111 | Installing spacer and spring..... | 143 |
| Installing balancer shaft drive wheel..... | 111 | Installing clutch cover..... | 143 |
| Installing crankshaft bearing inner ring..... | 111 | Mounting water pump cover..... | 144 |
| | | Installing thermostat..... | 144 |

| | | | |
|---|-----|---------------------------|-----|
| Installing the oil filter | 144 | Page 3 of 10..... | 188 |
| Installing gear position sensor..... | 145 | Page 4 of 10..... | 190 |
| Installing the spacer | 145 | Page 5 of 10..... | 192 |
| Installing oil screens..... | 146 | Page 6 of 10..... | 194 |
| Installing alternator cover..... | 146 | Page 7 of 10..... | 196 |
| Installing starter motor..... | 147 | Page 8 of 10..... | 198 |
| Installing valve cover | 147 | Page 9 of 10..... | 200 |
| Taking engine off universal mounting rack | 147 | Page 10 of 10..... | 202 |
| 32/CLUTCH | 148 | SUBSTANCES..... | 204 |
| Checking/rectifying the fluid level of the hydraulic clutch | 148 | AUXILIARY SUBSTANCES..... | 206 |
| 35/WATER PUMP, COOLING SYSTEM | 149 | SPECIAL TOOLS..... | 208 |
| Draining coolant..... | 149 | STANDARDS..... | 220 |
| Filling the cooling system..... | 149 | INDEX | 221 |
| Checking the antifreeze and coolant level | 150 | | |
| Checking the coolant level..... | 151 | | |
| 38/LUBRICATION SYSTEM | 152 | | |
| Oil circuit | 152 | | |
| Checking the engine oil level | 152 | | |
| Checking the engine oil pressure..... | 153 | | |
| Changing the engine oil and filter, cleaning the oil screens..... | 154 | | |
| Draining engine oil | 154 | | |
| Removing the oil filter..... | 155 | | |
| Installing the oil filter | 155 | | |
| Cleaning the oil screens | 156 | | |
| Filling up with engine oil..... | 157 | | |
| Adding engine oil | 157 | | |
| 39/IGNITION SYSTEM | 158 | | |
| Alternator - checking the stator winding..... | 158 | | |
| Checking the spark plug connector..... | 158 | | |
| Ignition coil - checking the secondary winding..... | 159 | | |
| 41/THROTTLE VALVE BODY..... | 160 | | |
| Checking the basic setting of the motor drive | 160 | | |
| Adjusting the basic setting of the motor drive..... | 161 | | |
| Flashing the EFI control unit and/or the EPT control unit..... | 164 | | |
| Requesting the enabling code..... | 165 | | |
| Coding the EFI control unit and/or EPT control unit | 166 | | |
| TECHNICAL DATA - ENGINE | 168 | | |
| Capacity - engine oil | 168 | | |
| Capacity - coolant..... | 168 | | |
| TECHNICAL DATA - TOLERANCE, WEAR LIMITS OF ENGINE | 169 | | |
| TECHNICAL DATA - ENGINE TIGHTENING TORQUES..... | 171 | | |
| TECHNICAL DATA - CHASSIS | 173 | | |
| Lighting equipment | 173 | | |
| Capacity - fuel..... | 174 | | |
| TECHNICAL DATA - FORK..... | 175 | | |
| TECHNICAL DATA - SHOCK ABSORBER | 176 | | |
| TECHNICAL DATA - CHASSIS TIGHTENING TORQUES | 177 | | |
| CLEANING/PROTECTIVE TREATMENT | 179 | | |
| Cleaning the motorcycle..... | 179 | | |
| Protective treatment for winter operation | 180 | | |
| STORAGE | 181 | | |
| Storage..... | 181 | | |
| Putting into operation after storage | 181 | | |
| SERVICE SCHEDULE..... | 182 | | |
| Service schedule | 182 | | |
| WIRING DIAGRAM | 184 | | |
| Page 1 of 10..... | 184 | | |
| Page 2 of 10..... | 186 | | |

Symbols used

The symbols used are explained in the following.

| | |
|--|---|
|  | Indicates an expected reaction (e.g. of a work step or a function). |
|  | Indicates an unexpected reaction (e.g. of a work step or a function). |
|  | Identifies a page reference (more information is provided on the specified page). |
|  | Indicates information with more details or tips. |
|  | Indicates the result of a testing step. |
|  | Identifies a voltage measurement. |
|  | Identifies a current measurement. |
|  | Identifies a resistance measurement. |

Formats used

The typographical and other formats used are explained below.

| | |
|----------------------|-------------------------------|
| Specific name | Indicates a proprietary name. |
| Name® | Identifies a protected name. |
| Brand™ | Identifies a trademark. |

Warranty

The work prescribed in the service plan must only be carried out in an authorized KTM workshop and confirmed in the service record; otherwise all warranty claims will be disregarded. No warranty claim can be met for damage resulting from manipulation and/or other changes to the vehicle.

Fuel, oils, etc.

You should use the fuels, oils and greases according to specifications as listed in the repair manual.

Spare parts, accessories

Only use spare parts and accessories approved and/or recommended by KTM. KTM accepts no liability for other products and any resulting damage.

You will find the current **KTM PowerParts** for your vehicle on the KTM website.
International KTM Website: <http://www.ktm.com>

Work rules

Special tools are necessary for certain tasks. The tools are not contained in the vehicle but can be ordered under the number in parentheses. Example: valve spring mounter (59029019000)

During assembly, non-reusable parts (e.g. self-locking screws and nuts, seals and seal rings, O-rings, pins, lock washers) must be replaced by new parts.

If a thread lock (e.g. **Loctite®**) is used for screw connections, be sure to comply with the manufacturer's specific instructions on its usage.

Parts that you want to reuse following repairs and servicing should be cleaned and checked for damage and wear. Change damaged or worn parts.

Following repairs or servicing, the vehicle must be checked for roadworthiness.

Notes/warnings

Pay close attention to the notes/warnings.



Info

Various information and warning labels are affixed to the vehicle. Do not remove information/warning labels. If they are missing, you or others may not recognize potential hazards and may therefore be injured.

Grades of risks



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.




Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

Repair manual


- Read this repair manual carefully and thoroughly before beginning work. It contains useful information and tips that will help you repair and service your motorcycle.
- This manual assumes that the necessary special KTM tools and workplace and workshop equipment are available.

Chassis number/type label (690 SMC EU, 690 SMC AUS/UK)




The chassis number ❶ is stamped on the right of the steering head.
The type label ❷ is on the right of the frame behind the steering head.

Chassis number/type label (690 SMC USA)



The chassis number ❶ is stamped on the right of the steering head.
The USA type label ❷ is on the right of the frame behind the steering head.



The Canada type label ❸ is on the right of the frame behind the steering head.

Key number




The key number ❶ can be found on the **KEYCODECARD**.

i Info


You need the key number to order a spare key. Keep the **KEYCODECARD** in a safe place.

Engine number



The engine number ❶ is stamped on the left side of the engine under the engine sprocket.

Fork part number



600480-10

The fork part number ❶ is stamped on the inner side of the fork stub.

Shock absorber part number



100216-10

The shock absorber part number ❶ is on the right of the shock absorber.

Raising the motorcycle with the rear wheel stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Insert the adapter into the rear wheel stand and screw into the swingarm on both sides.

| |
|----------------------------------|
| Adapter (61029055110) (🔧 p. 210) |
|----------------------------------|

| |
|---|
| Rear wheel stand (61029055100) (🔧 p. 210) |
|---|

- Position the motorcycle upright, align the stand and raise the motorcycle.

Taking the motorcycle off of the rear wheel stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Secure the motorcycle against falling over.
- Remove the rear wheel stand and lean the vehicle on the side stand.

Raising the motorcycle with the front wheel stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Raise the motorcycle with the rear wheel stand. (🔧 p. 9)
- Move the handlebar to the straight-ahead position. Align the front wheel stand with the fork legs using the adapters.

| |
|--|
| Front wheel stand (61029055300) (🔧 p. 211) |
|--|



Info

Always raise the rear of the motorcycle first.

- Raise the front of the motorcycle.

Taking the motorcycle off of the front wheel stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.
- Secure the motorcycle against falling over.
- Remove the front wheel stand.

Raising the motorcycle with the work stand

Note


Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Mount the special tool on the footrest.

Work stand adapter (75029036000) (➡ p. 213)



- Position the motorcycle upright, align the special tool and raise the motorcycle.


Work stand (62529055000) (➡ p. 211)

Removing the motorcycle from the work stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.




- Secure the motorcycle against falling over.
- Remove the work stand and lean the vehicle on the side stand.




- Remove the special tool.

Starting

 **Danger**
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

 **Caution**
Danger of accidents If the vehicle is operated with a discharged battery or without a battery, electronic components and safety equipment may be damaged.


- Never operate the vehicle with a discharged battery or without a battery.

Note
Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.




- Turn the emergency OFF switch to the position ○.
- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- ✓ After you switch on the ignition, you can hear the fuel pump working for about 2 seconds. At the same time, the function test of the combination instrument is run.
- Shift gear to neutral.
- ✓ The green idling speed indicator lamp **N** lights up.
- Press the electric starter button ⓘ.


 **Info**
Do not press the electric starter button until the function test of the combination instrument is finished.
When starting, **DO NOT** open the throttle. If you open the throttle during the starting procedure, fuel is not injected by the engine management system and the engine cannot start.
Press the starter for a maximum of 5 seconds. Wait for at least 5 seconds before trying again.
This motorcycle is equipped with a safety start system. You can only start the engine if the gearbox is in neutral or if the clutch is pulled when a gear is engaged. If the side stand is folded out and you shift into gear and release the clutch, the engine stops.


- Take the weight off the side stand and swing it back up with your foot as far as it will go.

Starting the motorcycle to make checks


 **Danger**
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

 **Info**
Press the starter for a maximum of 5 seconds. Wait for a least 5 seconds before trying again.



- Turn the emergency OFF switch to the position ○.
- Shift gear to neutral.
- Switch on the ignition.
- Press the electric starter button ⓘ.

 **Info**
Do not open the throttle.

Adjusting compression damping of fork



Info

The hydraulic compression damping determines the fork suspension behavior.



- Turn adjusting screws **1** clockwise until they stop.



Info

The adjusting screws are located at the bottom end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise the number of clicks corresponding to the fork type.

Guideline

| Compression damping | |
|---------------------|-----------|
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |



Info


Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Adjusting rebound damping of fork



Info

The hydraulic rebound damping determines the fork suspension behavior.



- Turn adjusting screws **1** clockwise until they stop.



Info

The adjusting screws are located at the top end of the fork legs. Make the same adjustment on both fork legs.

- Turn back counterclockwise the number of clicks corresponding to the fork type.

Guideline


| Rebound damping | |
|-----------------|-----------|
| Comfort | 15 clicks |
| Standard | 10 clicks |
| Sport | 5 clicks |
| Full payload | 5 clicks |



Info

Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Bleeding the fork legs




- Lean the motorcycle on the side stand.
- Remove bleeder screws **1** briefly.
- ✓ Any excess pressure escapes from the interior of the fork.
- Mount and tighten bleeder screws.



Info

Carry out this action on both fork legs.

Cleaning the dust boots of the fork legs



- Jack up the motorcycle and secure it against falling over.
 - ✓ The front wheel is no longer in contact with the ground and the fork legs are no longer under tension.
- Remove the fork protector. (☛ p. 13)
- Push dust boot 1 of both fork legs downwards.



Info

The dust boots should remove dust and coarse dirt particles from the fork tubes. Over time, dirt can penetrate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean and oil the dust boots and inner fork tube of both fork legs.

Universal oil spray (☛ p. 207)


- Press the dust boots back into their normal position.
- Remove excess oil.
- Install the fork protector. (☛ p. 13)
- Remove the motorcycle from the lift stand.

Removing the fork protector



- Remove screws 1 and take off clamp.
- Remove screws 2 on left fork leg. Remove the fork protector.
- Remove the screws on the right fork leg. Remove the fork protector.

Installing the fork protector



- Position the fork protection on the left fork leg. Mount and tighten screws 1.

Guideline

| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|


- Position the brake line and cable harness. Put the clamp on, mount and tighten screws 2.

- Position the fork protection on the right fork leg. Mount and tighten the screws.

Guideline

| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|


Removing fork legs



- Raise the motorcycle with the work stand. (☛ p. 10)
- Tie the rear of the vehicle down.
- Remove screws ① and spacers ②.
- Press back the brake linings with a light lateral tilting of the brake caliper on the brake disc. Carefully pull the brake caliper backwards from the brake disc.

**Info**

Do not pull the handbrake lever when the brake caliper is removed.




- Loosen screws ③ and ④.
- Unscrew screw ③ about 6 turns and press your hand on the screw to push the wheel spindle out of the axle clamp. Remove screw ③.


**Warning**

Danger of accidents Reduced braking efficiency caused by damaged brake discs.


- Always lay the wheel down in such a way that the brake disc is not damaged.




- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.
- Remove screws ⑤ and the clamp. Take the brake line and wiring harness out of the holder.



- Remove the screws of the wheel speed sensor ⑥. Hang the wheel speed sensor to one side.




- Remove screws ⑦. Take off the fork protector.



- Loosen the screws 8 of the triple clamp. Remove the fork legs from the bottom.

Installing the fork legs



- Slide the fork legs into the triple clamps on both sides.



Info

The bleeder screws must face forwards.

The topmost milled groove in the fork leg must be flush with the top edge of the upper triple clamp.

The upper fork projection must be the same on both sides.

- Tighten screws 1 on both sides.



Guideline

| | | |
|----------------------------|----|------------------------|
| Screw, top triple clamp | M8 | 17 Nm (12.5 lbf ft) |
| Screw, bottom triple clamp | M8 | 12 Nm (8.9 lbf ft) |

- Position the fork protection. Mount and tighten screws 2.

Guideline


| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|




- Position the wheel speed sensor. Mount and tighten screws 3.

Guideline

| | | | |
|---------------------------|----|----------------------|---------------|
| Screw, wheel speed sensor | M4 | 2 Nm (1.5 lbf ft) | Loctite® 243™ |
|---------------------------|----|----------------------|---------------|



- Position the brake line, wiring harness and clamp.
- Mount and tighten screws 4.

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.

- Clean screw 5 and the wheel spindle.
- Lift the front wheel into the fork, position it, and insert the wheel spindle.
- Mount and tighten screw 5.

Guideline

| | | |
|----------------------------|---------|------------------------|
| Screw, front wheel spindle | M24x1.5 | 40 Nm (29.5 lbf ft) |
|----------------------------|---------|------------------------|

- Position the brake caliper and check that the brake linings are seated correctly.
- Mount screws 6 spacers 7 but do not tighten.
- Operate the hand brake lever repeatedly until the brake linings lie on the brake disc and there is a pressure point. Fix the hand brake lever in the activated position.
- ✓ The brake caliper straightens.
- Fully tighten screw 6.



Guideline

| | | | |
|----------------------------|----------|------------------------|---------------|
| Screw, front brake caliper | M10x1.25 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|----------------------------|----------|------------------------|---------------|

- Remove the fixation of the hand brake lever.
- Unload the rear of the vehicle.
- Remove the motorcycle from the work stand. (p. 10)
- Pull the front brake and compress the fork powerfully a few times.
- ✓ The fork legs straighten.
- Tighten screws 8.

Guideline


| | | |
|------------------|----|------------------------|
| Screw, fork stub | M8 | 15 Nm (11.1 lbf ft) |
|------------------|----|------------------------|

**Servicing the fork****Info**

These operations are the same on both fork legs.

Condition

The fork legs have been removed.



- Disassemble the fork legs. (☛ p. 17)
- Check the fork legs. (☛ p. 20)
- Assemble the fork legs. (☛ p. 21)

Disassembling the fork legs




Info

These operations are the same on both fork legs.

Condition

The fork legs have been removed.

- Establish and note the current state of the rebound damping ❶ and compression damping ❷.
- Completely open the adjusters of the rebound and compression damping.



- Clamp the fork leg in the area of the lower triple clamp.

Clamping stand (T1403S) (☛ p. 219)





- Loosen screw cover ❸.



Info

The screw cover cannot be removed yet.






- Release the fork leg and clamp it with the axle clamp.


Info

Use soft jaws.




- Push the outer tube downward.
- Pull the spring downwards. Mount the special tool on the hexagon.


Open-end wrench (T14032) (☛ p. 219)


Info


The preload spacers ④ should be above the special tool.



- Clamp the special tool in the vise. Loosen screw cover ③.



- Remove screw cover ③ with preload spacers ④.
- Remove adjusting tube ⑤.




- Pull the spring downward. Remove the special tool.
- Remove the spring.




- Drain the fork oil.


Info

Pull out and push in the piston rod a few times to empty the cartridge.



- Clamp the fork leg with the axle clamp.
- Remove screws ⑥ of the axle clamp.



- Loosen screw ⑦ of the cartridge and remove it with the sealing ring.




Info


Place a container underneath to catch any oil that may run out.




- Remove the cartridge.



- Remove valve ⑧ of the rebound damping with the spring from the cartridge.



- Remove dust boot ⑨.




- Remove lock ring ⑩.



Info

The lock ring has a beveled end where a screwdriver can be applied.



- Heat up the outer tube in area **A** of the lower sliding bushings.

Guideline

50 °C (122 °F)

- Pull the outer tube of the fork off of the inner tube with a jerk.



Info

The lower sliding bushing **11** must be pulled from its bearing seat.



- Remove the upper sliding bushing **12**.



Info

Without using tools, carefully pull the stack apart by hand.



- Take off the lower sliding bushing **11**.
- Take off support ring **13**.
- Take off seal ring **14**.
- Take off lock ring **10**.
- Take off dust boot **9**.

Checking the fork legs

Condition

The fork legs have been disassembled.


- Check the inner tube and the axle clamp for damage.
 - » If damage is found:
 - Replace the inner tube.




- Measure the external diameter of the inner tube in several places.

| | |
|---------------------------------|---|
| External diameter of inner tube | 47.975... 48.005 mm (1.88878... 1.88996 in) |
|---------------------------------|---|

- » If the measured value is less than the specified value:
 - Replace the inner tube.







- Measure the run-out of the inner tube.

| | |
|-----------------------|--|
| Run-out of inner tube | $\leq 0.20 \text{ mm } (\leq 0.0079 \text{ in})$ |
|-----------------------|--|


- » If the measured value is greater than the specified value:
 - Replace the inner tube.



- Check the outer tube for damage.
 - » If damage is found:
 - Replace the outer tube.



- Check the surface of the sliding bushings.
 - » If the bronze-colored layer **A** under sliding layer **B** is visible:
 - Replace the sliding bushings.



- Check the spring length.

Guideline

| | |
|--------------------------------------|------------------|
| Spring length with preload spacer(s) | 480 mm (18.9 in) |
|--------------------------------------|------------------|

- » If the measured value is greater than the specified value:
 - Reduce the strength of the pretensioning bushes.
- » If the measured value is less than the specified value:
 - Increase the strength of the preload spacers.

Assembling the fork legs



Info

These operations are the same on both fork legs.



- Check the fork legs. (☞ p. 20)
- Clamp the inner tube with the axle clamp.
- Mount the special tool.

| |
|--------------------------------------|
| Protecting sleeve (T1401) (☞ p. 218) |
|--------------------------------------|

- Grease and push on dust boot **1**.


| |
|-----------------------------|
| Lubricant (T511) (☞ p. 206) |
|-----------------------------|



Info

Always replace the dust boot, seal ring, lock ring, and support ring. Install the dust boot with the sealing lip and spring expander facing downward.

- Push on lock ring **2**.



- Grease and push on seal ring ③.

Lubricant (T511) (☞ p. 206)



Info

Sealing ring downward, open side upward.

- Push on support ring ④.
- Remove the special tool.
- Sand the edges of the sliding bushes with 600-grain sandpaper, then clean and grease them.

Fork oil (SAE 5) (☞ p. 205)

- Push on the lower sliding bushing ⑤.
- Mount the upper sliding bushing ⑥.



Info

Without using tools, carefully pull the stack apart by hand.

- Push on the outer tube.
- Heat up the outer tube in area ① of the lower sliding bushings.

Guideline

50 °C (122 °F)

- Hold the lower sliding bushing with the longer side of the special tool.

Assembly tool (T1402S) (☞ p. 218)

- Press on the outer tube as far as it will go.

- Position the support ring.
- Hold the seal ring with the shorter side of the special tool.

Assembly tool (T1402S) (☞ p. 218)


- Press on the outer tube as far as it will go.

- Mount lock ring ⑦.




Info

The lock ring must engage audibly.



- Install dust boot 8.



- Grease the O-ring of valve 9 of the rebound damping.

Lubricant (T158) (☛ p. 206)

- Mount valve 9 of the rebound damping with the spring on adjusting tube 10.
- Mount valve 9 of the rebound damping from below in cartridge 11.
- ✓ The adjusting tube protrudes 5 mm from the cartridge and can be pressed in against the resistance of the spring.
- ✗ The adjusting tube protrudes more than 7 mm from the cartridge and cannot be pressed in against the resistance of the spring.
- Screw on fluid barrier B as far as it will go.



Info

The fluid barrier must be tightened as much as possible. Do not use tools.




- Install the special tool on the cartridge.

Gripping tool (T14026S1) (☛ p. 218)



Info


The special tool must be used to prevent the adjusting tube being lifted and thus to prevent oil from reaching the piston rod.



- Push the cartridge with the spring seat and preload spacer into the inner tube.
- Mount screw 12 of the cartridge with the seal ring and tighten it.

Guideline

| | | |
|-----------------|-------|------------------------|
| Cartridge screw | M12x1 | 25 Nm (18.4 lbf ft) |
|-----------------|-------|------------------------|



- Grease and mount screws 13 of the axle clamp but do not tighten.

Lubricant (T152) (☛ p. 207)




- Clamp the fork vertically.
- Fill it with fork oil.

| | | |
|-----------------------|---------------------------|-----------------------------|
| Fork oil per fork leg | 634 ml (21.44 fl. oz.) | Fork oil (SAE 5) (☛ p. 205) |
|-----------------------|---------------------------|-----------------------------|

**Info**

Pull out and push in the piston rod completely a few times to remove air from the cartridge.



- Remove pin **C** of the special tool.

Gripping tool (T14026S1) (☛ p. 218)

- Pull out the piston rod. Mount the spring. Mount the spring again.

Guideline

| Spring rate | |
|-------------------|-----------------------|
| Soft | 5.0 N/mm (28.6 lb/in) |
| Medium (standard) | 5.2 N/mm (29.7 lb/in) |
| Hard | 5.4 N/mm (30.8 lb/in) |

- Pull the spring downwards. Mount the special tool on the hexagonal part.

Open-end wrench (T14032) (☛ p. 219)

- Remove the special tool.

Gripping tool (T14026S1) (☛ p. 218)



- Clamp the special tool in the vise.
- Grease the thread of the piston rod.

Lubricant (T159) (☛ p. 207)

- Grease the upper edge of the piston rod.

Lubricant (T158) (☛ p. 206)

- Screw the screw cover with the preload spacers on to the piston rod.

**Info**

The screw cover must be screwed to the stop before the piston rod starts to turn. If the thread of the piston rod is stiff, it must be held to prevent it from turning. If the screw cover is not screwed to the stop, the rebound adjustment will not work correctly.

- Tighten the screw cover.

Guideline

| | | |
|---------------------------|-------|------------------------|
| Screw cover on piston rod | M12x1 | 25 Nm (18.4 lbf ft) |
|---------------------------|-------|------------------------|

- Release the special tool. Pull the spring downward and take off the special tool.





- Push the outer tube upward.
- Clamp the fork in the area of the lower triple clamp.

Clamping stand (T1403S) (☞ p. 219)


- Grease the O-ring of the screw cover.

Lubricant (T511) (☞ p. 206)

- Screw on and tighten the screw cover.

Guideline

| | | |
|---------------------------|---------|------------------------|
| Screw cover on outer tube | M51x1.5 | 50 Nm (36.9 lbf ft) |
|---------------------------|---------|------------------------|



Alternative 1

- Turn the adjusting screw of rebound damping 15 and the adjusting screw of compression damping 16 clockwise as far as possible.
- Turn back counterclockwise by the number of clicks corresponding to the fork leg type.

Guideline

| Rebound damping | |
|---------------------|-----------|
| Comfort | 15 clicks |
| Standard | 10 clicks |
| Sport | 5 clicks |
| Full payload | 5 clicks |
| Compression damping | |
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |

Alternative 2



Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.

- Turn the adjusting screws to the position they were in before dismantling.

Checking the steering head bearing play



Warning

Danger of accidents Unstable vehicle handling from incorrect steering head bearing play.


- Adjust the steering head bearing play without delay.



Info

If the bike is driven for a longer time with play in the steering head bearing, the bearing and the bearing seats in the frame can be damaged after time.

- Raise the motorcycle and secure it against falling over.
- ✓ The front wheel is no longer in contact with the ground and the fork legs are no longer under tension.




- Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

No play should be noticeable in the steering head bearing.
- » If there is noticeable play present:
 - Adjust the play of the steering head bearing. (🔧 p. 26)
- Move the handlebar to and fro over the entire steering range.


The handlebar must be able to move easily over the entire steering range. No resting locations should be noticeable.
- » If click positions are noticeable:
 - Adjust the play of the steering head bearing. (🔧 p. 26)
 - Check the steering head bearing and change if necessary.
- Remove the motorcycle from the work stand.

Adjusting the steering head bearing play



- Raise the motorcycle and secure it against falling over.
 - ✓ The front wheel is no longer in contact with the ground and the fork legs are no longer under tension.
 - Loosen screws ❶. Remove screw ❷.
 - Loosen and retighten screw ❸.
- Guideline
- | | | |
|--------------------------|---------|--------------------|
| Screw, top steering head | M20x1.5 | 10 Nm (7.4 lbf ft) |
|--------------------------|---------|--------------------|
- Using a plastic hammer, tap lightly on the upper triple clamp to avoid strains.
 - Fully tighten screw ❶.
- Guideline
- | | | |
|-------------------------|----|---------------------|
| Screw, top triple clamp | M8 | 17 Nm (12.5 lbf ft) |
|-------------------------|----|---------------------|
- Mount and tighten screw ❷.
- Guideline
- | | | | |
|----------------------|----|---------------------|---------------|
| Screw, steering stem | M8 | 20 Nm (14.8 lbf ft) | Loctite® 243™ |
|----------------------|----|---------------------|---------------|
- Check the steering head bearing play. (🔧 p. 25)
 - Remove the motorcycle from the work stand.

Handlebar position



On the upper triple clamp, there are 2 holes at a distance **A** to each other.


| | |
|---------------------------------|-----------------|
| Distance A between holes | 15 mm (0.59 in) |
|---------------------------------|-----------------|

The holes on the handlebar support are placed at a distance **B** from the center.

| | |
|---------------------------------|-------------------|
| Distance B between holes | 3.5 mm (0.138 in) |
|---------------------------------|-------------------|

The handlebar can be mounted in 4 different positions. In this way, the handlebar can be installed in the position most comfortable for the rider.

Adjusting handlebar position



- Remove the four screws **1**. Remove the handlebar clamp. Remove the handlebar and lay it to one side.



Info

Protect the motorcycle and its attachments from damage by covering them. Do not bend the cables and lines.

- Remove the two screws **2**. Remove the handlebar support.
- Place the handlebar support in the required position. Fit and tighten the two screws **2**.

Guideline

| | | |
|--------------------------|-----|------------------------|
| Screw, handlebar support | M10 | 40 Nm (29.5 lbf ft) |
|--------------------------|-----|------------------------|



Info

Position the left and right handlebar supports evenly.

- Position the handlebar.



Info


Make sure cables and wiring are positioned correctly.

- Position the handlebar clamp. Fit and evenly tighten the four screws **1**.

Guideline

| | | | |
|------------------------|----|------------------------|---------------|
| Screw, handlebar clamp | M8 | 20 Nm (14.8 lbf ft) | Loctite® 243™ |
|------------------------|----|------------------------|---------------|

Checking the play in the throttle cable



- Move the handlebar to the straight-ahead position. Move the throttle grip backwards and forwards to ascertain the play in the throttle cable.

| | |
|---------------------|----------------------------|
| Throttle cable play | 3... 5 mm (0.12... 0.2 in) |
|---------------------|----------------------------|

- » If the throttle cable play does not meet specifications:
 - Adjust the play in the throttle cable. (☛ p. 28)



Danger

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.


- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.
- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- » If the idle speed changes:

- Adjust the play in the throttle cable. (🔧 p. 28)

Adjusting the play in the throttle cable



- Move the handlebar to the straight-ahead position.
- Use the KTM diagnostics tool to set the motor drive to the basic position.
- Loosen counter nut ❶.
- Set the play in the throttle cable by turning the adjusting screw ❷.

Guideline

| | |
|---------------------|----------------------------|
| Throttle cable play | 3... 5 mm (0.12... 0.2 in) |
|---------------------|----------------------------|

- Tighten counter nut ❶.


Adjusting the high-speed compression damping of the shock absorber

**Danger****Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**

The high-speed setting can be seen during the fast compression of the shock absorber.



- Turn adjusting screw ❶ all the way clockwise using a socket wrench.

**Info**

Do not loosen nut ❷!

- Turn back counterclockwise the number of turns corresponding to the shock absorber type.

Guideline

| Compression damping, high-speed | |
|---------------------------------|-----------|
| Comfort | 1.5 turns |
| Standard | 1 turn |
| Sport | 0.5 turn |
| Full payload | 0.5 turn |

**Info**

Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.


Adjusting the low-speed compression damping of the shock absorber

**Danger****Danger of accidents** Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**

The low-speed setting can be seen during the slow to normal compression of the shock absorber.



- Turn the adjusting screw ❶ clockwise with a screwdriver up to the last perceptible click.

**Info**

Do not loosen nut ❷!

- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

| Compression damping, low-speed | |
|--------------------------------|-----------|
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |

**Info**


Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Adjusting the rebound damping of the shock absorber

**Danger**

Danger of accidents Disassembly of pressurized parts can lead to injury.


- The shock absorber is filled with high density nitrogen. Adhere to the description provided.



- Turn adjusting screw ❶ clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

| Rebound damping | |
|-----------------|-----------|
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |

**Info**


Turn clockwise to increase damping, turn counterclockwise to reduce suspension damping.

Measuring the unloaded rear wheel sag




- Raise the motorcycle with the lift stand.
- Measure the vertical distance between the rear axle and a fixed point such as a marking on the side cover.
- Note down the value as dimension ❶.
- Remove the motorcycle from the lift stand.

Checking the static sag of the shock absorber



- Measure distance ❶ of rear wheel unloaded. (☛ p. 30)
- Hold the motorcycle upright with the aid of an assistant.
- Measure the distance between the rear axle and the fixed point again.
- Note down the value as dimension ❷.

**Info**


The static sag is the difference between measurements ❶ and ❷.

- Check the static sag.

| | |
|------------|-----------------|
| Static sag | 20 mm (0.79 in) |
|------------|-----------------|

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber. (☛ p. 31)

Checking the riding sag of the shock absorber



- Measure distance **A** of rear wheel unloaded. (☞ p. 30)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person now measures the distance between the rear axle and a fixed point.
- Note down the value as dimension **C**.

**Info**

The riding sag is the difference between measurements **A** and **C**.

- Check the riding sag.

| | |
|------------|-------------------------------|
| Riding sag | 70... 80 mm (2.76... 3.15 in) |
|------------|-------------------------------|

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. (☞ p. 32)

Adjusting the spring preload of the shock absorber


**Danger**

Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.

**Info**

Before changing the spring preload, make a note of the present setting, e.g., by measuring the length of the spring.



- Remove the shock absorber. (☞ p. 32)
- After removing the shock absorber, clean it thoroughly.
- Loosen locking ring **1**.
- Turn adjusting ring **2** until the spring is no longer under tension.

| |
|--------------------------------|
| Hook wrench (T106S) (☞ p. 217) |
|--------------------------------|

- Measure the overall spring length without a load.
 - Tension the spring by turning the adjusting ring **2** to the prescribed value.
- Guideline


| | |
|----------------|-----------------|
| Spring preload | 18 mm (0.71 in) |
|----------------|-----------------|

**Info**

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

- Tighten locking ring **1**.
- Install the shock absorber. (☞ p. 33)

Adjusting the riding sag



201352-10

- Remove the shock absorber. (🔧 p. 32)
- After removing the shock absorber, clean it thoroughly.
- Choose and mount a suitable spring.

Guideline

| Spring rate | |
|-------------------|---------------------|
| Soft | 80 N/mm (457 lb/in) |
| Medium (standard) | 85 N/mm (485 lb/in) |
| Hard | 90 N/mm (514 lb/in) |




Info


The spring rate is shown on the outside of the spring.

- Install the shock absorber. (🔧 p. 33)
- Check the static sag of the shock absorber. (🔧 p. 30)
- Adjust the rebound damping of the shock absorber. (🔧 p. 30)


Removing the shock absorber



300562-10




300563-10




300564-10

- Raise the motorcycle with the work stand. (🔧 p. 10)
- Remove screws ❶.
- Lift the rear fairing.
- Remove screws ❷.
- Remove screw ❸.
- Repeat the operation on the opposite side.




- Loosen screw 4.
- Remove screw 5.
- Remove screw 4.




- Swing the rear end upwards.
- Lift shock absorber 6 upwards and remove.

Installing the shock absorber



- Swing the rear end upwards and insert shock absorber 1 from above.



- Mount screw 2 but do not tighten yet.
- Mount and tighten screw 3.


Guideline

| | | | |
|------------------------------|-----|------------------------|---------------|
| Screw, bottom shock absorber | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|------------------------------|-----|------------------------|---------------|

- Tighten screw 2.

Guideline

| | | | |
|---------------------------|-----|------------------------|---------------|
| Screw, top shock absorber | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|---------------------------|-----|------------------------|---------------|




- Mount and tighten screw ④.

Guideline

| | | |
|--------------------------|----|------------------------|
| Screw, fuel tank, bottom | M8 | 20 Nm (14.8 lbf ft) |
|--------------------------|----|------------------------|


- Repeat the operation on the opposite side.



- Lift the rear fairing.
- Mount and tighten screws ⑤.

Guideline

| | | | |
|--|----|------------------------|---------------|
| Screw, main silencer holder on fuel tank | M8 | 25 Nm (18.4 lbf ft) | Loctite® 243™ |
|--|----|------------------------|---------------|



- Mount and tighten screws ⑥.

Guideline

| | | |
|-------------------|----|-------------------|
| Screw, side cover | M5 | 2 Nm (1.5 lbf ft) |
|-------------------|----|-------------------|

- Mount the side cover. (☛ p. 55)
- Remove the motorcycle from the work stand. (☛ p. 10)

Servicing the shock absorber



Danger


Danger of accidents Disassembly of pressurized parts can lead to injury.

- The shock absorber is filled with high density nitrogen. Adhere to the description provided.




Condition

The shock absorber has been removed.

- Remove the spring. (☛ p. 35)
- Dismantle the damper. (☛ p. 35)
- Disassemble the piston rod. (☛ p. 36)
- Check the damper. (☛ p. 37)
- Remove the heim joint. (☛ p. 38)
- Install the heim joint. (☛ p. 39)
- Assemble the piston rod. (☛ p. 40)
- Assemble the damper. (☛ p. 41)
- Install the spring. (☛ p. 45)



Removing the spring



Condition

The shock absorber has been removed.

- Clamp the shock absorber in the vise using soft jaws for protection.
- Measure and note spring length in preloaded state.
- Loosen retaining ring ❶ and the adjusting ring with the special tool.

Hook wrench (T106S) (☞ p. 217)

Hook wrench (T157S) (☞ p. 219)

- Turn the retaining ring and adjusting ring until the spring is fully relieved of tension.



- Press down the spring with the special tool.

Spring compressor (T101S) (☞ p. 217)

- Remove spring retainer ❷.


- Take off spring ❸ with the retaining ring and adjusting ring ❹.

Dismantling the damper



- Remove the spring. (☞ p. 35)
- Establish and note the current state of the rebound damping and compression damping.
- Completely open the adjusters of the rebound and compression damping.
- Remove cap ❶.
- Press in valve needle ❷.
- ✓ The pressurized nitrogen escapes.

- Remove locking cap ❸.




- Press in seal ring retainer ④. Remove lock ring ⑤.



Info


Do not scratch the inner surface.




- Remove screw ⑥. Drain the oil.



- Remove the piston rod. Drain the remaining oil.




- Remove compression damping adjuster ⑦. Remove the spring, sleeve and piston.




- Push back membrane cover ⑧.
- Remove lock ring ⑨.
- Remove membrane ⑩.

Disassembling the piston rod



- Dismantle the damper. (☛ p. 35)
- Clamp the piston rod with the heim joint in a vise.
- Remove nut ①.



- Remove supporting plate ❷ and rebound shim stack ❸ together with piston ❹.



Info

Thread the rebound shim set on a screwdriver and set the parts down together.




- Remove compression shim stack ❹ with supporting plate ❺.




Info

Thread the compression shim stack on a screwdriver and set the parts down together.



- Remove seal ring retainer ❶.



- Remove locking cap ❸ and rubber buffer ❹.

Checking the damper




Condition

The damper has been disassembled.

- Measure the inside diameter at both ends and in the center of the damper cartridge.

| Damper cartridge | |
|------------------|---------------------|
| Minimum diameter | 46.10 mm (1.815 in) |

- » If the measured value is greater than the specified value:
 - Change the damper cartridge.
- Check the damper cartridge for damage and wear.
 - » If there is damage or wear:
 - Change the damper cartridge.



- Measure the diameter of the piston rod.

| | |
|------------|---|
| Piston rod | |
| Diameter | $\geq 17.95 \text{ mm } (\geq 0.7067 \text{ in})$ |

- » If the specification is not reached:
 - Change the piston rod.

- Measure the run-out of the piston rod.

| | |
|------------|--|
| Piston rod | |
| Run-out | $\leq 0.03 \text{ mm } (\leq 0.0012 \text{ in})$ |


- » If the measured value is greater than the specified value:
 - Change the piston rod.

- Check the piston rod for damage and wear.

- » If there is damage or wear:
 - Change the piston rod.

- Check the heim joint for damage and wear.

- » If there is damage or wear:
 - Change the heim joint.



Removing the heim joint

Condition



The shock absorber has been removed.

- Clamp the shock absorber in the vise using soft jaws for protection.
- Remove collar bushing ❶ of the heim joint.


| |
|-----------------------|
| Pin (T120) (☞ p. 217) |
|-----------------------|

- Turn over the shock absorber and remove collar bushing ❷ of the heim joint.


| |
|-----------------------|
| Pin (T120) (☞ p. 217) |
|-----------------------|



- Remove seal rings ❸ on both sides.




- Remove lock rings ④ on both sides.



- Place special tool ⑤ underneath and press out the heim joint with special tool ⑥.

Pressing tool (T1207S) (☛ p. 217)


Installing the heim joint




- Place special tool ① underneath and press in the heim joint as far as the center using special tool ②.

Pressing tool (T1206) (☛ p. 217)

Pressing tool (T129) (☛ p. 218)




- Mount lock rings ③ on both sides.




- Mount seal rings ④ on both sides and grease them.

Lubricant (T158) (☛ p. 206)




- Press in both collar sleeves ⑤ of the heim joint.

Assembling the piston rod



- Check the damper. (☛ p. 37)
- Clamp the piston rod with the heim joint in a vise.
- Mount rubber buffer ❶ and locking cap ❷.



- Position special tool ❸ on the piston rod.
- Grease the seal ring and push seal ring retainer ❹ on to the piston rod.

Mounting sleeve (T1515) (☛ p. 219)

Lubricant (T625) (☛ p. 207)

- Remove the special tool.




- Mount supporting plate ❺ with the rounded side facing downward.
- Mount the compression shim stack ❻ with the smaller shims facing downward.




- Sand both sides of the piston on a surface plate using 1200-grit sandpaper.
- Clean the piston.
- Assemble the piston.



Info
The piston is the same on both sides.



- Mount the rebound shim stack ❼ with the smaller shims facing upward.
- Install supporting plate ❸.




- Mount and tighten nut ❹.


Guideline

| | | |
|----------------|-------|------------------------|
| Piston rod nut | M12x1 | 40 Nm (29.5 lbf ft) |
|----------------|-------|------------------------|

Assembling the damper




- Assemble the piston rod. (☛ p. 40)
- Position membrane ①.
- Mount and tighten membrane cover ②.
- Mount lock ring ③.



- Push the spring and sleeve onto the compression damping adjuster. Attach the piston.
- Mount and tighten the compression damping adjuster ④.

Guideline


| | | |
|--------------------------------|-------|------------------------|
| Compression damping adjustment | M26x1 | 30 Nm (22.1 lbf ft) |
|--------------------------------|-------|------------------------|



- Mount and tighten screw ⑤.


Guideline

| | | |
|--------------------|-------|------------------------|
| Filling port screw | M10x1 | 14 Nm (10.3 lbf ft) |
|--------------------|-------|------------------------|



- Fill the damper cartridge about half full.


| |
|--|
| Shock absorber oil (SAE 2,5) (50180342S1) (☛ p. 205) |
|--|



- Grease O-ring ⑥ of the seal ring retainer.

| |
|-----------------------------|
| Lubricant (T158) (☛ p. 206) |
|-----------------------------|

- Mount the piston rod carefully.



- Mount seal ring retainer ⑦ and push it under the ring groove.
- Mount lock ring ⑧.




Info

Do not scratch the inner surface.

- Pull out the piston rod so that the seal ring retainer rests against the lock ring.



- Mount locking cap 9 of the damper cartridge.
- Bleed and fill the damper. (☛ p. 43)
- Fill the damper with nitrogen. (☛ p. 45)



Alternative 1

- Turn the adjusting screw 10 clockwise with a screwdriver up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

| Compression damping, low-speed | |
|--------------------------------|-----------|
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |

- Turn adjusting screw 11 all the way clockwise using a socket wrench.
- Turn back counterclockwise the number of turns corresponding to the shock absorber type.

Guideline

| Compression damping, high-speed | |
|---------------------------------|-----------|
| Comfort | 1.5 turns |
| Standard | 1 turn |
| Sport | 0.5 turn |
| Full payload | 0.5 turn |

- Turn adjusting screw 12 clockwise up to the last perceptible click.
- Turn back counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

| Rebound damping | |
|-----------------|-----------|
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |

Alternative 2



Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.

- Turn adjusting screws 10, 11 and 12 to the position determined during disassembly.
- Install the spring. (☛ p. 45)

Bleeding and filling the damper



Info

Before working with the vacuum pump, be sure to read the operating instructions carefully. Completely open the adjusters of the rebound and compression damping.



- Remove the screw of the filling port.
- Install adapter ① on the damper.



Info

Tighten hand-tight only without using tools.

- Connect adapter ① to connector ② of the vacuum pump.


Vacuum pump (T1240S) (☛ p. 218)

- Clamp the damper with soft jaws or hold it as shown in the photo.



Info

Clamp the damper only lightly.
The filling port must be at the highest point.
During filling, the piston rod slides in and out - do not prevent it from moving by holding it.



- Place the control lever as shown in the photo.
- ✓ The **External tank** ③ control lever is on **Closed**, **Damper** ④ on **Vacuum**, and **Oil reservoir** ⑤ on **Vacuum**.
- Operate the **On/Off** switch ⑥.
- ✓ The vacuum pump process starts.
- ✓ Pressure gauge ⑦ falls to the specified value.

< 0 bar

- ✓ Vacuum gauge ⑧ falls to the specified value.

8 mbar



- When the vacuum gauge reaches the specified value, turn the **Oil reservoir** ⑤ control lever to **Equalize pressure**.

Guideline

8 mbar

- ✓ The pressure gauge rises to the specified value.

0 bar



- When the pressure gauge reaches the specified value, turn the **Damper** ④ control lever to **Pressure**.


Guideline

0 bar

- ✓ Oil is pumped into the damper.

- ✓ The pressure gauge rises to the specified value.

3 bar




- When the pressure gauge reaches the specified value, turn the **Damper ④** control lever to **Vacuum**.

Guideline

3 bar

- ✓ The pressure gauge falls to the specified value.

0 bar



- When the pressure gauge reaches the specified value, turn the **Oil reservoir ⑤** control lever to **Vacuum**.

Guideline

0 bar

- ✓ The vacuum gauge falls to the specified value.

8 mbar




- When the vacuum gauge reaches the specified value, turn the **Oil reservoir ⑤** control lever to **Equalize Pressure**.

Guideline

8 mbar

- ✓ The pressure gauge falls to the specified value.

0 bar




- When the pressure gauge reaches the specified value, turn the **Damper ④** control lever to **Pressure**.

Guideline

0 bar

- ✓ Oil is pumped into the damper.
- ✓ The pressure gauge rises to the specified value.

3 bar



- When the pressure gauge reaches the specified value, turn the **Damper ④** control lever to **Vacuum**.

Guideline

3 bar

- ✓ The pressure gauge falls to the specified value.

0 bar

- When the pressure gauge reaches the specified value, operate the **On/Off** switch.

Guideline

0 bar

- ✓ The vacuum pump is switched off.

- Remove the adapter.




Info

Hold the damper so that the filling port is at the highest point.

- Remove the filling port.

- ✓ A little oil is forced out of the damper.




- Mount and tighten screw 9.

Guideline

| | | |
|--------------------|-------|------------------------|
| Filling port screw | M10x1 | 14 Nm (10.3 lbf ft) |
|--------------------|-------|------------------------|

Filling the damper with nitrogen



- Clamp the damper in the vise using soft jaws.
- Mount special tool 1 on the damper connector.

Filling adapter (T1516) (☛ p. 219)



Info

The piston rod is fully extended.



- Connect the filling cylinder to connector 2.

Filling gas - nitrogen

- Adjust pressure regulator 3.

Guideline

| | |
|--------------|------------------|
| Gas pressure | 10 bar (145 psi) |
|--------------|------------------|



- Open valve 4.
- Fill the damper for at least 15 seconds.

Guideline

| | |
|--------------|------------------|
| Gas pressure | 10 bar (145 psi) |
|--------------|------------------|



Info

Watch the pressure regulator dial.


Make sure that the damper is filled to the specified pressure.

- Close the valve.
- Close the filling cylinder.
- Remove the special tool.


Filling adapter (T1516) (☛ p. 219)

- Install the cap.

Installing the spring



- Clamp the damper in the vise using soft jaws.
- Install retaining ring 1 and turn it down as far as possible.
 - ✓ The collar points to the adjusting ring.
- Mount adjusting ring 2 and turn it down as far as possible.
 - ✓ The collar points to the spring.
- Measure the overall spring length without a load.
- Mount the spring.



Guideline

| Spring rate | |
|-------------------|---------------------|
| Soft | 80 N/mm (457 lb/in) |
| Medium (standard) | 85 N/mm (485 lb/in) |
| Hard | 90 N/mm (514 lb/in) |

- Tension the spring with the special tool.

| |
|--------------------------------------|
| Spring compressor (T101S) (🔧 p. 217) |
|--------------------------------------|

- Install the spring retainer ③.
✓ The open end is opposite the spring end.

Alternative 1

- Tension the spring to the prescribed amount by turning the adjusting ring.

Guideline

| | |
|--------------------------------|-----------------|
| Spring preload | 18 mm (0.71 in) |
| Hook wrench (T106S) (🔧 p. 217) | |
| Hook wrench (T157S) (🔧 p. 219) | |

Alternative 2



Warning

Danger of accidents Modifications to the suspension settings can seriously alter the vehicle's ride behavior.

- Extreme modifications to the adjustment of the spring elements can cause a serious deterioration in the handling characteristics and overload some components.
- Only make adjustments within the recommended range.
- After making adjustments, ride slowly at first to get the feel of the new ride behavior.

- Tension the spring to the amount measured during dismantling by turning the adjusting ring.

| |
|--------------------------------|
| Hook wrench (T106S) (🔧 p. 217) |
| Hook wrench (T157S) (🔧 p. 219) |

- Lock the retaining ring with the adjusting ring.


Removing the exhaust manifold




Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down. Do not touch hot components.



- Remove the air filter box. (➔ p. 51)
- Unplug connector ① of the lambda sensor. Open the cable binder.



- Remove screws ②.
- Remove the heat shield.




- Remove nuts ③ of the manifold.




Info

Do not misplace the spacers.




- Loosen screw ④.
- Remove the manifold.

Installing exhaust manifold




- Position the manifold at the rear with the seals.



- Position the spacer.
- Position the manifold at the front with the seals.
- Mount and tighten nuts ❶.

Guideline


| | | | |
|--------------------------------|----|---------------------|--------------|
| Nut, manifold on cylinder head | M8 | 25 Nm (18.4 lbf ft) | Copper paste |
|--------------------------------|----|---------------------|--------------|




- Position the exhaust clamp.
- Tighten screw ❷.

Guideline

| | | | |
|----------------------------------|----|---------------------|--------------|
| Screw, exhaust clamp on manifold | M8 | 25 Nm (18.4 lbf ft) | Copper paste |
|----------------------------------|----|---------------------|--------------|



- Plug in the connector of the lambda sensor ❸. Secure the cable with the cable binders.



- Position the heat shield.
- Mount and tighten screws ❹.

Guideline

| | | | |
|----------------------------|----|-------------------|--|
| Screw, exhaust heat shield | M5 | 8 Nm (5.9 lbf ft) | |
|----------------------------|----|-------------------|--|


- Install the air filter box. (➡ p. 52)

Removing the main silencer


Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.


- Allow the exhaust system to cool down. Do not touch hot components.




- Remove screws ❶.
- Take off the exhaust heat shield.



- Loosen screw ❷.




- Remove screws ❸.
- Lift the rear fairing.




- Remove screws ❹.
- Remove the main silencer.

Installing the main silencer




- Position the main silencer.
- Mount and tighten screws ❶.

| | | |
|-----------------------------|----|------------------------|
| Guideline | | |
| Screw, main silencer holder | M8 | 25 Nm (18.4 lbf ft) |




- Position the exhaust clamp.
- Tighten screw ❷.

| | | | |
|----------------------------------|----|------------------------|--------------|
| Guideline | | | |
| Screw, exhaust clamp on manifold | M8 | 25 Nm (18.4 lbf ft) | Copper paste |



- Position the exhaust heat shield.
- Mount and tighten screws ❸.

| | | |
|----------------------------|----|-------------------|
| Guideline | | |
| Screw, exhaust heat shield | M5 | 8 Nm (5.9 lbf ft) |




- Mount and tighten screws ④.


Guideline

| | | |
|--------------------|----|-------------------|
| Rear fairing screw | M5 | 2 Nm (1.5 lbf ft) |
|--------------------|----|-------------------|

Removing the air filter



- Remove the seat. (☛ p. 54)
- Remove screws ❶. Remove filter box top ❷.




Note

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

- Never ride the vehicle without an air filter since dust and dirt can get into the engine and result in increased wear.
- Remove air filter ❸.

Installing the air filter



- Clean the air filter box.
- Mount air filter ❶.



Info

The air filter must lie flush against the air filter box along the entire sealing surface A.


If the air filter is not correctly mounted, dust and dirt can penetrate into the engine and can cause damage.

- Hook filter box top ❷ into the front of the air filter box and swing down.
- Mount and tighten screws ❸.


Guideline

| | | |
|---------------------------|----|-------------------|
| Screw, air filter box top | M6 | 2 Nm (1.5 lbf ft) |
|---------------------------|----|-------------------|


- Mount the seat. (☛ p. 54)




Removing the air filter box




- Take off the side cover. (☛ p. 54)
- Remove screws ❶.
- Take off the voltage regulator and hang it to the side in a de-energized state.
- Detach and expose hose ❷.




- Remove screws ③.



- Remove screws ④.



- Loosen hose clip ⑤.




- Raise the air filter box at the rear.
- Loosen the spring-loaded band-type clamp with the special tool and detach bleed hose ⑥.

Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 210)


- Detach connector ⑦ of the intake air temperature sensor.
- Take off the air filter box.

Installing the air filter box




- Attach connector ① of the intake air temperature sensor.
- Mount bleed hose ②. Mount the spring-loaded band-type clamp using the special tool.

Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 210)




- Position the air filter box.
- Mount and tighten hose clip ③.



- Mount and tighten screws ❹.

Guideline


| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|



- Mount and tighten screws ❺.

Guideline

| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|



- Position the voltage regulator.
- Mount and tighten screws ❻.

Guideline

| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

- Route and mount vent hose ❷ without kinking.
- Mount the side cover. (🔧 p. 55)

Opening filler cap



- Lift the cover of the filler cap ❶ and insert the ignition key.
- Turn the ignition key 90° counterclockwise and remove the filler cap.



Info


The filler cap has a tank air vent system.

Closing filler cap




- Put the filler cap back on and turn the ignition key 90° clockwise.
- Remove the ignition key and fold down the cover.

Removing the seat




- Pull on strap ❶ and raise the rear of the seat at the same time.
- Pull back the seat and lift it off.

Mounting the seat




- Hook slot ❶ of the seat onto screw ❷, press the rear downward and at the same time push it forward.
- Push locking pin ❸ into lock housing ❹ and push the back of the seat down until the locking pin locks in place with an audible click.
- Finally, check that the seat is correctly mounted.

Taking off the side cover



- Remove the seat. (➡ p. 54)
- Remove screws ❶.
- Pull off the side cover in area A and take off from above.
- Repeat the operation on the opposite side.

Mounting the side cover



- Attach the side cover in area **A** and engage it in area **B**.
- Mount and tighten screws **1**.

Guideline

| | | |
|-------------------|----|-------------------|
| Screw, side cover | M5 | 2 Nm (1.5 lbf ft) |
|-------------------|----|-------------------|

- Repeat the operation on the opposite side.
- Mount the seat. (➡ p. 54)

Checking the fuel pressure

**Danger**

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.

**Warning**

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.

Condition

The fuel tank is completely full.



The ignition is off.

The diagnostics tool is connected.

- Press on the metal plate and disconnect the fuel hose connection **1**.

**Info**

Remaining fuel may run out of the fuel hose.



- Mount special tool **2**.

| |
|--|
| Pressure testing tool (61029094000) (➡ p. 211) |
|--|

- Mount special tool **3** with nozzle code **0,60**.

| |
|---------------------------------------|
| Testing hose (61029093000) (➡ p. 211) |
|---------------------------------------|

- Insert the hose end in a fuel canister.

Guideline

| | |
|--------------------------------|-------------------|
| Minimum fuel canister capacity | 10 l (2.6 US gal) |
|--------------------------------|-------------------|

- Switch on the ignition.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Actuator test"**.
- **"Please enter the password:"**
- Press **"Continue"**.

- Select **"Fuel pump relay function test"**.
- Press **"Continue"**.
- In the KTM diagnostics tool, read the information page and start the actuator test with **"Continue"**.



Guideline

| | |
|-----------------------------------|-------|
| Maximum duration of actuator test | 3 min |
|-----------------------------------|-------|

- Check the fuel pressure with the filler cap closed.

| | |
|------------------------------|-------------------------------|
| Fuel pressure | |
| When the fuel pump is active | 3.3... 3.7 bar (48... 54 psi) |

- » If the specification is not reached:
 - Open the filler cap. (☛ p. 54)
 - Check the tank air vent system.



- Check the fuel pressure with the filler cap open.

| | |
|------------------------------|-------------------------------|
| Fuel pressure | |
| When the fuel pump is active | 3.3... 3.7 bar (48... 54 psi) |

- » If the specification is not reached:
 - Check that the fuel line is clear.
 - Change the fuel filter. (☛ p. 56)
 - Replace the fuel pump.
- Stop the **"Function test of fuel pump control"** actuator test by pressing the **"Quit"** button.
- Dismantle the special tools.
- Connect the fuel hose connection.

Changing the fuel filter



Danger

Fire hazard Fuel is highly flammable.

- Never refuel the vehicle near open flames or burning cigarettes, and always switch off the engine first. Be careful that no fuel is spilt, especially on hot vehicle components. Clean up spilt fuel immediately.
- Fuel in the fuel tank expands when warm and can escape if the tank is overfilled. See the notes on refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid contact between fuel and skin, eyes and clothing. Do not inhale fuel vapors. If fuel gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If fuel is swallowed, contact a doctor immediately. Change clothing that has come into contact with fuel. Store fuel in a suitable canister according to regulations and keep it out of the reach of children.





Warning

Environmental hazard Improper handling of fuel is a danger to the environment.


- Do not allow fuel to get into the ground water, the ground, or the sewage system.

- Disconnect the battery. (☛ p. 68)
- Drain the fuel from the fuel tank into a suitable container.
- Remove screws ❶.







- Lift the rear fairing.
- Remove screws ②.




- Remove screw ③.
- Repeat the operation on the opposite side.
- Swing the rear end upwards and secure it.




- Remove screws ④.
- Pull out the fuel pump.




- Remove hose clamps ⑤.
- Remove fuel filter ⑥.



- Press lock ⑦.
- Remove fuel pump housing ⑧.




- Change fuel screen ⑨.
- Mount the fuel pump housing.



- Mount fuel filter ⑥.
- ✓ Arrow ① points away from the fuel pump.
- Mount hose clamps ⑤.


Hose clamp pliers (60029057000) (☛ p. 210)



- Position the fuel pump.
- Mount and tighten screws ④.

Guideline

| | | |
|------------------|----|-------------------|
| Screw, fuel pump | M5 | 6 Nm (4.4 lbf ft) |
|------------------|----|-------------------|




- Position the rear end.
- Mount and tighten screw ③.

Guideline

| | | |
|--------------------------|----|------------------------|
| Screw, fuel tank, bottom | M8 | 20 Nm (14.8 lbf ft) |
|--------------------------|----|------------------------|


- Repeat the operation on the opposite side.



- Lift the rear fairing.
- Mount and tighten screws ②.

Guideline

| | | | |
|--|----|------------------------|---------------|
| Screw, main silencer holder on fuel tank | M8 | 25 Nm (18.4 lbf ft) | Loctite® 243™ |
|--|----|------------------------|---------------|




- Mount and tighten screws ①.

Guideline

| | | |
|-------------------|----|-------------------|
| Screw, side cover | M5 | 2 Nm (1.5 lbf ft) |
|-------------------|----|-------------------|

- Disconnect the battery. (☛ p. 69)

Removing front wheel




- Raise the motorcycle with the rear wheel stand. (🔧 p. 9)
- Raise the motorcycle with the front wheel stand. (🔧 p. 9)
- Remove screws ① and spacers ②.
- Press back the brake linings with a light lateral tilting of the brake caliper on the brake disc. Pull the brake caliper carefully back from the brake disc and hang it to one side.



Info

Do not pull the handbrake lever when the brake caliper is removed.




- Loosen screws ③ and ④.
- Unscrew screw ③ about 6 turns and press your hand on the screw to push the wheel spindle out of the axle clamp. Remove screw ③.



Warning

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- Always lay the wheel down in such a way that the brake disc is not damaged.



- Holding the front wheel, withdraw the wheel spindle. Take the front wheel out of the fork.
- Remove distance bushings ⑤.


Installing the front wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Replace the wheel bearing.
- Clean and grease the shaft seal rings and bearing surface of the distance bushings ①.

Long-life grease (🔧 p. 206)

- Insert the spacers.



- Clean and grease the thread of the wheel spindle and screw ②.

Long-life grease (🔧 p. 206)

- Lift the front wheel into the fork, position it, and insert the wheel spindle. Mount and tighten screw ②.

Guideline

| | | |
|----------------------------|---------|------------------------|
| Screw, front wheel spindle | M24x1.5 | 40 Nm (29.5 lbf ft) |
|----------------------------|---------|------------------------|

- Position the brake caliper and check that the brake linings are seated correctly.
- Position spacers ③. Mount screws ④ but do not tighten.
- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point. Fix the hand brake lever in the activated position.
- ✓ The brake caliper straightens.
- Fully tighten screws ④.

Guideline


| | | | |
|----------------------------|----------|------------------------|---------------|
| Screw, front brake caliper | M10x1.25 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|----------------------------|----------|------------------------|---------------|

- Remove the fixation of the hand brake lever.
- Take the motorcycle off of the front wheel stand. (☛ p. 9)
- Pull the front wheel brake and push down hard on the fork several times to align the fork legs.
- Tighten screws ⑤.

Guideline

| | | |
|------------------|----|------------------------|
| Screw, fork stub | M8 | 15 Nm (11.1 lbf ft) |
|------------------|----|------------------------|

- Take the motorcycle off of the rear wheel stand. (☛ p. 9)




Checking the tire air pressure



Info

Low tire air pressure leads to abnormal wear and overheating of the tire.
Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove dust cap.
- Check tire air pressure when tires are cold.

| Tire air pressure, solo | |
|-------------------------|------------------|
| Front | 2.0 bar (29 psi) |
| Rear | 2.0 bar (29 psi) |

| Tire air pressure with passenger / fully loaded | |
|---|------------------|
| Front | 2.0 bar (29 psi) |
| Rear | 2.2 bar (32 psi) |

- » If the tire pressure does not meet specifications:
 - Correct tire pressure.
- Mount dust cap.

Checking the tire condition



Warning

Danger of accidents Uncontrollable handling characteristic caused by a flat tire.

- For your own safety, have damaged tires changed immediately.



Warning

Danger of crashing Poor vehicle handling due to different tire tread patterns on front and rear wheels.

- The front and rear wheels must be fitted with tires with similar tread patterns to prevent loss of control over the vehicle.



Warning

Danger of accidents Uncontrollable handling characteristic due to non-approved and/or non-recommended tires/wheels.

- Only tires/wheels approved by KTM and with the corresponding speed index should be used.


**Warning**

Danger of accidents Reduced road grip with new tires.

- New tires have a smooth rolling surface and therefore cannot provide full road grip. The entire rolling surface must be roughened in the first 200 kilometers (124.3 miles) by moderate riding at alternating angles. The full grip levels are not achieved until the tires have been run in.

**Info**

The type, condition and air pressure of the tires all have a major impact on the handling of the motorcycle. Worn tires have a negative effect on riding behavior, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects and other damage.
 - » If the tires exhibit cuts, run-in objects or other damage:
 - Change the tires.
- Check the depth of the tread.

**Info**

Note local national regulations concerning the minimum tread depth.

| | |
|---------------------|---|
| Minimum tread depth | $\geq 2 \text{ mm } (\geq 0.08 \text{ in})$ |
|---------------------|---|

- » If the tread depth is less than the minimum permissible depth:
 - Change the tires.
- Check the age of the tires.

**Info**

The tire's date of manufacture is usually part of the tire markings and is indicated by the last four digits of the **DOT** marking. The first two digits refer to the week of manufacture and last two digits refer to the year of manufacture.

KTM recommends that the tires are changed regardless of the actual wear, at the latest after five years.


- » If a tire is more than five years old:
 - Change the tires.

Checking the brake discs

**Warning**

Danger of accidents Reduced braking efficiency due to worn brake disc(s).

- Change the worn brake disc(s) without delay.



- Check the thickness of the front and rear brake discs in several places to ensure that it conforms to measurement **A**.


**Info**

Wear reduces the thickness of the brake disc at the contact surface **1** of the brake disc.

| Brake discs - wear limit | |
|--------------------------|-------------------|
| Front | 4.0 mm (0.157 in) |
| Rear | 4.5 mm (0.177 in) |

- » If the brake disc thickness is less than the specified value:
 - Replace the brake disc.
- Check the front and rear brake discs for damage, cracks, and deformation.
 - » If damage, cracks, or deformation are visible on the brake disc:
 - Replace the brake disc.

Removing rear wheel



100267-10



600627-01

- Raise the motorcycle with the rear wheel stand. (🔧 p. 9)
- Press the brake caliper by hand on to the brake disc in order to press back the brake piston.
- Remove nut ❶. Remove chain adjuster ❷.
- Holding the rear wheel, withdraw the wheel spindle ❸.



Warning

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- Always lay the wheel down in such a way that the brake disc is not damaged.

- Take the rear wheel out of the swing arm.



Info

Do not operate the foot brake when the rear wheel is removed.

Installing the rear wheel



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.


- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents No braking effect when operating the rear brake.

- After installing the rear wheel, always operate the foot brake until the pressure point is reached.



600628-10

- Check the rear hub rubber dampers. (🔧 p. 66)
- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Replace the wheel bearing.
- Remove the bushing ❶. Clean and grease the roll surfaces of the bushing and the shaft seal ring ❷.

Long-life grease (🔧 p. 206)


- Clean and grease the thread of the wheel spindle and nut ❸.

Long-life grease (🔧 p. 206)

- Install the rubber damper and rear sprocket carrier in the rear wheel.
- Place the rear wheel in the swingarm and bring the brake disc on the brake caliper into contact.
- Push the rear wheel forward as far as possible and lay the chain on the rear sprocket.
- Mount the wheel spindle, chain adjusters and nuts.

Guideline

In order that the rear wheel is correctly aligned, the markings on the left and right chain adjusters must be in the same position relative to the reference marks A.



100270-10



Info

Mount the left and right chain adjusters ❹ in the same position.


- Tighten nut ③.

Guideline


| | | |
|-------------------------|---------|------------------------|
| Nut, rear wheel spindle | M25x1.5 | 90 Nm (66.4 lbf ft) |
|-------------------------|---------|------------------------|

- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Take the motorcycle off of the rear wheel stand. (🔧 p. 9)


Checking the chain tension

**Warning**
Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.



- Lean the motorcycle on the side stand.
- Shift gear to neutral.
- Push the chain upward at a distance ② from the chain sliding guard and determine the chain tension ①.


**Info**

The upper chain section ③ must be taut.
Chain wear is not always even, so you should repeat this measurement at different chain positions.

| | |
|---------------------------------|-----------------|
| Chain tension | 5 mm (0.2 in) |
| Distance to chain sliding guard | 30 mm (1.18 in) |


- » If the chain tension does not meet specifications:
 - Adjust the chain tension. (🔧 p. 63)

Adjusting the chain tension

**Warning**
Danger of accidents Danger caused by incorrect chain tension.

- If the chain tension is too high, the components of the secondary power train (chain, engine sprocket, rear sprocket, bearings in transmission and rear wheel) are under additional load. Apart from premature wear, in extreme cases the chain can rupture or the countershaft of the transmission can break. On the other hand, if the chain is loose, it can fall off the engine sprocket or the rear sprocket and block the rear wheel or damage the engine. Check the chain tension and correct if necessary.

- Check the chain tension. (🔧 p. 63)



- Loosen nut ①.
- Loosen nuts ②.
- Adjust the chain tension by turning adjusting screws ③ on the left and right.

Guideline

| | |
|---|---------------|
| Chain tension | 5 mm (0.2 in) |
| Turn the left and right adjusting screws ③ so that the markings on the left and right chain adjusters ④ are in the same position relative to the reference marks ⑥. The rear wheel is then correctly aligned. | |



Info

The upper chain section must be taut.
Chain wear is not always even, so you should check this setting at different chain positions.

- Tighten nuts ②.
- Make sure that the chain adjusters ④ are installed correctly on adjusting screws ③.
- Tighten nut ①.

Guideline


| | | |
|-------------------------|---------|------------------------|
| Nut, rear wheel spindle | M25x1.5 | 90 Nm (66.4 lbf ft) |
|-------------------------|---------|------------------------|



Info

The wide adjustment range of the chain adjusters (30 mm (1.18 in)) enables different secondary transmissions with the same chain length.
The chain adjusters ④ can be turned through 180°.

Adjusting chain guide



- Remove screws ① and ②. Take off the chain guide.

Condition

Number of teeth: ≤ 44 teeth

- Insert nut ③ in hole ④. Position the chain guide.
- Mount and tighten screws ① and ②.

Guideline

| | | |
|---------------------------|----|-----------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|-----------------------|

Condition


Number of teeth: ≥ 45 teeth

- Insert nut ③ in hole ⑤. Position the chain guide.
- Mount and tighten screws ① and ②.

Guideline

| | | |
|---------------------------|----|-----------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|-----------------------|

Checking the chain, rear sprocket and engine sprocket




- Check the rear sprocket and engine sprocket for wear.
 - » If the rear sprocket and engine sprocket are worn:
 - Replace the rear sprocket or engine sprocket.



Info

The engine sprocket, rear sprocket and chain should always be replaced together.



- Shift into neutral; pull the lower chain section with specified weight **A**.

Guideline

| | |
|----------------------------------|----------------|
| Weight of chain wear measurement | 15 kg (33 lb.) |
|----------------------------------|----------------|

- Measure distance **B** of 18 chain links in the lower chain section.

**Info**

Chain wear is not always even, so you should repeat this measurement at different chain positions.

| | |
|--|-------------------|
| Maximum distance B at the longest chain section | 272 mm (10.71 in) |
|--|-------------------|

- » If distance **B** is greater than the specified measurement:
 - Replace the chain.

**Info**

When the chain is replaced, the rear sprocket and engine sprocket should also be changed.

New chains wear out faster on old, worn sprockets.

For safety reasons, the chain has no chain joint.



- Check the chain sliding guard for wear.
 - » If the chain sliding guard is worn:
 - Replace the chain sliding guard.
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the chain sliding guard.

Guideline

| | | |
|---------------------------|----|-----------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|-----------------------|



- Check the chain guide for wear.
 - » If the chain guide is worn:
 - Change the chain guide.
- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the chain guide.

Guideline

| | | |
|---------------------------|----|-----------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|-----------------------|

Cleaning the chain

**Warning**

Danger of accidents Oil or grease on the tires reduces their grip.

- Remove oil and grease with a suitable cleaning material.

**Warning**

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.


**Warning**

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

The service life of the chain depends largely on its maintenance.



- Clean the chain regularly.
- Rinse off loose dirt with a soft jet of water.
- Remove old grease remains with chain cleaner.

Chain cleaner (☛ p. 206)

- After drying, apply chain spray.


Chain lube for road use (☛ p. 206)

Checking the rear hub rubber dampers



Info

The engine power is transmitted from the rear sprocket to the rear wheel via 6 rubber dampers. They eventually wear out during operation. If the rubber dampers are not changed in time, the rear sprocket carrier and the rear hub will be damaged.



- Remove the rear wheel. (☛ p. 62)
- Check bearing ❶.
 - » If the bearing is damaged or worn:
 - Replace the bearings.
- Check rubber dampers ❷ of the rear hub for damage and wear.
 - » If the rubber dampers of the rear hub are damaged or worn:
 - Change all rubber dampers in the rear hub.



- Lay the rear wheel on a workbench with the rear sprocket facing upwards and insert the wheel spindle in the hub.
- To check play ❸, hold the rear wheel tight and try to rotate the rear sprocket.



Info

Measure the play on the outside of the rear sprocket.

| | |
|------------------------------------|-------------------|
| Play in rubber dampers, rear wheel | ≤ 5 mm (≤ 0.2 in) |
|------------------------------------|-------------------|

- » If play ❸ is larger than the specified value:
 - Change all rubber dampers in the rear hub.
- Install the rear wheel. (☛ p. 62)

Checking the spoke tension



Warning


Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct.



Info

A loose spoke causes wheel imbalance and rapidly leads to more loose spokes. If the spokes are too tight, they can break due to local overload. Check the spoke tension regularly, especially on a new motorcycle.



- Briefly strike each spoke with a screwdriver blade.



Info

The frequency of the tone is a function of the spoke length and spoke diameter.

If you hear different tone frequencies from individual spokes of the same length and thickness, this is an indication of different spoke tensions.

| |
|------------------------------|
| You should hear a high note. |
|------------------------------|


- » If the spoke tensions differ:
 - Correct the spoke tension.

Checking the rim run-out

Warning
Danger of accidents Instable handling due to incorrect spoke tension.

- Ensure that the spoke tension is correct.

i Info
A loose spoke can cause wheel imbalance, which leads to more loose spokes in a short time.
If the spokes are too tight, they can break due to local overload.
Check the spoke tension regularly, especially on a new motorcycle.



- Check the axial run-out and radial run-out of the rim.

| Axial run-out | |
|--------------------------|-----------------------|
| outside of the rim joint | < 1.8 mm (< 0.071 in) |

| Radial run-out | |
|--------------------------|-----------------------|
| outside of the rim joint | < 1.8 mm (< 0.071 in) |

- » If the measured value is greater than the specified value:
 - Center the rim.

i Info
Center the rim by tightening the spoke nipple on the opposite side of the rim run-out. Change the rim if it is excessively deformed.

- Correct the spoke tension.


Removing the battery



Warning

Risk of injury Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- Flush with copious amounts of water in case of skin contact. If battery acid comes into contact with the eyes, flush the eyes with water for at least 15 minutes and consult a physician.




- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 54)
- Disconnect the negative (minus) cable of the battery.
- Pull off the plug connector ❶ upwards.
- Remove screws ❷.
- Pull the retaining bracket ❸ of the battery forward and remove it.
- Take off the positive pole cover ❹.
- Disconnect the positive (plus) cable of the battery.
- Push the wiring harness to the side and pull the battery out of the battery rack.



Info

Never operate the motorcycle with a discharged battery or without a battery. In both cases, electrical components and safety devices can be damaged. The vehicle is therefore no longer roadworthy.

Installing the battery



- Slide the battery into the battery rack.



Info

The battery terminals must be at the rear.


- Attach the positive cable and mount positive terminal cover ❶.
- Position retaining bracket ❷.
- Mount and tighten screws ❸.

Guideline

| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

- Plug in connector ❹.
- Attach the minus cable .
- Mount the seat. (☛ p. 54)
- Set the clock. (☛ p. 82)

Disconnecting the battery




- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 54)
- Disconnect the negative (minus) cable ❶ of the battery.



Info

Never operate the motorcycle with a discharged battery or without a battery. In both cases, electrical components and safety equipment can be damaged. The vehicle is therefore no longer roadworthy.

Connecting the battery



300199-11

- Reconnect minus cable ❶.
- Mount the seat. (☛ p. 54)
- Set the clock. (☛ p. 82)

Recharging the battery



Warning

Risk of injury Battery acid and battery gases cause serious cauterization.

- Keep batteries out of the reach of children.
- Wear suitable protective clothing and goggles.
- Avoid contact with battery acid and battery gases.
- Keep the battery away from sparks or open fire. Charge only in well ventilated rooms.
- Flush with copious amounts of water in case of skin contact. If battery acid comes into contact with the eyes, flush the eyes with water for at least 15 minutes and consult a physician.



Warning

Environmental hazard Battery parts and acid are harmful to the environment.

- Do not discard batteries with the household trash. Dispose of a defective battery in an environmentally compatible manner. Give the battery to your KTM dealer or to a recycling center that accepts used batteries.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

Even when there is no load on the battery, it still loses power steadily.

The charge state and the type of charge are very important for the service life of the battery.

Rapid recharging with a high charging current shortens the battery's service life.

If the charging current, charging voltage and charging time are exceeded, electrolyte escapes through the safety valves. This reduces the battery capacity.

If the battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.

If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfate, destroying the battery.

The battery is maintenance-free, which means that the acid level does not need to be checked.

- Switch off all power consumers and switch off the engine.
- Remove the battery. (☛ p. 68)



- Connect the battery charger to the battery. Switch on the battery charger.

Battery charger (58429074000)

You can also use the battery charger to test rest potential and start potential of the battery, and to test the alternator. With this device, you cannot overcharge the battery.



Info

Never remove lid ①.

Charge the battery with a maximum of 10% of the capacity specified on the battery housing ②.

- Switch off and disconnect the charger after charging.

Guideline

The charge current, charge voltage and charge time must not be exceeded.

| | |
|--|----------|
| Charge the battery regularly when the motorcycle is not in use | 3 months |
|--|----------|



- Install the battery. (☛ p. 68)

Checking the charging voltage

Condition

The battery must be fully functional and completely charged.

- Remove the seat. (☛ p. 54)
- Remove screws ①.
- Push the retaining bracket forward and take off the terminal cover.
- Start the motorcycle to make checks. (☛ p. 11)



- **V** Measure the voltage between the specified points.
Measuring point **Plus (+)** – Measuring point **Ground (-)**

Charging voltage

| | |
|-----------|----------------|
| 5,000 rpm | 13.5... 15.0 V |
|-----------|----------------|

- » If the displayed value is less than the specified value:
 - Check the plug-in connections from the alternator to the voltage regulator.
 - Check the plug-in connections from the voltage regulator to the wiring harness.
 - Check the stator winding of the alternator. (☛ p. 158)
- » If the displayed value is greater than the specified value:
 - Change the voltage regulator.

Changing the main fuse



Warning



Fire hazard The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.



Info

The main fuse protects all power consumers in the vehicle. It is in the housing of the starter relay next to the battery.



- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 54)
- Remove protection covers ❶.

- Remove a defective main fuse ❷ with needle nose pliers.
- Install a new main fuse.

Fuse (58011109130) (☛ p. 173)



Info

A reserve fuse ❸ is located in the starter relay.



- Check that the electrical equipment is functioning properly.
- Mount the protection covers.
- Mount the seat. (☛ p. 54)
- Set the clock. (☛ p. 82)

Changing fuses of individual power consumers



Info

The fuse box containing the fuses of individual power consumers is located under the seat.



- Switch off all power consumers and switch off the engine.
- Remove the seat. (☛ p. 54)
- Open fuse box cover ❶.

- Remove the defective fuse.

Guideline

| |
|---|
| Fuse 1 - 10A - ignition, combination instrument |
| Fuse 2 - 10A - clock, ignition (EFI control unit) |
| Fuse 3 - 10A - throttle valve control unit |
| Fuse 4 - 10A - fuel pump |
| Fuse 5 - 10A - radiator fan |
| Fuse 6 - 10A - horn, brake light, turn signal |
| Fuse 7 - 15A - high beam, low beam, parking light, tail light, license plate lamp |
| Fuse 8 - 10A - for supplementary equipment (accessories connected with ignition switch) |
| Fuse 9 - 10A - for accessories (permanent positive) |
| Fuse 10 - not used |
| Fuse SPARE - 10A/15A - spare fuses |



Info

A defective fuse is shown by a burned-out fuse wire A.

**Warning**

Fire hazard The electrical system can be overloaded by the use of incorrect fuses.

- Use only fuses with the prescribed amperage. Never by-pass or repair fuses.

- Replace with a spare fuse of the right rating.

| |
|-------------------------------|
| Fuse (75011088010) (☛ p. 173) |
|-------------------------------|



| |
|-------------------------------|
| Fuse (75011088015) (☛ p. 173) |
|-------------------------------|

**Tip**

Put a new spare fuse in the fuse box for future use if needed.

- Checking the function of power consumers.
- Close the fuse box cover.
- Mount the seat. (☛ p. 54)

Adjusting the engine characteristic



- Switch off the ignition by turning the ignition key in the position ☒ (690 SMC EU, 690 SMC AUS/UK) OFF (690 SMC USA).
- Remove the seat. (☛ p. 54)
- Pull the **Map-Select** switch and holder ❶ upward off of the retaining bracket.
- Pull the **Map-Select** switch out of the holder.

- Turn the adjusting wheel until the desired digit is next to marking ❷.

Set the Map-Select switch to Soft.

- Set the adjusting wheel to position 1.
 - ✓ Soft – reduced homologated peak performance for better driveability.

Set the Map-Select switch to Advanced.

- Set the adjusting wheel to position 2.
 - ✓ Advanced – homologated performance with extremely direct responsiveness.

Set the Map-Select switch to Standard.

- Set the adjusting wheel to position 3, 4, 5, 6, 7, 8 or 9.
 - ✓ Standard – homologated performance with balanced responsiveness.

Set the Map-Select switch to poor fuel quality.

- Set the adjusting wheel to position 0.
 - ✓ Poor fuel quality – homologated performance is reduced in accordance with the fuel quality, use for no more than 1 tank of fuel

- Position the **Map-Select** switch in the holder.
- Slide the **Map-Select** switch with the holder downward onto the retaining bracket.
- Mount the seat. (☛ p. 54)

Checking the front brake linings



Warning


Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately.

Note

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.



- Check the brake linings for minimum thickness **A**.

| | |
|----------------------------|---|
| Minimum thickness A | $\geq 1 \text{ mm } (\geq 0.04 \text{ in})$ |
|----------------------------|---|

- » If the minimum thickness is less than specified:
 - Change the front brake linings. (🔧 p. 73)
- Check the brake linings for damage and cracking.
 - » If there is wear or tearing:
 - Change the front brake linings. (🔧 p. 73)

Changing the front brake linings



Warning

Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally.



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents Reduced braking efficiency due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info


Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



- Remove the front brake linings.
- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Press the brake piston back to its basic position and make sure that no brake fluid overflows from the brake fluid reservoir.
- Install the front brake linings.



- Add brake fluid level to A.

Guideline

| | |
|--|---------------|
| Level A | 5 mm (0.2 in) |
| Brake fluid DOT 4 / DOT 5.1 (🔧 p. 204) | |

- Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilt brake fluid immediately with water.

Adjusting the basic position of the hand brake lever



- Adjust the basic setting of the hand brake lever to your hand size by turning adjusting wheel ❶.



Info

Pull the brake lever forwards and turn the adjusting wheel.
Do not make any adjustments while riding!

Checking the front brake fluid level



Warning

Danger of accidents Failure of the brake system.


- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.



Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.




- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in the viewer ❶.
 - » If the brake fluid level is below the **MIN** mark:
 - Add front brake fluid. (🔧 p. 75)

Adding front brake fluid

- Warning**
Danger of accidents Failure of the brake system.
- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.
- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Danger of accidents Reduced braking effect caused by old brake fluid.
- Change the brake fluid of the front and rear brake according to the service schedule.
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

- i Info**
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ①.
- Remove cover ② with membrane ③.
- Add brake fluid to level A.

Guideline

| | |
|------------------|---------------|
| Measurement of A | 5 mm (0.2 in) |
|------------------|---------------|

| |
|--|
| Brake fluid DOT 4 / DOT 5.1 (☞ p. 204) |
|--|


- Position the cover with the membrane. Mount and tighten the screws.

- i Info**
Clean up overflowed or spilt brake fluid immediately with water.

Changing the front brake fluid

- Warning**
Skin irritation Brake fluid can cause skin irritation on contact.
- Avoid contact with skin and eyes, and keep out of the reach of children.
 - Wear suitable protective clothing and goggles.
 - If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.
- Warning**
Environmental hazard Hazardous substances cause environmental damage.
- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.


- i Info**
Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.
Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!
Use only clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Draw the old brake fluid out of the brake fluid reservoir using a syringe and fill with fresh brake fluid.

| |
|--|
| Bleed syringe (50329050000) (🔧 p. 208) |
|--|

| |
|--|
| Brake fluid DOT 4 / DOT 5.1 (🔧 p. 204) |
|--|




- Pull off dust cap ❹ and connect a commercially available suction device (standard workshop equipment).
- Release bleeder screw ❺ and draw out the old brake fluid.

**Info**

During suction, ensure that the brake fluid reservoir is always filled with a sufficient amount of fresh brake fluid.

- Tighten the bleeder screw. Remove the suction device and mount the dust cap.



- Add brake fluid to level A.

Guideline

| | |
|---------|---------------|
| Level A | 5 mm (0.2 in) |
|---------|---------------|

| |
|--|
| Brake fluid DOT 4 / DOT 5.1 (🔧 p. 204) |
|--|

- Position the cover with the membrane. Mount and tighten the screws.

**Info**

Clean up overflowed or spilt brake fluid immediately with water.

Checking the rear brake linings

**Warning**


Danger of accidents Reduced braking efficiency caused by worn brake linings.

- Change worn brake linings immediately.

Note

Danger of accidents Reduced braking efficiency caused by damaged brake discs.

- If the brake linings are not changed in time, the steel brake lining carriers grind on the brake disc. The braking effect is greatly reduced and the brake discs are rendered unserviceable. Check the brake linings regularly.



- Check the brake linings for minimum thickness A.

| | |
|---------------------|--------------------|
| Minimum thickness A | ≥ 1 mm (≥ 0.04 in) |
|---------------------|--------------------|

» If the minimum thickness is less than specified:

- Change the rear brake linings. (🔧 p. 77)

- Check the brake linings for damage and cracking.

» If there is wear or tearing:

- Change the rear brake linings. (🔧 p. 77)

Changing rear brake linings



Warning

Danger of accident Brake system failure.

- Maintenance work and repairs must be carried out professionally.



Warning

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.



Warning

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.



Warning

Danger of accidents Reduced braking efficiency due to oil or grease on the brake discs.

- Always keep the brake discs free of oil and grease, and clean them with brake cleaner when necessary.



Warning

Danger of accidents Reduced braking efficiency due to use of non-approved brake linings.

- Brake linings available from accessory suppliers are often not tested and approved for use on KTM vehicles. The construction and friction factor of the brake linings and therefore the brake power can differ considerably from the original KTM brake linings. If brake linings are used that differ from the originals, there is no guarantee that they comply with the original license. The vehicle no longer corresponds to the condition at delivery, and the warranty is no longer valid.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.




- Stand the vehicle upright.
- Remove the screw cap ① with the membrane ②.
- Press the brake caliper onto the brake disc by hand in order to push back the brake pistons. Make sure that no brake fluid escapes from the brake fluid reservoir. If it does, clean it up.




Info


Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.



- Remove the safety clip ③, knock the pin ④ out to the left, and remove the brake linings.
- Clean brake caliper and brake caliper support.



- Check that leaf spring **5** in the brake caliper and sliding plate **6** in the brake caliper support are seated correctly.



- Insert the brake pads, insert the bolt and mount the split pin.
- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☛ p. 204)

- Mount the screw cap with the membrane.



Info

Clean up overflowed or spilt brake fluid immediately with water.

Checking the free travel of foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel **A**.

Guideline

| | |
|---------------------------------|----------------------------|
| Free travel at foot brake lever | 3... 5 mm (0.12... 0.2 in) |
|---------------------------------|----------------------------|



Info

You will know that contact has been made with the foot brake cylinder piston when there is increased resistance when you activate the foot brake lever.

- » If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. (☛ p. 78)


Adjusting the basic position of the foot brake lever



Warning

Danger of accidents Brake system failure.

- If there is no free travel on the foot brake lever, pressure builds up on the rear brake circuit. The rear brake can fail due to overheating. Adjust free travel on foot brake lever according to specifications.



- Remove screws ③ on foot brake cylinder ④.
- To adjust the basic position of the foot brake lever individually, loosen nut ① and turn screw ② accordingly.

**Info**

The range of adjustment is limited. The screw must be screwed into the footrest bracket by at least four turns.

- Position foot brake cylinder ④ so that the foot brake lever has the necessary free travel. Hold screws ③ in place and tighten the nuts.

Guideline

| | | |
|--------------------------------|----|--------------------|
| Nut, foot brake cylinder screw | M6 | 10 Nm (7.4 lbf ft) |
|--------------------------------|----|--------------------|

- Check the free travel of the foot brake lever. (☛ p. 78)
- Tighten nut ①.

Checking rear brake fluid level

**Warning**


Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.

**Warning**

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.



- Stand the vehicle upright.
- Check the brake fluid level in the brake fluid reservoir.
 - » If the fluid level reaches the **MIN** marking ①:
 - Add rear brake fluid. (☛ p. 79)

Adding rear brake fluid

**Warning**

Danger of accidents Failure of the brake system.

- If the brake fluid level falls below the **MIN** mark, this indicates a leakage in the brake system or worn-out brake linings. Check the brake system and do not continue riding.

**Warning**

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

**Warning**

Danger of accidents Reduced braking effect caused by old brake fluid.

- Change the brake fluid of the front and rear brake according to the service schedule.

**Warning**

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!

Use only clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove screw cap ❶ with the washer and membrane ❷.
- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☞ p. 204)

- Mount the screw cap with the washer and membrane.

**Info**

Clean up overflowed or spilt brake fluid immediately with water.

Changing the rear brake fluid

**Warning**

Skin irritation Brake fluid can cause skin irritation on contact.

- Avoid contact with skin and eyes, and keep out of the reach of children.
- Wear suitable protective clothing and goggles.
- If brake fluid comes into contact with the eyes, flush the eyes thoroughly with water and consult a physician immediately.

**Warning**

Environmental hazard Hazardous substances cause environmental damage.


- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.

**Info**

Never use DOT 5 brake fluid! It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint!


Use only clean brake fluid from a sealed container.



- Remove screw cap ❶ with washer ❸ and membrane ❷.
- Draw the old brake fluid out of the brake fluid reservoir using a syringe and fill with fresh brake fluid.

Bleed syringe (50329050000) (☞ p. 208)

Brake fluid DOT 4 / DOT 5.1 (☞ p. 204)



- Pull off dust cap ❹ and connect a commercially available suction device (standard workshop equipment).
- Release bleeder screw ❺ and draw out the old brake fluid.

**Info**

During suction, ensure that the brake fluid reservoir is always filled with a sufficient amount of fresh brake fluid.

- Tighten the bleeder screw. Remove the suction device and mount the dust cap.

- Add brake fluid to the **MAX** mark.

Brake fluid DOT 4 / DOT 5.1 (☞ p. 204)

- Mount the screw cap with the washer and membrane.
- Activate the foot brake lever until there is a firm pressure point.

**Info**


Clean up overflowed or spilt brake fluid immediately with water.

Setting kilometers or miles



Info

If you change the unit, the value **ODO** is retained and converted accordingly. Making the setting according to the country.




700120-01

Condition

The motorcycle is stationary.

- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button pressed until the display mode changes from **km/h** to **mph** or from **mph** to **km/h**.

Setting the clock



700115-10

Condition

The motorcycle is stationary.

- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- Press the **MODE** button repeatedly until the **ODO** mode is active.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time display begins to flash.
- Press the **MODE** button to set the hour.
- Press the **SET** button to set the minute.
- Keep the **MODE** button and the **SET** button pressed simultaneously.
 - ✓ The time is set.


Combination instrument - setting/resetting TRIP 1



Info

The **TRIP 1** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



700121-01

- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- Press the **MODE** button repeatedly until the **TRIP 1** mode is active.
- Keep the **SET** button pressed.
 - ✓ The **TRIP 1** display is set to **0.0**.


Combination instrument - setting/resetting TRIP 2



Info

The **TRIP 2** trip counter is always running and counts up to **999.9**.

The trip counter can be used to measure the distance covered during trips or between two refueling stops. After the value **999.9** is reached, the trip counter starts at **0.0** again.



- Switch on the ignition by turning the ignition key in the position \bigcirc (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- Press the **MODE** button repeatedly until the **TRIP 2** mode is active.
- Keep the **SET** button pressed.
- ✓ The **TRIP 2** display is set to **0.0**.

Combination instrument - setting the wheel circumference



Danger


Voiding of the government approval for road use and the insurance coverage The vehicle is only authorized for operation on public roads in the homologated version.

- If the vehicle is modified in any way, it may only be used on designated tracks away from public roads. Advise the vehicle owner and rider of this.
- If you undertake any modifications, please insist on receiving a signed workshop order from your customer in which you inform the customer in writing that these modifications are performed at the customer's own risk and that the vehicle will no longer be approved for use on public roads once modified.

Condition

The motorcycle is stationary.

- Switch off all power consumers and switch off the engine.
- Remove the headlight mask with the headlight. (☛ p. 84)
- Unplug connector **ED** from the combination instrument.
- Unlock pin **18** **A** and remove it from connector **ED**.
- Plug connector **ED** into the combination instrument.
- Switch on the ignition by turning the ignition key in the position \bigcirc (690 SMC EU, 690 SMC AUS/UK) **ON** (690 SMC USA).
- Press the **MODE** button repeatedly until the **TRIP 1** display mode is active.
- Press and hold the **MODE** button for 10 seconds.
- ✓ The wheel circumference is displayed in millimeters.



Increasing the wheel circumference

- Press the **MODE** button **1**.


Reducing the wheel circumference

- Press the **SET** button **2**.


- Keep the **MODE** button and the **SET** button pressed simultaneously.

✓ The settings are saved and the Setup menu is closed.

- Switch off the ignition by turning the ignition key in the position \boxtimes (690 SMC EU, 690 SMC AUS/UK) **OFF** (690 SMC USA).
- Unplug connector **ED** from the combination instrument.
- Connect pin **18** to connector **ED**.
- Plug connector **ED** into the combination instrument.
- Install the headlight mask with the headlight. (☛ p. 85)



Checking the headlight setting



- Stand the vehicle upright on a horizontal surface in front of a light wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first mark.

Guideline

| | |
|-------------------|-------------|
| Distance B | 5 cm (2 in) |
|-------------------|-------------|

- Position the vehicle vertically at a distance **A** in front of the wall.

Guideline

| | |
|-------------------|-------------|
| Distance A | 5 m (16 ft) |
|-------------------|-------------|

- The rider, with luggage and a passenger if applicable, now sits down on the motorcycle.
- Switch on the low beam.
- Check the headlight setting.

For a ready-to-operate motorcycle with a rider, and with luggage and a passenger if applicable, the light-dark boundary must lie exactly on the lower mark.

- » If the boundary between light and dark does not meet specifications:
 - Adjust the headlight range. (☛ p. 84)

Adjusting the headlight range



- Check the headlight setting. (☛ p. 84)
- Turn adjusting screw **1** to adjust the headlight range.

Guideline

For a motorcycle with rider, the light/dark boundary must be exactly on the lower mark (made in: Checking headlight adjustment).



Info


Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.

If you have a heavy payload, you will need to correct the headlight range.

Removing the headlight mask with the headlight




- Switch off all power consumers and switch off the engine.
- Cover the fender with a cloth to protect it from damage.
- Remove screws **1** on the left and right.
- Tip the headlight mask forward and pull it off in an upward direction.




- Disconnect the connectors of turn signals **2** and headlight **3**.
- Put down the headlight mask.


Installing the headlight mask with the headlight




- Connect the connectors of headlight ❶ and flasher lights ❷.
- Check lighting function.



- Remove the cloth from the fender, attach the headlight mask to points ❸ on the fender and swing it up to the steering head.



- Position groove ❹ on counterpiece ❺.



- Position brake-hose guide ❻. Mount and tighten screws ❼.

Guideline


| | | |
|---------------------------|----|--------------------|
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

Changing the parking light bulb


Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the headlight mask with the headlight. (➡ p. 84)
- Remove rubber cap ❶.



- Pull bulb socket ② out of the reflector.
- Pull parking light bulb ③ out of the bulb socket.
- Insert a new parking light bulb in the bulb socket.

Parking light (W5W / socket W2.1x9.5d) (☛ p. 173)


- Insert the bulb socket in the reflector.
- Insert the rubber cap.
- Install the headlight mask with the headlight. (☛ p. 85)

Changing the headlight bulb


Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the headlight mask with the headlight. (☛ p. 84)
- Pull off connector ①.
- Take off rubber cap ② of the headlight bulb.



- Detach spring bar ③.
- Remove headlight bulb ④.
- Insert a new headlight bulb into the headlight housing.

Headlight (H4 / socket P43t) (☛ p. 173)

- Fix the headlight bulb in the headlight using the spring bar.
- Replace the rubber cap. Attach the connector.
- Install the headlight mask with the headlight. (☛ p. 85)

Changing the flasher bulb

Note

Damage to reflector Reduced luminance.

- Grease on the lamp will evaporate due to the heat and be deposited on the reflector. Clean the lamp and keep it free of grease before mounting.



- Remove the screw from the rear of the flasher housing.
- Tilt headlamp diffuser ① forward carefully and take it off.
- Press the flasher bulb carefully into the socket, turn it counterclockwise by about 30°, and take it out of the socket.



Info

Do not touch the reflector with your fingers, and keep it free from grease.


- Press the new flasher bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (RY10W / socket BAU15s) (☛ p. 173)

- Position the diffuser.


- Insert the screw and turn it counterclockwise first until it engages in the thread. Tighten the screw slightly.
- Check the flasher system function.

Removing the engine




- Raise the motorcycle with the work stand. (☛ p. 10)
- Disconnect the battery. (☛ p. 68)
- Remove the exhaust manifold. (☛ p. 47)
- Drain the coolant. (☛ p. 149)
- Loosen the spring-loaded band-type clamp **1** using the special tool. Detach the radiator hoses.


Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 210)




- Remove screws **2**.



- Remove screws **3**.
- Take off the engine sprocket cover.
- Remove screw **4**.
- Take off the shift lever.



- Have an assistant operate the rear brake.
- Bend up the lock washer.
- Remove the nut of the engine sprocket with the lock washer.
- Remove screws **5**.



- Remove nut **6**. Remove the chain adjuster.
- Pull out the wheel spindle only far enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible and take the chain off the rear sprocket.



Info

The rear wheel must be fully removed.


- Take off the engine sprocket.
- Take off the clutch slave cylinder and hang it to the side.




Info

Do not bend the clutch line.


Do not operate the clutch when the clutch slave cylinder is removed.




- Take off the clutch push rod.
- Unscrew the electrical connection ⑦ from the starter motor.
- Remove ground wire ⑧ from the starter motor.




- Loosen hose clip ⑨.
- Pull off the throttle valve body from the rear.



- Disconnect plug-in connections ⑩ of the gear position sensor, the crankshaft position sensor and the alternator.
- Remove the cable binders and release the cables.




- Pull of the spark plug connector.
- Unplug the connector of the engine coolant temperature sensor ⑪.




- Loosen the spring-loaded band-type clamp ⑫ from the breather, SLS and oil return line with the special tool.

Pliers for spring-loaded band-type clamp (60029057100) (➔ p. 210)




- Remove screws ⑬. Remove the engine bearer.




- Position the floor jack under the engine and fix it using the special tool.


Floor jack attachment (75029055000) (☛ p. 215)



- Remove nut 14 of the lower engine bracket. Remove the screw.



- Remove screw 15 of the swingarm pivot.
- Remove the swingarm pivot.




- Lower the engine.



Info

You should have an assistant for this step.
Make sure that the engine is sufficiently secured against falling over.
Protect the frame and attachments from damage.


Installing the engine




- Raise the engine onto the special tool and fix it.

Floor jack attachment (75029055000) (☛ p. 215)

- Position the engine in the frame.
- Mount swingarm pivot 1.
- Mount the screw of the swingarm pivot but do not tighten yet.




- Install the screw and nut ② of the lower engine bracket, but do not tighten them yet.



- Remove the floor jack with the special tool.

Floor jack attachment (75029055000) (☛ p. 215)



- Position the engine bearer.
- Mount and tighten screws ③.

Guideline

| | | |
|-------------------------------|-----|------------------------|
| Screw, engine bearer on frame | M10 | 45 Nm (33.2 lbf ft) |
|-------------------------------|-----|------------------------|

- Mount and tighten screw ④ with nut.

Guideline

| | | | |
|-----------------------|-----|------------------------|---------------|
| Engine carrying screw | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|-----------------------|-----|------------------------|---------------|

- Tighten the swingarm pivot.

Guideline

| | | |
|-----------------------|----------|-------------------|
| Screw, swingarm pivot | M12x1.75 | 80 Nm (59 lbf ft) |
|-----------------------|----------|-------------------|



- Tighten the lower engine bracket.

Guideline


| | | | |
|-----------------------|-----|------------------------|---------------|
| Engine carrying screw | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
|-----------------------|-----|------------------------|---------------|

- Position the hoses of the engine breather, the SLS and the oil return line. Mount the spring-loaded band-type clamp ⑤ using the special tool.


Pliers for spring-loaded band-type clamp (60029057100) (☛ p. 210)




- Attach the spark plug connector.
- Plug in the connector of the engine coolant temperature sensor ⑥.



- Reconnect plug connectors 7 of the gear position sensor, the crankshaft position sensor and the alternator.



- Position the throttle valve body.
- Position and tighten hose clip 8.




- Position the electrical connection 9 on the starter motor. Mount and tighten screw.

| | | |
|---------------------------------|----|-------------------|
| Screw, starter cable on starter | M5 | 3 Nm (2.2 lbf ft) |
|---------------------------------|----|-------------------|

- Position the ground wire on the starter motor. Mount and tighten screw 10.

Guideline

| | | | |
|----------------------|----|--------------------|---------------|
| Screw, starter motor | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|----------------------|----|--------------------|---------------|




- Insert the clutch push rod.
- Position the clutch slave cylinder.
- Mount and tighten screws 11.

Guideline

| | | | |
|------------------------------|-------|--------------------|---------------|
| Screw, clutch slave cylinder | M6x20 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, clutch slave cylinder | M6x35 | 10 Nm (7.4 lbf ft) | - |


- Mount the engine sprocket with the chain.
- Position the new lock washer and mount nut 12 but do not tighten yet.



- Position the rear wheel.
- Mount the chain adjuster and nut.
- Push the rear wheel forward so that the chain adjusters are on the tensioning screws, and tighten the nut 13.

Guideline

| | | |
|-------------------------|---------|---------------------|
| Nut, rear wheel spindle | M25x1.5 | 90 Nm (66.4 lbf ft) |
|-------------------------|---------|---------------------|




- Have an assistant operate the rear brake.
- Tighten the engine sprocket nut.

Guideline

| | | | |
|----------------------|---------|---------------------|---------------|
| Nut, engine sprocket | M20x1.5 | 60 Nm (44.3 lbf ft) | Loctite® 243™ |
|----------------------|---------|---------------------|---------------|

- Secure the nut with the lock washer.



- Position the rear sprocket cover.
- Mount and tighten screw 15.

| | | |
|---------------------------|----|------------------------|
| Guideline | | |
| Remaining screws, chassis | M8 | 25 Nm (18.4 lbf ft) |

- Mount and tighten screw 16.



| | | |
|---------------------------|----|--------------------|
| Guideline | | |
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) |

- Position the shift lever.
- Mount and tighten screw 17.


| | | |
|--------------------|----|-----------------------|
| Guideline | | |
| Screw, shift lever | M6 | 10 Nm (7.4 lbf ft) |
| | | Loctite® 222 |

- Mount and tighten screws 18.

| | | |
|-------------------------|----|-------------------|
| Guideline | | |
| Screw, radiator bracket | M6 | 5 Nm (3.7 lbf ft) |



- Position the radiator hoses. Install the spring-loaded band-type clamps 19.
- Install the exhaust manifold. (🔧 p. 47)
- Disconnect the battery. (🔧 p. 69)




- Remove the oil filler plug with O-ring 20 from the clutch cover and fill up with engine oil.

| | | | |
|------------|------------------|---|--|
| Engine oil | 1.70 l (1.8 qt.) | Engine oil (SAE 10W/60) (00062010035) (🔧 p. 204) | |
| | | Alternative engine oil | Engine oil (SAE 10W/50) (🔧 p. 204) |

- Install and tighten the oil filler plug with O-ring 20.
- Fill the cooling system. (🔧 p. 149)
- Remove the motorcycle from the work stand. (🔧 p. 10)
- Take a short test ride.
- Read out the fault memory using the KTM diagnostics tool.
- Check the engine for leakage.
- Check the engine oil level. (🔧 p. 152)
- Check the coolant level. (🔧 p. 151)

Clamping engine into engine work stand



- Mount special tool ❶ on engine work stand ❷.

Engine work stand (61229001000) (☞ p. 211)

Support for engine work stand (75012001060) (☞ p. 212)

Holder for engine work stand (75012001070) (☞ p. 212)


- Mount the engine on special tool ❶.




Info

Have an assistant help you or use a crane.

Draining the engine oil




- Remove the oil drain plug ❶ with the magnet and seal ring.
- Remove plug ❷ with oil screen and the O-rings.




- Remove plug ❸ with oil screen ❹ and the O-rings.
- Completely drain the engine oil.

Removing starter motor




- Remove screws ❶. Take off the starter motor.

Removing valve cover




- Remove screws ❶. Take off the valve cover with the valve cover seal.

Removing the alternator cover




- Remove screws ❶. Take off the alternator cover.
- Remove dowels.

Removing spacer




- Remove the spacer ❶ of the countershaft.

Removing gear position sensor




- Remove screws. Remove the gear position sensor ❶.




- Remove O-ring ❷.
- Remove contact pin ❸ and the contact springs ❹.

Removing oil filter



- Remove screws. Remove the oil filter cover ❶ with the O-ring.
- Pull the oil filter element ❷ out of the oil filter case.


Circlip pliers reverse (51012011000) (☛ p. 208)



- Remove screws. Remove the oil filter cover ③ with the O-ring.
- Pull the oil filter element ④ out of the oil filter case.


Circlip pliers reverse (51012011000) (☞ p. 208)

Removing thermostat




- Remove screws. Take off the thermostat case ① with the radiator hose.
- Pull out the thermostat ②.

Setting engine to ignition top dead center



- Turn the crankshaft counterclockwise until markings ① of the camshafts are flush with the marks of the camshaft support plate.



- Remove screw ②.




Info

Look through the hole to check that the position hole of the balancer shaft is visible.


- Screw in special tool ③.

Engine blocking screw (77329010000) (☞ p. 216)

Removing water pump wheel



- Remove screws ①. Take off the water pump cover.




- Remove screw ②. Take off the water pump wheel ③.
- Take off the water pump cover seal.




Info

Do not lose the centering pins.




- Remove the shaped washer ④.

Removing clutch cover




- Remove screws ①. Take off the clutch cover.
- Take off the dowels. Remove the clutch cover seal.

Removing spacer and spring



- Remove the spacer ① and spring ② of the shift shaft.


Removing spark plug



- Remove the spark plug using the special tool ①.


Spark plug wrench (75029172000) (☞ p. 216)

Removing timing chain tensioner




- Remove screw ❶. Take off the seal ring.
- Pull out timing chain tensioner ❷.

Removing camshafts




- Remove screw ❶. Take off the camshaft support plate ❷.




- Pull the camshaft out of the bearing seats. Take the timing chain off the camshaft gear. Remove the camshaft.

Removing cylinder head



- Remove screws ❶.
- Alternately loosen screws ❷ and remove them.
- Take off the cylinder head.


Removing piston



- Take off the cylinder head gasket ❶.
- Remove screw ❷.
- Push the cylinder upward.

Info

Push the cylinder upward only far enough to allow removal of the piston pin. Ensure that the two grooved pins remain in place.



- Remove piston pin retainer ③.
- Remove the piston pin.
- Take off the cylinder with the piston.
- Push the piston upward out of the cylinder.


**Info**

If no other work is required on the cylinder and the piston, you can leave the piston in the cylinder.

- Take off the cylinder base gasket.


**Info**

Ensure that the two grooved pins remain in place.

Removing rotor

- Remove special tool ①.

Engine blocking screw (77329010000) (☛ p. 216)




- Use the special tool to hold the rotor tight.

Holding spanner (75029091000) (☛ p. 215)

- Loosen the nut ① of the rotor and remove it with the tab washer.

**Info**


The crankshaft must not be blocked.



- Install the special tool ② on the rotor. Hold it tight using the special tool and pull off the rotor by turning the screw in.

Extractor (58429009000) (☛ p. 208)

- Remove the special tool.


Removing timing chain rails

- Remove screws ①.
- Pull the timing chain guide rails ② out of the timing chain securing guide ③.

**Info**


The support bushing is plugged through the timing chain guide rails into the timing chain securing guide.

- Take out the timing chain guide rails upwards through the chain shaft.



- Hold the timing chain securing guide tight and pull the timing chain tensioning rail ④ out of the timing chain securing guide.
- Take out the timing chain tensioning rail upwards through the chain shaft.
- Remove the timing chain securing guide ③.

Removing timing chain and timing chain sprocket




- Unthread the timing chain.



Info

Mark the direction of travel.


- Take off the lock ring ①.



- Pull of the timing chain sprocket with the special tool ②.


Extractor (59029033000) (☛ p. 209)

Removing crankshaft position sensor



- Remove the screws of crankshaft position sensor ①.
- Pull cable support sleeve ② out of the engine case. Take off the crankshaft position sensor.

Removing clutch cage




- Compress the antihopping clutch with the special tool ①.

Assembly screws (75029033000) (☛ p. 212)




Info


Apply the special tool with the hand only, do not use another tool.



- Loosen the screws ② diagonally and remove them with their spring retainers and clutch springs.
- Remove the pressure cap ③.



- Remove the pressure piece ④.
- Bend up the lock washer ⑤.



- Hold the clutch cage using the special tool and remove the nut ⑥ of the inner clutch hub.

Gear segment (75029081000) (☛ p. 215)



Info


Make sure that the crankshaft is not blocked.

- Remove the nut ⑦ of the primary gear.




Info

Left-handed thread!




- Take off the stepped washer and remove the half-washers ⑧.
- Take off the clutch cage.



- Remove needle bearing ⑨ and supporting plate ⑩.

Removing primary gear



- Plug the special tool into the crankshaft.


Protection cover (75029090000) (☞ p. 215)

- Screw the special tool **1** on to the primary gear **2**.


Extractor (75029021000) (☞ p. 212)

- Hold it using the special tool and pull off the primary gear by turning the screw in.
- Remove the special tools.

Removing starter drive




- Remove the lock ring of the starter idler gear **1** and the torque limiter **2**.
- Take off the starter idler gear **1** with the washers.
- Remove the torque limiter **2** with the washers and needle bearing.




- Take off the free-wheel gear **3**.
- Remove the woodruff key **4** and both needle bearings **5**.

Removing shift shaft




- Push sliding plate **1** away from the shift drum locating **2**. Remove shift shaft **3** with the washer.

Removing shift drum locating




- Remove screw **1**.
- Press locking lever **2** away from shift drum locating **3** and take off the shift drum locating.
- Release the locking lever.

Removing locking lever




- Remove screw ❶.
- Take off locking lever ❷ with the sleeve and spring.


Removing oil pumps



- Remove the lock washers ❶ and normal washers ❷ from both oil pumps.
- Take off the oil pump toothed wheels ❸.




- Remove the pins ❹ and washers ❺.
- Remove screws. Take off the oil pump cover ❻.




- Remove both oil pump shafts ❷ with internal rotors ❸.
- Take the external rotors out of the engine case.

Removing left engine case



- Remove screws ❶.
- Swing the left engine case up and remove the nut or screw of the engine holder.



- Install the special tool ② with suitable screws.

Extractor (75029048000) (☛ p. 214)



Info

Use the **750** drill hole.

- Pull off the section of the engine case.




Info


Do not tension the section of the engine case.

The balancer shaft and the main shaft have a stop disk, these usually stick to the bearing.

- Take off the left section of the engine case.
- Remove the special tool.
- Remove dowels.
- Remove O-ring ③.




Removing crankshaft and balancer shaft




- Remove the crankshaft ① and the balancer shaft ②.


Removing transmission shafts



- Remove the shift rail ①.




- Swing shift forks ② to one side.
- Remove shift drum ③.




- Remove shift forks ②.

**Info**

Ensure that the pins remain in place.



- Remove the lock ring ④ and the stop disk.




- Pull both transmission shafts ⑤ out of the bearing seats together.

**Info**

The stop disk of the countershaft usually sticks to the bearing.

- Take the O-ring off the countershaft ⑥.

Work on the right section of the engine case



- Remove oil jet ❶.
- Remove bearing locks of the main shaft bearing ❸, of the countershaft bearing ❹, and of the shift drum bearing ❺.
- Remove any sealing mass remnants and clean the engine case section thoroughly.
- Pull the dowels out of the housing.
- Warm the engine case section in an oven.

Guideline


| |
|-----------------|
| 150 °C (302 °F) |
|-----------------|

- Knock the engine case section against a level wooden plate. This will cause the bearings to drop out of the bearing seats.



Info

Any bearings that remain in the engine case section must be removed using a suitable tool.



- Remove oil jet ❷.
- Remove the cover plate ❻ for the oil return line.
- Press out the shaft seal ring ❼ of the crankshaft from the inside to the outside.
- Remove the shaft seal rings ❸ of the water pump.
- Press in the shaft seal ring ❼ of the crankshaft from the outside to the inside with the open side facing in.



Info

The shaft seal ring must be flush on the outside.

- Press in the shaft seal rings of the water pump with the open side facing out so that it is flush.
- Warm the engine case section again.

Guideline

| |
|-----------------|
| 150 °C (302 °F) |
|-----------------|

- Insert the new cold bearings into the bearing seats of the hot engine case section and, if necessary, use a suitable press drift to push the bearing from the inside to the outside, all the way to the stop or so it is flush.



Info

The shift shaft bearing ❹ must be pressed in from the outside to the inside until it is flush.

When pressing the bearing in, ensure that the engine case section is level to prevent damage.

Only press the bearings in via the outer ring; otherwise, the bearings will be damaged when they are pressed in.

- After the engine case section has cooled, check that the bearings are firmly seated.



Info

If the bearings are not firmly seated after cooling, it is likely that they will rotate in the engine case when warm. In this case, the engine case must be renewed.

- Position all bearing locks. Mount and tighten the screws.

Guideline


| | | | |
|---------------------------|----|----------------------|---------------|
| Locking screw for bearing | M5 | 6 Nm (4.4 lbf ft) | Loctite® 243™ |
|---------------------------|----|----------------------|---------------|

- Mount and tighten the oil jet ❶.

Guideline

| | | | |
|-------------------------|---------|--------------------|---------------|
| Oil jet, piston cooling | M6x0.75 | 4 Nm (3 lbf ft) | Loctite® 243™ |
|-------------------------|---------|--------------------|---------------|

- Mount and tighten the oil jet ❷.



Guideline

| | | | |
|-----------------------------|----|----------------------|---------------|
| Oil jet, conrod lubrication | M4 | 2 Nm (1.5 lbf ft) | Loctite® 243™ |
|-----------------------------|----|----------------------|---------------|


- Blow compressed air through all oil holes and check that they are clear.
- Position the cover plate ⑥. Mount and tighten the screws.

Guideline

| | | |
|--|----|-------------------|
| Screw, cover plate for oil return line | M5 | 6 Nm (4.4 lbf ft) |
|--|----|-------------------|

- Reinstall the dowels.

Work on the left section of the engine case





- Remove all dowels.
- Remove oil jet ①.
- Remove the shaft seal ring of the countershaft ② and the shift shaft ③.



Info

The shaft seal ring ④ of the crankshaft cannot be removed before the crankshaft bearing.

- Screw off the membrane support plate ⑤ and remove it together with the membrane ⑥.



- Remove the plug ⑦ and take the pressure spring ⑧ with the piston valve ⑨ out of the drill hole.
- Remove any sealing mass remnants and clean the engine case section thoroughly.
- Warm the engine case section in an oven.

Guideline

| |
|-----------------|
| 150 °C (302 °F) |
|-----------------|

- Knock the engine case section against a level wooden plate. This will cause the bearings to drop out of the bearing seats.



Info

Any bearings that remain in the engine case section must be removed using a suitable tool.

- Press out the shaft seal ring of the crankshaft from the outside to the inside.
- Press in the shaft seal ring of the crankshaft from the inside to the outside with the open side facing out.



Info

The shaft seal ring must be flush on the outside.

- Warm the engine case section again.

Guideline

| |
|-----------------|
| 150 °C (302 °F) |
|-----------------|

- Insert the new cold bearings into the bearing seats of the hot engine case section and, if necessary, use a suitable press drift to push the bearing, all the way to the stop or so that it is flush.

**Info**

When pressing the bearing in, ensure that the engine case section is level to prevent damage.

Only press the bearings in via the outer ring; otherwise, the bearings will be damaged when they are pressed in.

- After the engine case section has cooled, check that the bearings are firmly seated.

**Info**

If the bearings are not firmly seated after cooling, it is likely that they will rotate in the engine case when warm. In this case, the engine case must be renewed.

- Press in the shaft seal ring of the countershaft ② and the shift shaft ③ with the open side facing inwards so that it is flush.
- Mount and tighten the oil jet ①.

Guideline

| | | | |
|-------------------------|---------|--------------------|---------------|
| Oil jet, piston cooling | M6x0.75 | 4 Nm (3 lbf ft) | Loctite® 243™ |
|-------------------------|---------|--------------------|---------------|

- Mount the dowels.
- Blow compressed air through all oil holes and check that they are clear.
- Measure the spring length of the oil pressure regulator valve.

| | |
|--|--------------------|
| Oil pressure regulator valve - minimum spring length | 27.5 mm (1.083 in) |
|--|--------------------|

» If the measured value does not equal the specified value:

- Change the spring.

- Check the piston valve for damage and wear.

» If there is damage or wear:

- Replace the piston valve.

- Lubricate the piston valve ⑨ and mount it with the pressure spring ⑧. Mount and tighten plug ⑦ with the new seal ring.

Guideline

| | | |
|-----------------------------------|---------|------------------------|
| Oil pressure regulator valve plug | M12x1.5 | 20 Nm (14.8 lbf ft) |
|-----------------------------------|---------|------------------------|

- Position the membrane support plate ⑤ with the membrane ⑥. Mount and tighten the screws.

Guideline




| | | | |
|--------------------------|----|-------------------------|---------------|
| Screw, membrane fixation | M3 | 2.5 Nm (1.84 lbf ft) | Loctite® 243™ |
|--------------------------|----|-------------------------|---------------|

**Info**

The membrane support plate is curved and must point away from the membrane.

An incorrectly installed membrane support plate results in loss of performance and increased oil consumption or leaks.

Do not apply thread locking material between the membrane and the membrane support plate since this would badly affect the functioning.

**Work on the clutch cover**


- Remove the shaft seal ring ① of the crankshaft.
- Press in a new shaft seal ring with the open side facing inward until it stops.

**Info**

Support the clutch cover sufficiently when pressing in.

- Blow compressed air through the oil channel and check that it is clear.


Removing crankshaft bearing inner ring



- Fix the crankshaft with special tools 1 and 2 in the vise.

Upper part, pressing-out tool (75029047050) (p. 214)

Under part, pressing-out tool (75029047051) (p. 214)



- Heat the special tool 3.


Guideline

150 °C (302 °F)

Tool for inner bearing race (58429037043) (p. 209)


- Push the heated special tool 3 on to the inner bearing race, press them hard together, and pull them together off the crankshaft.
- Take off the compensation shim.
- Repeat the operation on the opposite side.

Removing balancer shaft drive wheel



- Remove the crankshaft bearing inner ring. (p. 109)
- Screw in 2 M6 screws 1 in the threads. Tighten the two screws evenly to pull the drive wheel 2 off the crankshaft.

Changing the conrod bearing



- Remove the drive wheel of the balancer shaft. (p. 109)
- Position the crankshaft with the special tool 1 in the press.

Under part, pressing-out tool (75029047051) (p. 214)

- Position the special tool 2 between the crankwebs.

Upper part, pressing-out tool (75029047050) (p. 214)

- Press the crank pin with the push-out drift of the special tool out of the upper crankweb.


Pressing device for crankshaft, complete (75029047000) (p. 213)




Info

Hold the lower crankweb.

- Take off the connecting rod and bearing.
- Press the crank pin out of the crankweb.






- Press in the new crank pin ③ as far as possible.

**Info**

The crank pin must be pressed in so that oil hole ① is aligned with oil hole ②.

If the oil holes are not correctly aligned, the conrod bearing will not be supplied with oil.


- Blow compressed air through the oil passage to check that it is clear.



- Install the bearing ④ and the connecting rod ⑤.

**Info**


Lubricate the bearing thoroughly.



- Position special tool ⑥ on the press.

Pressing device for crankshaft, complete (75029047000) (☛ p. 213)

- Place the crankweb in with the connecting rod and the bearing. Position the second crankweb.



- Position the special tool ⑦ with the heel at the bottom.

Pressing device for crankshaft, complete (75029047000) (☛ p. 213)

- Press the upper crankweb in as far as possible.

**Info**

The press mandrel must be applied above the crank pin.

- Take the crankshaft out of the special tool, and check the connecting rod for freedom of movement.

- Measure the axial clearance between the connecting rod and the crankwebs using the special tool ⑧.

Feeler gauge (59029041100) (☛ p. 210)


| | |
|--|---------------------------------------|
| Connecting rod - axial clearance of lower conrod bearing | 0.40... 0.60 mm (0.0157... 0.0236 in) |
|--|---------------------------------------|

» If the specified value is not met:


- Correct until it complies with the specified value.

- Check the crankshaft run-out at the bearing pin. (☛ p. 111)

- Install the drive wheel of the balancer shaft. (☛ p. 111)



Checking crankshaft run-out at bearing pin




- Position the crankshaft on a roller block.
- Rotate the crankshaft slowly.
- Check the crankshaft run-out at both bearing pins.

| | |
|-----------------------------------|---|
| Crankshaft run-out at bearing pin | $\leq 0.10 \text{ mm}$ ($\leq 0.0039 \text{ in}$) |
|-----------------------------------|---|

- » If the crankshaft run-out at the bearing pin is greater than the specified value:
 - Align the crankshaft.

Installing balancer shaft drive wheel



- Fix the crankshaft with special tools ❶ and ❷ in the vise.


| |
|--|
| Upper part, pressing-out tool (75029047050) (☛ p. 214) |
|--|

| |
|--|
| Under part, pressing-out tool (75029047051) (☛ p. 214) |
|--|


- Warm the drive wheel.

Guideline


| |
|-----------------|
| 100 °C (212 °F) |
|-----------------|



- Place the drive wheel on the crankshaft.
 - ✓ The dowel of the crankshaft must fit in the drill hole ❹.
 - ✓ The side of the drive wheel with the punch mark ❸ must be visible after assembly, and the side with the bevel ❷ must be in contact with the crankweb.
- Install the crankshaft bearing inner ring. (☛ p. 111)



Installing crankshaft bearing inner ring



- Fix the crankshaft with special tools ❶ and ❷ in the vise.

| |
|--|
| Upper part, pressing-out tool (75029047050) (☛ p. 214) |
|--|

| |
|--|
| Under part, pressing-out tool (75029047051) (☛ p. 214) |
|--|

- Push on the compensation shim.
- Heat the special tool. Install the inner bearing race.

Guideline

| |
|-----------------|
| 120 °C (248 °F) |
|-----------------|


- Repeat the operation on the opposite side.
- Make sure that the new inner ring is flush installed.



Info

After changing the crankshaft bearing, measure the axial clearance of the crankshaft.

Measuring axial clearance of crankshaft and balancer shaft



- Insert the crankshaft and balancer shaft in the right engine casing.

**Info**

Do not forget the dowels.

- Mount the left engine casing.
- Mount and tighten the screws.

Guideline

| | | |
|--------------------|----|--------------------|
| Screw, engine case | M6 | 10 Nm (7.4 lbf ft) |
|--------------------|----|--------------------|

- Mount the dial gauge support on the engine case and measure and note the axial clearance of the crankshaft.

Guideline

| | |
|------------------------------|---------------------------------------|
| Crankshaft - axial clearance | 0.15... 0.25 mm (0.0059... 0.0098 in) |
|------------------------------|---------------------------------------|

- » If the measured value does not equal the specified value:
 - Remove the crankshaft.
 - Remove the crankshaft bearing inner ring. (☛ p. 109)
 - Calculate the thickness of the compensation shims.
 - Add or remove compensation shims equally on both sides.

**Info**

If the axial clearance is too small, remove compensation shims.
If the axial clearance is too large, add compensation shims.

- Install the crankshaft bearing inner ring. (☛ p. 111)

- Mount the dial gauge support on the engine case and measure and note the axial clearance of the balancer shaft.

Guideline

| | |
|--------------------------------|--------------------------------------|
| Balancer shaft axial clearance | 0.05... 0.20 mm (0.002... 0.0079 in) |
|--------------------------------|--------------------------------------|

- » If the measured value does not equal the specified value:
 - Remove the balancer shaft.
 - Calculate the thickness of the compensation shims.
 - Add compensation shims to the ignition side only.

**Info**

If the axial clearance is too small, remove compensation shims.
If the axial clearance is too large, add compensation shims.




Cylinder - Nikasil® coating



Nikasil® is a surface protection layer for a coating method developed by the Mahle company. The name is derived from the two materials used in this method - a layer of nickel, in which silicon carbide (a particularly hard substance) is embedded. The most important advantages of the **Nikasil®** coating are the excellent heat conductivity resulting in better performance, less wear, and low cylinder weight.

Checking/measuring the cylinder




- Check the O-ring of the chain adjuster for damage and wear.
 - » If there is damage or wear:
 - Replace the O-ring.
- Check the cylinder bearing surface for damage.
 - » If the cylinder bearing surface is damaged:
 - Change the cylinder and piston.
- Measure the cylinder diameter at several places in the **X** and **Y** axes using a micrometer to check for oval wear.
- To determine the size, measure the cylinder at a distance **B** from the top edge of the cylinder.

Guideline

| | |
|--------------------------|---|
| Distance B | 55 mm (2.17 in) |
| Cylinder - bore diameter | |
| Size I | 102.000... 102.012 mm (4.01574... 4.01621 in) |
| Size II | 102.013... 102.025 mm (4.01625... 4.01672 in) |

- The cylinder size **1** is marked on the side of the cylinder.




- Check the sealing area of the cylinder head for distortion using a straight edge and the special tool.

Feeler gauge (59029041100) (☛ p. 210)

| | |
|--|-------------------------|
| Cylinder/cylinder head - sealing area distortion | ≤ 0.10 mm (≤ 0.0039 in) |
|--|-------------------------|

- » If the measured value does not equal the specified value:
 - Change the cylinder.

Checking/measuring the piston



- Use the special tool to measure clearance **A** of the piston rings in the piston ring groove.

Guideline

| | |
|--------------------------------|-------------------------|
| Piston ring - groove clearance | ≤ 0.08 mm (≤ 0.0031 in) |
|--------------------------------|-------------------------|

Feeler gauge (59029041100) (☛ p. 210)

- » If clearance **A** is larger than the specified value:
 - Change the piston and piston rings.
 - Check/measure the cylinder. (☛ p. 113)
- Check the piston bearing surface for damage.
 - » If the piston bearing surface is damaged:
 - Change the piston and, if necessary, the cylinder.
- Check that the piston rings can move easily in the piston ring grooves.
 - » If the piston ring is stiff:



- Clean the piston ring groove.

**Tip**

Use an old piston ring to clean the piston ring groove.

- Check the piston rings for damage.
 - » If the piston ring is damaged:
 - Change the piston ring.


**Info**

Mount the piston ring with the marking facing upward.

- Check the piston pin for discoloration or signs of wear.
 - » If the piston pin has strong discoloration/signs of wear:
 - Change the piston pin.
- Insert the piston pin into the connecting rod and check the bearing for play.
 - » If the piston pin bearing has too much play:
 - Change the connecting rod and the piston pin.
- Measure the piston at the piston skirt, at right angles to the piston pin, at a distance **B**.


Guideline

| | |
|-------------------|---|
| Distance B | 31.5 mm (1.24 in) |
| Piston - diameter | |
| Size I | 101.955... 101.965 mm (4.01397... 4.01436 in) |
| Size II | 101.965... 101.975 mm (4.01436... 4.01476 in) |

**Info**

Piston size **1** is marked on the piston head.

Checking piston ring end gap



- Remove the piston ring from the piston.
- Place the piston ring in the cylinder and align it with the piston.

Guideline

| | |
|--------------------------------------|-----------------|
| Under the upper edge of the cylinder | 10 mm (0.39 in) |
|--------------------------------------|-----------------|

- Measure the end gap with a feeler gauge **A**.

Guideline

| | |
|---------------------|------------------------------------|
| Piston ring end gap | |
| Compression rings | ≤ 0.80 mm (≤ 0.0315 in) |
| Oil scraper ring | ≤ 1.00 mm (≤ 0.0394 in) |

- » If the end gap is more than the specified value:
 - Check/measure the cylinder. (➡ p. 113)
- » If the cylinder wear is within the tolerance range:
 - Change the piston ring.
- Mount the piston ring with the marking facing toward the piston head.

Checking piston/cylinder mounting clearance

- Check/measure the cylinder. (☛ p. 113)
- Check/measure the piston. (☛ p. 113)
- The smallest piston/cylinder mounting clearance is the result of the smallest cylinder bore diameter minus the largest piston diameter. The largest piston/cylinder mounting clearance is the result of the largest cylinder bore diameter minus the smallest piston diameter.

Guideline


| Piston/cylinder - mounting clearance | |
|--------------------------------------|---|
| New condition | 0.035... 0.060 mm (0.00138... 0.00236 in) |
| Wear limit | 0.10 mm (0.0039 in) |

Checking oil pumps for wear



Info

The oil pump wear check shown here is on the suction pump but it applies to all oil pumps.




- Use a feeler gauge ❶ to measure the play between the external rotor and the engine case as well as between the external rotor and the internal rotor.


| Oil pump | |
|---|---------------------------------------|
| Clearance between external rotor and engine case | ≤ 0.20 mm (≤ 0.0079 in) |
| Clearance between external rotor and internal rotor | ≤ 0.20 mm (≤ 0.0079 in) |
| Axial clearance | 0.04... 0.08 mm (0.0016... 0.0031 in) |

- » If the measured value does not meet specifications:
 - Change the oil pump and, if necessary, the engine case.


Replacing autodecompressor




- Take the lock ring ❶ off the autodecompression shaft and dispose of it.



- Pull the autodecompression shaft ❷ from the camshaft.



- Disconnect the autodecompression spring. Loosen the screw ❸ and remove it together with the autodecompression spring and the autodecompression weight ❹.



- When assembling, first connect the autodecompression spring and then insert the screw through the autodecompression weight.
- ✓ The arm of the autodecompression spring ⑤ is long enough to pass right through the autodecompression weight.
- Position the autodecompression weight. Mount and tighten screw ③. Reconnect the autodecompression spring.

Guideline

| | | | |
|--------------------------|----|-----------------------------------|---------------|
| Screw, autodecompression | M6 | 3... 4 Nm (2.2... 3 lbf ft) | Loctite® 243™ |
|--------------------------|----|-----------------------------------|---------------|

- Mount the autodecompression shaft in the camshaft. Install a new lock ring.
- Check the functioning.
 - » If the autodecompression spring does not completely retract the autodecompression shaft:
 - Replace the autodecompression spring.

Preparing timing chain tensioner for installation



- Fully compress the timing chain tensioner.



Info

This requires considerable force since the oil has to be pressed out.

- Release the timing chain tensioner.
- ✓ Without pressure, the timing chain tensioner expands fully.



- Place two spacing washers or similar aids next to the piston of the timing chain tensioner. This should ensure that when pushed down, the piston does not fully withdraw.

Guideline

| | |
|----------------------|--------------------------------|
| Thickness of spacers | 2... 2.5 mm (0.08... 0.098 in) |
|----------------------|--------------------------------|

- Release the timing chain tensioner.
- ✓ The latching system locks and the piston stops moving.

| | |
|---------------------------------------|----------------|
| End position of piston after latching | 3 mm (0.12 in) |
|---------------------------------------|----------------|




Info

This position is necessary for installation.


If the timing chain tensioner is now pressed in once more (while it is installed) and then pulled out no more than halfway (preventing it from coming out fully), the latching system locks and the timing chain tensioner can no longer be compacted; this function is necessary to ensure sufficient tension of the timing chain, even at low oil pressure.

Checking timing assembly




- Clean all parts well.
- Check the timing chain gear / timing chain sprocket ❶ for damage and wear.
 - » If there is damage or wear:
 - Replace the timing chain gear / timing chain sprocket.
- Check timing chain tensioning rail ❷ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain tensioning rail.
- Check timing chain guide rail ❸ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain guide rail.
- Check timing chain securing guide ❹ for damage and wear.
 - » If there is damage or wear:
 - Replace the timing chain securing guide.
- Check timing chain ❺ for damage and wear.
 - » If there is damage or wear:
 - Change the timing chain.
- Check that the timing chain links move easily. Let the timing chain hang down freely.
 - » If the chain links no longer straighten out:
 - Change the timing chain.

Removing rocker arm




- Remove screws ❶.



- Screw a suitable screw ❸ into the rocker arm shafts ❷. Pull out the rocker arm shafts.
- Take off the rocker arm ❹.


Changing camshaft bearing



- Remove the rocker arm. (☛ p. 117)
- Clamp the cylinder head.

Clamping plate (75029050000) (☛ p. 214)
- Remove the large camshaft bearing using the special tool ❶.


Push-out drift (75029051000) (☛ p. 214)



- Remove the small camshaft bearing ❷ using the special tool.


Insert for bearing puller (15112018100) (☞ p. 208)

Bearing puller (15112017000) (☞ p. 208)



- Press in the small camshaft bearing as far as possible using the special tool ❸.

Push-in drift (75029044020) (☞ p. 213)




- Press in the large camshaft bearing as far as possible using the special tool ❹.


Push-in drift (75029044010) (☞ p. 213)

- Install the rocker arm. (☞ p. 121)

Removing valves



- Take the shims ❶ out of the valve spring retainers and lay them to one side according to their normal built-in position.



- Pretension the valve springs using the special tool.

Valve spring compressor (59029019000) (☞ p. 209)

Valve spring mounting device (78029060000) (☞ p. 216)


- Remove valve keys and release tension on the valve springs.
- Remove spring retainers and spring.
- Pull the valve down and out of the valve guide, remove the valve stem seal and valve spring retainer.

- Mark the valves according to their normal built-in position.



Info

Place the valve into a box according to the installation position and label the box.




Checking valves



- Check the run-out at the valve plate.

| Valve - run-out | |
|--------------------|-----------------------------------|
| On the valve plate | ≤ 0.05 mm (≤ 0.002 in) |

- » If the measured value does not equal the specified value:
 - Change the valve.



- Check the sealing seat **A** on the valve.

| Valve - sealing seat width | |
|----------------------------|--------------------|
| Intake | 1.60 mm (0.063 in) |

| Valve - sealing seat width | |
|----------------------------|---------------------|
| Exhaust | 2.00 mm (0.0787 in) |

- » If the sealing area is not in the center of the valve seat or deviates from the specified value:
 - Machine the valve seat.

Checking valve springs



- Check the valve springs for fractures and wear (visual check).
 - » If the valve spring is fractured or worn:
 - Change the valve spring.
- Measure the valve spring lengths.

| Valve spring | |
|---|--------------------|
| Minimum length (without valve spring cap) | 42.3 mm (1.665 in) |

- » If the measured value does not equal the specified value:
 - Change the valve spring.

Checking valve spring retainer




- Check the valve spring retainer for fractures and wear (visual check).
 - » If the valve spring retainer is fractured or worn:
 - Change the valve spring retainer.
- Measure the thickness of the valve spring retainer.

| | |
|------------------------------|-----------------------------------|
| Valve spring cap - thickness | 2.4... 2.5 mm (0.094... 0.098 in) |
|------------------------------|-----------------------------------|

- » If the measured value does not equal the specified value:
 - Change the valve spring retainer.


Checking cylinder head



- Check the valve guides using the special tool **1**.

| |
|---|
| Limit plug gauge (59029026006) (☞ p. 209) |
|---|

- » If the special tool is easy to insert into the valve guide:
 - Change the valve guide and valve.
- Check the sealing area of the spark plug thread and the valve seats for damage and tearing.
 - » If there is wear or tearing:
 - Change the cylinder head.




- Check the sealing area of the cylinder for distortion using a straight edge and the special tool.

Feeler gauge (59029041100) (☛ p. 210)

| | |
|--|-------------------------|
| Cylinder/cylinder head - sealing area distortion | ≤ 0.10 mm (≤ 0.0039 in) |
|--|-------------------------|

- » If the measured value does not equal the specified value:
 - Change the cylinder head.



- Check sealing seat **A** of the valves.

Valve - sealing seat width

| | |
|--------|--------------------|
| Intake | 1.60 mm (0.063 in) |
|--------|--------------------|


Valve - sealing seat width

| | |
|---------|---------------------|
| Exhaust | 2.00 mm (0.0787 in) |
|---------|---------------------|


- » If the measured value does not equal the specified value:
 - Machine the valve seat.

- Blow compressed air through all oil holes and check that they are clear.

Installing valves




- Position the valve spring cap **1**. Install new valve stem seals **2**.
- Install the valves **3** according to their normal built-in position.
- Install the valve springs **4** and the spring retainers.



- Pretension the valve springs using the special tool.

Valve spring compressor (59029019000) (☛ p. 209)

Valve spring mounting device (78029060000) (☛ p. 216)



- Mount valve keys.




Info

When mounting the valve keys, check that they are seated correctly; preferably, fix the valve keys to the valve with a little grease.

- Place shims **5** into the valve spring retainers according to the installation position.

Installing rocker arm




- Position the rocker arm ❶ and push in the rocker arm shafts ❷.

**Info**

Make sure that the tapped hole of the rocker arm shaft is positioned facing outwards.

The small drill hole and the flat surface must point upwards.




- Install and tighten the screws ❸ of the rocker arm shafts.

Guideline

| | | |
|-------------------------|----|--------------------|
| Screw, rocker arm shaft | M6 | 12 Nm (8.9 lbf ft) |
|-------------------------|----|--------------------|

Dismantling antihopping clutch




- Clamp the clutch ❶ in a vise.


**Info**

Use soft jaws.

- Carefully loosen and gradually remove the special tool ❷.




- Take the clutch out of the vise and lay it on a clean workbench with the outer clutch hub ❸ facing down.
- Take the inner clutch hub ❹ and release springs ❺ out of the outer clutch hub ❸.



- Take off the clutch disks ❻ from the inner clutch hub.
- Remove pretension ring ❼ and support ring ❸.
- Clean all parts well.
- Check the clutch. (☛ p. 122)

Checking the clutch

- Dismantle the antihopping clutch. (☛ p. 121)



300123-01

- Check pressure piece **1** for damage and wear.
 - » If there is damage or wear:
 - Replace the pressure piece.
- Check axial bearing **2** for damage and wear.
 - » If there is damage or wear:
 - Change the axial bearing.
- Place push rod **3** on a level surface and check it for run-out.
 - » If there is run-out:
 - Change the push rod.
- Check the length of clutch springs **4**.

| | |
|------------------------|------------------------------------|
| Clutch spring - length | 31.5... 33.5 mm (1.24... 1.319 in) |
|------------------------|------------------------------------|

- » If the clutch spring length is less than the specified value:
 - Change all clutch springs.
- Check the contact surface of pressure cap **5** for damage and wear.
 - » If there is damage or wear:
 - Change the pressure cap.
- Check the contact surfaces of the clutch facing discs in the outer clutch hub **6** for wear.

| | |
|--|----------------------|
| Clutch cage - contact surface of clutch facing discs | ≤ 0.5 mm (≤ 0.02 in) |
|--|----------------------|


- » If the contact surface is very worn:
 - Change the clutch facing discs and the outer clutch hub.
- Check needle bearing **7** and supporting plate **8** for damage and wear.
 - » If there is damage or wear:
 - Replace the needle bearing and supporting plate.
- Check intermediate discs **9** for damage and wear.

- » If the intermediate discs are not level or are pitted:
 - Replace all intermediate discs.
- Check clutch facing discs 10 for discoloration and scoring.
 - » If there is discoloration or scoring:
 - Change all clutch facing discs.
- Check the thickness of clutch facing discs 10.

| | |
|--------------------------------|--|
| Clutch facing disc - thickness | $\geq 2.5 \text{ mm } (\geq 0.098 \text{ in})$ |
|--------------------------------|--|

- » If the clutch facing disc does not meet specifications:
 - Change all clutch facing discs.
- Check stepped washer 11 for damage and wear.
 - » If there is damage or wear:
 - Replace the stepped washer.
- Check half washers 12 for damage and wear.
 - » If there is damage or wear:
 - Replace the half washers.
- Check inner clutch hub 13 for damage and wear.
 - » If there is damage or wear:
 - Replace the inner clutch hub.
- Check the outer clutch hub 14 for damage and wear.
 - » If there is damage or wear:
 - Replace the outer clutch hub.
- Preassemble the antihopping clutch. (🔧 p. 123)

Preassembling antihopping clutch




- Lubricate the clutch discs thoroughly.
- Push the support ring 1 and the pretension ring 2 on to the outer clutch hub.




Info

The pretension ring must be installed so that it is flush with the inner edge A on the support ring.



- Position the trimmed clutch facing disc with the notch for the pretension ring on the outer clutch hub.
- Beginning with a clutch disc, position all further clutch facing discs and clutch discs alternately.
- Position the release springs 3.



- Push on the outer clutch hub 4 and pay attention to the markings.
 - ✓ The arrow 6 of the outer clutch hub must point to the notch 5 of the inner clutch hub.
- Push the two clutch hubs firmly together and have an assistant screw in the special tool.


Assembly screws (75029033000) (🔧 p. 212)



Info

Apply the special tool with the hand only, do not use another tool. Apply the special tool only firmly enough to all the clutch discs to be turned against each other since they still have to be aligned for mounting in the clutch cage.


Checking shift mechanism




- Check the shift forks **1** (see **A**) for damage and wear (visual check).
 - » If there is damage or wear:
 - Change the shift fork and the idler/fixed gear pair.
- Check shift grooves **B** of shift drum **2** for wear.
 - » If the shift groove is worn:
 - Change the shift roller.
- Check the seat of the shift drum in the bearings **3**.
 - » If the shift roller is not seated correctly:
 - Replace the shift drum and/or the bearing.
- Check bearing **3** for stiffness and wear.
 - » If the bearings do not move freely or are worn:
 - Replace the bearings.
- Check the needle bushing **4** for stiffness and wear.
 - » If the needle bushing does not move freely or is worn:
 - Replace the needle bushing.
- Check the shift rail **5** on a flat surface for run-out.
 - » If there is run-out:
 - Change the shift rail.
- Check the shift rail for scoring, signs of corrosion and stiffness in the shift forks.
 - » If there is scoring or corrosion, or if the shift fork is stiff:
 - Change the shift rail.
- Check sliding plate **6** in contact areas **C** for wear.
 - » If the sliding plate is worn:
 - Change the sliding plate.
- Check return surface **D** on the sliding plate for wear.
 - » If deep notches are present:
 - Change the sliding plate.
- Check guide pin **E** for looseness and wear.
 - » If the guide pin is loose and/or worn:
 - Change the sliding plate.
- Preassemble the shift shaft. (☛ p. 124)
- Check the clearance **F** between the sliding plate and the shift quadrant.

| | |
|--|---------------------------------------|
| Shift shaft - play in sliding plate/shift quadrant | 0.40... 0.80 mm (0.0157... 0.0315 in) |
|--|---------------------------------------|

- » If the measured value does not equal the specified value:
 - Change the sliding plate.




Preassembling shift shaft



- Fix the short end of the shift shaft in a vise.
- Guideline
- | |
|----------------|
| Use soft jaws. |
|----------------|
- Mount sliding plate **1** with the guide pin facing down and attach the guide pin to the shift quadrant.
 - Mount preload spring **2**.
 - Push on spring guide **3**, push return spring **4** over the spring guide with the offset end facing upward and lift the offset end over abutment bolt **5**.
 - Mount stop disk **6**.

Disassembling the main shaft



300127-03


- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws.

- Remove stop disk **1** and second-gear fixed gear **2**.
- Remove the sixth-gear idler gear **3**.
- Remove the split needle bearing **4** and stop disk **5**.
- Remove lock ring **6**.
- Remove the third/fourth-gear sliding gear **7**.
- Remove lock ring **8**.
- Remove stop disk **9** and the fifth-gear idler gear **10**.
- Remove bearing bush **11**.

Dismantling countershaft



300128-01

- Fix the countershaft in the vise with the geared end facing downward.


Guideline

Use soft jaws

- Remove stop disk ❶ and the first-gear idler gear ❷.
- Remove needle bearing ❸ and stop disk ❹.
- Remove the fifth-gear sliding gear ❺ and lock ring ❻.
- Remove stop disk ❼ and the third-gear idler gear ❸.
- Remove the needle bearing ❹ and the fourth-gear idler gear ❺.
- Remove needle bearing ❻ and stop disk ❽.
- Remove lock ring ❽ and the sixth-gear sliding gear ❾.
- Remove lock ring ❿ and stop disk ❿.
- Remove the second-gear idler gear ⓫ and needle bearing ⓬.

Checking the transmission

- Disassemble the main shaft. (☛ p. 125)
- Dismantle the countershaft. (☛ p. 125)



- Check needle bearing ❶ for damage and wear.
 - » If there is damage or wear:
 - Change the needle bearing.
- Check the pivot points of main shaft ❷ and countershaft ❸ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the tooth profiles of main shaft ❷ and countershaft ❸ for damage and wear.
 - » If there is damage or wear:
 - Change the main shaft and/or countershaft.
- Check the pivot points of idler gears ❹ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the shift dogs of idler gears ❹ and fixed gears ❺ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth faces of idler gears ❹ and fixed gears ❺ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check the tooth profiles of fixed gears ❺ for damage and wear.
 - » If there is damage or wear:
 - Change the idler/fixed gear pair.
- Check fixed gears ❺ for smooth operation in the profile of main shaft ❷.

- » If the fixed gear does not move easily:
 - Change the fixed gear or the main shaft.
- Check fixed gears ⑤ for smooth operation in the profile of countershaft ③.
 - » If the fixed gear does not move easily:
 - Change the fixed gear or the countershaft.
- Check stop disks ⑥ for damage and wear.
 - » If there is damage or wear:
 - Change the stop disk.
- Use new lock rings ⑦ in every repair job.
- Check bearing bush ⑧ for damage and wear.
 - » If there is damage or wear:
 - Change the bearing bush.
- Assemble the countershaft. (🔧 p. 128)
- Assemble the main shaft. (🔧 p. 127)


Assembling the main shaft



Info

Use new lock rings in every repair job.

- Oil all parts carefully before assembling.
- Check the transmission. (🔧 p. 126)



- Fix the main shaft in the vise with the geared end facing downward.

Guideline

Use soft jaws

- Lubricate and mount bearing bush ①.

Long-life grease (🔧 p. 206)

- Put on the fifth-gear idler gear ② with the shifting claws facing upward.
- Mount stop disk ③ and lock ring ④.
- Push on the third/fourth-gear sliding gear ⑤ with the small gear wheel pointing downward, and mount lock ring ⑥.
- Push on stop disk ⑦ and split needle bearing ⑧.
- Put on the sixth-gear idler gear ⑨ with the shifting claws facing downward.
- Mount the second-gear fixed gear ⑩ with the collar facing downward and mount stop disk ⑪.
- Finally, check all gear wheels for smooth operation.


Assembling countershaft



Info

Use new lock rings in every repair job.

- Oil all parts carefully before assembling.
- Check the transmission. (🔧 p. 126)



300128-02


- Fix the countershaft in the vise with the geared end facing downward.

Guideline

Use soft jaws


- Mount needle bearing ① and the second-gear idler gear ② on the countershaft with the protruding collar facing downward.
- Mount stop disk ③ and lock ring ④.
- Mount the sixth-gear sliding gear ⑤ with the shift groove facing upward.
- Install lock ring ⑥ and stop disk ⑦.
- Mount needle bearing ⑧ and the fourth-gear idler gear ⑨ with the collar facing upward.
- Mount needle bearing ⑩ and the third-gear idler gear ⑪ with the collar facing downward.
- Install stop disk ⑫ and lock ring ⑬.
- Mount the fifth-gear sliding gear ⑭ with the shift groove facing downward and stop disk ⑮.
- Mount needle bearing ⑯, first-gear idler gear ⑰ with the groove facing downward and stop disk ⑱.
- Finally, check all gear wheels for smooth operation.

Checking electric starter drive




- Check the teeth and seating of the starter idler gear **1** for damage and wear.
 - » If there is damage or wear:
 - Replace the starter idler gear and/or needle bushing.
- Check the teeth and seating of the torque limiter **2** for damage and wear.
 - » If there is damage or wear:
 - Replace the torque limiter and/or needle bushing.
- Check freewheel gear **3** and bearing when removed for damage and wear.
 - » If there is damage or wear:
 - Replace the freewheel gear and/or the bearing.
- Check the freewheel **4** when removed for damage and wear.
 - » If there is damage or wear:
 - Replace the freewheel.
- Check the toothing of the starter motor **5** for damage and wear.
 - » If there is damage or wear:
 - Replace the starter motor.
- Clamp the minus (negative) cable of a 12 Volt power supply to the starter motor housing. Briefly connect the plus (positive) cable of the power supply to the starter motor connection.
 - » If the starter motor does not turn when you close the power circuit:
 - Replace the starter motor.
- Replace the O-ring **6** of the starter motor.

Removing freewheel




- Extract the lock ring **1** from the groove using suitable pliers.



- Compress the expansion ring ② and remove it, using suitable pliers.
- Take the freewheel ③ out of the primary gear.

Checking freewheel



- Insert the freewheel gear ① in the primary gear ②, turning the primary gear clockwise; do not twist!
- Check the locking action of the freewheel gear ①.
 - » If the primary gear does not turn clockwise or if it does not lock counterclockwise:
 - Remove the freewheel. (☛ p. 129)
 - Turn the freewheel 180°.
 - Install the freewheel. (☛ p. 130)

Installing freewheel



- Lubricate all parts thoroughly.
- Push the freewheel ① into the primary gear.




Info

Note the direction of rotation.



- Install the expansion ring ②.




- Make sure that all lugs of the expansion ring locate in the slits ④ of the freewheel.




Info

If necessary, use a screwdriver to ease them in.



- Insert the lock ring ③ into the groove with suitable pliers and check that it is seated correctly.

Installing transmission shafts




- Clamp the right section of the engine case.

| |
|---|
| Holder for engine work stand (75012001070) (☛ p. 212) |
|---|


| |
|--|
| Support for engine work stand (75012001060) (☛ p. 212) |
|--|

| |
|--|
| Engine work stand (61229001000) (☛ p. 211) |
|--|

- Make sure that both stop disks 1 are installed.
- Mount the inner bearing race 2 on the countershaft.




- Lubricate all bearings.
- Assemble the two transmission shafts and slide them into the bearing seats together.




- Mount the upper shift fork 3, the middle shift fork 4, and the lower shift fork 5.

**Info**


For the assembly of the middle shift fork 4, the sliding gear of the third/fourth gear must be lifted.



- Insert shift drum 6 into the bearing seat.
- Hang the shift forks into the shift drum.




- Install the shift rail 7.
- Check the transmission for smooth operation.



- Install the shim 8 and lock ring of the countershaft.

Installing crankshaft and balancer shaft





300085-10

- Mount the special tool ❶ on the alternator side of the crankshaft.

Mounting sleeve (75029080000) (☛ p. 215)

- Mount the special tool ❷ on the balancer shaft.


Mounting sleeve (58529005000) (☛ p. 209)



300165-10

- Push the crankshaft into the bearing seat and take off the special tool.
- Grease the shaft seal rings of the balancer shaft.
- Push the balancer shaft ❸ into the bearing seat and take off the special tool.
- ✓ Align marks A and B.
- Mount stop disk ❹.


Installing left engine case



300077-11

- Mount the dowels.
- Mount the O-ring ❶.
- Degrease the sealing area. Apply the sealing compound to the left engine case half.

Loctite® 5910



300075-11

- Put on the left engine case half. If necessary, tap lightly with a rubber mallet and turn the transmission shafts.



Info

Do not tighten the engine case sections using the screws.

- Install the screws ❷ and tighten them diagonally.

Guideline


| | | |
|--------------------|----|--------------------|
| Screw, engine case | M6 | 10 Nm (7.4 lbf ft) |
|--------------------|----|--------------------|




Info

Install the screw in the oil filter housing with a new copper washer.

Installing oil pumps



- Install pins and internal rotors on both oil pump shafts.
- Mount external rotors in the engine case.
 - ✓ The marking is not visible after mounting.
- Mount the oil pump shafts ① with internal rotors ②.
 - ✓ The marking A is visible after mounting.
- Oil the parts.




- Position both oil pump covers ③. Mount and tighten the screws.

Guideline


| | | | |
|-----------------------|----|----------------------|---------------|
| Screw, oil pump cover | M5 | 6 Nm (4.4 lbf ft) | Loctite® 243™ |
|-----------------------|----|----------------------|---------------|

- Install washers ④ and pins ⑤.



- Mount the oil pump gears ⑥, washers ⑦ and lock washers ⑧.

Installing locking lever




- Position locking lever ① with sleeve and spring ②.
- Mount and tighten screw ③.

Guideline

| | | | |
|----------------------|----|-----------------------|---------------|
| Screw, locking lever | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|----------------------|----|-----------------------|---------------|

Installing shift drum locating




- Press locking lever ① down and position shift drum locating.



Info

The flat surfaces A of the shift drum locating are not symmetric.




- Release the locking lever.
- Mount and tighten screw ②.

Guideline


| | | | |
|----------------------------|----|-----------------------|---------------|
| Screw, shift drum locating | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|----------------------------|----|-----------------------|---------------|

Installing shift shaft




- Slide shift shaft ① with the washer into the bearing seat.
- Push sliding plate ② away from the shift drum locating ③. Insert the shift shaft all the way.
- Let the sliding plate engage in the shift drum locating.
- Shift through the transmission.

Installing starter drive




- Install the two needle bearings ① and the woodruff key ②.
- Push on the freewheel gear ③.



- Push on the starter idler gear ④ with washer. Mount lock ring.
- Push on the needle bearing and torque limiter ⑤ with washer. Mount lock ring.

Installing primary gear




- Ensure that the spring washer is seated properly.
- Mount primary gear ①.




Info

Turn the freewheel gear backwards and forwards to ease meshing.

Installing clutch cage



- Install supporting plate ❶ and needle bearing ❷.



- Install the clutch cage ❸.




Info
Turn the clutch cage and oil pump gear wheels backwards and forwards slightly to help them mesh more easily.

- Mount the half washers with the sharp edge facing outward.




Info
Grease the half washers to ease assembly.



- Position the stepped washer with the cut-out towards the half washers.
- Insert the clutch package ❹ in the clutch cage.



Info
If necessary, turn the main shaft a little to ease access.
Make sure that the upper clutch disc is offset by one notch.



- Position a new lock washer and install the nut ❺.
- Lock the clutch cage and primary gear using the special tool, and tighten the nut.
Guideline

| | | | |
|-----------------------|---------|-------------------------|---------------|
| Nut, inner clutch hub | M20x1.5 | 100 Nm (73.8 lbf ft) | Loctite® 243™ |
|-----------------------|---------|-------------------------|---------------|

Gear segment (75029081000) (☛ p. 215)



Info
Make sure that the crankshaft is not blocked.


- Secure the nut with the lock washer ❻.
- Lock the clutch cage and primary gear using the special tool.


Gear segment (75029081000) (☛ p. 215)

- Mount and tighten the nut ❼.


Guideline

| | | | |
|-------------------|-----------|------------------------|---------------|
| Nut, primary gear | M20LHx1.5 | 90 Nm (66.4 lbf ft) | Loctite® 243™ |
|-------------------|-----------|------------------------|---------------|





- Insert the pressure piece 8.




- Place the pressure cap on.
- Install and tighten the screws 9 with the spring retainers and clutch springs.

Guideline

| | | |
|----------------------|----|-------------------|
| Screw, clutch spring | M5 | 6 Nm (4.4 lbf ft) |
|----------------------|----|-------------------|

- Remove the special tool.

Installing crankshaft position sensor




- Position the crankshaft position sensor 1.
- Mount screws but do not tighten them yet.

Guideline

| | | | |
|---------------------------------|----|--------------------|---------------|
| Screw, ignition pulse generator | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|---------------------------------|----|--------------------|---------------|

- Position the cable and push the cable support sleeve 2 into the engine case.

Installing timing chain and timing chain sprocket




- Heat the timing chain sprocket and push it immediately on to the crankshaft.

Guideline

| |
|-----------------|
| 100 °C (212 °F) |
|-----------------|

- Mount lock ring 1.




- Thread the timing chain 2 in and lay it over the timing chain sprocket.



Info

If the timing chain is not new, pay attention to the direction of travel.

Installing timing chain rails




- Position the timing chain securing guide ❶.



Info

The cable of the crankshaft position sensor must be laid in the cable channel of the timing chain securing guide.

- Thread in the timing chain tensioning rail ❷ from above. Insert the support bushing into the timing chain securing guide.



- Thread in the timing chain guide rail ❸ from above. Insert the support bushing into the timing chain securing guide.
- Mount and tighten screws ❹.

Guideline

| | | | |
|-------------------------------------|----|-----------------------|---------------|
| Screw, timing chain guide rail | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, timing chain tensioning rail | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |




Info

Ensure that there is no thread locking material at the collar of the screw; otherwise, the timing chain tension rail could lock and break.

- Check both timing chain rails for freedom of motion.

Installing rotor



- Ensure that the spring washer ❶ is seated properly.
- Degrease the cone of the crankshaft and the rotor.
- Mount the rotor.




Info

Make sure that the crankshaft is not blocked.

- Use the special tool to hold the rotor tight.

Holding spanner (75029091000) (☞ p. 215)




- Mount the tab washer and the nut ❷. Tighten nut.

Guideline

| | | |
|-----------|---------|-------------------------|
| Rotor nut | M18x1.5 | 100 Nm (73.8 lbf ft) |
|-----------|---------|-------------------------|

Adjusting crankshaft position sensor distance



- Adjust the distance between the crankshaft position sensor ❶ and the conductive element of the rotor using the special tool ❷.

Guideline

| | |
|---|---------------------|
| Crankshaft position sensor/rotor - distance | 0.70 mm (0.0276 in) |
|---|---------------------|


Feeler gauge (59029041100) (☞ p. 210)

- Fully tighten screws ❸.

Guideline

| | | | |
|---------------------------------|----|-----------------------|---------------|
| Screw, ignition pulse generator | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|---------------------------------|----|-----------------------|---------------|


Setting engine to top dead center



- Set the crankshaft to top dead center and lock it with the special tool ❶.


Engine blocking screw (77329010000) (☞ p. 216)

Installing piston




- Shift the joint of the piston rings by 120°.
- Push the oiled piston into the special tool.


Piston assembly ring (75029015102) (☞ p. 212)



- Position the piston on the cylinder using the special tool.
- Push the piston carefully into the cylinder from above.
- ✓ The piston rings should not become caught; otherwise, they may be damaged.



- Ensure that piston marking ❶ faces the outfeed side.



- Apply a thin layer of sealing compound in area ❶.

Loctite® 5910

- Place the cylinder base gasket on.



Info


Make sure the grooved pins are seated correctly.




- Cover the engine case opening with a cloth. Thread the timing chain through the chain shaft. Mount the piston pin.

**Info**

For clarity, the following steps are illustrated using a disassembled piston.




- Position the piston pin retainer.



- Insert the special tool and firmly press it toward the piston.
- Turn the special tool counterclockwise, thereby pressing the piston pin retainer into the groove.


Piston pin lock ring insert (75029035000) (☛ p. 213)

- Make sure that the piston pin retainer is seated correctly on both sides.



- Remove the cloth.
- Keep the timing chain tensioned. Push the cylinder down carefully and let the grooved pins engage.

Installing cylinder head



- Put on the cylinder head gasket.

**Info**

Make sure the grooved pins are seated correctly.

- Mount the cylinder head. Mount and tighten cylinder head screw ❶ with the washers.

Guideline

| | | | |
|---------------------|-----|---|----------------------------|
| Cylinder head screw | M10 | Tightening sequence: Tighten diagonally, beginning with the rear screw on the chain shaft. Step 1 15 Nm (11.1 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 45 Nm (33.2 lbf ft) Step 4 60 Nm (44.3 lbf ft) | Lubricated with engine oil |
|---------------------|-----|---|----------------------------|

**Info**


Always use new cylinder head screws.

- Mount and tighten screws ②.

Guideline

| | | | |
|----------------------|----|-----------------------|----------------------|
| Screw, cylinder head | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|----------------------|----|-----------------------|----------------------|

Installing camshafts




300163-10

- Lay the timing chain over the camshaft. Push the timing chain into the bearing seats. The middle drill hole of the camshaft ① and the drill hole of the cylinder head ② must be aligned.

**Info**

Make sure that the crankshaft is at top dead center.




300022-10

- Position the camshaft support plate ③. Mount and tighten screw ④.

Guideline

| | | | |
|-------------------------------|----|-----------------------|----------------------|
| Screw, camshaft support plate | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|-------------------------------|----|-----------------------|----------------------|

Installing timing chain tensioner




300017-11

- Insert the timing chain tensioner ①.
- Mount and tighten plug ② with the new seal ring.

Guideline

| | | |
|------------------------------|---------|------------------------|
| Plug, timing chain tensioner | M20x1.5 | 25 Nm (18.4 lbf ft) |
|------------------------------|---------|------------------------|




- Remove screw 3 and use the special tool to push the timing chain tensioner toward the timing chain.
- Release device for timing chain tensioner (77329051000) (☞ p. 216)


- ✓ The timing chain tensioner unlocks.
- Mount and tighten screw 3.

| | | |
|--|-------|--------------------|
| Guideline | | |
| Screw, unlocking of timing chain tensioner | M10x1 | 10 Nm (7.4 lbf ft) |

Checking valve clearance



- Remove special tool 1.
- Crank the engine several times.
- Set the engine to ignition top dead center. (☞ p. 96)




- Check the valve clearance on all valves between the valve and the rocker arm using the special tool 2.


| | |
|---------------------------------------|---------------------------------------|
| Guideline | |
| Valve play, cold | 0.07... 0.13 mm (0.0028... 0.0051 in) |
| Feeler gauge (59029041100) (☞ p. 210) | |

- » If valve clearance does not meet specifications:
 - Adjust the valve clearance. (☞ p. 142)


Adjusting valve clearance




- Remove screws 1.

 **Info**

Make sure that the crankshaft is at top dead center.



- Screw suitable screws 2 into the rocker arm shafts 3. Pull out the rocker arm shafts.
- Take off the rocker arm.




- Remove shims ④ and set them down according to the installation position.
- Correct the shims as indicated by the results of the valve clearance check.
- Insert suitable shims.
- Position the rocker arms and push in the rocker arm shafts.

**Info**

Make sure that the tapped hole of the rocker arm shaft is positioned facing outwards.

The small drill hole and the flat surface must point upwards.




- Install and tighten the screws ⑤ of the rocker arm shafts.

Guideline

| | | |
|-------------------------|----|--------------------|
| Screw, rocker arm shaft | M6 | 12 Nm (8.9 lbf ft) |
|-------------------------|----|--------------------|

- Check the valve clearance. (☛ p. 142)


Installing spark plug

- Mount and tighten the spark plug ① using the special tool.


Guideline

| | | |
|------------|----------|------------------------|
| Spark plug | M12x1.25 | 17 Nm (12.5 lbf ft) |
|------------|----------|------------------------|

Spark plug wrench (75029172000) (☛ p. 216)

Installing spacer and spring

- Install the spacer ① and spring ② of the shift shaft.


Installing clutch cover

- Mount the dowels. Put on the clutch cover seal.
- Position the clutch cover. Mount and tighten screws ①.

Guideline


| | | |
|---------------------|----|--------------------|
| Screw, clutch cover | M6 | 10 Nm (7.4 lbf ft) |
|---------------------|----|--------------------|

Mounting water pump cover



300014-11

- Push on the shaped washer ①.



300013-12


- Attach the water pump wheel ②. Mount and tighten screw ③

Guideline

| | | | |
|-------------------------|----|-----------------------|---------------|
| Screw, water pump wheel | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|-------------------------|----|-----------------------|---------------|

Loctite® 243™

- Lay on the water pump cover seal ④.




300012-12

- Put on the water pump cover ⑤. Mount and tighten screws.

Guideline

| | | | |
|-------------------------|----|-----------------------|---------------|
| Screw, water pump wheel | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|-------------------------|----|-----------------------|---------------|

Installing thermostat




300010-11

- Position the thermostat ① with the gasket.
✓ The drill hole ① must face upward.
- Install the thermostat case ② with the radiator hose.
- Mount and tighten the screws.

Guideline

| | | | |
|---------------------------|----|-----------------------|---------------|
| Screw, thermostat housing | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|---------------------------|----|-----------------------|---------------|

Installing the oil filter




300009-11

- Insert the oil filter ①.
- Lubricate the O-ring of the oil filter cover. Install the oil filter cover ②.
- Mount and tighten the screws.

Guideline

| | | | |
|-------------------------|----|-------------------|--|
| Screw, oil filter cover | M5 | 6 Nm (4.4 lbf ft) | |
|-------------------------|----|-------------------|--|




- Insert the oil filter ③.
- Lubricate the O-ring of the oil filter cover. Install the oil filter cover ④.
- Mount and tighten the screws.


Guideline

| | | |
|-------------------------|----|-------------------|
| Screw, oil filter cover | M5 | 6 Nm (4.4 lbf ft) |
|-------------------------|----|-------------------|

Installing gear position sensor



- Mount the contact springs ① and contact bolt ②.
- ✓ The contact bolts are mounted with the flat side forward; the pointed sides face the sensor.
- Position O-ring ③.




- Install the gear position sensor ④.
- Position the ground wire ⑤.
- Mount and tighten the screws.

Guideline

| | | | |
|--------------------|----|-------------------|---------------|
| Screw, gear sensor | M5 | 5 Nm (3.7 lbf ft) | Loctite® 243™ |
|--------------------|----|-------------------|---------------|


Installing the spacer



- Grease spacer ① in area A and O-ring ② before mounting.

Long-life grease (☛ p. 206)

- Position the O-ring in the cut-out of the spacer.




- Grease the shaft seal ring.


Long-life grease (☛ p. 206)

- Slide the spacer with the O-ring onto the countershaft with a twisting motion.
- ✓ The cut-out with the O-ring faces inward.
- ✓ The shaft seal ring rests against the spacer along its entire circumference.

Installing oil screens



- Push the oil screen with O-rings on to a pin wrench. Push the pin wrench through the opening into the drill hole of the opposite engine case wall and push the oil screen as far as possible into the engine case.



- Install the oil drain plug with magnet ❶ and a new seal ring and tighten it.


Guideline

| | | |
|----------------------------|---------|------------------------|
| Oil drain plug with magnet | M12x1.5 | 20 Nm (14.8 lbf ft) |
|----------------------------|---------|------------------------|

- Install and tighten the plug ❷ with O-rings.

Guideline

| | | |
|------------------|---------|------------------------|
| Plug, oil screen | M20x1.5 | 15 Nm (11.1 lbf ft) |
|------------------|---------|------------------------|




- Position the oil screen ❸ with O-rings.
- Install and tighten the plug ❹ with O-rings.


Guideline

| | | |
|------------------|---------|------------------------|
| Plug, oil screen | M20x1.5 | 15 Nm (11.1 lbf ft) |
|------------------|---------|------------------------|

Installing alternator cover



- Apply sealing compound lightly in the area of the cable support sleeve.
- Install the dowel ❶. Put on the alternator cover seal.



- Position the alternator cover.
- Mount and tighten screws ❷.


Guideline

| | | |
|---------------------------|----|--------------------|
| Screw in alternator cover | M6 | 10 Nm (7.4 lbf ft) |
|---------------------------|----|--------------------|

- Mount and tighten screw ❸.

Guideline

| | | | |
|---|----|-----------------------|---------------|
| Screw, alternator cover (chain shaft through-hole) | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|---|----|-----------------------|---------------|



- Remove special tool ④.


Engine blocking screw (77329010000) (☛ p. 216)

- Mount and tighten screw ⑤.

Guideline

| | | |
|---------------------------|----|------------------------|
| Plug, crankshaft location | M8 | 20 Nm (14.8 lbf ft) |
|---------------------------|----|------------------------|

Installing starter motor



- Grease O-ring. Mount the starter motor.


Long-life grease (☛ p. 206)

- Mount and tighten screws ①.

Guideline

| | | | |
|----------------------|----|-----------------------|---------------|
| Screw, starter motor | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
|----------------------|----|-----------------------|---------------|

Installing valve cover




- Put the valve cover in place with the seal. Mount and tighten screws ①.

Guideline

| | | |
|--------------------|----|--------------------|
| Screw, valve cover | M6 | 10 Nm (7.4 lbf ft) |
|--------------------|----|--------------------|

Taking engine off universal mounting rack



- Remove the screw ① or the nut ②.
- Take the engine off the universal mounting rack.




Info

Have an assistant help you or use a crane.

Checking/rectifying the fluid level of the hydraulic clutch**Info**

The fluid level rises with increasing wear of the clutch lining disc.
Do not use brake fluid.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws ❶.
- Remove cover ❷ with membrane ❸.
- Check the fluid level.

| | |
|--|----------------|
| Fluid level under top level of container | 4 mm (0.16 in) |
|--|----------------|

» If the level of the coolant does not meet specifications:

- Correct the fluid level of the hydraulic clutch.

| |
|---------------------------------|
| Hydraulic fluid (15) (🔧 p. 205) |
|---------------------------------|

- Position the cover with the membrane. Mount and tighten the screws.

Draining coolant

**Warning**


Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.

**Warning**

Danger of poisoning Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Stand the vehicle upright.
- Place a suitable container under the engine.
- Remove screw ❶. Remove the radiator cap.
- Completely drain the coolant.
- Fit screw ❶ with a new seal and tighten it.

Guideline

| | | |
|--------------------------------|-------|------------------------|
| Plug, drain hole of water pump | M10x1 | 15 Nm (11.1 lbf ft) |
|--------------------------------|-------|------------------------|

Filling the cooling system


**Warning**

Danger of poisoning Coolant is poisonous and a health hazard.

- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



- Stand the motorcycle on its side stand on a horizontal surface.
- Remove radiator cap ❶.



- Refill the coolant.


Alternative 1

Coolant (☞ p. 204)

Alternative 2

Coolant (mixed ready to use) (☞ p. 204)

- Fill the radiator completely with coolant. Mount radiator cap ❶.



- Remove the cap from compensating tank ❷ and add coolant to the level shown in the figure.
- Mount the cap of the compensating tank.

**Danger**

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and run it until the 5th bar of the temperature indicator lights up.
- Switch off the engine and allow it to cool down.
- After the engine has cooled down, check the coolant level in the radiator and in the compensating tank again and add more coolant if necessary.

Checking the antifreeze and coolant level

- Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



Condition

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Remove the cap of the compensating tank ❶.
- Check antifreeze of coolant.

–25... –45 °C (–13... –49 °F)

» If the antifreeze of the coolant does not meet specifications:

- Correct the antifreeze of the coolant.

- Check the coolant level in the compensating tank.

The coolant level must be within the range shown in the figure.

» If the coolant level does not meet specifications:

- Correct the coolant level.

Alternative 1

Coolant (☞ p. 204)

Alternative 2

Coolant (mixed ready to use) (☞ p. 204)

- Mount the cap of the compensating tank.
- Screw off the radiator cap ❷.
- Check antifreeze of coolant.

–25... –45 °C (–13... –49 °F)

» If the antifreeze of the coolant does not meet specifications:

- Correct the antifreeze of the coolant.

- Check the coolant level in the radiator.

The radiator must be completely filled.

» If the coolant level does not meet specifications:

- Correct the coolant level and find out the cause of the loss.


Alternative 1

Coolant (☞ p. 204)

Alternative 2

Coolant (mixed ready to use) (☞ p. 204)

- Mount the radiator cap.



Checking the coolant level

- Warning**
Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.
- Do not remove the radiator cap, radiator hoses or other cooling system components when the engine is hot. Allow the engine and cooling system to cool down. In case of scalding, rinse immediately with lukewarm water.
- Warning**
Danger of poisoning Coolant is poisonous and a health hazard.
- Avoid contact between coolant and skin, eyes and clothing. If it gets into your eyes, rinse immediately with water and contact a doctor. Wash affected skin areas immediately with soap and water. If coolant is swallowed, contact a doctor immediately. Change clothes that have come into contact with coolants. Keep coolant out of the reach of children.



Condition

Engine is cold.

- Stand the motorcycle on its side stand on a horizontal surface.
- Check the coolant level in the compensating tank ①.

The coolant level must be within the range shown in the figure.

- » If the coolant level does not meet specifications:
 - Correct the coolant level.

Alternative 1

Coolant (☛ p. 204)

Alternative 2

Coolant (mixed ready to use) (☛ p. 204)

- Screw off the radiator cap ② and check the coolant level in the radiator.

The radiator must be completely filled.

- » If the coolant level does not meet specifications:
 - Correct the coolant level and find out the cause of the loss.


Alternative 1

Coolant (☛ p. 204)


Alternative 2

Coolant (mixed ready to use) (☛ p. 204)

- Mount the radiator cap.



Oil circuit



400500-60

- | | |
|----|------------------------------|
| 1 | Oil screen |
| 2 | Force pump |
| 3 | Oil filter |
| 4 | Oil pressure regulator valve |
| 5 | Timing chain tensioner |
| 6 | Rocker arm shaft |
| 7 | Transmission |
| 8 | Clutch |
| 9 | Oil jet for piston cooling |
| 10 | Oil filter |
| 11 | Crankshaft |
| 12 | Oil screen |
| 13 | Suction pump |
| 7 | Transmission |

Checking the engine oil level




Info

The engine oil level must be checked when the engine is warm.

Condition

The engine is at operating temperature.

- Stand the motorcycle upright on a horizontal surface.



- Check the engine oil level.

Info
After switching off the engine, wait one minute before checking the level.

The engine oil must be between the lower and upper edge of the oil level viewer.

- » If the engine oil level is not at the specified level:
 - Add the engine oil. (☛ p. 157)

Checking the engine oil pressure

Warning
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.


- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

Warning
Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Remove screw ❶.



- Position the banjo bolt with the connector and sealing rings. Mount and tighten the banjo bolt.

| | | |
|---|-------|-------------------|
| Guideline | | |
| Banjo bolt | M10x1 | 8 Nm (5.9 lbf ft) |
| Oil pressure adapter (77329006000) (☛ p. 216) | | |

- Connect the pressure tester to the special tool without the T-plate.

| |
|--|
| Pressure testing tool (61029094000) (☛ p. 211) |
|--|

- Check the engine oil level. (☛ p. 152)

Danger
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and let it run warm.
- Check the engine oil pressure.

| | |
|--|----------------------|
| Engine oil pressure | |
| Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 1,500 rpm | ≥ 0.4 bar (≥ 6 psi) |
| Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 5,000 rpm | ≥ 1.5 bar (≥ 22 psi) |

- » If the specification is not reached:

- Change the oil filter. Check the oil pumps for wear. Check that all oil holes are clear.
- Switch off the engine.



Warning

Danger of burns Some vehicle components get very hot when the machine is driven.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

- Remove the special tools.
- Mount and tighten screw ❶.

Guideline

| | | |
|--|-------|--------------------|
| Screw, unlocking of timing chain tensioner | M10x1 | 10 Nm (7.4 lbf ft) |
|--|-------|--------------------|

- Check the engine oil level. (🔧 p. 152)

Changing the engine oil and filter, cleaning the oil screens



- Drain the engine oil. (🔧 p. 154)
- Remove the oil filter. (🔧 p. 155)
- Clean the oil screens. (🔧 p. 156)
- Install the oil filter. (🔧 p. 155)
- Fill up with engine oil. (🔧 p. 157)

Draining engine oil



Warning

Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.



Warning


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.




Info

Drain the engine oil only when the engine is warm.



- Place a suitable container under the engine.
- Remove the oil drain plug ❶ with the magnet and seal ring.
- Completely drain the engine oil.




- Thoroughly clean the oil drain plug with a magnet.
- Check parts for damage and wear. Replace damaged or worn parts.
- Refit the oil drain plug with the magnet and seal ring and tighten it.

Guideline


| | | |
|----------------------------|---------|------------------------|
| Oil drain plug with magnet | M12x1.5 | 20 Nm (14.8 lbf ft) |
|----------------------------|---------|------------------------|

Removing the oil filter

**Warning**


Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.

- Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.

**Warning**


Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Place a suitable container under the engine.
- Remove screws ❶. Remove the oil filter cover ❷ with the O-ring.
- Pull oil filter ❸ out of the oil filter housing.

Circlip pliers reverse (51012011000) (👉 p. 208)




- Remove screws ❹. Remove oil filter ❺ with the O-ring.
- Pull oil filter ❻ out of the oil filter housing.

Circlip pliers reverse (51012011000) (👉 p. 208)

- Completely drain the engine oil.
- Thoroughly clean the parts and sealing area.

Installing the oil filter






- Insert oil filters ❶ and ❷.
- Oil the O-rings of the oil filter covers. Mount oil filter covers ❸ and ❹.
- Mount and tighten the screws.

Guideline


| | | |
|-------------------------|----|-------------------|
| Screw, oil filter cover | M5 | 6 Nm (4.4 lbf ft) |
|-------------------------|----|-------------------|

Cleaning the oil screens


- **Warning**
Danger of scalding Engine oil and gear oil get very hot when the motorcycle is ridden.
 - Wear appropriate protective clothing and safety gloves. In case of burns, rinse immediately with lukewarm water.
- **Warning**
Environmental hazard Hazardous substances cause environmental damage.
 - Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



- Place a suitable container under the engine.
- Remove screw plug 1 with oil screen 2 and the O-rings.




- Remove screw plug 3 with oil screen 4 and the O-rings.
- Completely drain the remaining engine oil.
- Thoroughly clean the parts and sealing area.



- Position oil screen 2 with the O-rings.
- Mount and tighten screw plug 1 with the O-ring.

Guideline

| | | |
|------------------|---------|------------------------|
| Plug, oil screen | M20x1.5 | 15 Nm (11.1 lbf ft) |
|------------------|---------|------------------------|




- Position oil screen 4 with the O-rings.
- Mount and tighten screw plug 3 with the O-ring.

Guideline

| | | |
|------------------|---------|------------------------|
| Plug, oil screen | M20x1.5 | 15 Nm (11.1 lbf ft) |
|------------------|---------|------------------------|

Filling up with engine oil

i Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove filler plug with O-ring ❶ from the clutch cover and add engine oil.

| | | | |
|------------|------------------|--|------------------------------------|
| Engine oil | 1.70 l (1.8 qt.) | Engine oil (SAE 10W/60) (00062010035) (☛ p. 204) | |
| | | Alternative engine oil | Engine oil (SAE 10W/50) (☛ p. 204) |

- Refit plug with O-ring ❶ and tighten it.


! Danger
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Check the engine oil level. (☛ p. 152)

Adding engine oil

i Info
Too little engine oil or poor-quality engine oil results in premature wear to the engine.



- Remove the oil filler plug with O-ring ❶ from the clutch cover and fill up with engine oil.

| |
|--|
| Engine oil (SAE 10W/60) (00062010035) (☛ p. 204) |
| Engine oil (SAE 10W/50) (☛ p. 204) |

i Info
For optimal performance of the engine oil, do not mix different types of engine oil.
If appropriate, change the engine oil.


- Install and tighten the oil filler plug with O-ring ❶.

! Danger
Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and check that it is oil-tight.
- Check the engine oil level. (☛ p. 152)

Alternator - checking the stator winding



Condition

The stator is disconnected.

- Reinstall the fuel tank.

Stator winding, measurement I - check the resistance

- Measure the resistance between the specified points.
Stator, connector EN pin 1 – Stator, connector EN pin 2

| Alternator | |
|---|-------|
| Resistance of stator winding at: 20 °C (68 °F) | ≤ 1 Ω |



- » If the displayed value is not equal to the setpoint value:
 - Replace the stator.

Stator winding, measurement II - check the resistance

- Measure the resistance between the specified points.
Stator, connector EN pin 1 – Stator, connector EN pin 3

| Alternator | |
|---|-------|
| Resistance of stator winding at: 20 °C (68 °F) | ≤ 1 Ω |

- » If the displayed value is not equal to the setpoint value:
 - Replace the stator.




Stator winding - check for a short circuit to ground (terminal 31)

- Measure the resistance between the specified points.
Stator, connector EN pin 1 – Measuring point Ground (-)

| | |
|------------|-----|
| Resistance | ∞ Ω |
|------------|-----|

- » If the displayed value is not equal to the setpoint value:
 - Replace the stator.

Checking the spark plug connector



Condition

Spark plug connector cylinder 1 has been removed.

- Measure the resistance between the specified points.
Measuring point 1 – Measuring point 2

| Spark plug connector | |
|------------------------------|---------------|
| Resistance at: 20 °C (68 °F) | 4.3... 5.7 kΩ |

- » If the specification is not reached:
 - Change the spark plug connector.


Ignition coil - checking the secondary winding


Condition

Ignition coil cylinder 1 is disconnected.
Spark plug connector cylinder 1 has been removed.

- Remove the fuel tank.

Ignition coil cylinder 1 - check the secondary winding resistance


-  Measure the resistance between the specified points.
Ignition coil pin 2 (+) – Ignition coil pin 3



| Ignition coil | |
|--|-----------------|
| Resistance of secondary winding at: 20 °C (68 °F) | 10.4... 15.6 kΩ |

- » If the displayed value is not equal to the setpoint value:
 - Replace the ignition coil.

Checking the basic setting of the motor drive



Condition

The diagnostics tool is connected.

- Ensure that the locking cap ❶ was not opened.



Info
Sealing varnish ❷ on the screws should not be damaged.



- » If the sealing varnish is damaged:
 - Contact customer service.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Adjustment"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Checking the basic setting of the motor drive"**.
- Press **"Continue"**.
- Read the information page in the KTM diagnostics tool and use **"Continue"** to open the **"Check the throttle position sensor circuit A position"** menu.
- ✓ The motor drive moves the throttle valve to the basic position (completely closed).
- Determine the voltage value via the **"Test"** button.



Info
The **"Continue"** button only appears if the measured value equals the set-point value.

| Throttle position sensor circuit A | |
|--|----------------|
| Basic position - voltage "THAD" | 0.50... 0.54 V |

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.
 - Adjust the basic setting of the motor drive. (🔧 p. 161)




- Use **"Continue"** to start the **"Checking the emergency position of the throttle valve"** menu.
- ✓ The motor drive moves the throttle valve to the emergency running position.
- Check the voltage value.



Info
The **"Continue"** button only appears if the measured value equals the set-point value.

| Throttle position sensor circuit A | |
|--|----------------|
| Emergency running position - voltage "THAD" | 0.70... 0.74 V |

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.



- Adjust the basic setting of the motor drive. (☛ p. 161)
- Use **"Continue"** to start the **"Checking the position of the throttle grip sensor"** menu.
- ✓ The motor drive keeps the throttle valve in the emergency running position.
- Check the voltage value.

**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.


| Throttle grip sensor | |
|-----------------------|----------------|
| Voltage "APAD" | 0.70... 0.74 V |

- » If the displayed value is not equal to the setpoint value:
 - Close the menu with **"Exit"**.
 - Adjust the basic setting of the motor drive. (☛ p. 161)
- Close the menu with **"Continue"**.


Adjusting the basic setting of the motor drive


Condition

The diagnostics tool is connected.



- Remove the air filter box. (☛ p. 51)
- Disconnect the connector of the motor drive **DR 1**.
- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) 0N (690 SMC USA).
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Adjustment"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Adjusting the basic setting of the motor drive"**.
- Press **"Continue"**.
- Read the information page in the KTM diagnostics tool and use **"Continue"** to open the **"Adjusting the position of the throttle position sensor in circuit A"** menu.





- Carefully close the throttle valve with your finger and hold it.
- Check the voltage value.

**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

| | |
|--|----------------|
| Basic position - voltage "THAD" | 0.50... 0.54 V |
|--|----------------|

- » If the displayed value is not equal to the setpoint value:
 - Loosen screw ②.
 - Adjust the throttle position sensor circuit A ③ by turning to the specified value.
 - Tighten screws ②.
- Press **"Continue"**.
- Release the throttle valve.
- Open and close the throttle grip fully ten times.
- ✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Carefully close the throttle valve again with your finger and hold it.
- Check the voltage value.


**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

| | |
|--|----------------|
| Basic position - voltage "THAD" | 0.50... 0.54 V |
|--|----------------|

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.
- Use **"Continue"** to start the **"Adjusting the emergency position of the throttle valve"** menu.
- Release the throttle valve.
- Fix screws ② with locking varnish.



- Check the voltage value.


**Info**

The **"Continue"** button only appears if the measured value equals the set-point value.

Throttle position sensor circuit A

| | |
|--|----------------|
| Emergency running position - voltage "THAD" | 0.70... 0.74 V |
|--|----------------|

- » If the displayed value is not equal to the setpoint value:
 - Screw off fuse cover ④.
 - Loosen nut ⑤.
 - Adjust the emergency running position by turning screw ⑥ to the specified value.
 - Tighten nut ⑤.
 - Mount and tighten fuse cover ④.



Loctite® 648™



Info
Tighten by hand only, do not use a tool.

- Press **"Continue"**.
- Open and close the throttle grip fully ten times.
✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

| Throttle position sensor circuit A | |
|--|----------------|
| Emergency running position - voltage "THAD" | 0.70... 0.74 V |

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.
- Fix fuse cover ④ with locking varnish.



- Use **"Continue"** to start the **"Adjusting the position of the throttle grip sensor"** menu.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

| Throttle grip sensor | |
|-----------------------|----------------|
| Voltage "APAD" | 0.70... 0.74 V |

- » If the displayed value is not equal to the setpoint value:
 - Loosen screws ⑦.
 - Adjust the accelerator position sensor ⑧ by turning to the specified value.
 - Tighten screws ⑦.
- Press **"Continue"**.
- Open and close the throttle grip fully ten times.
✓ The **"Continue"** button appears.
- Press **"Continue"**.
- Check the voltage value.

Info
The **"Continue"** button only appears if the measured value equals the set-point value.

| Throttle grip sensor | |
|-----------------------|----------------|
| Voltage "APAD" | 0.70... 0.74 V |

- » If the displayed value is not equal to the setpoint value:
 - Repeat the setting.



601136-10

- Fix screws ⑦ with locking varnish.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and, using **"Continue"**, start the **"ECU Reset"** menu.
 - ✓ The control unit is reset.
- Complete the procedure with **"Continue"**.
- Switch off the ignition by turning the ignition key in the position ☒ (690 SMC EU, 690 SMC AUS/UK) OFF (690 SMC USA).
- Plug in the connector of the motor drive **DR ①**.
- Switch to the main menu.
- Switch on the ignition by turning the ignition key in the position ○ (690 SMC EU, 690 SMC AUS/UK) ON (690 SMC USA).
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- **"Read trouble code"** selected.
- Complete the procedure with **"Back"**.
- Select **"Delete trouble codes"**.
- Complete the procedure with **"Back"**.

**Danger**

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

- Start the engine and perform an initialization run.

Guideline

| | |
|--------------------|--------|
| Initialization run | 15 min |
|--------------------|--------|

Flashing the EFI control unit and/or the EPT control unit

Condition

The ignition is on.

The diagnostics tool is connected and running.

EFI control unit

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"ECU Flashing"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the safety instructions and create the necessary preliminary conditions.
- Confirm the instructions by clicking on **"OK"**.
- Press **"Select file"** and select a new mapping.

**Info**

"The BLZ file and the exhaust system must match!"

- Press the **"ECU flash process"** button.
- Read the prompt and confirm with **"OK"**.
 - ✓ The new mapping is loaded.
- Switch to the main menu.



400687-60

EPT control unit

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"ECU Flashing"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the safety instructions and create the necessary preliminary conditions.
- Confirm the instructions by clicking on **"OK"**.
- Press **"Select file"** and select a new mapping.

**Info**

"The BLZ file and the exhaust system must match!"

- Press the **"ECU flash process"** button.
- Read the prompt and confirm with **"OK"**.
- ✓ The new mapping is loaded.

**Info**

Start the engine and perform an initialization run.

Requesting the enabling code

**Condition**

The changed EFI control unit and/or the EPT control unit is connected.
 The ignition is on.
 The diagnostics tool is connected and running.
 Flashing of the EFI control unit and/or the EPT control unit is completed.

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Change VIN - New identity"**.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and, using **"Continue"**, start the coding process.
- Overwrite the entry under **"Please enter VIN:"** with the new chassis number.

**Info**

For used control units, the chassis number programmed last is displayed.

- Press **"Continue"**.
- Select **"Code form"**.
- Press **"Print"**.
- ✓ The protocol is being printed out.
- Fill out the protocol and send to **"diagnostic@ktm.com"**.
- ✓ A response mail containing the enabling code arrives.

Coding the EFI control unit and/or EPT control unit

**Condition**

The ignition is on.

The diagnostics tool is connected and running.

Flashing of the EFI control unit and/or EPT control unit is completed.

For a used control unit

- Request the enabling code. (☛ p. 165)

EFI control unit

- Switch to the main menu.
- Select model.
- Select **"ECU Diagnostics"**.
- Highlight the **"Injection management EFI LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Select **"Change VIN - New identity"**.
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and using **"Continue"** start the coding process.
- Under **"Please enter VIN:"** enter the new VIN.

**Info**

For new control units, a sample VIN is displayed.

For used control units, the last programmed VIN is displayed.

- Press **"Continue"**.
- Select **"Code entry"**.
- **"Please enter the code"**
- Press **"Continue"**.
- ✓ The new VIN is written to the EFI control unit.
- Switch to the main menu.
- Select **"Show identification"**.
- Compare the old VIN to the new VIN.
- ✓ The new VIN is shown.

EPT control unit

- Select model.
- Select **"ECU Diagnostics"**.
- Highlight **"EPT throttle motor drive control LC4"** control unit.
- Press **"Continue"**.
- Select **"Coding"**.
- **"Please enter the password:"**
- Press **"Continue"**.
- Read the information page on the KTM diagnostics tool and using **"Continue"** start the coding process.
- Under **"Please enter VIN:"** enter the new VIN.

**Info**

For new control units, a sample VIN is displayed.

For used control units, the last programmed VIN is displayed.

- Press **"Continue"**.
- Select **"Code entry"**.
- **"Please enter the code"**
- Press **"Continue"**.
- ✓ The new VIN is transferred to the EPT control unit.

- Switch to the main menu.
- Select **"Show identification"**.
- Compare the old VIN to the new VIN.
 - ✓ The new VIN is shown.

| | | | |
|---|---|--|--|
| Design | 1-cylinder 4-stroke engine, water-cooled | | |
| Displacement | 654 cm ³ (39.91 cu in) | | |
| Stroke | 80 mm (3.15 in) | | |
| Bore | 102 mm (4.02 in) | | |
| Compression ratio | 11.8:1 | | |
| Control | OHC, 4 valves controlled via rocker arm, chain drive | | |
| Valve diameter, intake | 40 mm (1.57 in) | | |
| Valve diameter, exhaust | 34 mm (1.34 in) | | |
| Valve play, cold | 0.07... 0.13 mm (0.0028... 0.0051 in) | | |
| Crankshaft bearing | 2 roller bearings | | |
| Conrod bearing | Needle bearing | | |
| Piston pin bearing | Bronze bush | | |
| Pistons | Forged light alloy | | |
| Piston rings | 1 L-ring, 1 tapered compression piston ring, 1 oil scraper ring | | |
| Engine lubrication | Semi-dry sump lubrication with two rotor pumps | | |
| Primary transmission | 36:79 | | |
| Clutch | APTC™ Antihopping clutch in oil bath / hydraulically operated | | |
| Gearbox | 6-gears, claw-shifted | | |
| Transmission ratio | | | |
| 1st gear | 14:35 | | |
| 2nd gear | 16:28 | | |
| 3rd gear | 21:28 | | |
| 4th gear | 21:23 | | |
| 5th gear | 23:22 | | |
| 6th gear | 23:20 | | |
| Mixture preparation | Electronic fuel injection | | |
| Ignition | Contactless controlled fully electronic ignition with digital ignition adjustment | | |
| Alternator | 12 V, 224 W | | |
| Spark plug | NGK LKAR 8AI - 9 | | |
| Spark plug electrode gap | 0.9 mm (0.035 in) | | |
| Cooling | Water cooling, permanent circulation of coolant by water pump | | |
| Idle speed | | | |
| Coolant temperature: ≥ 70 °C (≥ 158 °F) | 1,550... 1,650 rpm | | |
| Starting aid | Electric starter, automatic decompressor | | |

Capacity - engine oil

| | | | |
|------------|------------------|--|------------------------------------|
| Engine oil | 1.70 l (1.8 qt.) | Engine oil (SAE 10W/60) (00062010035) (☞ p. 204) | |
| | | Alternative engine oil | Engine oil (SAE 10W/50) (☞ p. 204) |

Capacity - coolant

| | | | |
|---------|-------------------|---|--|
| Coolant | 1.20 l (1.27 qt.) | Coolant (☞ p. 204) | |
| | | Coolant (mixed ready to use) (☞ p. 204) | |

| | |
|--|---|
| Camshafts - diameter, bearing pin | |
| Next to exhaust cam | ≥ 39.95 mm (≥ 1.5728 in) |
| Next to inlet cam | ≥ 17.96 mm (≥ 0.7071 in) |
| Valve spring | |
| Minimum length (without valve spring cap) | 42.3 mm (1.665 in) |
| Valve spring cap - thickness | 2.4... 2.5 mm (0.094... 0.098 in) |
| Valve - valve stem diameter | |
| Exhaust | ≥ 5.93 mm (≥ 0.2335 in) |
| Intake | ≥ 5.93 mm (≥ 0.2335 in) |
| Valve guide - diameter | |
| New condition | 6.004... 6.016 mm (0.23638... 0.23685 in) |
| Wear limit | 6.050 mm (0.23819 in) |
| Valve - sealing seat width | |
| Intake | 1.60 mm (0.063 in) |
| Exhaust | 2.00 mm (0.0787 in) |
| Valve - run-out | |
| On the valve plate | ≤ 0.05 mm (≤ 0.002 in) |
| On the valve stem | ≤ 0.05 mm (≤ 0.002 in) |
| Cylinder/cylinder head - sealing area distortion | ≤ 0.10 mm (≤ 0.0039 in) |
| Cylinder - bore diameter | |
| Size I | 102.000... 102.012 mm (4.01574... 4.01621 in) |
| Size II | 102.013... 102.025 mm (4.01625... 4.01672 in) |
| Piston - diameter | |
| Size I | 101.955... 101.965 mm (4.01397... 4.01436 in) |
| Size II | 101.965... 101.975 mm (4.01436... 4.01476 in) |
| Piston/cylinder - mounting clearance | |
| New condition | 0.035... 0.060 mm (0.00138... 0.00236 in) |
| Wear limit | 0.10 mm (0.0039 in) |
| Piston ring - groove clearance | ≤ 0.08 mm (≤ 0.0031 in) |
| Piston ring end gap | |
| Compression rings | ≤ 0.80 mm (≤ 0.0315 in) |
| Oil scraper ring | ≤ 1.00 mm (≤ 0.0394 in) |
| Piston - piston pin hole diameter | 20.010... 20.020 mm (0.78779... 0.78819 in) |
| Piston pin - diameter | 19.995... 20.004 mm (0.7872... 0.78756 in) |
| Connecting rod - axial clearance of lower conrod bearing | 0.40... 0.60 mm (0.0157... 0.0236 in) |
| Connecting rod - radial clearance of lower conrod bearing | 0.05 mm (0.002 in) |
| Crankshaft - axial clearance | 0.15... 0.25 mm (0.0059... 0.0098 in) |
| Crankshaft run-out at bearing pin | ≤ 0.10 mm (≤ 0.0039 in) |
| Balancer shaft axial clearance | 0.05... 0.20 mm (0.002... 0.0079 in) |
| Clutch facing disc - thickness | ≥ 2.5 mm (≥ 0.098 in) |
| Intermediate disk - thickness | ≥ 1.35 mm (≥ 0.0531 in) |
| Clutch spring - length | 31.5... 33.5 mm (1.24... 1.319 in) |
| Clutch cage - contact surface of clutch facing discs | ≤ 0.5 mm (≤ 0.02 in) |
| Oil pressure regulator valve - minimum spring length | 27.5 mm (1.083 in) |
| Oil pump | |
| Clearance between external rotor and engine case | ≤ 0.20 mm (≤ 0.0079 in) |
| Clearance between external rotor and internal rotor | ≤ 0.20 mm (≤ 0.0079 in) |
| Axial clearance | 0.04... 0.08 mm (0.0016... 0.0031 in) |
| Engine oil pressure | |
| Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 1,500 rpm | ≥ 0.4 bar (≥ 6 psi) |
| Coolant temperature: ≥ 70 °C (≥ 158 °F) Engine speed: 5,000 rpm | ≥ 1.5 bar (≥ 22 psi) |

| | |
|--|---------------------------------------|
| Main shaft axial clearance | 0.10... 0.40 mm (0.0039... 0.0157 in) |
| Transmission shaft run-out | ≤ 0.025 mm (≤ 0.00098 in) |
| Shift shaft - play in sliding plate/shift quadrant | 0.40... 0.80 mm (0.0157... 0.0315 in) |
| Fuel pressure | |
| Under every load condition | 3.3... 3.7 bar (48... 54 psi) |

| | | | |
|--|--------------|---|----------------------------|
| Oil hole plug | self-tapping | 9 Nm (6.6 lbf ft) | Loctite® 243™ |
| Screw, membrane fixation | M3 | 2.5 Nm (1.84 lbf ft) | Loctite® 243™ |
| Hose clamp, intake flange | M4 | 1.5 Nm (1.11 lbf ft) | – |
| Oil jet, conrod lubrication | M4 | 2 Nm (1.5 lbf ft) | Loctite® 243™ |
| Locking screw for bearing | M5 | 6 Nm (4.4 lbf ft) | Loctite® 243™ |
| Screw, breather cover on valve cover | M5 | 3 Nm (2.2 lbf ft) | Loctite® 243™ |
| Screw, clutch spring | M5 | 6 Nm (4.4 lbf ft) | – |
| Screw, cover plate for oil return line | M5 | 6 Nm (4.4 lbf ft) | – |
| Screw, gear sensor | M5 | 5 Nm (3.7 lbf ft) | Loctite® 243™ |
| Screw, oil filter cover | M5 | 6 Nm (4.4 lbf ft) | – |
| Screw, oil pump cover | M5 | 6 Nm (4.4 lbf ft) | Loctite® 243™ |
| Plug, vacuum connection | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw in alternator cover | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, alternator cover (chain shaft through-hole) | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, autodecompression | M6 | 3... 4 Nm (2.2... 3 lbf ft) | Loctite® 243™ |
| Screw, axial lock of camshaft | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, camshaft support plate | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, clutch cover | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, clutch slave cylinder | M6x20 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, clutch slave cylinder | M6x35 | 10 Nm (7.4 lbf ft) | – |
| Screw, cylinder | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, cylinder head | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, engine case | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, ignition pulse generator | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, locking lever | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, rocker arm shaft | M6 | 12 Nm (8.9 lbf ft) | – |
| Screw, shift drum locating | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, shift lever | M6 | 10 Nm (7.4 lbf ft) | Loctite® 222 |
| Screw, starter motor | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, stator bracket | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, thermostat housing | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, timing chain guide rail | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, timing chain tensioning rail | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, valve cover | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, water pump cover | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, water pump wheel | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Oil jet, piston cooling | M6x0.75 | 4 Nm (3 lbf ft) | Loctite® 243™ |
| Plug, crankshaft location | M8 | 20 Nm (14.8 lbf ft) | – |
| Stud, exhaust flange | M8 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Cylinder head screw | M10 | Tightening sequence: Tighten diagonally, beginning with the rear screw on the chain shaft. Step 1 15 Nm (11.1 lbf ft) Step 2 30 Nm (22.1 lbf ft) Step 3 45 Nm (33.2 lbf ft) Step 4 60 Nm (44.3 lbf ft) | Lubricated with engine oil |
| Oil hole plug | M10x1 | 15 Nm (11.1 lbf ft) | Loctite® 243™ |
| Plug, drain hole of water pump | M10x1 | 15 Nm (11.1 lbf ft) | – |

| | | | |
|---|-----------|----------------------|----------------------|
| Plug, oil bore for oil radiator | M10x1 | 15 Nm (11.1 lbf ft) | – |
| Screw, unlocking of timing chain tensioner | M10x1 | 10 Nm (7.4 lbf ft) | – |
| Spark plug | M12x1.25 | 17 Nm (12.5 lbf ft) | – |
| Coolant temperature sensor on cylinder head | M12x1.5 | 12 Nm (8.9 lbf ft) | – |
| Oil drain plug with magnet | M12x1.5 | 20 Nm (14.8 lbf ft) | – |
| Oil pressure regulator valve plug | M12x1.5 | 20 Nm (14.8 lbf ft) | – |
| Plug, oil bore | M14x1.5 | 15 Nm (11.1 lbf ft) | Loctite® 243™ |
| Engine case stud | M16x1.5 | 25 Nm (18.4 lbf ft) | Loctite® 243™ |
| Rotor nut | M18x1.5 | 100 Nm (73.8 lbf ft) | – |
| Nut, engine sprocket | M20x1.5 | 60 Nm (44.3 lbf ft) | Loctite® 243™ |
| Nut, inner clutch hub | M20x1.5 | 100 Nm (73.8 lbf ft) | Loctite® 243™ |
| Nut, primary gear | M20LHx1.5 | 90 Nm (66.4 lbf ft) | Loctite® 243™ |
| Plug, oil screen | M20x1.5 | 15 Nm (11.1 lbf ft) | – |
| Plug, timing chain tensioner | M20x1.5 | 25 Nm (18.4 lbf ft) | – |
| Plug, oil thermostat | M24x1.5 | 15 Nm (11.1 lbf ft) | – |
| Screw in alternator cover | M24x1.5 | 8 Nm (5.9 lbf ft) | – |

| | | |
|---|---|--|
| Frame | Lattice frame made of chrome molybdenum steel tubing, powder-coated | |
| Fork | WP Suspension Up Side Down 4860 ROMA | |
| Shock absorber | WP Suspension 4618 with Pro-Lever deflector | |
| Suspension travel | | |
| Front | 275 mm (10.83 in) | |
| Rear | 265 mm (10.43 in) | |
| Brake system | | |
| Front | Disc brake with radially screwed four-piston brake caliper, floating brake disc | |
| Rear | Disc brake with single-piston brake caliper, floating | |
| Brake discs - diameter | | |
| Front | 320 mm (12.6 in) | |
| Rear | 240 mm (9.45 in) | |
| Brake discs - wear limit | | |
| Front | 4.0 mm (0.157 in) | |
| Rear | 4.5 mm (0.177 in) | |
| Tire air pressure, solo | | |
| Front | 2.0 bar (29 psi) | |
| Rear | 2.0 bar (29 psi) | |
| Tire air pressure with passenger / fully loaded | | |
| Front | 2.0 bar (29 psi) | |
| Rear | 2.2 bar (32 psi) | |
| Secondary drive ratio | 16:42 | |
| Chain | 5/8 x 1/4" X-ring | |
| Steering head angle | 63° | |
| Wheelbase | 1,480±15 mm (58.27±0.59 in) | |
| Seat height unloaded | 900 mm (35.43 in) | |
| Ground clearance unloaded | 290 mm (11.42 in) | |
| Weight without fuel approx. | 139.5 kg (307.5 lb.) | |
| Maximum permissible front axle load | 150 kg (331 lb.) | |
| Maximum permissible rear axle load | 200 kg (441 lb.) | |
| Maximum permissible overall weight | 350 kg (772 lb.) | |

| | | |
|---------|-------------|---|
| Battery | YTZ10S | Battery voltage: 12 V Nominal capacity: 8.6 Ah maintenance-free |
| Fuse | 58011109130 | 30 A |
| Fuse | 75011088015 | 15 A |
| Fuse | 75011088010 | 10 A |

Lighting equipment

| | | |
|---|------------------------|-----------------|
| Headlight | H4 / socket P43t | 12 V 60/55 W |
| Parking light | W5W / socket W2.1x9.5d | 12 V 5 W |
| Instrument lights and indicator lamps | LED | |
| Turn signal | RY10W / socket BAU15s | 12 V 10 W |
| Brake/tail light (690 SMC EU, 690 SMC AUS/UK) | LED | |
| Brake/tail light (690 SMC USA) | P21/5W / socket BAY15d | 12 V 21/5 W |

| | | |
|--------------------|------------------------|-------------|
| License plate lamp | W5W / socket W2.1x9.5d | 12 V 5 W |
|--------------------|------------------------|-------------|

| Front tire | Rear tire |
|--|---|
| 120/70 ZR 17 M/C 58W TL Pirelli Dragon Supercorsa Pro | 160/60 ZR 17 M/C 69W TL Pirelli Dragon Supercorsa Pro |
| Additional information is available in the Service section under: http://www.ktm.com | |

Capacity - fuel

| | | |
|--------------------------------------|-------------------|--|
| Total fuel tank capacity, approx. | 12 l (3.2 US gal) | Super unleaded (ROZ 95 / RON 95 / PON 91) (🔧 p. 205) |
| Fuel reserve, approx. | 2.5 l (2.6 qt.) | |

| | |
|--------------------------------------|---|
| Fork part number | 14.18.7D.12 |
| Fork | WP Suspension Up Side Down 4860 ROMA |
| Compression damping | |
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |
| Rebound damping | |
| Comfort | 15 clicks |
| Standard | 10 clicks |
| Sport | 5 clicks |
| Full payload | 5 clicks |
| Spring length with preload spacer(s) | 480 mm (18.9 in) |
| Spring rate | |
| Soft | 5.0 N/mm (28.6 lb/in) |
| Medium (standard) | 5.2 N/mm (29.7 lb/in) |
| Hard | 5.4 N/mm (30.8 lb/in) |
| Fork length | 915 mm (36.02 in) |
| Air chamber length | 100 \pm 20 mm (3.94 \pm 0.79 in) |
| Fork oil per fork leg | 634 ml (21.44 fl. oz.) |
| Fork oil (SAE 5) (☛ p. 205) | |

| | |
|---------------------------------|---|
| Shock absorber part number | 15.18.7D.12 |
| Shock absorber | WP Suspension 4618 with Pro-Lever deflector |
| Compression damping, high-speed | |
| Comfort | 1.5 turns |
| Standard | 1 turn |
| Sport | 0.5 turn |
| Full payload | 0.5 turn |
| Compression damping, low-speed | |
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |
| Rebound damping | |
| Comfort | 20 clicks |
| Standard | 15 clicks |
| Sport | 10 clicks |
| Full payload | 10 clicks |
| Spring preload | 18 mm (0.71 in) |
| Spring rate | |
| Soft | 80 N/mm (457 lb/in) |
| Medium (standard) | 85 N/mm (485 lb/in) |
| Hard | 90 N/mm (514 lb/in) |
| Spring length | 220 mm (8.66 in) |
| Gas pressure | 10 bar (145 psi) |
| Static sag | 20 mm (0.79 in) |
| Riding sag | 70... 80 mm (2.76... 3.15 in) |
| Fitted length | 400 mm (15.75 in) |
| Shock absorber fluid | Shock absorber oil (SAE 2,5) (50180342S1) (🔍 p. 205) |

| | | | |
|--|-------|---------------------|---------------|
| Screw, combination instrument | EJOT | 1 Nm (0.7 lbf ft) | – |
| Screw, combination instrument holder | EJOT | 1 Nm (0.7 lbf ft) | – |
| Screw, license plate holder, bottom | EJOT | 3 Nm (2.2 lbf ft) | – |
| Screw, SLS valve | EJOT | 2 Nm (1.5 lbf ft) | – |
| Remaining screws, chassis | M4 | 4 Nm (3 lbf ft) | – |
| Spoke nipple, front wheel | M4.5 | 4 Nm (3 lbf ft) | – |
| Bolt, foot brake lever stub | M5 | 6 Nm (4.4 lbf ft) | Loctite® 243™ |
| Rear fairing screw | M5 | 2 Nm (1.5 lbf ft) | – |
| Remaining screws, chassis | M5 | 4 Nm (3 lbf ft) | – |
| Screw, electrical holder | M5 | 3 Nm (2.2 lbf ft) | – |
| Screw, exhaust heat shield | M5 | 8 Nm (5.9 lbf ft) | – |
| Screw, fuel level sensor | M5 | 3 Nm (2.2 lbf ft) | – |
| Screw, fuel pump | M5 | 6 Nm (4.4 lbf ft) | – |
| Screw, headlight mask | M5 | 5 Nm (3.7 lbf ft) | – |
| Screw, seat lock | M5 | 3 Nm (2.2 lbf ft) | Loctite® 222 |
| Screw, side cover | M5 | 2 Nm (1.5 lbf ft) | – |
| Screw, side stand switch | M5 | 3 Nm (2.2 lbf ft) | – |
| Screw, starter cable on starter | M5 | 3 Nm (2.2 lbf ft) | – |
| Spoke nipple, rear wheel | M5 | 4 Nm (3 lbf ft) | – |
| Nut, foot brake cylinder screw | M6 | 10 Nm (7.4 lbf ft) | – |
| Remaining nuts, chassis | M6 | 15 Nm (11.1 lbf ft) | – |
| Remaining screws on fuel tank | M6 | 6 Nm (4.4 lbf ft) | – |
| Remaining screws, chassis | M6 | 10 Nm (7.4 lbf ft) | – |
| Screw, ball joint of push rod on foot brake cylinder | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, brake fluid reservoir of rear brake | M6 | 5 Nm (3.7 lbf ft) | – |
| Screw, front brake disc | M6 | 14 Nm (10.3 lbf ft) | Loctite® 243™ |
| Screw, ignition lock | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, magnetic holder on side stand | M6 | 10 Nm (7.4 lbf ft) | Loctite® 243™ |
| Screw, radiator bracket | M6 | 5 Nm (3.7 lbf ft) | – |
| Screw, rear brake disc | M6 | 14 Nm (10.3 lbf ft) | Loctite® 243™ |
| Screw, voltage regulator | M6 | 8 Nm (5.9 lbf ft) | – |
| Nut, manifold on cylinder head | M8 | 25 Nm (18.4 lbf ft) | Copper paste |
| Nut, rear sprocket screw | M8 | 35 Nm (25.8 lbf ft) | Loctite® 243™ |
| Remaining nuts, chassis | M8 | 30 Nm (22.1 lbf ft) | – |
| Remaining screws, chassis | M8 | 25 Nm (18.4 lbf ft) | – |
| Screw, bottom triple clamp | M8 | 12 Nm (8.9 lbf ft) | – |
| Screw, connection lever on frame | M8 | 30 Nm (22.1 lbf ft) | – |
| Screw, exhaust clamp on main silencer | M8 | 25 Nm (18.4 lbf ft) | – |
| Screw, fork stub | M8 | 15 Nm (11.1 lbf ft) | – |
| Screw, front footrest bracket | M8 | 25 Nm (18.4 lbf ft) | – |
| Screw, fuel tank, bottom | M8 | 20 Nm (14.8 lbf ft) | – |
| Screw, handlebar clamp | M8 | 20 Nm (14.8 lbf ft) | Loctite® 243™ |
| Screw, handrail | M8 | 20 Nm (14.8 lbf ft) | – |
| Screw, license plate holder, top | M8 | 20 Nm (14.8 lbf ft) | – |
| Screw, main silencer holder | M8 | 25 Nm (18.4 lbf ft) | – |
| Screw, main silencer holder on fuel tank | M8 | 25 Nm (18.4 lbf ft) | Loctite® 243™ |
| Screw, rear footrest bracket | M8x16 | 25 Nm (18.4 lbf ft) | – |
| Screw, side stand bracket | M8 | 25 Nm (18.4 lbf ft) | – |
| Screw, spring holder on side stand bracket | M8 | 25 Nm (18.4 lbf ft) | Loctite® 243™ |

| | | | |
|----------------------------------|----------|------------------------|---------------|
| Screw, steering stem | M8 | 20 Nm (14.8 lbf ft) | Loctite® 243™ |
| Screw, top triple clamp | M8 | 17 Nm (12.5 lbf ft) | – |
| Upper fuel tank screw | M8 | 20 Nm (14.8 lbf ft) | – |
| Engine carrying screw | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
| Remaining nuts, chassis | M10 | 50 Nm (36.9 lbf ft) | – |
| Remaining screws, chassis | M10 | 45 Nm (33.2 lbf ft) | – |
| Screw, bottom shock absorber | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
| Screw, engine bearer on frame | M10 | 45 Nm (33.2 lbf ft) | – |
| Screw, foot brake lever | M10LH | 25 Nm (18.4 lbf ft) | Loctite® 243™ |
| Screw, handlebar support | M10 | 40 Nm (29.5 lbf ft) | – |
| Screw, side stand | M10 | 35 Nm (25.8 lbf ft) | Loctite® 243™ |
| Screw, top shock absorber | M10 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
| Screw, front brake caliper | M10x1.25 | 45 Nm (33.2 lbf ft) | Loctite® 243™ |
| Lambda sensor | M12x1.25 | 24.5 Nm (18.07 lbf ft) | Copper paste |
| Screw, swingarm pivot | M12x1.75 | 80 Nm (59 lbf ft) | – |
| Nut, linkage lever on swingarm | M14x1.5 | 100 Nm (73.8 lbf ft) | – |
| Nut, linkage lever to rocker arm | M14x1.5 | 100 Nm (73.8 lbf ft) | – |
| Screw, bottom steering head | M20x1.5 | 60 Nm (44.3 lbf ft) | Loctite® 243™ |
| Screw, top steering head | M20x1.5 | 10 Nm (7.4 lbf ft) | – |
| Screw, front wheel spindle | M24x1.5 | 40 Nm (29.5 lbf ft) | – |
| Nut, rear wheel spindle | M25x1.5 | 90 Nm (66.4 lbf ft) | – |

Cleaning the motorcycle

Note

Material damage Damage and destruction of components by high-pressure cleaning equipment.

- Never clean the vehicle with high-pressure cleaning equipment or a strong water-jet. The excessive pressure can penetrate electrical components, socket connects, throttle cables, and bearings, etc., and can damage or destroy these parts.



Warning

Environmental hazard Hazardous substances cause environmental damage.

- Oil, grease, filters, fuel, cleaners, brake fluid, etc., should be disposed of as stipulated in applicable regulations.



Info

If you clean the motorcycle regularly, its value and appearance will be maintained over a long period.
Avoid direct sunshine on the motorcycle during cleaning.

- Seal the exhaust system to keep water out.
- First remove coarse dirt particles with a gentle spray of water.
- Spray very dirty areas with a normal motorcycle cleaner and then clean with a brush.

Motorcycle cleaner (🔧 p. 207)



Info

Clean the vehicle using a soft sponge and warm water containing normal motorcycle cleaner.
If the vehicle was operated in road salt, clean it with cold water. Warm water enhances the corrosive effects of salt.

- After the motorcycle has been thoroughly cleaned with a gentle spray of water, it should be dried with compressed air and a cloth.



Warning

Danger of accidents Reduced braking efficiency due to wet or dirty brakes.

- Clean or dry dirty or wet brakes by riding and braking gently.

- After cleaning, ride the vehicle a short distance until the engine is warm, applying the brakes occasionally.



Info

The heat produced causes water at inaccessible locations in the engine and the brakes to evaporate.

- Push back the protection covers of the handlebar controls to allow any water that has penetrated to evaporate.
- After the motorcycle has cooled off, oil or grease all moving parts and bearings.
- Clean the chain. (🔧 p. 65)
- Treat bare metal parts (except for brake discs and exhaust system) with anti-corrosion materials.

Cleaning and preserving materials for metal, rubber and plastic (🔧 p. 206)

- Treat all painted parts with a mild paint polish.

High-luster polish for paint (🔧 p. 206)

- Treat all plastic parts and powder-coated parts with a mild cleaning and care agent.

Paint cleaner and polish for high-gloss and matte finishes, bare metal and plastic surfaces (🔧 p. 207)

- To prevent electrical problems, treat electric contacts and switches with contact spray.

Contact spray (🔧 p. 206)

- Oil the ignition/steering lock.

Universal oil spray (🔧 p. 207)

Protective treatment for winter operation



Info

If you use the motorcycle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

If the vehicle was operated in road salt, clean it with cold water. Warm water would enhance the corrosive effects of salt.

-
- Clean the motorcycle. (🔧 p. 179)
 - Treat the engine, the swingarm, and all other bare or galvanized parts (except brake discs) with a wax-based anti-corrosion substance.



Info

To prevent serious reduction of the braking efficiency, make sure no anti-corrosion substance gets on to the brake discs. After use on salted roads, clean the motorcycle thoroughly with cold water and dry it properly.

-
- Clean the chain. (🔧 p. 65)

Storage

Info

If you want to garage the motorcycle for a longer period, take the following actions.

Before storing the motorcycle, check all parts for function and wear. If service, repairs or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.

- Make sure the tank is as empty as possible so that you can fill up with fresh fuel when you put the motorcycle back into operation.
- Clean the motorcycle. (🔧 p. 179)
- Change the engine oil and filter, clean the oil screens. (🔧 p. 154)
- Check the antifreeze and coolant level. (🔧 p. 150)
- Check the tire air pressure. (🔧 p. 60)
- Remove the battery. (🔧 p. 68)
- Recharge the battery. (🔧 p. 69)

Guideline

| | |
|--|--------------------------|
| Storage temperature of battery without direct sunshine | 0... 35 °C (32... 95 °F) |
|--|--------------------------|

- The storage place should be dry and not subject to large temperature differences.

Info

KTM recommends jacking up the motorcycle.

- Raise the motorcycle with the rear wheel stand. (🔧 p. 9)
- Raise the motorcycle with the front wheel stand. (🔧 p. 9)
- Cover the motorcycle with a tarp or cover that is permeable to air.

Info

Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and exhaust system to rust.

Putting into operation after storage

- Take the motorcycle off of the front wheel stand. (🔧 p. 9)
- Take the motorcycle off of the rear wheel stand. (🔧 p. 9)
- Recharge the battery. (🔧 p. 69)
- Install the battery. (🔧 p. 68)
- Set the clock. (🔧 p. 82)
- Refuel.
- Carry out checks before putting into operation.
- Make a test ride.

Service schedule


| | K10N | K50A | K100A | K300A |
|--|------|------|-------|-------|
| Check that the electrical equipment is functioning correctly. | • | • | • | • |
| Read out the fault memory using the KTM diagnostics tool. | • | • | • | • |
| Change the engine oil and filter, clean the oil screens. (🔧 p. 154) | • | • | • | • |
| Check the front brake linings. (🔧 p. 73) | • | • | • | • |
| Check the rear brake linings. (🔧 p. 76) | • | • | • | • |
| Check the brake discs. (🔧 p. 61) | • | • | • | • |
| Check the brake lines for damage and leakage. | • | • | • | • |
| Check the rear brake fluid level. (🔧 p. 79) | • | • | • | • |
| Check the free travel of the foot brake lever. (🔧 p. 78) | • | • | • | • |
| Lubricate the linkage of the rear wheel suspension. | | | | • |
| Check that the shock absorber and fork are leak tight. If necessary and depending on use, service the fork and shock absorber. | • | • | • | • |
| Check the swingarm bearing. | | • | • | • |
| Check the wheel bearing for play. | | • | • | • |
| Check the tire condition. (🔧 p. 60) | • | • | • | • |
| Check the tire air pressure. (🔧 p. 60) | • | • | • | • |
| Check the spoke tension. (🔧 p. 66) | • | • | • | • |
| Check for rim run-out. | • | • | • | • |
| Check the chain, rear sprocket and engine sprocket. (🔧 p. 64) | | • | • | • |
| Check the chain tension. (🔧 p. 63) | • | • | • | • |
| Grease all moving parts (e.g. side stand, hand lever, chain, ...) and check for smooth operation. | • | • | • | • |
| Clean the dust boots of the fork legs. (🔧 p. 13) | | • | • | • |
| Check the front brake fluid level. (🔧 p. 74) | • | • | • | • |
| Bleed the fork legs. (🔧 p. 12) | | • | • | • |
| Check the steering head bearing play. (🔧 p. 25) | • | • | • | • |
| Change the spark plug. | | | • | • |
| Check the valve clearance. | | | • | • |
| Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and bellows for cracking, leaks, and correct routing. | | | • | • |
| Check the antifreeze and coolant level. (🔧 p. 150) | • | • | • | • |
| Check the cables for damage and routing without sharp bends. | | • | • | • |
| Check that the throttle cables are undamaged, routed without sharp bends and set correctly. | • | • | • | • |
| Replace the fuel evaporation container. (only applies to spare part number 75015001000) (690 SMC USA) | | | • | • |
| Change the air filter. Clean the air filter box. | | • | • | • |
| Check/rectify the fluid level of the hydraulic clutch. (🔧 p. 148) | | • | • | • |
| Check the screws and nuts for tightness. | • | • | • | • |
| Change the coolant. | | | | • |
| Change the front brake fluid. (🔧 p. 75) | | | • | • |
| Change the rear brake fluid. (🔧 p. 80) | | | • | • |
| Check the clutch. | | | • | • |
| Check the headlight setting. (🔧 p. 84) | • | • | • | • |
| Check that the radiator fan is functioning properly. | • | • | • | • |
| Final check: Check the vehicle for roadworthiness and take a test ride. | • | • | • | • |
| Read out the fault memory using the KTM diagnostics tool after a test ride. | • | • | • | • |
| Make the service entry in KTM DEALER.NET and in the service record. | • | • | • | • |

K10N: Once after 1,000 km (621.4 mi)


K50A: Every 5,000 km (3,107 mi) or annually

K100A: Every 10,000 km (6,214 mi) or every 2 years


K300A: Every 30,000 km (18,641 mi) or every 4 years



| | |
|------|--|
| A11 | EFI control unit |
| F9 | Fuse |
| G10 | Battery |
| G20 | Generator |
| K10 | Starter relay with main fuse |
| K11 | Start auxiliary relay |
| M10 | Starter motor |
| T20 | Voltage regulator |
| X291 | Connector for accessory ground (terminal 31) ACC 1 (not assigned) |
| X292 | Connector for accessory plus (terminal 30) ACC 1 (not assigned) |




| | |
|------|---|
| A11 | EFI control unit |
| A12 | EPT control unit |
| F1 | Fuse |
| K12 | Light relay |
| K30 | Power relay |
| P10 | Combination instrument |
| S11 | Ignition/steering lock |
| S23 | Emergency OFF switch, electric starter button |
| X295 | Diagnostics connector |




690 Enduro/SMC 08/09/10

| | |
|-----|--|
| E13 | Low beam, high beam |
| F6 | Fuse |
| F7 | Fuse |
| P10 | Combination instrument |
| P15 | Horn |
| P35 | Parking light |
| S29 | High beam/low beam switch, horn button, turn signal switch |




| | |
|-----|--------------------------|
| B76 | Front brake light switch |
| B77 | Brake light switch, rear |
| E60 | License plate lamp |
| P36 | Brake/tail light |




| | |
|-----|--|
| K20 | Turn signal relay |
| P10 | Combination instrument |
| P41 | Turn signal, front left |
| P42 | Turn signal, front right |
| P45 | Turn signal, rear left |
| P46 | Turn signal, rear right |
| S29 | High beam/low beam switch, horn button, turn signal switch |


| | |
|------|--|
| B33 | Temperature switch for radiator fan |
| F5 | Fuse |
| F8 | Fuse |
| M14 | Radiator fan |
| X293 | Connector for accessory ground (terminal 31) ACC 2 (not assigned) |
| X294 | Connector for accessory plus (terminal 15) ACC 2 (not assigned) |




| | |
|------|------------------------|
| A11 | EFI control unit |
| A12 | EPT control unit |
| F2 | Fuse |
| F3 | Fuse |
| F4 | Fuse |
| M13 | Fuel pump |
| M60 | Motor drive |
| P10 | Combination instrument |
| X295 | Diagnostics connector |



| | |
|-----|---|
| A11 | EFI control unit |
| B51 | Lambda sensor (cylinder 1) |
| B70 | Front wheel speed sensor |
| M20 | Fuel evaporation valve (USA version only) |
| M21 | Secondary air valve |
| M51 | Injector (cylinder 1) |
| P10 | Combination instrument |
| R51 | Ignition coil (cylinder 1) |



| | |
|-----|------------------------------------|
| A11 | EFI control unit |
| B10 | Throttle position sensor circuit A |
| B12 | Intake air temperature sensor |
| B26 | Rollover sensor |
| B30 | Side stand switch |
| B31 | Accelerator position sensor |
| B34 | Gear position sensor |
| P10 | Combination instrument |



690 Enduro/SMC 08/09/10

| | |
|-----|--|
| A11 | EFI control unit |
| B13 | Ambient air pressure sensor |
| B21 | Engine coolant temperature sensor (cylinder 1) |
| B32 | Fuel level indicator |
| B37 | Crankshaft position sensor |
| B38 | Clutch switch |
| B41 | Manifold absolute pressure sensor (cylinder 1) |
| P10 | Combination instrument |
| S55 | Map-Select Switch |
| bl | Black |
| br | Brown |
| bu | Blue |
| gn | Green |
| gr | Gray |
| lbu | Light blue |
| or | Orange |
| pk | Pink |
| pu | Violet |
| rd | Red |
| wh | White |
| ye | Yellow |

Brake fluid DOT 4 / DOT 5.1**According to**

- DOT

Guideline

- Use only brake fluid that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Castrol** and **Motorex®** products.

Supplier**Castrol**

- **RESPONSE BRAKE FLUID SUPER DOT 4**

Motorex®

- **Brake Fluid DOT 5.1**

Coolant**Guideline**

- Use only suitable coolant (also in countries with high temperatures). Use of low-quality antifreeze can lead to corrosion and foaming. KTM recommends **Motorex®** products.

Mixture ratio

| | |
|--|---|
| Antifreeze protection: -25... -45 °C (-13... -49 °F) | 50 % corrosion inhibitor/antifreeze 50 % distilled water |
|--|---|

Coolant (mixed ready to use)

| | |
|------------|-----------------|
| Antifreeze | -40 °C (-40 °F) |
|------------|-----------------|

Supplier**Motorex®**

- **Anti Freeze**

Engine oil (SAE 10W/60) (00062010035)**According to**

- JASO T903 MA (☛ p. 220)
- SAE (☛ p. 220) (SAE 10W/60)
- KTM LC4 2007+

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

| |
|----------------------|
| Synthetic engine oil |
|----------------------|

Supplier**Motorex®**

- **Motorex® KTM Cross Power 4T**

Engine oil (SAE 10W/50)**According to**

- JASO T903 MA (☛ p. 220)
- SAE (☛ p. 220) (SAE 10W/50)

Guideline

- Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

| |
|----------------------------|
| Fully synthetic engine oil |
|----------------------------|

Supplier**Motorex®**

- **Power Synt 4T**

Fork oil (SAE 5)**According to**

- SAE (🔊 p. 220) (SAE 5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties. KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Racing Fork Oil**

Hydraulic fluid (15)**According to**

- ISO VG (15)

Guideline

- Use only hydraulic oil that complies with the specified standard (see specifications on the container) and that possesses the corresponding properties. KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Hydraulic Fluid 75**

Shock absorber oil (SAE 2,5) (50180342S1)**According to**

- SAE (🔊 p. 220) (SAE 2,5)

Guideline

- Use only oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Super unleaded (ROZ 95 / RON 95 / PON 91)**According to**

- DIN EN 228 (ROZ 95 / RON 95 / PON 91)

Chain cleaner**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Chain Clean 611**

Chain lube for road use**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Chain Lube 622 Strong**

Cleaning and preserving materials for metal, rubber and plastic**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Protect & Shine 645**

Contact spray**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Accu Contact**

High-luster polish for paint**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Moto Polish**

Long-life grease**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Fett 2000**

Lubricant (T511)**Guideline**

- KTM recommends **Lubcon®** products.

Supplier**Lubcon®**

- **Turmsilon® GTI 300 P**

Lubricant (T158)**Guideline**

- KTM recommends **Lubcon®** products.

Supplier**Lubcon®**

- **Turmogrease® PP 300**

Lubricant (T152)**Guideline**

- KTM recommends **Bel-Ray®** products.

Supplier**Bel-Ray®**

- **Molylube® Anti-Seize**

Lubricant (T159)**Guideline**

- KTM recommends **Bel-Ray®** products.

Supplier**Bel-Ray®**

- **MC-11®**

Lubricant (T625)**Guideline**

- KTM recommends **Molykote®** products.

Supplier**Molykote®**

- **33 Medium**

Motorcycle cleaner**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**

- **Moto Clean 900**

Paint cleaner and polish for high-gloss and matte finishes, bare metal and plastic surfaces**Guideline**

- KTM recommends **Motorex®** products.

Supplier**Motorex®**


- **Clean & Polish**

Universal oil spray**Guideline**

- KTM recommends **Motorex®** products.


Supplier**Motorex®**

- **Joker 440 Universal**

Bearing puller

400037-01

Art. no.: 15112017000


Insert for bearing puller

400125-01

Art. no.: 15112018100


Feature

18... 23 mm (0.71... 0.91 in)

Bleed syringe


400058-01

Art. no.: 50329050000

Circlip pliers reverse

400059-01


Art. no.: 51012011000

Extractor

400073-01


Art. no.: 58429009000

Tool for inner bearing race




Art. no.: 58429037043

Mounting sleeve




Art. no.: 58529005000

Valve spring compressor




Art. no.: 59029019000

Limit plug gauge




Art. no.: 59029026006

Extractor



Art. no.: 59029033000


Feeler gauge



400110-01

Art. no.: 59029041100


Hose clamp pliers



400142-01

Art. no.: 60029057000

Pliers for spring-loaded band-type clamp



400085-01

Art. no.: 60029057100

Rear wheel stand



500077-01

Art. no.: 61029055100

Adapter



500079-01


Art. no.: 61029055110

Front wheel stand




Art. no.: 61029055300

Testing hose




Art. no.: 61029093000

Pressure testing tool




Art. no.: 61029094000

Engine work stand




Art. no.: 61229001000

Work stand




Art. no.: 62529055000

Support for engine work stand




Art. no.: 75012001060

Holder for engine work stand




Art. no.: 75012001070

Piston assembly ring




Art. no.: 75029015102

Extractor




Art. no.: 75029021000

Assembly screws




Art. no.: 75029033000

Piston pin lock ring insert




Art. no.: 75029035000

Work stand adapter




Art. no.: 75029036000

Push-in drift




Art. no.: 75029044010

Push-in drift




Art. no.: 75029044020

Pressing device for crankshaft, complete




Art. no.: 75029047000

Upper part, pressing-out tool




Art. no.: 75029047050

Under part, pressing-out tool




Art. no.: 75029047051

Extractor




Art. no.: 75029048000

Clamping plate




Art. no.: 75029050000

Push-out drift




Art. no.: 75029051000

Floor jack attachment




Art. no.: 75029055000

Mounting sleeve




Art. no.: 75029080000

Gear segment




Art. no.: 75029081000

Protection cover




Art. no.: 75029090000

Holding spanner




Art. no.: 75029091000

Spark plug wrench




Art. no.: 75029172000

Oil pressure adapter




Art. no.: 77329006000

Engine blocking screw




Art. no.: 77329010000

Release device for timing chain tensioner




Art. no.: 77329051000

Valve spring mounting device



Art. no.: 78029060000


Spring compressor



300573-10

Art. no.: T101S

Hook wrench



301085-01

Art. no.: T106S

Pin



201235-10

Art. no.: T120

Pressing tool



200583-10

Art. no.: T1206

Pressing tool



200585-01

Art. no.: T1207S

Vacuum pump



200273-10

Art. no.: T1240S

Pressing tool



200584-01

Art. no.: T129

Protecting sleeve



200635-10

Art. no.: T1401

Gripping tool



200639-10

Art. no.: T14026S1

Assembly tool



200634-10

Art. no.: T1402S

Open-end wrench




Art. no.: T14032

Clamping stand



Art. no.: T1403S

Mounting sleeve



Art. no.: T1515

Filling adapter



Art. no.: T1516

Hook wrench



Art. no.: T157S

JASO T903 MA

Different technical development directions required a new specification for 4-stroke motorcycles– the JASO T903 MA Standard. Earlier, engine oils from the automobile industry were used for 4-stroke motorcycles because there was no separate motorcycle specification. Whereas long service intervals are demanded for automobile engines, high performance at high engine speeds are in the foreground for motorcycle engines. With most motorcycles, the gearbox and the clutch are lubricated with the same oil as the engine. The JASO MA Standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

A

| | |
|--|-----|
| Accessories | 6 |
| Air filter | |
| installing | 51 |
| removing | 51 |
| Air filter box | |
| fitting | 52 |
| removing | 51 |
| Alternator | |
| stator winding, checking | 158 |
| Antifreeze | |
| checking | 150 |
| Assembling the engine | |
| alternator cover, installing | 146 |
| camshafts, installing | 141 |
| clutch cage, installing | 136 |
| clutch cover, installing | 143 |
| crankshaft and balancer shaft, installing | 133 |
| crankshaft position sensor distance, adjusting | 138 |
| crankshaft position sensor, installing | 137 |
| cylinder head, installing | 140 |
| engine, setting to top dead center | 139 |
| gear position sensor, installing | 145 |
| left engine case, installing | 133 |
| locking lever, installing | 134 |
| oil filter, installing | 144 |
| oil pumps, installing | 134 |
| oil screens, installing | 146 |
| piston, installing | 139 |
| primary gear, installing | 135 |
| rotor, installing | 138 |
| shift drum locating, installing | 134 |
| shift shaft, installing | 135 |
| spacer, installing | 145 |
| spark plug, installing | 143 |
| starter drive, installing | 135 |
| starter motor, installing | 147 |
| taking engine off universal mounting rack | 147 |
| thermostat, installing | 144 |
| timing chain and timing chain sprocket, installing | 137 |
| timing chain rails, installing | 138 |
| timing chain tensioner, installing | 141 |
| transmission shafts, installing | 132 |
| valve clearance, adjusting | 142 |
| valve clearance, checking | 142 |
| valve cover, installing | 147 |
| water pump cover, mounting | 144 |

B

| | |
|---------------------------|----|
| Battery | |
| connecting | 69 |
| disconnecting | 68 |
| fitting | 68 |
| recharging | 69 |
| removing | 68 |
| Brake discs | |
| checking | 61 |
| Brake fluid | |
| front brake, adding | 75 |

| | |
|-----------------------------|----|
| front brake, changing | 75 |
| rear brake, adding | 79 |
| rear brake, changing | 80 |

Brake fluid level

| | |
|-----------------------------|----|
| front brake, checking | 74 |
| rear brake, checking | 79 |

Brake linings

| | |
|-----------------------------|----|
| front brake, changing | 73 |
| front brake, checking | 73 |
| rear brake, changing | 77 |
| rear brake, checking | 76 |

C**Chain**

| | |
|----------------|----|
| checking | 64 |
| cleaning | 65 |

Chain guide

| | |
|-----------------|----|
| adjusting | 64 |
|-----------------|----|

Chain tension

| | |
|-----------------|----|
| adjusting | 63 |
| checking | 63 |

Changing flasher bulb

| | |
|-------|----|
| | 86 |
|-------|----|

Charging voltage

| | |
|----------------|----|
| checking | 70 |
|----------------|----|

Chassis number

| | |
|-------|---|
| | 7 |
|-------|---|

Clutch

| | |
|---------------------------------------|-----|
| checking/correcting fluid level | 148 |
|---------------------------------------|-----|

Combination instrument

| | |
|---|----|
| clock, setting | 82 |
| kilometers or miles, setting | 82 |
| TRIP 1 display, setting/resetting | 82 |
| TRIP 2 display, setting/resetting | 83 |
| wheel circumference, setting | 83 |

Coolant

| | |
|----------------|-----|
| draining | 149 |
|----------------|-----|

Coolant level

| | |
|----------------|---------|
| checking | 150-151 |
|----------------|---------|

Cooling system

| | |
|---------------|-----|
| filling | 149 |
|---------------|-----|

Cylinder - Nikasil® coating

| | |
|-------|-----|
| | 112 |
|-------|-----|

D**Disassembling the engine**

| | |
|---|-----|
| alternator cover, removing | 95 |
| camshafts, removing | 98 |
| clutch cage, removing | 100 |
| clutch cover, removing | 97 |
| crankshaft and balancer shaft, removing | 104 |
| crankshaft position sensor, removing | 100 |
| cylinder head, removing | 98 |
| engine into engine work stand, clamping | 94 |
| engine oil, draining | 94 |
| engine, setting to ignition top dead center | 96 |
| gear position sensor, removing | 95 |
| left engine case, removing | 103 |
| locking lever, removing | 103 |
| oil filter, removing | 95 |
| oil pumps, removing | 103 |
| piston, removing | 98 |

| | |
|--|-----|
| primary gear, removing | 102 |
| rotor, removing | 99 |
| shift drum locating, removing | 102 |
| shift shaft, removing | 102 |
| spacer and spring, installing | 143 |
| spacer and spring, removing | 97 |
| spacer, removing | 95 |
| spark plug, removing | 97 |
| starter drive, removing | 102 |
| starter motor, removing | 94 |
| thermostat, removing | 96 |
| timing chain and timing chain sprocket, removing | 100 |
| timing chain rails, removing | 99 |
| timing chain tensioner, removing | 98 |
| transmission shafts, removing | 104 |
| valve cover, removing | 94 |
| water pump wheel, removing | 96 |

E**EFI control unit**

| | |
|----------|-----|
| coding | 166 |
| flashing | 164 |

Enabling code

| | |
|------------|-----|
| requesting | 165 |
|------------|-----|

Engine

| | |
|----------|----|
| fitting | 90 |
| removing | 88 |

Engine - Work on individual parts

| | |
|---|-----|
| antihopping clutch, dismantling | 121 |
| antihopping clutch, preassembling | 123 |
| autodecompressor | 115 |
| axial clearance of crankshaft and balancer shaft, measuring | 112 |
| balancer shaft drive wheel, installing | 111 |
| balancer shaft drive wheel, removing | 109 |
| camshaft bearing, changing | 117 |
| clutch cover | 108 |
| clutch, checking | 122 |
| countershaft, assembling | 128 |
| countershaft, dismantling | 125 |
| crankshaft bearing inner ring, installing | 111 |
| crankshaft bearing inner ring, removing | 109 |
| crankshaft run-out at bearing pin, checking | 111 |
| cylinder - Nikasil® coating | 112 |
| cylinder head, checking | 119 |
| cylinder, checking/measuring | 113 |
| electric starter drive, checking | 129 |
| freewheel, checking | 130 |
| freewheel, installing | 130 |
| freewheel, removing | 129 |
| left engine case section | 107 |
| main shaft, assembling | 127 |
| main shaft, disassembling | 125 |
| oil pumps for wear, checking | 115 |
| piston ring end gap, checking | 114 |
| piston, checking/measuring | 113 |
| piston/cylinder mounting clearance, checking | 115 |
| right engine case section | 106 |
| rocker arm, installing | 121 |
| rocker arm, removing | 117 |
| shift mechanism, checking | 124 |

| | |
|--|-----|
| shift shaft, preassembling | 124 |
| the conrod bearing, changing | 109 |
| timing assembly, checking | 117 |
| timing chain tensioner, preparing for installation | 116 |
| transmission, checking | 126 |
| valve spring retainer, checking | 119 |
| valve springs, checking | 119 |
| valves, checking | 119 |
| valves, installing | 120 |
| valves, removing | 118 |

Engine characteristic

| | |
|-----------|----|
| adjusting | 72 |
|-----------|----|

Engine number

7

Engine oil

| | |
|-----------|-----|
| adding | 157 |
| changing | 154 |
| draining | 154 |
| refilling | 157 |

Engine oil level

| | |
|----------|-----|
| checking | 152 |
|----------|-----|

Engine oil pressure

| | |
|----------|-----|
| checking | 153 |
|----------|-----|

Engine sprocket

| | |
|----------|----|
| checking | 64 |
|----------|----|

EPT control unit

| | |
|----------|-----|
| coding | 166 |
| flashing | 164 |

Exhaust manifold

| | |
|----------|----|
| fitting | 47 |
| removing | 47 |

F**Filler cap**

| | |
|---------|----|
| closing | 54 |
| opening | 54 |

Foot brake lever

| | |
|---------------------------|----|
| basic position, adjusting | 78 |
| free travel, checking | 78 |

Fork

| | |
|-------------------------------|----|
| Adjusting compression damping | 12 |
| Adjusting rebound | 12 |
| dust boots, cleaning | 13 |
| fork legs, bleeding | 12 |

Fork legs

| | |
|--------------------|----|
| assembling | 21 |
| checking | 20 |
| disassembling | 17 |
| fitting | 15 |
| removing | 14 |
| servicing the fork | 16 |

Fork part number

8

Fork protector

| | |
|------------|----|
| installing | 13 |
| removing | 13 |

Fork service

16

Front wheel

| | |
|----------|----|
| fitting | 59 |
| removing | 59 |

| | |
|--|----------|
| Fuel filter | |
| changing | 56 |
| Fuel pressure | |
| checking | 55 |
| Fuel, oils, etc. | 6 |
| Fuse | |
| of individual power consumer, changing | 71 |
| H | |
| Hand brake lever | |
| basic position, adjusting | 74 |
| Handlebar position | 27 |
| adjusting | 27 |
| Headlight | |
| light range, adjusting | 84 |
| Headlight bulb, changing | 86 |
| Headlight mask with headlight | |
| installing | 85 |
| removing | 84 |
| Headlight setting, checking | 84 |
| I | |
| Ignition coil | |
| secondary winding, checking | 159 |
| K | |
| Key number | 7 |
| M | |
| Main fuse | |
| changing | 70 |
| Main silencer | |
| fitting | 49 |
| removing | 48 |
| Motor drive | |
| basic setting, checking | 160 |
| basic settings, adjusting | 161 |
| Motorcycle | |
| cleaning | 179 |
| raising with the front wheel stand | 9 |
| raising with the rear wheel stand | 9 |
| raising with work stand | 10 |
| removing from work stand | 10 |
| taking off of the front wheel stand | 9 |
| taking off of the rear wheel stand | 9 |
| O | |
| Oil circuit | 152 |
| Oil filter | |
| changing | 154 |
| installing | 155 |
| removing | 155 |
| Oil screens | |
| cleaning | 154, 156 |
| P | |
| Parking light bulb | |
| changing | 85 |
| Play in throttle cable | |
| adjusting | 28 |
| checking | 27 |
| Protective treatment for winter operation | 180 |
| Putting into operation | |
| after storage | 181 |
| R | |
| Rear hub rubber dampers | |
| checking | 66 |
| Rear sprocket | |
| checking | 64 |
| Rear wheel | |
| fitting | 62 |
| removing | 62 |
| Riding sag | |
| adjusting | 32 |
| Rim run-out | |
| checking | 67 |
| S | |
| Seat | |
| mounting | 54 |
| removing | 54 |
| Service schedule | 182 |
| Servicing the shock absorber | 34 |
| Shock absorber | |
| compression damping, high-speed, adjusting | 29 |
| compression damping, low-speed, adjusting | 29 |
| damper, assembling | 41 |
| damper, bleeding and filling | 43 |
| damper, checking | 37 |
| damper, dismantling | 35 |
| damper, filling with nitrogen | 45 |
| heim joint, installing | 39 |
| heim joint, removing | 38 |
| installing | 33 |
| piston rod, assembling | 40 |
| piston rod, disassembling | 36 |
| rebound damping, adjusting | 30 |
| removing | 32 |
| riding sag, checking | 31 |
| shock absorber, servicing | 34 |
| spring preload, adjusting | 31 |
| spring, installing | 45 |
| spring, removing | 35 |
| static sag, checking | 30 |
| Shock absorber part number | 8 |
| Side cover | |
| mounting | 55 |
| removing | 54 |
| Spare parts | 6 |
| Spark plug connector | |
| checking | 158 |
| Spoke tension | |
| checking | 66 |
| Starting | 11 |
| Starting procedure | |
| for making checks | 11 |

Steering head bearing play

| | |
|-----------------|----|
| adjusting | 26 |
| checking | 25 |

Storage 181**T****Technical data**

| | |
|---------------------------------------|---------|
| chassis | 173-174 |
| chassis tightening torques | 177-178 |
| engine | 168 |
| engine - tolerance, wear limits | 169-170 |
| engine tightening torques | 171-172 |
| fork | 175 |
| shock absorber | 176 |

Tire air pressure

| | |
|----------------|----|
| checking | 60 |
|----------------|----|

Tire condition

| | |
|----------------|----|
| checking | 60 |
|----------------|----|

Type label 7**W****Warranty** 6**Wiring diagram** 184-203

| | |
|---------------------|-----|
| page 1 of 10 | 184 |
| page 10 of 10 | 202 |
| page 2 of 10 | 186 |
| page 3 of 10 | 188 |
| page 4 of 10 | 190 |
| page 5 of 10 | 192 |
| page 6 of 10 | 194 |
| page 7 of 10 | 196 |
| page 8 of 10 | 198 |
| page 9 of 10 | 200 |

Work rules 6



3206042en



02/2010 Photo: Mitterbauer



KTM-Sportmotorcycle AG
5230 Mattighofen/Austria
<http://www.ktm.com>