



---

# **SERVICE STATION MANUAL**

---

**1Q000958**

---



**MP3 530 hpe**

---

## TABLE OF CONTENTS

GENERAL STANDARDS	NORM
-------------------	------

CHECKS BEFORE DELIVERY	CON OFF
------------------------	---------

TECHNICAL DATA	DT
----------------	----

TOOLS	WORK
-------	------

MAINTENANCE	WAR
-------------	-----

ELECTRICAL SYSTEM	THEY ANL
-------------------	----------

ENGINE FROM THE VEHICLE	MOT DRIVE
-------------------------	-----------

MOTOR	AGAINST
-------	---------

BRAKE SYSTEM	BRAKE
--------------	-------

COOLING SYSTEM	COOL
----------------	------

BODY	IN THE WARS
------	-------------



TABLE OF CONTENTS

GENERAL STANDARDS	NORM
-------------------	------

**General information**

This section contains general information about using the manual and the vehicle as well as important safety instructions.

**IMPORTANT WARNINGS AND NOTES**

Each symbol has a precise meaning as shown below.

- NOTE: - This symbol indicates health risks to the operator or those nearby if the procedures described are not carried out properly become.
- ATTENTION:- This symbol indicates that the component being worked on is can be damaged if the described procedures are not carried out properly be guided.
- NOTE:- This paragraph contains additional instructions regarding the ongoing Procedures so that the operations can be carried out effectively.

**REACH REGULATION WARNINGS:**

To protect the health and safety of the PROFESSIONAL CUSTOMER, as intended through:

- Regulation (EC) No. 1907/2006 (REACH);
- Directive 2000/53/EC (END of LIFE VEHICLES);
- SCIP Database Directive (Article 9(1)(i)) of the Waste Framework Directive, amended modified by Directive 2018/851

The technical personnel working during ordinary and extraordinary maintenance are obliged to always wear the following personal protective equipment:

1. Chemical protection gloves unless the specific type is specifically stated is given, or if necessary, specific gloves based on the treatment to be treated fabric;
2. Mask, possibly of a chemically active type, if expressly requested;
3. Safety glasses.

The foregoing applies as an alternative to the provisions of the other regulations and those in the one laws applicable in individual countries. Regarding the use of other PPE provided by the Occupational safety is regulated, the current regulations on this subject apply.

**GENERAL SAFETY INSTRUCTIONS:**

1. Always wear safety glasses and appropriate clothing.
2. Always use a safety support when working under the vehicle.
3. Verify that the ignition key is always in the OFF position unless otherwise specified in the procedure  
ben.
4. Apply the handbrake (if equipped) before starting any work on the vehicle.
5. Run the engine only in well-ventilated areas to avoid exposure to carbon monoxide  
to avoid dangers.
6. When the engine is running, maintain a safe distance from moving parts, especially  
fans and belts.
7. To prevent serious burns, avoid contact with hot metal parts such as radiators  
Avoid exhaust manifold, exhaust pipe, catalytic converter and muffler.
8. Do not smoke during maintenance work.
9. To avoid possible injuries, remove rings, watches,  
Take off jewelry and loose clothing.
10. Keep your hands and other objects away from the radiator fan blades (if equipped).  
keep away!
11. The radiator fan (if equipped) is mounted on the radiator and can be installed due to an increase  
of the coolant temperature at any time. It is important to check that the engine is cool  
The fan has been disconnected from the wiring before starting work.

The units of measurement used in this manual are referred to as SI UNITS (in international system of units). Example: 24.5 ÷ 34.3 Nm

---

TABLE OF CONTENTS

CHECKS BEFORE DELIVERY

CON OFF

The ASR system is a driver assistance system, that the driver during acceleration maneuvers is supported, especially on surfaces with less traction and under conditions that cause the rear wheel to suddenly slip. The ASR takes effect under these circumstances automatically and reduces the power from the engine to maintain the given performance within the confinement of the predetermined limit, whereby it is important for maintaining the stability of the vehicle contributes.


**WARNING**

**THE ASR SYSTEM IS BASED ON DETECTION OF THE SPEED DIFFERENCE BETWEEN FRONT AND REAR WHEELS. SO THAT THE SYSTEM CAN MAINTAIN MAXIMUM EFFICIENCY UNDER ALL CONDITIONS, IT IS NECESSARY CALIBRATION TO BE PERFORMED EVERY TIME YOU HAVE CHANGED ONE OF THE TIRES. TO CALIBRATE THE CONTROL UNIT THE BELOW PROCEDURES INDICATED.**

- BUTTON ASR «1»: activation / deactivation
- ASR WARNING LAMP «2»: Function

**Indicator light flashing mode:**

- Switched off when the vehicle is moving: This condition means the system works, but is not active (normal condition).
- Fast flashing when the vehicle is moving: This condition means the system works and is active (low grip and intervention to reduce engine power); special caution is recommended because the limit of liability has been exceeded; Bring the vehicle back to safety conditions by slowly releasing the throttle grip.
- Permanently switched on when the vehicle is moving: This condition means the system is deactivated and takes effect when adhesion is lost.



- If deactivation is intentional  
was taken (pressure of the corresponding  
button «1» for longer than 1 second  
de), we recommend the system like this  
to turn it back on as quickly as possible  
ten.
- If deactivation is NOT done  
is wanted, there is a malfunction in the ASR  
before: In this case the Diag  
nose and the reactivation of the  
system.

To ensure maximum safety of the vehicle  
We definitely recommend this  
to keep the system active. Deactivation could  
only be necessary if you click on sub  
foundations with extremely low traction  
(mud, snow) starts on which the one  
The ASR stopped the vehicle from moving  
could prevent.

**ANNOTATION**

WHEN STARTING THE VEHICLE, THE ASR WARNING LIGHT  
FLASHES AT THE SAME FREQUENCY  
ABS WARNING LAMP, INDICATING A DIAG NOSE PHASE OF  
THE SYSTEM. IF NO ERRORS  
IF PRESENT, BOTH WARNING LIGHTS TURN ON  
AT THE SAME TIME OFF AS SOON AS YOU EXCEED 5 km/h.

**WARNING**

THE ASR SYSTEM IS ACTIVATED EVERY TIME  
THE IGNITION LOCK IS TURNED TO «ON».  
IF DEACTIVATED BY THE USER, THE ASR SYSTEM ONLY KEEP  
THE INACTIVE STATE  
WHEN THE VEHICLE IS TURNED ON WITH THE SWITCH  
TURNING OFF THE ENGINE; AT  
THE FOLLOWING ROTATION OF THE IGNITION LOCK, THE  
ASR SYSTEM AUTOMATICALLY ACTIVATES.

**DANGER**

IT IS NOTED THAT THE DRIVER'S ASSISTANCE SYSTEMS CANNOT  
CHANGE THE PHYSICAL LIMITS AND CANNOT PROVIDE  
CORRECT POWER MANAGEMENT

REPLACE TRACK AND IN THE CURVE. THE  
VEHICLE SHOULD ALWAYS BE USED TO THE EXTENT  
CAUTION AND COMPLY WITH THE LAWS  
BE USED.

## DANGER



AT LOW SPEED, IE BELOW 5 km/h  
(3 mph), THE ASR SYSTEM IS NOT EFFECTIVE.  
BE PARTICULARLY CAREFUL WHEN ACCELERATING FROM A  
STOPPING WHEN GROUND IS LOW, PARTICULARLY FOR THE  
FIRST METERS.

## ANNOTATION

IN CASE OF UNEVEN ROAD SURFACE, SHORT ACTIVATIONS  
OF THE ASR SYSTEM MAY OCCUR. THIS IS PART OF THE  
VEHICLE'S NORMAL OPERATIONAL CONDITION.

## WARNING



THE ACTIVE ASR SYSTEM PREVENTS THE REAR WHEEL FROM  
REACHING HIGH ROTATION SPEEDS,  
WHEN THE VEHICLE IS BACKED ON THE MAIN STAND.

IT IS RECOMMENDED THAT YOU DO NOT CONTINUE USING  
THE THROTTLE IN THIS PARTICULAR CONDITION AS THIS WILL  
CAUSE ERROR SHUTDOWNS AND/OR DAMAGE  
CAN LEAD TO THE CATALYSTS.

## DANGER



IN CASE OF A MALFUNCTION OF THE BATTERY, THE ABS - ASR  
SYSTEM WILL SWITCH OFF.

## DANGER



POOR MAINTENANCE OF THE TIRES  
MAY CAUSE MALFUNCTIONS IN THE ASR SYSTEM.  
EVEN WITH REPEATED INTERVENTIONS OF THE ASR  
ROAD SURFACE WITH GOOD ADHESION OR IF  
WHEN YOU GIVE IT A LITTLE THROTTLE, THE WEAR AND/OR  
PRESSURE OF THE TIRES MUST BE CHECKED FIRST.

The status of the ASR system (activated/deactivated  
fourth) is also shown on the digital display when  
the Vehicle CONFIGURATION menu is selected  
(see section “**Digital display**”).





HOW THE ASR WARNING LAMP WORKS

STATUS ASR-SYSTEM	ASR WARNING LAMP WHEN OFF ENGINE OR KEY ON«ON»	ASR WARNING LAMP WITH THE ENGINE RUNNING AND DRIVING VEHICLE	ASR DURING DRIVING IN OPERATION (CONDITION LOWER GROUND GROUND)
ASR ACTIVE and calibrated	«ASR» symbol: flashes slowly at 1 Hz	«ASR» symbol: Off tet	«ASR» symbol: flashes quickly 5 Hz
ASR ACTIVE not calibrated		«ASR» symbol: lights up permanently	«ASR» symbol: flashes quickly 5 Hz
ASR intentionally deactivated	«ASR» symbol: lights up permanently	«ASR» symbol: lights up permanently	
ASR does not work (malfunction)	«ASR» symbol: lights up permanently	«ASR» symbol: lights up permanently	
ASR programming phase (successful)		«ASR» symbol: flashes slowly at 1 Hz; at the next start of the motor, symbol switched off if the programming is successful.	
ASR-Programmierphase (not successful)		«ASR» symbol: lights up permanently the next time you start the Motors if the programming was not successful.	

CALIBRATION PROCEDURE ASR SYSTEM

Calibrate the ASR system before driving the vehicle

is delivered to the customer. It is advisable,

the procedure also after the replacement

one or more tires.

- Wait until the diagnostic phase of the systems ASR and ABS is completed;



- Start the engine and drive in a short straight line

Distance on a flat road at more than 5 km/h

(3.1 mph) and the blinker goes out

Wait for the ABS warning light to turn off. If the

Tires need to be changed, wait until

The ASR warning light also stops flashing.

- Stop and let the engine idle at least

Run for 5 seconds ;


- Press the ASR «1» button and select one of the

Brake lever pulled for at least 7 seconds

hold on.



- **Activating** the process for learning the wheel diameter or for ASR calibration is indicated by the ASR control lighting up. Lamp «2» confirms with slow flashes tight.
- **At a constant speed of 30÷40 km/h (18.6÷24.8 mph)** accelerate and hold this **for at least 8 seconds**. The Bei maintaining vehicle speed in the correct range to complete the procedure is indicated by faster flashing of the ASR con Troll lamp «2» confirmed.



- **The end of the process** is marked by the sale. The ASR indicator lamp «2» is displayed and the ASR system is now functional.
- **To save the process, the engine** by turning the ignition key to the position. Switch off "OFF" and wait at least 60 seconds before turning it to «ON» again. Wait until a gear is engaged.



- **Complete the process within 5 minutes** when the ASR indicator light «2» lights up steadily remains, it means that the procedure failed. Therefore, the calibration process of the ASR must be repeated until a positive result is obtained. Regarding the ASR indicator light after detection:

- Procedure OK: ASR indicator light OFF and system active. If the ignition switch is... next time it is set to "ON", the new wheel diameter will be saved.
- Procedure failed: ASR INDICATOR LAMP SOLID ON and system active (for safety) with previously recorded wheel diameter value or standard value (if never previously recorded).

#### ANNOTATION

**HOWEVER, THE SYSTEM IS ABLE TO PERFORM AN AUTOMATIC CALIBRATION AFTER A TIRE CHANGE.**

## Aesthetic control

### Aesthetic control:

- Lack
- Fitting the plastic parts together
- scratches

---

- Dirt

---

## **Check torques**

### **Control of torques**

- Safety torques

- Fastening screws

#### **Safety torques:**

- Rear shock absorber top mount
  - Lower mounting rear shock absorbers
- Front shock absorber top mount
  - Lower mounting front shock absorbers
  - Fastening slide rods
  - Fastening brake calipers
  - Fastening screws front wheels
  - Front wheel axle nuts
- Rear wheel axle nut
  - Fasteners swingarm frame - engine
  - Handlebar fastening nut
  - Lower threaded ring on side steering tubes
- Upper threaded ring on side steering tubes
  - Lower threaded ring middle steering tube
- Upper threaded ring middle steering tube
  - Constant velocity joints

---

## **Electrical system**

- Battery
- Main switch
- Headlights: high beam, low beam, parking lights (front and rear) and the corresponding controls to shine
- Headlight adjustment in accordance with applicable laws
- Brake light switch on front and rear brakes and corresponding brake light lamp
- Turn signals and indicator control
- Instrument lighting
- Instruments: Fuel level gauge and water temperature gauge
- Indicator lights on the instrument unit
- Horn
- Electric starting

## MP3 530 hpe

Checks before delivery

- Switch off the engine using the emergency stop switch
- Electric opening of the seat with remote control
- Lock - Unlock Button Roll Lock System **TO OBTAIN**

**BEST PERFORMANCE, THE BATTERY MUST BE FULLY CHARGED BEFORE USE. INADEQUATE BATTERY CHARGE PRIOR TO FIRST SET AND LOW BATTERY FLUID LEVEL WILL RESULT IN PREMATURE BATTERY AGING.**

### **DANGER**

**WHEN INSTALLING THE BATTERY, ATTACH THE PLUS CABLE FIRST AND THEN THE NEGATIVE CABLE.**

### **WARNING**

**THE BATTERY ELECTROLYTE IS TOXIC AND CAN CAUSE SERIOUS BURNS. IT CONTAINS SULFURIC ACID. CONTACT WITH EYES, SKIN AND CLOTHING ABSOLUTELY AVOID.**

**IF IN EYES OR SKIN, RINSE WITH PLENTY OF WATER FOR 15 MINUTES AND THEN IMMEDIATELY SEEK A DOCTOR.**

**IF TAKING THE LIQUID, IMMEDIATELY DRINK LARGE AMOUNTS OF WATER OR VEGETABLE OIL. NOTIFY A DOCTOR IMMEDIATELY.**

**BATTERIES GENERATE EXPLOSIVE GASES; KEEP AWAY FROM OPEN FLAMES, SPARKS AND LIT CIGARETTES. WHEN CHARGING BATTERIES IN CLOSED ROOMS, THE ROOMS MUST BE WELL VENTILATED. ALWAYS WEAR SAFETY GLASSES WHEN WORKING NEAR BATTERIES.**

**KEEP AWAY FROM CHILDREN.**

### **DANGER**

**NEVER USE FUSES OF GREATER CAPACITY THAN THE STATED CAPACITY. USE OF AN INCORRECT PERFORMANCE FUSE CAN CAUSE DAMAGE TO THE VEHICLE AND IS A FIRE HAZARD.**

---

## Level controls

### **Level controls:**

- Brake fluid level
- Fluid level Roll-Lock system - Oil level rear wheel transmission
- Engine coolant level
- Engine oil level

---

## Test drive

### **Test drive:**

- Cold start
- Function of the instruments
- Reaction to accelerating
- Stability during acceleration and braking
- Front and rear brake function
- Efficiency parking brake
- Front and rear shock absorber function

- Excessive noise
- Efficiency locking and unlocking system Roll Lock

---

## Static control

### Static check after the test drive:

- Start with a warm engine
- Idle stability (when turning the handlebars) •

Smooth rotation of the steering

- Possible leakage of liquids
- Function of the cooling fan

### **DANGER**

**TIRE PRESSURE MUST BE CHECKED AND ADJUSTED WHEN TIRES ARE COLD.**

### **DANGER**

**DO NOT EXCEED THE SPECIFIED TIRE PRESSURE AS THE TIRE MAY BURST.**

---

## Functional control

Functional check:

- Hydraulic brake system: lever travel
- Clutch: Check correct functioning
- Motor: General functional check and no excessive noise
- Other: Check vehicle documents, check frame number and engine number, on-board tools,

Attaching the license plate, checking locking devices, checking tire pressure, installing

Rearview mirrors and any accessories

---

## Special work for the vehicle

### TOOLS SUPPLIED

The on-board tool kit consists of:

- Key for adjusting the shock absorbers tension;
- Fuses removal tool.

The on-board tools are located in the helmet compartment.



**LICENSE PLATE HOLDER****DANGER****ANNOTATION**

**ONLY THE LICENSE PLATE HOLDER IN THE THE VEHICLE IS SUPPLIED WITH ASSEMBLY AS YOU EQUIPPED WITH THE APPROVED MANDATORY REAR SPOTLIGHTS.**

**Change unit of measurement**

When the **SETTINGS** function is called

by briefly pressing the **"UP"** or buttons

Scroll through **"DOWN"** and open the **"CONFIG**

**RATION"** by briefly pressing the **"SET"** button

call.

By briefly pressing the **"UP"** or buttons

**"DOWN"** select the parameter:

- Speed: The desired one  
Select unit of measurement: Km/h, mph  
mpg ENG / mph mpg USA / ON, OFF.
- Temperature: The desired measurement  
select degree: degrees C°, F° / ON, OFF.



Select the desired parameter by briefly pressing  
press the **"SET"** button .

**Setting the clock**

When the **SETTINGS** function is called

by briefly pressing the **"UP"** or buttons

Scroll through **"DOWN"** and open the **"CONFIG**

**RATION"** by briefly pressing the **"SET"** button


call.

By briefly pressing the **"UP"** or buttons

**"DOWN"** select the desired parameter

only:

- Clock setting (hours, minutes, Leave)
- 12h
- 24 hours



Checks before delivery

**MP3 530 hpe**

- 
- Leave

Select the desired parameter by briefly pressing  
press the **"SET"** button .

---

TABLE OF CONTENTS

TECHNICAL DATA

DT



This section describes general features of the vehicle.

---

## **Regulations**

This section contains the general regulations for safety and maintenance work on the vehicle stuff played back.

---

## **Safety regulations**

- Ensure there is adequate ventilation in the workshop when working on the vehicle while it is running  
Engine must be carried out. The rooms must be well ventilated. If necessary, have to  
Appropriate extraction systems must be used. Never run the engine indoors  
sen. The exhaust fumes are toxic.
  - The electrolyte contains sulfuric acid. Eyes, clothing and skin must be protected. Schwe  
Felic acid is highly corrosive. In case of contact with eyes or skin, rinse immediately with plenty of water  
see a doctor immediately.
  - The battery produces hydrogen. Hydrogen gas can be highly explosive. Especially during  
When charging the battery, do not smoke near the battery, keep away from naked flames and have fun  
avoid formation of marks.
  - Gasoline is extremely flammable and can be explosive under certain conditions. In Ar  
Smoking is not allowed in the working area, keep open flames away and avoid the formation of sparks.
  - The brake pads must be cleaned in well-ventilated rooms. The compressed air jet must  
be directed so that the dust created by the abrasive material is not inhaled. The  
Brake pads do not contain asbestos, but inhaling the dust is still harmful.
- 


## **Maintenance instructions**

- Only original PIAGGIO spare parts and the lubricants recommended by the manufacturer  
turn around. Non-original or unsuitable spare parts can damage the vehicle.
  - Only use special tools designed for this vehicle.
  - When reinstalling, always use new gaskets, sealing rings and split pins.
  - After removing the individual components, they must be covered with a non-flammable or flame-retardant material  
Cleaned with solvents. All work surfaces, with the exception of conical connections,  
Lubricate before reassembly.
  - After reassembly, check whether all components are installed correctly and function properly  
kidneys.
  - Use only metric tools for removal, overhaul and reassembly. The  
Screws, nuts and bolts of the metric system are not the same as those of the English inch system  
tems interchangeable. The use of unsuitable tools or parts can cause damage to the  
Drive vehicle.
-

- When working on the electrical system, pay particular attention to the correct cable connections
- Pay attention when connecting ground and battery.

Chassis and engine number

The frame and engine numbers consist of a prefix and a number, each on are stamped on the frame or the engine. These numbers must be included when ordering from Er parts of the sentence must always be specified. Check Check whether the frame number on the vehicle matches the Number in the vehicle documents matches true.




DANGER



A CHANGE OF THE FRAME NUMBER IS A PUNISHMENT AND MAY, AMONG OTHERS, RESULT IN CONFUSION OF THE DRIVING A VEHICLE.


Frame number

To read the frame number «A» , open it the access flap to the tank cap and the Lift the fuel drip pan flap.



Engine number

The engine number «B» is near the bottom Rear left shock absorber bracket punched.



CHASSIS AND ENGINE NUMBER

Technical information	Description/Value
Frame prefix	ZAPTD3100
Engine prefix	TD31M

## Vehicle data


### VEHICLE DATA

Technical information	Description/Value
Frame	Made of steel pipes and pressed steel sheet
Front suspension	Roll system with parallelogram suspension, with two die-cast aluminum arms, two side tubes and shock absorbers with hydraulic locking system
Rear suspension	Two gas shock absorbers with preload control.
Front brake	Double hydraulic disc brake Ø 258 mm with brake lever on the right of the handlebar; ABS with brake assist.
Rear brake	Hydraulic disc brake Ø 240 with brake lever on the left handlebars; ABS with brake assist.
Combination brake system	Works on 3 discs at the same time, hydraulically via the pedal operated on the running board; ABS with brake assist.
Wheel rim gene type	Made of light metal.
Front rims	13" x 3,00
Rear wheel rim	14" x 4,50
Front tires	Tubeless 110/70 - 13" 48S
rear tire	Tubeless 140/70 - 14" 68S
Tire pressure front tires	2 bar
Rear tire pressure (with passenger)	2,4 (2,6) bar
Vehicle mass ready to drive	280 Kg
Technically permissible maximum mass at full load	460 Kg
Battery	12V-12Ah

## Engine data

### ENGINE DATA

Technical information	Description/Value
Type	Single cylinder 4-stroke engine
displacement	530 cm³
Bore x stroke	97,5 x 71 mm
Compression ratio	11,5 ± 0,5 : 1
Engine idle speed	1,600 ± 100 U/Min
Valve control	Four valve, single, chain controlled overhead camshaft.
Valve clearance (cold)	Suction: 0.15mm Outlet: 0.15mm
Maximum Performance	32,5 kW bei 7.250 U/min
maximum torque	50,0 Nm bei 5.250 U/min
drive	Continuously variable automatic transmission with expansion discs and Torque support, V-belt, automatic self-ventilating dry centrifugal clutch, drive compartment with cooling fan.
	Reverse gear with electric actuation.
Rear wheel transmission	With gears in oil bath.
lubrication	Engine lubrication with chain-controlled cam pump (in the housing) and double mesh and paper filter.
cooling	With pressure circulation of liquid.
Motorstart	Electric
ignition	Inductive electronic high-performance ignition integrated with the injection, variable ignition timing advance, separate ignition coil and double spark plug.
Pre-ignition spark plug	With three-dimensional map controlled by the control unit NGK MR7BI-8 / MR8BI-8
Electrode gap	0,7 ÷ 0,9 mm
care	Electronic injection with electric fuel pump.
care	Bleifreies Benzin max. E10 (ROZ 95)
Exhaust	Absorption exhaust with catalytic converter and lambda sensor.
Emissions standard	EURO 5

**Dimensions and weight****Filling quantities****FILLING QUANTITIES**

Technical information	Description/Value
Engine oil	1,7 Liter
Gear oil	250 cm³
coolant	~ 1,8 l
Petrol tank	13,7 ± 0,5 l

**Torque guidelines****FRONT BRAKE**

Name	Torque guidelines in Nm
Connection of the brake caliper line to the side steering tube	25 ÷ 28 Nm (18 ÷ 21 lb*ft)
Connection of the brake line to the brake caliper	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Connection line - brake pump	20 ÷ 25 Nm
Brake caliper connecting screw	22 ÷ 27 Nm (16 ÷ 20 lb*ft)
Fastening screw brake caliper to bracket	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Brake fluid bleeder screw	8 ÷ 12 Nm (5.9 ÷ 9 lb*ft)
Front brake disc screws	8 ÷ 10 Nm (5.9 ÷ 7 lb*ft)

**REAR BRAKE**

Name	Torque guidelines in Nm
Adjusting nut for parking brake cable	10 Nm
Brake line connection on the rear brake caliper	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Connection line - brake pump	20 ÷ 25 Nm

Name	Torque guidelines in Nm
Connection pipe-hose screws	13 ÷ 18 Nm (10 ÷ 13 lb*ft)
brake disc rear wheel brake (°)	5 ÷ 6,5 Nm (3.7 ÷ 4.8 lb*ft)
Fastening screws for the rear brake caliper	41,5 ÷ 51,5 Nm (31 ÷ 38 lb*ft)
Fastening screws for the retaining bracket Lines	6 ÷ 8 Nm
Fastening screws for the rear brake caliper cable Parking	6 ÷ 10 Nm
brake - Fastening screw for the brake caliper on the bracket (°)	24 ÷ 27 Nm (18 ÷ 20 lb*ft)

(°) Apply LOCTITE screw locking medium strength type 243.

### **PEDAL-COMBI BRAKES**

Name	Torque guidelines in Nm
Connection line - brake pump	20 ÷ 25 Nm
Fastening screw brake pedal to the frame	20 ÷ 25 Nm
Fastening screw brake fluid reservoir combination brake with	1 ÷ 1,7 Nm

### **ABS SYSTEM**

Name	Torque guidelines in Nm
Connections cables - ABS control unit	19 ÷ 21 Nm
Connections lines - ABS distributor	20 ÷ 25 Nm
Fastening screws ABS control unit to bracket	6 ÷ 10 Nm
Fastening screws holding plates rigid cables ABS	4 ÷ 6 Nm
Fixing screw for ABS control unit holder	6 ÷ 10 Nm
ABS sensor tensioning screws	6 ÷ 10 Nm (4.4 ÷ 7 lb*ft)

### **FRONT SUSPENSION**

Name	Torque guidelines in Nm
Fastening nuts constant velocity joints	18 ÷ 20 Nm (13 ÷ 15 lb*ft)
Bolzenmutter Lenkarm	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Lower shock absorber mount	19 ÷ 26 Nm (14 ÷ 19 lb*ft)
Upper shock mount	19 ÷ 29 Nm (14 ÷ 21 lb*ft)
Attachment sliding shaft suspension locking system	6,5 ÷ 10,5 Nm (4.8 ÷ 8 lb*ft)
Attachment of electric motor to roll lock device	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Fastening the pump bolt to the roll-lock device	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Attachment of pump to roll-lock device	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Fastening potentiometer to roll lock device	8 ÷ 10 Nm (5.9 ÷ 7 lb*ft)
Fastening the sensor to the Roll-Lock saddle	2,5 ÷ 2,9 Nm (1.8 ÷ 2.1 lb*ft)
Lower threaded ring of the side steering tube	12 ÷ 15 Nm (9 ÷ 11 lb*ft)
Upper threaded ring of the side steering tube	20 ÷ 24 Nm (15 ÷ 18 lb*ft)
Pressure regulator on brake distributor	18 ÷ 20 Nm (13 ÷ 15 lb*ft)
Connection to pump for roll lock device	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Connection line brake caliper Roll Lock system on the side steering tube	25 ÷ 28 Nm (18 ÷ 21 lb*ft)
Pipe end pieces on brackets for steering bearings	7 ÷ 11 Nm (5.2 ÷ 8 lb*ft)
Cable control saddle roll lock	10 Nm
Fastening screw sliding shaft on the shock absorber	45 ÷ 50 Nm (33 ÷ 37 lb*ft)
Connecting screws arms	45 ÷ 50 Nm (33 ÷ 37 lb*ft)
Mounting screws arms on side steering tubes	45 ÷ 50 Nm (33 ÷ 37 lb*ft)
Mounting screws arms on the middle steering tube	45 ÷ 50 Nm (33 ÷ 37 lb*ft)
Fastening screws connecting flange wishbone	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Mounting screws brake caliper suspension locking system	20 ÷ 25 Nm (15 ÷ 18 lb*ft)
Front wheel fastening screws	19 ÷ 24 Nm (14 ÷ 18 lb*ft)
Fastening screws brake disc segment for the suspension locking system	20 ÷ 25 Nm (15 ÷ 18 lb*ft)

### **REAR SUSPENSION**

Name	Torque guidelines in Nm
Upper shock mount	33 ÷ 41 Nm (24 ÷ 30 lb*ft)
Lower shock absorber mount	33 ÷ 41 Nm (24 ÷ 30 lb*ft)
Shock absorber retaining bracket - housing	20 ÷ 27 Nm (15 ÷ 18 lb*ft)
Rear wheel axle	104 ÷ 126 Nm (77 ÷ 93 lb*ft)
Exhaust mounting arm mounting screw	27 ÷ 30 Nm (20 ÷ 22 lb*ft)

**STEERING**

Name	Torque guidelines in Nm
Lower steering tube threaded ring (middle steering tube)	10 ÷ 12 Nm (7 ÷ 9 lb*ft)
Upper steering tube threaded ring (middle steering tube)	32,5 ÷ 40 Nm (24 ÷ 30 lb*ft)
Handlebar mounting screw	50 ÷ 55 Nm (37 ÷ 41 lb*ft)
Fixing screws U-bolt handlebar gear unit	7 ÷ 10 Nm (5.2 ÷ 7 lb*ft)

**FRAME**

Name	Torque guidelines in Nm
Swingarm adjustment bushing	5 ÷ 7 Nm (3.7 ÷ 5.2 lb*ft)
Fastening bolts engine arm - frame arm	32,5 ÷ 40 Nm (24 ÷ 30 lb*ft)
Swingarm adjustment bushing nut	54 ÷ 60 Nm (40 ÷ 44 lb*ft)
Bolt swingarm - engine	98 ÷ 118 Nm (72 ÷ 87 lb*ft)
Bolt frame - swingarm	54 ÷ 60 Nm (40 ÷ 44 lb*ft)
Main stand fixing bolts	31 ÷ 39 Nm (23 ÷ 29 lb*ft)

**EXHAUST**

Name	Torque guidelines in Nm
Exhaust heat protection mounting screw	4 ÷ 5
Exhaust mounting screw on bracket	27 ÷ 30
Tightening the lambda sensor on the exhaust manifold	20 ÷ 30
Tightening the exhaust manifold-exhaust connector	12 ÷ 14
Fastening clamp for exhaust manifold - exhaust silencer	15,5 ÷ 18,5

**LUBRICATION**

Name	Torque guidelines in Nm
Oil pump cover screws	0,7 ÷ 0,9 Nm (0.52 ÷ 0.66 lb*ft)
Oil pump fastening screws to the housing	5 ÷ 6 Nm (3.7 ÷ 4.4 lb*ft)

**CYLINDER KIT AND VALVE TIMING**

Name	Torque guidelines in Nm
spark plug	11,0 ± 1,0
Screws cylinder head - cylinder	11,0 ± 1,0
Fastening nuts cylinder head - cylinder	13 Nm + 90° + 90°
Mounting nuts cylinder head exhaust/intake	10 ÷ 12 Nm (7 ÷ 9 lb*ft)
Cylinder head lubrication control nozzle	5 ÷ 7 Nm (3.7 ÷ 5.2 lb*ft)
Coolant temperature sensor - cylinder head	22,0 ± 1,0
Injector mounting screw	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Decompression device screw	7 ÷ 8,5 Nm (5.2 ÷ 6.3 lb*ft)
Fastening screw chain tensioner pad	10 ÷ 14 Nm (7 ÷ 10 lb*ft)
Pick-up housing	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Screws intake manifold	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Valve cover fastening screws	7 ÷ 9 Nm (5.2 ÷ 6.6 lb*ft)
Throttle body fastening screws	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Cylinder head mounting screws	10 ÷ 12 Nm (7 ÷ 9 lb*ft)
Fastening screws for camshaft bracket	4 ÷ 6 Nm (3 ÷ 4.4 lb*ft)
Chain tensioner screw	4,5 ± 0,5 Nm
Fastening screws clamping device	11 ÷ 13 Nm (8 ÷ 10 lb*ft)

**DRIVE COVER**

Name	Torque guidelines in Nm
Nut guided pulley	92 ÷ 100 Nm (68 ÷ 74 lb*ft)
Drive pulley nut	160 ÷ 175 Nm (118 ÷ 129 lb*ft)
Fasteners M8 drive cover	23 ÷ 26 Nm (17 ÷ 19 lb*ft)
Fasteners M6 drive cover	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Threaded ring coupling	65 ÷ 75 Nm (48 ÷ 55 lb*ft)
Screws air baffle	7,0 ± 1,0 Nm
Screws water pump cover	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Noise protection cover - drive cover	7,0 ± 1,0 Nm
Alternator cover screws	11 ÷ 13 Nm (8 ÷ 10 lb*ft)

**FLYWHEEL COVER**

Name	Torque guidelines in Nm
Chain tensioner support complete chain guide - housing	3,5 ± 0,5 Nm
Flywheel mounting nut	115 ÷ 125 Nm (85 ÷ 92 lb*ft)
Fasteners stator	8 ÷ 10 Nm (5.9 ÷ 7 lb*ft)
Fastening screws for the blow-by line	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Fastening screws for freewheel to alternator	13 ÷ 15 Nm (10 ÷ 11 lb*ft)
Stator wiring fixing screws	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Screws holder protective wall	6,0 ± 1,0 Nm
Minimum oil pressure sensor	12 ÷ 14 Nm (9 ÷ 10 lb*ft)
Impeller water pump	5,0 ± 1,0 Nm

**ENGINE CASE AND CRANKSHAFT**

Name	Torque guidelines in Nm
Countershaft fastening nut	25 ÷ 29 Nm (18 ÷ 21 lb*ft)
Engine oil	12 ÷ 16 Nm (9 ÷ 12 lb*ft)
filter oil drain plug engine oil	24 ÷ 30 Nm (18 ÷ 22 lb*ft)
Motor housing connecting screws	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Oil pump screws	5 ÷ 6 Nm (3.7 ÷ 4.4 lb*ft)
Fastening screws gear to crankshaft	12,0 ± 1,0 Nm
Screws partition oil pump room	3,5 ± 0,5 Nm

**COOLING**

Name	Torque guidelines in Nm
Impeller water pump	5,0 ± 1,0 Nm
Screws water pump cover	3 ÷ 4 Nm (2.2 ÷ 3 lb*ft)
Bleed screw	3,5 ± 0,5 Nm


**THROTTLE CABLES**

Name	Torque guidelines in Nm
Adjusting nuts cables	5 ÷ 6 Nm
Fastening screw cover on the throttle body	6 ÷ 10 Nm

**REVERSE GEAR SYSTEM**

Name	Torque guidelines in Nm
Reverse gear control bushing ring nut. Reverse gear	66 ÷ 74 Nm (49 ÷ 55 lb*ft)
system oil filler plug	15 ÷ 17 Nm (11 ÷ 13 lb*ft)
Reverse gear cover screws	11 ÷ 13 Nm (8 ÷ 10 lb*ft)
Reverse gear motor mounting screws	11 ÷ 13 Nm (8 ÷ 10 lb*ft)

**Revision dates****CLASSIFICATION BOLT/DECOMPRESSION MASS - CAMSHAFT**



**CLASSIFICATION DECOMPRESSION MASS (BOLT) - CAMSHAFT**

	Class D (black) Ø	Class E (light blue)	Class F (light blue)
Decompression mass (bolts)	6.75 ± 0.004	Ø 6.60 ± 0.004	Ø 6,45 ± 0,004
camshaft	0,81 - 0,88	0,88 - 0,96	0,96 - 1,03

**COMBINATION CLASSES**

	Decompression mass (Bolt) - Class D	Decompression mass (Bolt) - Class E	Decompression mass (Bolt) - Class F
Cam Axle - Class D	D - D	NO	NO
Cam Axle - Class E	NO	AND AND	NO
Cam Axle - Class F	NO	NO	F - F

**Bolt/decompression compound**

- Class identification: D - E - F
- Stamping of the class identifier: bolt their





**camshaft**

- Class identification: D - E - F
  - Stamping of the class identifier: camshaft view of the valve
- control gear ring

**ANNOTATION****THE CLASSES OF TWO COMPONENTS MUST BE IDENTICAL.**

Check the pressure value in the combustion chamber in the starter motor to ensure that it is within the following listed acceptance limits, as well as the determination of the engine drive speeds.

The test must be carried out with a charged battery and ambient temperature

Use a pressure gauge to measure the (relative) pressure value on the drive and the corresponding motor speeds.

**PRESSURE TEST COMBUSTION CHAMBER IN THE STARTING DRIVE**

	Engine speed drive (rpm) 415	Relative pressure (bar)
MIN		5,2
MAX	550	7,2

**Built-in games****cylinder head****Operating limits of the valves**


- Measure the diameter of the valve stem at the three locations shown in the figure.

**STANDARD DIAMETER**

Technical information	Description/Value
Suction:	4,987 ÷ 4,972 mm
Outlet:	4,975 ÷ 4,960 mm

**SMALLEST ALLOWABLE DIAMETER**

Technical information	Description/Value
Suction:	4,96 mm
Outlet:	4,945 mm




- Measure the bend of the valve stem. Plus that  
Place the valve on a V-shaped holder and the  
Measure the bend with a dial indicator.

**Technical specifications**

**Permissible limit:**

0,1 mm




- The rounding of the valve head with a dial indicator  
measure. To do this, the dial indicator must be at right angles  
be attached to the valve head. The valve  
is rotated on a V-shaped holder.

**Technical specifications**

**Permissible limit:**

0,03 mm



**Guide clearance - valve clearance**

- After measuring the diameter of the valve guide and the diameter of the valve stem, the  
Calculate the fitting clearance between the valve guide and the stem.

**SUCTION**

Technical information	Description/Value
Standard installation clearance:	0,013 ÷ 0,04 mm
Permissible limit:	0,08 mm

**OUTLET**

Technical information	Description/Value
Standard installation clearance:	0,025 ÷ 0,052 mm
Permissible limit:	0,09 mm



STANDARD LENGTH OF VALVE

Technical information	Description/Value
Suction:	95,0 ± 0,3 mm
Outlet:	94,2 ± 0,3 mm

Seat - valve mating surface


Technical specifications

Default value:


1 ÷ 1,3 mm

Permissible limit:

1,6 mm



Camshaft treads




STANDARD DIAMETER

Technical information	Description/Value
Tread A Ø:	42 - 0,060 -0,085 mm
Tread B Ø:	20 - 0,020 -0,041 mm

SMALLEST ALLOWABLE DIAMETER

Technical information	Description/Value
Tread A Ø:	41,910 mm
Tread B Ø:	19,940 mm

## Height cam

STANDARD HEIGHT

Technical information	Description/Value
Suction	31,982 mm
outlet	31,297 mm

ALLOWABLE LIMIT

Technical information	Description/Value
Suction	31,747 mm
outlet	31,064 mm
Standard-Axialspiel:	0 ÷ 0,22 mm
Largest permissible axial play:	0,3 mm

## System for calculating seal strength

System for calculating the seal thickness


Includes the compression ratio.

THE VALUE «A» TO BE DETERMINED IS THE MEASURE FOR THE EXCESS OR PISTON BOTTOM RESIDUE ACROSS THE TOP CYLINDER SURFACE.

THE VALUE «A» IS NEEDED TO DETERMINE THE THICKNESS

«B» OF THE CYLINDER BASE GASKET (FOR BALANCE THE COMPRESSION RATIO). EVER NEXT THE PISTON BOTTOM OUT OF THE CYLINDER THE MORE STRONGER THE CYLINDER BASE GASKET

«B» TO BE FITTED MUST BE. THE FURTHER THE PISTON INTO THE CYLINDER, THE REVERSE THE THINNER THE CYLINDER BASE GASKET TO BE FITTED MUST BE.



## Technical specifications

## Compression ratio

11,5 ± 0,5 :1

CYLINDER BASE GASKET THICKNESS

Name	Ma A	Strength
MEASURED VALUE «A»	- 0,185 ÷ - 0,10	0,4
MEASURED VALUE «A»	- 0,10 ÷ + 0,10	0,6
MEASURED VALUE «A»	+ 0,10 ÷ + 0,185	0,8

## ANNOTATION

THE VALUES INDICATED WITH «-» CORRESPOND TO THE RESIDUE OF THE PISTON BOTTOM REGARDING THE CYLINDER SURFACE.

## ANNOTATION







DIMENSION «A» MUST BE MEASURED WITHOUT GASKET ATTACHED TO «B»







## TABLE OF CONTENTS

TOOLS
-------

WORK
------

**SPECIAL TOOL**

Stock code number	Description	
001330Y	Tool for installing steering head bearing cups	
001467Y002	Basket for bearings with outside diameter Ø 73 mm	
001467Y006	Pliers for removing 20 mm bearings	
001467Y007	Basket for bearings with outside diameter Ø 54 mm	
001467Y008	Pliers for removing bearings with Ø 17 mm	
001467Y014	Pliers for removing bearings with Ø 15 mm	

Stock code number	Description	
001467Y017	Basket for bearings with outside diameter Ø 39 mm	
001467Y031	Basket	
001467Y031	Pliers for removing bearings with Ø 15 mm	
001467Y035	Basket for bearings with outside diameter Ø 47 mm	
006029Y	Punch mandrel for installing steering bearing seats on the fork shaft	
020004Y	Punch mandrel for removing the steering bearings from the steering tube	







Stock code number	Description	
020055Y	Key for threaded ring fork shaft	
020193Y	Pressure gauge for oil pressure control	
020201Y	Tube for inserting the spacer bushing	
020262Y	Plate for housing separation	
020306Y	Impact mandrel for installing the valve sealing rings	
020335Y	Magnetic holder for dial indicator	









Stock code number	Description	
020357Y	Adapter 32 x 35 mm	
020358Y	Adapter 37 x40 mm	
020359Y	Adapter 42 x 47 mm	
020360Y	Adapter 52 x 55 mm	
020364Y	Guide 25 mm	
020376Y	Handle for adapter	

**MP3 530 hpe****Tools**

<b>Stock code number</b>	<b>Description</b>	
020382Y012	Cylindrical spacer (tool for removing the valves)	
020412Y	Guide 15 mm	
020424Y	Impact mandrel for installing the roller container of the guided pulley	
020431Y	Oil seal valve puller	
020434Y	Connection for oil pressure control	
020439Y	Guide 17 mm	







Stock code number	Description	
020444Y	Tool for attaching and removing the clutch to the guided pulley	
020456Y	Adapter Ø 24 mm	
020458Y	Lower steering tube bearing puller	
020459Y	Impact mandrel for installing bearings on the fork shaft	
020467Y	Flywheel puller	
020470Y	Assembly tool for piston pin retainers	

**MP3 530 hpe****Tools**

Stock code number	Description	
020472Y	Key to block the alternator	
020475Y	Tool for checking piston position	
020476Y	screw bolt	
020478Y	Punch mandrel for needle sleeve	
020479Y	Tool for blocking the countershaft	
020480Y	Fuel pressure control tool kit	

## Tools

## MP3 530 hpe

Stock code number	Description	
020482Y	Motor mount	
020483Y	Guide (30mm)	
020512Y	Fork for installing the piston	
020527Y	Motor mount stand	
020604Y011 020648Y	Adapter to equip Charge individual battery	
020565Y	Face wrench for blocking the alternator	

Stock code number	Description	
020661Y	Replacement kit for integral seal water pump	
020674Y	Clamp for installing the piston Ø 95 mm	
020892y	Key threaded ring for side steering tube	
020922Y	Diagnose-Instrument	
020924Y	Bluetooth for PADS diagnostic device	
021017Y	Diagnostic cable EOBD E5	





Stock code number	Description	
021021Y	Fuse drive pulley	
021022Y	Stop guided pulley	
021023Y	Key to lock the ring nut	
021024Y	Key to lock the control socket	

TABLE OF CONTENTS


MAINTENANCE	WAR
-------------	-----



## REAR GAS SHOCK ADJUSTMENT

To adjust the preload of the rear gas shock absorbers, proceed as follows:

1. The special key for the shock absorbers  
Use setting, the key from below  
insert and with two teeth of the threaded ring  
connect.
2. Unscrew the lower threaded ring «A» until  
it is a few millimeters from the upper threaded ring.
3. Turn the adjusting threaded ring «B» until the  
prescribed values have been reached.
4. Pull the lower threaded ring «A» up to An  
Screw on the upper threaded ring and  
tighten.



### Prescribed values «x»

**Position 1** min. preload; driver only: **100 - 105 mm**

**Position 2** max. preload; Driver, passenger  
and luggage: **119 mm**

### DANGER



**DRIVING WITH THE SPRING PRELOADING NOT PROPERLY ADJUSTED TO THE DRIVER AND PASSENGER WEIGHT CAN IMPROVE DRIVING COMFORT AND AFFECT DRIVING PRECISION.**

### WARNING



**TO RISK OF INJURY (ABRASIONS).  
AVOID SHOCK WHEN ADJUSTING  
DAMPER PROTECTIVE GLOVES MUST BE WEAR.**

### WARNING



**IT IS ABSOLUTELY ADVISED NOT TO USE THE INTRODUCTORY CREDITS  
DIFFERENCE ON THE TWO SHOCK ABSORBERS  
LIGHTLY ADJUST**

**DANGER**

PERFORM THE ADJUSTMENT PROCESS WHEN THE EXHAUST IS COLD AND WEAR APPROPRIATE PROTECTIVE GLOVES AND WEAR CLOTHES.

**ANNOTATION**

WITH ITS TWO TEETH THE KEY CAN FOR THE INDIVIDUAL POSITIONS SHOWN IN BOTH DIRECTIONS CAN BE USED.

**RESET MAINTENANCE SYMBOL**

Every time you turn the ignition key to "ON", after the initial testing of the fitting

boards if less than 300 km (186.41 mi) to missing for the next inspection, the flashes given symbol for 5 seconds.

When the mileage reaches the inspection is, the symbol remains every time the ignition is turned Pressing the key to «ON» switches it on permanently until the inspection is carried out.



To reset the maintenance symbol as follows proceed:

- select the "BATTERY" function .



- Press the "SET" button for more than 10 seconds hold down.

- When you release the button it will correspond de maintenance step reset and the symbol disappears.

**METHOD FOR ADJUSTING THE THREADED RINGS ON THE SIDE STEERING TUBE**

To tighten the threaded rings on the side

To adjust the steering tubes, proceed as follows:

- The windshield and the upper sports remove disc.



- Remove the front of the shield.



Use the special tool and as follows proceed:

- Loosen the upper threaded ring.
- The lower threaded ring with the specified tighten to the desired torque.

#### **Torque guide values (N\*m)**

**Lower threaded ring of the side steering tube res  $4 \div 5$**



- Pull the upper threaded ring by hand until you reach the end screw tight.

- The upper threaded ring with the specified tighten to the desired torque.

#### **Torque guide values (N\*m)**

**Upper threaded ring of the side steering tube res  $38 \div 42$  Nm**



- Reset the vehicle body.

## Maintenance program table

### SCHEDULED MAINTENANCE TABLE

I: CHECK AND CLEAN, ADJUST, LUBRICATE OR REPLACE AS NECESSARY.

C: CLEAN, R: REPLACE, A: ADJUST, L: LUBRICATE

km x 1,000 (mi x 1,000)	1 (0,6)	10 (6,2)	20 (12,4)	30 (18,6)	40 (24,9)	50 (31,1)	At 12 Sweet	At midnight Sweet
Safety locks								
spark plugs		R	R	R	R	R		
Main stand		L	L	L	L	L	L	L
Brake cable brake caliper suspension locking system		A	A	A	A	A		
drive belt		R	R	R	R	R		
Diagnosis with instrument								
Air filters and seals		R	R	R	R	R		
Engine oil filter	R	R	R	R	R	R	R	R
Valve clearance			A		A			
Clutch unit								
Running shoes / variator rollers		R	R	R	R	R		
Guided pulley - roller container								
Electrical system and battery								
Brake system								
coolant								R
brake fluid								R
Engine oil	R	R	R	R	R	R	R	R
Rear gear oil	R		R		R			
Headlight adjustment								
Brake pads								
Tire pressure and wear								
Test drive								
suspension								
Middle and side steering tube	A	A	A	A	A	A		
Power transmission								
Workload (minutes)	110	1 165	1 270	1 165	1 270	1 165	1 50	80

#### ANNOTATION

**EVERY PROGRAMMED MAINTENANCE MUST BE CHECKED FOR THE EXISTENCE OF ANY ERRORS AND THE CORRECTNESS OF THE PARAMETERS USING THE DIAGNOSTIC DEVICE.**

**ENSURE THE VEHICLE CALIBRATION IS UPDATED AFTER YOU HAVE PERFORMED THE UPDATING OF THE DIAGNOSTIC DEVICE.**

## suggested products

The Piaggio Group recommends the products of

**“Official partner Castrol” for the planned regular maintenance of their vehicles.**

Use lubricants and fluids that are the same have higher quality or higher specifications, than specified in the regulations. this is also valid for possible refilling.



### TABLE OF RECOMMENDED PRODUCTS

Product	Description Synthetic-	Declarations
Engine oil 5W-40	based lubricant for The 4-Stroke Engine.	SAE 5W-40; JASO MA, MA2; API SL; THAT A3

Product	Description	Declarations
Gear oil 75W-140	Synthetic lubricant for gears and drives.	SAE 75W-140, API GL-5
Brake fluid DOT 4	Synthetic brake fluid.	SAE J 1703; FMVSS 116; ISO 4925; ASS AND NC 956 DOT4
Antifreeze ready to use, paint rot	Antifreeze based on ethylene glycol with added organic Corrosion inhibitors. Color red, ready to use.	ASTM D 3306 - ASTM D 4656 - ASTM D 4985 - CRADLE NC 956-16
Grease	Yellow-brown lithium-based grease and medium fiber, suitable for various Applications.	ISO LX-BCHA 3 - DIN 51 825 K3K -20
Liquid-repellent spray grease	Spray grease containing calcium, stringy, liquid-repellent.	White spray grease based on calcium complex soap NLGI 2; ISO-L-XBCIB2

### **CONVERSION UNIT - FROM ANGLO-SAXON SYSTEM TO INTERNATIONAL SYSTEM (AND).**

Technical information	Description/Value
1 inch (in)	25,4 Millimeter (mm)
1 foot (ft)	0,305 Meter (m)
1 We (mi)	1,609 Kilometers (km)
1 Gallone US (gal US)	3,785 liters (l)
1 pound (lb)	0.454 Kilograms (Kg)
1 cubic inch (in³)	16.4 cubic centimeters (cc)
1 pound foot (lb ft)	1,356 Newton Meter (N m)
1 mile per hour (mi/h)	1,602 kilometers per hour (km/h)
1 pound per square inch (PSI)	0,069 (Bar)
1 Fahrenheit (°F)	32+(9/5) Celsius (°C)

### **spark plug**

The engine installed on the vehicle has two spark plugs.

Unscrew the fastening screw and the Flap on the left side of the vehicle "A" with help a small one inserted into the recess, Remove the screwdriver.



Proceed as follows:

1. Remove the ignition cable plug «B» from the ignition disconnect candles;
2. The spark plugs with a special spark plug Turn out the key
3. When reinstalling the spark plugs with the correct inclination all the way by hand tighten;
4. Use the candle wrench only for tightening turn around





5. Push the plug «B» onto the ignition as far as it will go  
put candles;
6. Reattach the flap. Pay attention,  
that the rear hook is inserted correctly.

**DANGER**

THE SPARK PLUGS MUST BE REMOVED WHEN THE ENGINE IS COLD. WORKING ON THE SPARK PLUGS ARE DESCRIBED IN THE SCHEDULED MAINTENANCE TABLE. THE USE OF NON-COMPLIANT TAX EQUIPMENT OR CONTROL DEVICES OR OTHER THAN THAT SPECIFIC SPARK PLUGS CAN CAUSE SERIOUS DAMAGE TO THE ENGINE.

**ANNOTATION**

THE USE OF SPARK PLUGS OTHER THAN THOSE SPECIFIED OR OF SPLITCH CAPS THAT ARE NOT SPARK SUPPRESSED MAY CAUSE MALFUNCTIONS IN THE VEHICLE ELECTRICAL SYSTEM.


---

**Gear oil**


---

**control**

- Place the vehicle on level ground  
Set the main stand.
- Unscrew the oil dipstick «A» with one  
Clean with a clean cloth, reinsert and  
**screw it in completely.**



- Extract the dipstick checking the oil level  
is between the **MAX** and **MIN indices**; in case  
where the level is below the **MIN mark**,  
it is necessary to restore the right quantity of oil in the  
hub.
- Screw the oil dipstick back in, checking that it is locked.

**Suggested products**

**Gear oil 75W-140 Synthetic lubricant for gears and drives.**

SAE 75W-140, API GL-5

## Change

- Remove the oil filler cap «A».
- Unscrew the oil drain plug «B» and leave it flow the oil completely.
- Screw the drain plug back on and refill the hub with the prescribed oil.

### Recommended products



**Gear oil 75W-140 Synthetic lubricant for gears and drives.**

SAE 75W-140, API GL-5

### Technical specifications

**Gear oil**

250 cm<sup>3</sup>



## Air filter

To replace the air filter, proceed as follows:

- The fixing screws of the cover of the Unscrew and remove the air filter box.




- Remove the air filter box cover.



- Remove the filter element.



- The condition of the rubber seals on the profile
- Check the filter box and cover.
- If they have cuts and/or tears, the
- Replace seals.



- Insert a new filter element into its seat.



- Attach the lid.
  - The air filter housing mounting screws
- Insert the lid and tighten it.






## Engine oil

In 4-stroke engines, the engine oil becomes greasy  
tion of the valve control, the main bearings and the  
Cylinder-piston unit used. **Too little oil  
leads to inadequate lubrication and can  
cause serious engine damage.**

It is normal for all 4-stroke engines that the oil  
gradually loses its lubrication performance and,  
especially during the break-in period, a certain amount  
Amount of oil is consumed. Oil consumption will  
strongly determined by the operating conditions of  
the vehicle (e.g. when driving frequently at full throttle  
oil consumption increases).



## Change

An oil change and filter change must be carried out accordingly  
be carried out according to the information in the  
maintenance program table. The oil must  
drained through the oil drain plug «B»  
become.



To make it easier for the oil to flow out, the oil  
Open filler screw/dipstick «A» .



Once the oil has stopped flowing from the drain hole, unscrew the cartridge oil filter and remove it.

Make sure the O rings are in good condition

Pre-filter and drain plug ring.

Lubricate them and refit the mesh filter and the oil drain plug locking it to the torque prescribed.

Refit the new cartridge filter carefully

lubricate the O-Ring before assembly.

Fill in the engine oil.

Since a certain amount of oil still remains in the circuit, filling must be done with oil from cap «A». Then start the vehicle, leave turn it on for a few minutes and turn it off: afterwards about 5 minutes check the level and if necessary top up without ever exceeding the **MAX level**.

Replacing the cartridge filter must be carried out at every oil change. For top-ups and to replace, use new oil of the recommended type liato.


#### ANNOTATION

**THE OIL MUST BE CHANGED WITH THE ENGINE WARM.**

### Suggested products

**Motor oil 5W-40 synthetic-based lubricant for 4-stroke engines.**

SAE 5W-40; JASO MA, MA2; API SL; ACEA A3



## control

This step must be carried out when the engine is cold be carried out as follows:

- Place the vehicle on level ground

Set the main stand.

- Unscrew the filler cap with dipstick «A»

Use, dry with a clean cloth

zen and **screw it back in completely.**



- Unscrew the filler cap with dipstick again

and check that the oil level is between the MIN and MAX markings. If applicable refill.

The oil level check is off when the engine is warm the displayed oil level is lower. For

The engine must be switched off for a proper check and about 10 before checking the oil level Cool for minutes.


### Refilling oil

Before topping up engine oil, you must first

the oil level must be checked. When refilling

Engine oil must **not exceed the MAX mark** **steps** can be MAX.

Topping up from **MIN** to **MAX** requires approximately **400 cm<sup>3</sup>**.



### Suggested products


**Motor oil 5W-40 synthetic-based lubricant for 4-stroke engines.**

SAE 5W-40; JASO MA, MA2; API SL; ACEA A3

## Oil pressure control

The vehicle has an oil on the dashboard equipped with pressure control. The indicator light lights up as soon as the ignition key is turned «ON» is rotated. After starting the engine, the... Oil pressure control goes out.

**The oil pressure control lights up when braking or when cornering, the oil level must be checked and the lubrication system checked and given if necessary, be filled up.**



### Check phase setting of valve control

- Remove the plastic cover from the alternator cover take.



- Turn the flywheel until the mark on the rotor as shown in the figure  
Marking on alternator cover aligned tet ist (OT).
- Make sure that the 4V mark on the Drive pulley of the camshaft onto the mark is aligned with the cylinder head. Located the marking is on the opposite one  
Side to the marking on the cylinder head must be the Crankshaft rotated another revolution become.



### Check valve clearance

The valve clearance must be checked accordingly the information from the table for maintenance program can be carried out.

- Place the vehicle on a suitable bridge, so that the rear wheel can be blocked.
- Disconnect the battery cables.
- The luggage racks, the rear sides and the Remove running boards.
- A scissor lift under the vehicle attach.



- The fixing screws of the cover
- Unscrew the cooling of the drive box.



- Remove the drive cooling cover.



- The inspection cover on the flywheel
- loosen cover.



- Loosen the spark plug, turn the crankshaft
- and the received references on the swing
- Align the wheel and the crankcase.






- The fastening screw of the two rear ones  
Loosen shock absorber.



- The rear brake mounting screw  
unscrew pipes.




- Open the frame by operating the pulley  
of the vehicle. The engine runs one  
slight rotation between the rear wheel and the  
Swing arm through.
- The connecting rod head rises and increases  
the space between the tappet cover and  
the container.
- The tappet cover mounting screws  
loosen and remove.



- Remove the tappet cover.



- The alignment of the marking on the cylinder head check with the one on the distributor ring.



- Use a thickness gauge to check the clearance between A Check position and valve.

### Technical specifications

#### Valve clearance (cold)

Suction: 0.15mm

Outlet: 0.15mm



- If an incorrect value is determined, on and bring it to the prescribed value gen.



- Install the valve lifter cover.
- Insert the special screws with dampers.
- Fastening screws in order 1-2-3-4 with specified tightening torque put on.

### Torque guide values (N\*m)

Valve cover fixing screws 7 ÷ 9 Nm (5.2 ÷ 6.6 lb\*ft)



- The rear brake mounting screw  
insert and tighten.



- Lower the vehicle using the lifting device  
until the lower fastening of the rear shock  
damper with the appropriate fasteners  
aligned on the engine.
- Insert the fastening screws for both shock absorbers  
and with the required tightening torque  
tighten momentarily.



- The inspection cover on the flywheel  
Insert cover and tighten.



- Install the drive cooling cover.



- Reinstall the running boards, rear sides and luggage rack.
- Connect the battery cables.



---

## Cooling system

The coolant level must be checked cold engine according to the information from the Table for the maintenance program can be made as follows:

- Place the vehicle on level ground

Set the main stand.

- Unscrew the screws shown in the picture and remove the cover of the expansion box remove the barrel.




Unscrew and remove the lid.



- Refill again if the fluid level is near or below the MIN mark.

The fluid level must always be between MIN and MAX markings. - The coolant is a mixture of decalcified water and antifreeze based on ethylene glycol and rust inhibitors.



### **DANGER**

TO PREVENT COOL FLUID LEAKING FROM THE EXPANSION TANK WHILE DRIVING  
AVOID NOT EXCEEDING THE MAX MARK WHEN FILLING.

## **Suggested products**

**Antifreeze ready for use, color red**  
**Antifreeze based on ethylene glycol with added organic corrosion inhibitors. Color red, ready to use.**

ASTM D 3306 - ASTM D 4656 - ASTM D 4985 -

CRADLE NC 956-16

---

## Brake system

---

## Level control

### **BRAKE FILL LEVEL CHECK**

#### **SYSTEM FRONT AND REAR**

The brake fluid reservoirs for the front and Rear brakes are on the handlebars. How

proceed as follows:


- The vehicle is aligned in the direction of travel  
Place the handlebars on the main stand.
- Check the brake fluid level through the corresponding sight glass. A slight drop in the brake fluid level can occur caused by wear on the brake pads.



### **FLUID CONTROL AT THE INTEG**

#### **RAIL BRAKE SYSTEM**

- Place the vehicle on level ground  
Set the main stand.
- Remove the control cover and check whether the Level of brake fluid in the reservoir written area can be read.
- A slight drop in brake fluid  
tands can be caused by wear of the brake pads  
be caused.



## Refill

### **REFILLING THE FRONT BRAKE SYSTEM AND BACK**

Proceed as follows for both master brake cylinders:

- Loosen the two fastening screws and remove the lid. To refill finally prescribed brake fluid to use. Never fill above the maximum level.
- Under normal climatic conditions must the brake fluid according to the information from the maintenance program table be changed.



#### **WARNING**



**USE ONLY CLASS DOT 4 BRAKE FLUID. THE BRAKE FLUID IS HIGHLY CORROSIVE: AVOID CONTACT WITH PAINTED VEHICLE PARTS.**

**DANGER**

**AVOID BRAKE FLUID IN EYES, COMES INTO CONTACT WITH SKIN OR CLOTHING. IF INTENTIONAL CONTACT RINSE IMMEDIATELY WITH PLENTY OF RUNNING WATER.**

**Suggested products**

**Brake fluid DOT 4 Synthetic brake fluid.**

SAE J 1703; FMVSS 116; ISO 4925; CUNA NC 956 DOT4

**REFILLING THE INTEGRAL BRAKE SAN MAKE**

- Remove the inspection cover, unscrew the container cover and use the recommended Refill product.

- If there is air in the line, the Vent the system.

**DANGER**

**THE PRESENCE OF AIR IN THE CIRCUIT OF THE INTEGRAL BRAKE SYSTEM IS PARTICULARLY DANGEROUS: THE USE OF THIS BRAKE SYSTEM CAN PUMP AIR INTO THE LINES OF THE FRONT OR REAR WHEEL BRAKES AND THEREFORE THE FUNCTION OF THE RESTRICT INDIVIDUAL BRAKE SYSTEMS.**

**Suggested products**

**Brake fluid DOT 4 Synthetic brake fluid.**

SAE J 1703; FMVSS 116; ISO 4925; CUNA NC 956 DOT4


## Adjusting the headlight

Proceed as follows:

- The vehicle is ready to drive, unloaded and with correct tire pressure on a flat surface in 10 m distance in front of a white one in partial shade the wall, the vehicle axle must be at right angles to the wall.
- Remove the upper shield cover.



- Turn on the headlight and check that the upper light-dark boundary on the wall does not about 9/10 of the center of the headlight from the ground and is not less than 7/10.



- Otherwise adjust the headlight by the corresponding screws can be turned.

### WARNING

THE PROCEDURE SPECIFIED IS SPECIFIED BY THE "EUROPEAN STANDARD" FOR THE MAXIMUM AND MINIMUM HEIGHT OF THE HEADLIGHT BEAM. NEVERTHELESS, THE APPLICABLE REGULATIONS IN THE INDIVIDUAL COUNTRIES OF USE OF THE VEHICLE MUST BE CHECKED.



## anti-evaporation system

The vehicle is equipped with the "canister", the essential component of the system for controlling the Ver vapor emissions of fuel equipped, in accordance with current standards.



**A.** Fuel pump

**B.** Gas tank

**C.** Two-way fuel vent valve

dampen

**D.** Activated carbon filter

**E.** Vent pipe to the environment **F.**

Unidirectional electronic force

material vapor vent valve (from the engine control unit



advises controlled)

**G.** Vacuum connection

**H.** Throttle body

**I.** Air intake manifold

**L.** Injector



#### Legend:

1. Activated carbon filter
2. Connection line from the solenoid valve to the activated carbon filter
3. Activated carbon filter solenoid valve
4. Connection line from the solenoid valve to the input connection
5. Vent line
6. Ventilation valve


7. Connection line from the fuel tank to the activated carbon filter

---

### disassembly of system components


To access the components of the system to limit evaporative emissions

Remove the helmet compartment and the side panels.



Remove the pipe clamps and the activated carbon filter


pull it out of its holder.



---


### assembly of system components

When reinstalling the components, pay attention to the connection of the lines to the activated carbon filter  
ten.

**Legend:**


1. Connection line from the fuel tank to the activated carbon filter
2. Connection line from the solenoid valve to the activated carbon filter
3. Vent line

Make sure the activated carbon filter is installed correctly is directed.




When installing the fuel line, ensure that it is properly attached to the tank.





When reinstalling, pay attention to the alignment of the vent  
tils pay attention.



#### DANGER



**ENSURE THE CORRECT INSTALLATION DIRECTION OF THE COMPONENTS. IF YOU  
IF MOUNTED REVERSE, THIS MAY AFFECT THE OPERATION OF THE ENTIRE EVAPORATION PREVENTION  
SYSTEM.**

After assembling the components, fasten the cables with new clamps.

## check canister

The activated carbon filter is essential for treating the hydrocarbons present in the gas volume  
are present, which escapes from the tank when the internal pressure increases (heating of the tank due to  
the radiator, the engine or the environment).



Even if the amount of hydrocarbons coming from the tank is quite small, the

Activated carbon is regenerated by a reverse flow of ambient air sucked in by the engine to avoid saturation of the activated carbon filter.

This pollution and regeneration phenomenon of coal occurs every time it is used cycle of the vehicle.

---

To check the activated carbon filter, it must be checked  
be removed, with the 2 lines attached  
remain closed.

- Shake and check the activated carbon filter  
check whether noises can be heard.
- Alternate with a compressed air gun  
blow into the 3 lines and safe  
that inside the Ak

Activated carbon filter does not form any pressure.

- Make sure the air flow is always  
is free and that from no line  
Coal residues escape.

If you notice noises, blockages or Koh

If oil losses are detected, replace the activated carbon filter  
rare.

---




TABLE OF CONTENTS

ELECTRICAL SYSTEM	THEY ANL
-------------------	----------

**DANGER****ANNOTATION**

THE GRAPHIC REPRESENTATION OF THE CABLE CONNECTORS SHOULD BE UNDERSTAND FROM THE CABLE ENTRY SIDE, AS SHOWN IN THE EXAMPLE.


**Attaching the components**

**1. Right brake lever stop switch**

Remove handlebar covers to access.

**2. Left brake lever stop switch.**

Remove handlebar covers to access.



**3. Brake pedal stop switch.**

To access, remove the right footboard.

**4. Preparation for heating accessories**


Remove handlebar covers to access.

**5. Air temperature sensor.**

In the lower handlebar cover.

**6. Keyless switch contacts**


To access, remove the back of the shield.





**7. PMP3**

To access the component, use the above  
Remove the remaining part of the shield.

**8. Sensor mechanical brake caliper roll****Lock**


To get to the component, the front one  
Remove shield.

**9. Roll-Lock hydraulic pressure sensor**

To get to the component, the front one  
Remove shield.

**10. Terminal board remote switch and fuse****gen**

Under the seat, for access to the battery  
Remove cover.



**11. Flasher**

On the left side of the vehicle for access

Remove rear side panel.

**12. Cable connector USB socket**


To get to the component, the front one

Remove shield.

**13. Stellmotor Roll-Lock**

To get to the component, the front one

Remove shield.


**14. Rotary sensor end stop**

To get to the component, the front one

Remove shield.



**15. Parking brake control unit** In order to access the component, the  
The back of the shield must be removed.



**16. Parking brake switch**

In order to get to the component, you have to  
The back of the shield must be removed.



**17. Fuel pump**

In order to get to the components, you have to  
middle frame panel must be removed.



**18. Voltage regulator**

In order to get to the component, you have to  
right rear side panel must be removed.





**19. Oil pressure sensor**

On the right side of the engine.

**20. Ignition coil.**

Positioned on the left side of the vehicle to

To access the component, remove the left side panel distant.

**21. Fuel filler flap opening adjustment device**

In order to get to the component, you have to

The back of the shield must be removed.

**22. Warnsummer**

In order to get to the component, you have to

Helmet compartment can be removed.



**23. Injection control unit 11MP**

Located on the right side of the vehicle. Around  
To be able to get to the component, you have to  
Helmet compartment can be removed.

**24. Driver detection sensor cable connector**

The driver presence sensor is in the seat  
installed, the connection is located at the seat  
bench hinge. To access the bench  
clap.

**25. Cable connector pre-equipment for heated seat bank**

The cable connector is located on the seat  
hinge. Open the bench for access.

**26. ABS control unit**

To get to the component, the front one  
Remove shield.



---

**27. Reverse gear actuator assembly**

In order to get to the component, you have to  
Protective cover of the drive cover removed  
become.



---

**28. Reverse gear motor**

The box of contacts of the positive cable of the Mo

The reverse gear gate is on the left side  
of the vehicle, above the drive cover  
tight.

In order to get to the component, you have to  
Drive cover must be removed as described in chapter. «Mon  
gate» is described.



---

**29. Cooling fan**

In order to get to the cable connector, the  
Remove back of shield.



---

**30. Speed sensors.**

The sensors are located on the inside of the  
Front suspension.





### 31. Lambda sensor

The lambda sensor is located on the exhaust manifold mer. To expose the cable connector, the right Remove rear side panel.



### 32. ABS sensor rear wheel

The rear wheel ABS sensor is located on Engine, between the wheel and the left rear Shock absorber.



In order to get to the cable connector, that Remove helmet compartment.



### 33. Starter motor

In order to get to the component, you have to Helmet compartment can be removed.



**34. Seat opening adjustment device**

In order to be able to access the component, the hint  
Remove the other side parts.

**35. Injector**

In order to get to the component, the In  
Remove the inspection flap in the helmet compartment.


**36. Engine temperature sensor**

In order to get to the component, you have to  
Helmet compartment can be removed.

**37. Demand-Sensor**

Located on the right side of the handlebar

**dashboard**

**Legend:**

- 1 = ASR indicator light
- 2 = ABS indicator light
- 3 = Daytime Running Lights indicator light switched on
- 4 = High beam indicator light switched on
- 5 = left indicator light
- 6 = Brightness sensor Digital display
- 7 = Digitaldisplay
- 8 LED immobilizer
- 9 = Right turn signal indicator light
- 10 = Indicator light for locking system (roll lock system) front suspension active
- 11 = Warning lamp malfunction locking system (Roll-Lock system) front suspension
- 12 = Insufficient engine oil pressure indicator light
- 13 = Parking brake indicator light activated

**Checking the power output of the charging system****Check for possible leakage current**

- 1) Remove the corresponding cover under the seat and clear access to the battery give.
- 2) Before checking the output voltage, check that no battery fluid has come out of the battery tery exits.

3) Turn the ignition key to OFF and connect the tester terminals between the negative (-) terminals.

on the battery and the black cable. Only then remove the black cable from the negative pole

Disconnect (-) at the battery.

4) With the ignition key still OFF, the ammeter must show a value of  $\approx 0.5$  mA.

### Check charging voltage

#### WARNING

**BEFORE CHECKING, MAKE SURE THE BATTERY IS IN GOOD CONDITION.**

1) Place the vehicle on the main stand.

2) With the battery properly connected to the circuit, connect the tester terminals between the Switch battery poles.

3) Start the engine, slowly increase the speed and measure the voltage at the same time.

### Electrical information

**Voltage between 14.0 and 15.0 V at 5000 rpm.**

#### Control maximum delivered current

- With the engine switched off and the ignition lock set to "ON", switch the vehicle lights on and off

Wait until the battery voltage reaches 12V.

- Connect a clamp current meter to the 2 positive battery charge cables at the output of the controller eat.

- Start the engine and bring it to high speed, at the same time take the reading on the clamp meter read off.

### VOLTAGE REGULATOR/RECTIFIER

Technical information	Description/Value
Type	Transistorized, non-adjustable three-phase
Tension	14 ÷ 15V at 5000 rpm with lights off

## Lamp list

In this section the equipment is included

Types of lamps provided for the vehicle counted.



### LAMP TABLE

Electrical information	Description/Value
1 Low beam lamp	Typ: LED Quantity: 1 RIGHT - 1 LEFT
2 High beam lamp	Typ: LED Quantity: 1 RIGHT - 1 LEFT
3 Lamp front parking light / daytime running light	Typ: LED Quantity: 1 RIGHT - 1 LEFT
4 Front turn signal lamp	Typ: LED


Electrical information		Description/Value
		Quantity: 1 RIGHT - 1 LEFT
5	Taillight lamp	Typ: LED Quantity: 1
6	Rear turn signal lamp	Typ: LED Quantity: 1 RIGHT - 1 LEFT
7	Brake light	Typ: LED Quantity: 1
8	Lamp license plate light	Typ: LED Quantity: 1
9	Lamp for helmet compartment lighting	Type: TORPEDO Power: 12V - 5W Quantity: 1

Fuses

The electrical system is equipped with 16 main protection fuses, which are divided into two fuse boxes «A» and «B» and one

General security “18”, which is located near the battery is located.

To access the fuses, the seat must be raised and the battery cover removed as described in the “Battery” section



becomes.

DANGER

BEFORE REPLACING A BLOWN FUSE, THE FAULT THAT CAUSED THE FUSE TO BLOW MUST BE LOCATED AND REMOVED. NEVER USE THE CIRCUIT

ANOTHER MATERIAL (E.G. A CABLE) OR A FUSE OTHER THAN THAT STATED BRIDGE (E.G. WITH A LARGER NUMBER OF AMPERS).

DANGER



WITHOUT CONCERNING THE TECHNICAL DATA INCORRECT CHANGES OR REPAIRS TO THE ELECTRICAL SYSTEM CAN CAUSE OPERATING MALFUNCTIONS CAUSE AND ARE FIRE HAZARD.

WARNING



TO AVOID DAMAGE TO THE ELECTRICAL SYSTEM, NEVER DISCONNECT THE BATTERY CABLE WHILE THE ENGINE IS RUNNING.



MAIN BACKUP

The table shows the position and the technical information about the devices in the vehicle  
neral fuse listed.




TABLE MAIN BACKUP

Electrical information	Description/Value
1 Fuse No. 18	<b>Power:</b> 30A <b>Supply:</b> from battery <b>Protected circuits (under ignition switch):</b> Fuses No. 1, 2, 3, 4, 5, 6, 7 and 8 (fuse holder «B»).

FUSE HOLDER «A»

The table shows the positions and the technical information about those in the vehicle  
Main fuses described, which are safe  
holder «A» .





TABLE OF FUSES BOX «A»

Electrical information	Description/Value
1 Fuse No. 1	<b>Power:</b> 5A <b>Protected circuits:</b> Supply via fuse No. 1 (fuse holder «B»); Light change switch High beam/low beam.
2 Fuse #2	<b>Power:</b> 20A <b>Protected circuits:</b> Power supply via battery; Parking brake control unit.
3 Fuse #3	<b>Power:</b> 7.5A <b>Protected circuits:</b> Power supply via battery; Preparation of alarm system, preparation of heated grips, Diagnostic socket.
4 Fuse #4	<b>Power:</b> 5A <b>Protected circuits:</b> Power supply via battery; Instrument unit.
5 Fuse #5	<b>Power:</b> 10A <b>Protected circuits:</b> Power supply via battery; Remote relay cooling fan, cooling fan.
6 Fuse #6	<b>Power:</b> 10A <b>Protected circuits:</b> Power supply via battery; Remote relay injection loads, engine control unit.
7 Fuse #7	<b>Power:</b> 7.5A <b>Protected circuits:</b> Power supply via battery; Helmet compartment lighting, alarm system preparation, Control element for direction indicators (turn signals), control

Electrical information		Description/Value
		PMP3 (Piaggio Multimedia Platform) control unit, "Keyless" control unit, electrical storage compartment preparation.
8	Fuse #8	<b>Power:</b> 30A <b>Protected circuits:</b> Power supply via battery; ABS control unit.

The table shows the positions and the technical specifications of the relays are described in Fuse holder «A» is housed.



KASTEN “A” RELAY TABLE

Electrical information		Description/Value
Relay No.		<b>Circuits:</b> main circuit.
1	1 Relay No.	<b>Circuits:</b> cooling fan.
2 3	2 Relay No. 3	<b>Circuits:</b> fuel pump.

FUSE HOLDER «B»

The table shows the positions and the technical information about those in the vehicle The main fuses are described and are housed in the fuse holder «B» .




TABLE OF FUSES BOX «B»

Electrical information		Description/Value
1	Fuse No. 1	<b>Power:</b> 5A <b>Protected circuits:</b> Power supply via ignition lock; USB port.
2	Fuse #2	<b>Power:</b> 7.5A <b>Protected circuits:</b> Power supply via ignition lock; Pre-equipment of alarm system, pre-equipment of heated grips, diagnostic socket.
3	Fuse #3	<b>Power:</b> 5A <b>Protected circuits:</b> Power supply via ignition lock; Direction indicator control (indicator), indicator switch, PMP3 (Piaggio Multimedia Platform) control unit, electrical storage compartment preparation.
4	Fuse #4	<b>Power:</b> 5A <b>Protected circuits:</b> Power supply via ignition lock; Daytime running light changeover switch, daytime running light remote relay, instrument cluster.
5	Fuse #5	<b>Power:</b> 5A

Electrical information		Description/Value
		<b>Protected circuits:</b> Power supply via ignition lock; Remote brake light relay, rear brake light, coil Remote starter relay.
6	Fuse #6	<b>Power:</b> 7.5A
		<b>Protected circuits:</b> Power supply via ignition lock; Parking brake control unit.
7	Fuse #7	<b>Power:</b> 7.5A
		<b>Protected circuits:</b> Power supply via ignition lock; "Keyless" control unit, ABS control unit, engine control unit.
8	Fuse #8	<b>Power:</b> 7.5A
		<b>Protected circuits:</b> Power supply via ignition lock; Horn switch, horn, rear radar, parking lights front and daytime running lights, rear parking lights, license plate light, rear camera, instrument cluster.

The table shows the positions and the technical technical specifications of the relays are described in Fuse holder «B» is housed.





TABLE RELAY BOX «B»

Electrical information		Description/Value
Relay No.		<b>Circuits:</b> Daytime running light changeover switch.
1	1 Relay No.	<b>Circuits:</b> enabling reverse gear.
2 3	2 Relay No. 4	<b>Circuits:</b> brake lights.

Cable connections

**DANGER**  
**ANNOTATION**  
THE GRAPHIC REPRESENTATION OF THE CABLE CONNECTORS IT IS VIEWED FROM THE CABLE ENTRY SIDE UNDERSTAND AS SHOWN IN THE EXAMPLE.



The following is the list of electrical components of the vehicle:

- Seat opening adjustment device
- Tank adjusting device
- Battery
- Ignition coil.
- Bulk wire mesh
- Development CAN
- ABS control unit


- Parking brake control unit
- Injection control unit
- Horn
- Ignition lock
- Light switch
- Ignition actuator contact
- Starter remote relay contact
- Flasher unit
- cooling fan
- Taillight
- Solenoid group
- Instrument unit
- License plate lighting
- injector
- Helmet compartment lighting switch
- Front right turn signal
- Front left turn signal
- LED Alarm
- Helmet compartment lighting
- Ignition coil ground.
- Frame dimensions
- Gear motor
- Starter motor
- Pick-Up
- Helmet compartment lighting
- PMP3
- Fuel pump
- Preparation for anti-theft protection
- Preparation for top case
- Preparation for heated grips, leg warmers and seat heating
- Diagnostic connector
- USB port
- Headlight
- Button switch on heating
- Seat opening switch
- Tank opening button
- Taste ASR
- Limit switch

- Handbrake switch
  - Brake pedal switch
  - Brake light switch on the right
  - Left brake light switch
- Voltage regulator
  - Selector switch for drive/reverse gear operating mode
  - Front ABS sensor right
  - Front ABS sensor on the left
- Rear ABS sensor
- Tilt sensor
  - Throttle grip position sensor
  - Seat sensor (driver present)
- Pressure sensor
  - Oil pressure sensor
  - Rotation sensor
- Outside temperature sensor
  - Engine temperature sensor
- Sensor T\_MAP
  - Speed sensor right
  - Speed sensor on the left
  - Solenoid valve actuator ignition
- Lambda probe with heater
- Summer
- Rear view camera
  - Starter remote relay
  - Remote relay reverse gear
  - Activated carbon filter valve

---


**CABLE CONNECTOR ACTUATOR SEAT****BANK OPENING**

1. Ground (Black)
2. Power supply (Yellow-Gray)



**CABLE PLUG ADJUSTMENT DEVICE FOR  
TANK**


1. Ground (Black)
2. Control input for tank opening via keyless  
(yellow Red)

**BATTERY-PLUS**


1. Power supply (red)

**BATTERY-MINUS**

1. Ground (Black)


**IGNITION COIL CABLE CONNECTOR.**

1. Remote relay injection charges (black-green)
2. Injection control unit (pink-black)




**MASS DUTY**


1. Ground black

**CABLE CONNECTOR DEVELOPMENT CAN**

1. Line CAN H (Orange-Grey)
2. Line CAN L (orange-light blue)

**ABS CONTROL UNIT CABLE CONNECTOR**

1. Powered by battery (red)
2. Rear ABS sensor ground (brown-black)
3. Rear ABS sensor signal (brown-red)
4. Not connected 5. Front right ABS sensor signal (purple-red)
6. Ground ABS sensor, front right (purple-black)
7. Not connected 8. Front left ABS sensor ground (light blue black)




9. Signal ABS sensor front left (light blue-red)
10. ABS indicator light (orange)
11. Not connected 12. Not connected 13. Not connected 14. Not connected 15. Not connected 16. Not connected 17. Not connected 18. Line K (Orange - Black)
19. Not connected
20. Power supply via ignition lock (orange Blue)
21. CAN L line (pink-white)

- 22. Mass (Black)
- 23. Line CAN H (Rosa-Rot)
- 24. Not connected
- 25. Not connected
- 26. Mass (Black)

---

**CONTROL UNIT CABLE CONNECTOR FIXED****PARKING BRAKE**

- 1. Powered by battery (Blue - Red)
- 2. Powered by battery (Blue - Red)
- 3. Ground (Black)
- 4. Ground (Black)
- 5. Servomotor (yellow)
- 6. Gear Motor (Blue)
- 7. Not connected
- 8. Not connected
- 9. Not connected
- 10. Not connected
- 11. Not connected
- 12. Not connected
- 13. Not connected
- 14. Not connected
- 15. Not connected
- 16. Not connected
- 17. Not connected
- 18. Not connected
- 19. CAN line H (red-pink)
- 20. Suspension lock/unlock button  
(blue yellow)
- 21. Lock/unlock suspension button (purple  
black)
- 22. Not connected
- 23. Not connected
- 24. Not connected
- 25. Not connected
- 26. Seat sensor (purple)
- 27. Rotation sensor (green-blue)
- 28. Limit switch button (brown)






- 29.** Limit switch button (brown-white)
- 30.** Pressure sensor (white)
- 31.** Not used
- 32.** CAN L line (pink-white)
- 33.** Lock/unlock suspension button (green degree)
- 34.** Not connected
- 35.** Right speed sensor ground (schwarz-rot)
- 36.** Left speed sensor ground (green black)
- 37.** Ground sensors (green-black)
- 38.** Not connected
- 39.** Not connected
- 40.** Not connected
- 41.** Not connected
- 42.** Not connected
- 43.** Not connected
- 44.** Not connected
- 45.** Speed sensor right (red)
- 46.** Power supply via ignition lock (yellow Black)
- 47.** Power supply via ignition lock (yellow Black)
- 48.** Not connected
- 49.** Power supply rotation sensor (orange blue)
- 50.** Not connected
- 51.** Not connected
- 52.** Not connected
- 53.** Not connected
- 54.** Not connected
- 55.** Horn (Yellow-pink)
- 56.** Not connected
- 57.** Summer (grau)
- 58.** Speed sensor left (green)

#### **INJECTION CONTROL UNIT**

- 1.** Signal -DC M throttle body (gray-black)

2. Not connected
3. Not connected
4. Not connected
5. AKF valve (white-black)
6. Signal + DC M throttle body (Red-Blue)
7. Not connected
8. Not connected
9. Not connected
10. Lambda sensor heater (white-blue)
11. Not connected
12. Not connected
13. Not connected
14. Not connected
15. Injector (Red-Yellow)
16. Not connected
17. Ignition coil. (pink-black)
18. Not connected
19. Not connected
20. Not connected
21. Not connected
22. Signal TPS1 throttle body (orange-white)
23. Lambda signal (-) (light blue-black)
24. Lambda signal (+) (green-blue)
25. Not connected
26. Not connected
27. Not connected
28. Not connected
29. Solenoid Coil Signal (Light Blue-Red)
30. Not connected
31. Not connected
32. Cruise Control Speed Increase Signal (Yellow/Gray)
33. Cruise Control Speed Reduction Signal (Yellow/Red)
34. Signal activation/deactivation cruise control (yellow/white)
35. Not connected 36. Not connected
37. Not connected
38. Not connected
39. Not connected
40. Not connected

**41.** Not connected **42.** Not connected **43.** Not connected **44.** Ground sensors (purple-black)  
**45.** Ground sensors (gray-green)  
**46.** Ground sensors (black-yellow)  
**47.** Not connected **48.** Not connected **49.** Reverse motor coil signal (white-violet)




**50.** Not connected **51.** TPS2 throttle body signal (green-orange)  
**52.** Not connected **53.** Not connected **54.** Power supply for solenoid group (Brown Rot)  
**55.** Not connected **56.** Not connected **57.** T-MAP sensor power supply (Green Rot)  
**58.** Not connected **59.** Brake pedal switch (White-Gray)  
**60.** Signal (+) Pick-Up (Rot)  
**61.** Not connected **62.** Not connected **63.** Air temperature signal T-MAP sensor (Yellow Blue)  
**64.** Not connected **65.** Not connected **66.** Not connected **67.** Power supply throttle body (Red Black)  
**68.** Brake pedal switch (white-pink)  
**69.** Not connected **70.** Signal (-) Pick-Up (Brown)  
**71.** Signal air pressure T-MAP sensor (yellow-green)  
**72.** Not connected **73.** Motor temperature sensor (light blue-green)

- 74.** Not connected
- 75.** Ground sensors (gray-brown)
- 76.** Not connected
- 77.** Not connected
- 78.** ASR button (light blue-white)
- 79.** Not connected
- 80.** Not connected

---

**HORN CABLE CONNECTOR**


- 1. Ground (Black)
- 2. Power supply (yellow-pink)

**1**

---

**IGNITION CABLE CONNECTOR**


- 1. Input power supply from fuse F18 (rot-schwarz)
- 2. Output switched plus (orange)
- 3. Not connected



---


**CABLE PLUG CHANGE SWITCH**

- 1. Contactor control DRL (yellow-pink)
- 2. DRL (yellow-brown)
- 3. Headlight (yellow-red)




**CABLE CONNECTOR CONTACT ACTUATOR****CAUTION FOR IGNITION**

1. Signal contact actuator for ignition (purple-white)
2. Mass (Brown - Black)

**CABLE CONNECTOR CONTACT STARTER****REMOTE RELAY**


1. Powered by battery (Red)

**CABLE CONNECTOR THROTTLE BODY**

1. Signal TPS1 injection control unit (orange White)
2. Power supply from injection control unit (Rot-Schwarz)
3. Signal + DC M injection control unit (red-blue)
4. Signal TPS2 injection control unit (green-orange ge)
5. Signal - DC M injection control unit (Gray Black)
6. Ground reference via injection control unit (Black yellow)

**FLASHER CABLE CONNECTOR**

1. HAZARD button (brown-purple)
2. Signal input switch on control left turn signal (rot-degree)
3. Signal input switch-on control right blink ker (light blue)
4. Signal output switch on control left turn signal (rosa)




5. Signal output switch-on control right blink  
ker (white-blue)
6. Powered by battery (Red-Blue)
7. Not connected
8. Power supply via ignition lock (brown  
Rot)
9. Ground (Black)
- 10.** Not connected
- 11.** Signal deactivation turn signal (blue-white)
- 12.** Not connected

---


**ELECTRONIC CABLE CONNECTOR****DIRECTION RE**

1. Signal to stop the engine for injection  
expensive device (gray)
2. Ground switch to stop the engine  
right (black-yellow)
3. Signal to stop the engine for injection  
expensive device (yellow-blue)
4. Ground switch for switching off the engine left  
(gray-green)
5. Power supply starter switch (orange  
Blue)
6. Signal output from starter switch (purple)
7. Power supply hazard warning lights button  
(Brown-Red)
8. Signal output from hazard warning lights button  
(brown-violet)
9. Suspension unlocking signal (blue-yellow)
- 10.** Parking brake control unit (green-gray)
- 11.** Suspension unlocking signal (purple  
Black)
- 12.** Mass button management suspension (black  
Green)
- 13.** Not connected




**ELECTRONIC CABLE CONNECTOR****DIRECTION LE**

1. Power supply turn signal switch (brown-red)
2. Ground Joystick (Black-Yellow)
3. Signal for instrument unit from Joy stick button on top (pink-yellow)
4. Signal for instrument unit from Joy stick button below (pink-gray)
5. Signal for instrument unit from Joy stick button on the left (white-pink)
6. Signal for instrument unit from Joystick button on the right (pink-brown)
7. Right turn signals (Red-Gray)
8. Turn signal deactivation button (blue-white)
9. Left turn signals (light blue)
10. Cruise speed increase signal  
Control for injection control unit (yellow-gray)
11. Signal activation/deactivation Cruise Control
12. Cruise speed reduction signal  
Control for injection control unit (yellow-red)
13. Masse Cruise Control (Grau-Braun)

**COOLING FAN CABLE CONNECTOR**


1. Input power supply via remote relay  
Cooling fan (red-gray)
2. Ground (Black)






**TAIL LIGHT CONNECTOR**


1. Brake light (white-black)
2. Rear parking light (light blue)
3. Right turn signal signal (white-blue)
4. Signal link Flashing (pink)
5. Ground (Black)

**CABLE CONNECTOR SOLENOID GROUP**

1. Supply via solenoid relay (Green)
2. Signal from injection control unit (brown-red)
3. Ground reference via injection control unit (Violet-black)
5. Not connected
6. Signal for injection control unit (brown)

**INSTRUMENT UNIT CABLE CONNECTOR**


1. Not connected
2. Signal (-) rear camera (orange-blue)
3. Signal (+) Rear view camera
4. Fuel level signal (white-green)
5. Air temperature sensor (Yellow - Blue)
6. Joystick top button (pink-yellow)
7. Not connected
8. Not connected
9. Battery Power (Red-White)
10. Handbrake switch (yellow-black)
11. Joystick bottom button (pink-gray)
12. Not connected
13. Low engine oil pressure signal (pink-black)
14. High beam indicator light (purple)
15. Welcome LED Keyless
16. Power supply via ignition lock (yellow-red)
17. Battery Power (Red-White)
18. Not connected
19. Turn signal control right (white-blue)
20. Blinkerkontrolle links (rosa)



21. LED immobilizer (yellow-orange)
22. Joystick button right (pink-brown)
23. Joystick left button (white-pink)
24. Mass (Black)
25. Ground sensors (black-yellow)
26. Not connected
27. DRL indicator light (yellow)
28. Parking light indicator light (light blue)
29. Not connected
30. Not connected
31. Not connected
32. CAN L line (pink-white)
33. Line CAN H (Rosa-Rot)
34. Not connected

#### CABLE CONNECTOR KEYLESS

1. Powered by battery (Red-Blue)
2. Signal (+) solenoid coil actuator for ignition  
dang (green-white)
3. Ground (Black)
4. Signal (-) solenoid coil actuator for ignition  
dang (green-black)
5. CAN H line (Rosa-Rot)
6. CAN L line (pink-white)
7. Preparation for electrical storage compartment (light blue  
yellow)
8. Seat opening adjustment device (yellow - gray)
9. Tank cap adjusting device (yellow-red)
10. Signal link Flashing (pink)
11. Signal input from contact actuator for  
Ignition (purple-white)
12. Power supply via ignition lock (orange -  
Blue)
13. Not connected
14. Input control seat opening button  
(brown-yellow)
15. Control input tank opening button (brown-red)
16. Mass (Brown - Black)



17. Switch-on control LED immobilizer (yellow orange)

18. Ground for comfort LED (gray)

19. Not connected

20. Signal right turn signal (white-blue)


---

#### **CABLE PLUG NUMBER PLATE**

##### **LIGHTING**

1. Power supply via ignition lock (light blue)


2. Ground (Black)



#### **INJECTOR CABLE CONNECTOR**

1. Power supply via remote injection relay dungs (black-green)


2. Minus from control unit (red-yellow)



#### **CABLE CONNECTOR FOR HELMET COMPARTMENT LIGHTING**

1. Power supply battery (Red-Blue)

2. Helmet compartment lighting (blue-black)




#### **FRONT RIGHT CABLE CONNECTOR**

##### **FLASHING**

1. Power supply (White-Blue)

2. Ground (Black)




---

**FRONT LEFT BLIN CABLE CONNECTOR**

BECAUSE


1. Power supply (pink)
2. Ground (Black)



---

**ALARM LED CABLE CONNECTOR**


1. Ground (Black)
2. Preparation for anti-theft protection (red)



---

**IGNITION COIL GROUND**


1. Ground (Black)



---


**FRAME DIMENSIONS**

1. Ground (Black)




**CABLE CONNECTOR ACTUATOR**


- A. Parking brake control unit (yellow)
- B. Parking brake control unit (blue)

**PLUS STARTER MOTOR**


- 1. Power supply (red)

**MINUS STARTER MOTOR**

- 1. Ground (Black)


**PLUS MOTOR FOR REVERSE GEAR**

- 1. Reverse gear motor (Red)




**CABLE CONNECTOR PICK-UP**


1. Injection control unit (red)
2. Injection control unit (brown)

**CABLE CONNECTOR FOR HELMET COMPARTMENT LIGHTING**

1. Power supply (Blue-Black)
2. Ground (Black)


**PMP3**

1. CAN H line (Rosa-Rot)
2. Power supply via ignition lock (brown Rot)
3. Signal output right turn signal (white-blue)
4. Signal output left turn signal (pink)
5. Follow me switch-on control (yellow)
6. Flasher unit (yellow)
7. DRL (yellow-brown)
8. Helmet compartment lighting (blue-black)
9. Powered by battery (Red-Blue)
10. Not connected
11. CAN L line (pink-white)
12. Mass (Black)
13. Heating switch on button (green)
14. Signal input indicator right side (red-gray)
15. Signal output left turn signal (light blue)
16. Flasher unit (yellow)
17. Turn signal deactivation button (blue-white)
18. Seat opening adjustment device (yellow - gray)
19. Mass (Black-Green)




**20. Not connected****FUEL PUMP CABLE CONNECTOR**


1. Not connected
2. Ground (Black)
3. Ground sensors (black-yellow)
4. Signal indicator light fuel indicator for In instrument unit (white-green)
5. Power supply via remote fuel relay pump (green)

**Preparation for anti-theft protection**

1. Power supply battery (red-black)
2. Power supply via ignition lock (red - green)
3. Not connected
4. Alarm-LED (rot)
5. Right turn signal signal (white-blue)
6. Signal link Flashing (pink)
7. Ground (Black)
8. Helmet compartment lighting (blue - black)
9. Not connected
10. Not connected
11. Not connected
12. Not connected

**PRE-EQUIPMENT FOR ELECTRICAL STORAGE COMPARTMENT**


1. Power supply via ignition lock (brown Rot)
2. Signal keyless control electronics (light blue-yellow)
3. Ground (Black)
4. Powered by battery (Red-Blue)






**CABLE CONNECTOR PREPARATION HANDLE****TONGUE/LEG WARMER/SEAT HEATER**


1. Power supply via ignition lock (red - green)
2. Ground (Black)
3. Powered by battery (Red-Black)
4. Preparation for heated bench (black-green)
5. CAN H line (Rosa-Rot)
6. CAN L line (pink-white)

**CABLE CONNECTOR DIAGNOSTIC CONNECTOR**


1. Power supply via ignition lock (red - green)
2. CAN H line (Rosa-Rot)
3. Ground (Black)
4. Powered by battery (pink-black)
5. CAN L line (pink-white)
6. Line K (Orange - Black)

**CABLE PLUG USB SOCKET**

1. Power supply switched plus (red black)
2. Ground (Black)


**HEADLIGHT CABLE CONNECTOR**

1. Daytime running lights (DRL) (yellow)
2. Parking light (light blue)
3. Ground (Black)
4. High beam (purple)
5. Low beam (brown)




**CABLE CONNECTOR POWER BUTTON HOT****ROOT**


1. Ground of control electronics PMP3 (black green)
2. Signal PMP3 control electronics (green)

**CABLE CONNECTOR SWITCH FOR SEAT****OPENING**


1. Signal seat opening for keyless (brown-yellow)
2. Mass (Brown - Black)

**CABLE CONNECTOR BUTTON TANK OPENING**


1. Signal tank opening button for keyless (brown red)
2. Mass (Brown - Black)

**CABLE CONNECTOR BUTTON ASR**

1. Signal (light blue-white)
2. Minus of injection control unit (gray-brown)


**CABLE CONNECTOR BUTTON LIMIT SWITCH**

1. Signal from the parking brake control electronics (braun)
2. Sensor ground (black-green)
3. Signal from parking brake control electronics (brown-white)
4. Sensor ground (black-green)




**CABLE CONNECTOR PARKING BRAKE BUTTON****SE**


1. Signal instrument unit (yellow-black)
2. Ground sensors (black-yellow)

**BRAKE LIGHT SWITCH CABLE CONNECTOR****BRAKE PEDAL**


2. Ground sensors (gray-brown)
3. Signal injection control unit (white-gray)
4. Signal injection control unit (white-pink)

**BRAKE LIGHT SWITCH CABLE CONNECTOR****RE**

2. Ground sensors (black-yellow)
3. Injection control unit (white-gray)
4. Injection control unit (white-black)


**CABLE CONNECTOR BRAKE LIGHT SWITCH LH**

2. Ground sensors (gray-green)
3. Injection control unit (pink-green)
4. Injection control unit (pink-brown)




**CABLE CONNECTOR VOLTAGE REGULATOR**


1. Battery plus (red-black)
2. Not connected
3. Ground (Black)


**CABLE PLUG SELECTOR SWITCH FOR BE  
DRIVE/REVERSE MODE**


1. Injection control unit (light blue)
2. Mass (grey-green)
3. Injection control unit (gray-black)
4. Not connected
5. Not connected
6. Not connected
7. Not connected
8. Not connected
9. Not connected
10. Not connected


**FRONT ABS SENSOR CABLE CONNECTOR  
RIGHT**

1. Minus of ABS control unit (purple-black)
2. Signal (lila-rot)



**FRONT ABS SENSOR CABLE CONNECTOR  
LINKS**

1. Negative ABS control unit (light blue Black)
- 2nd signal (light blue-red)




**REAR ABS SENSOR CABLE CONNECTOR**


- 1. Minus of ABS control unit (brown-black)
- 2nd signal (brown-red)

**CABLE CONNECTOR TILT SENSOR**


- 1. Not connected
- 2. Ground sensors (gray-green)
- 3. Supply via injection control unit (light blue green)
- 4. Signal for injection control unit (orange-green)

**CABLE CONNECTOR POSITION SENSOR GAS****HANDLE**

- 1. Power supply (1) from injection control unit (light blue-red)
- 2. Sensor ground (light blue-black)
- 3. Signal (1) injection control unit (light blue-yellow)
- 4. Power supply (2) from injection control unit (Brown-Red)
- 5. Sensor ground (brown-black)
- 6. Signal (2) injection control unit (brown-white)


**CABLE CONNECTOR DRIVER DETECTION SENSOR****SUNG**

- 1. Driver detection signal (purple)
- 2. Minus of the parking brake control electronics (black green)




**PRESSURE SENSOR CONNECTOR**


1. Parking brake control electronics (white)
2. Sensor ground (black-green)

**OIL PRESSURE SENSOR CABLE CONNECTOR**


1. Instrument unit (Pink-Black)
2. Not connected

**CONNECTOR ROTATION SENSOR**

1. Power supply from locking control unit  
brake (orange-blue)
- 2nd signal (green-blue)
3. Minus of parking brake control electronics  
(black green)


**CABLE CONNECTOR OUTDOOR TEMPERATURE SENSORS****BEER**

1. Ground (Black-Yellow)
- 2nd signal (yellow-blue)




**ENGINE TEMPERATURE SENSOR CABLE CONNECTOR****BEER**


1. Signal (light blue-green)
2. Not connected
3. Ground reference via injection control unit (Violet-black)
4. Not connected

**T-MAP SENSOR CABLE CONNECTOR**


1. Ground reference via injection control electronics (gray-green)
2. Air temperature signal output for injection expensive device (yellow-blue)
3. Supply via injection control unit (green Rot)
4. Air temperature signal output for injection expensive device (yellow-green)

**CABLE CONNECTOR SPEED SENSOR****SOR RIGHT**

1. Minus of the parking brake control electronics (schwarz-rot)
2. Speed signal (red)

**CABLE CONNECTOR SPEED SENSOR****SOR LINKS**


1. Minus of the parking brake control electronics (green-black)
2. Speed signal (Green)





**CABLE CONNECTOR SOLENOID INTRODUCTION****DIRECTION FOR IGNITION**


1. Signal + solenoid actuator for ignition  
(green white)
2. Signal - Solenoid actuator for ignition  
(green-black)

**CABLE PLUG LAMBDA SENSOR WITH HEATER****CONTRAPTION**


1. Lambda signal (+) from injection control electronics  
nik (green-blue)
2. Lambda signal (-) from injection control electronics  
(light blue-black)
3. Power supply via remote injection relay  
dungs (black-green)
4. Ground from heater for injection control electronics  
ronik (white-blue)

**CABLE PLUG BUZZER**

1. Ground (Black)
2. Power supply from locking control unit  
brake (gray)


**CABLE PLUG REAR CAMERA**

1. Power supply via ignition lock (light blue)
2. Ground (Black)
3. Signal Video (+) from Instrument Unit (Blue)
4. Signal video (-) from instrument unit (Orange-blue)




**STARTER MOTOR REMOTE RELAY CABLE CONNECTOR**


- 1A.** Output power supply via battery (red Black)
- 1B.** Output power supply via battery (red Black)
- 2.** Input power supply via ignition lock for coil starter remote relay (orange-white)
- 3.** Signal input for starter motor remote relay coil of injection control electronics (purple-white)

**CABLE CONNECTOR REMOTE RELAY BACK****GO FORWARD**

- 30R1.** Supply via relay for enabling the Reverse gear (red)
- 87R1.** Output power supply via relay motor for reverse gear (red)
- 85R1.** Signal from injection control unit for coil of the motor for reverse gear (white-purple)
- 86R1.** Power supply via remote injection relay Charges (Black-Green)
- 30R2.** Output power supply via relay for Release of reverse gear (red)
- 87R2.** Input power supply relay for enabling reverse gear (red)
- 85R2.** Signal from injection control unit for coil for enabling reverse gear (blue)
- 86R2.** Power supply via remote injection relay Charges (Black-Green)

**ACTIVATED CHARCOAL VALVE CABLE CONNECTOR****FILTERS**

- 1.** Signal for injection control unit (white-black)
- 2.** Power supply via remote injection relay dungs (black-green)

**Duplication of keys/remotes**

Procedure for duplicating the remote control with "Piaggio KeyLess" system.

**A= remote control**

**B= Master key**

### 1. Checking the initial conditions:

1.1 Battery voltage over > 12V. \_\_\_\_\_

1.2 The master key must be available

1.3 All remote controls to be coded must be present (including those already available before process coded),

1.4 The PADS diagnostic instrument must be connected to the vehicle's OBD connector to do this, use the special tool.

## Special tool

020922Y Diagnose-Instrument

021017Y Diagnostic cable EOBD E5

### 2. Start the duplication process before Up

call the self-diagnosis Keyless

**PADS:**

2.1 Ignition key to "OFF",

2.2 The remote control by pressing the first and deactivate the second button.

2.3 Press the ignition lock and at the same time

Master key (mechanical key).

approach the keyless control unit. (\*)

2.4 After the emergency indicators flash, the

Turn the ignition key to "ON" (\*\*).

(\*) The master key is with an integ

equipped with a transponder and must be on the contact between the back of the shield and the inner part

be approximated at the top left, where the

Keyless control unit is located.

(\*\*) From the moment the selector switch

is set to "ON", the process must be completed

Programming the remote controls internally

half of 120 seconds can be started (Be

write in step 3. Otherwise the

The process can be started from step 2.





**3. Start procedure in Self Diagnosis > Pro  
Programming the keyless remote controls  
through PADS:**

**3.1** With ignition key set to "ON",

**3.2** The self-diagnosis of the keyless control unit  
call,

**3.3** Possible errors in memory in the "MEM" status  
eliminate, and/or resolve the problems  
continue,

**3.4** Access the Settings section and  
the setting>programming remote control  
start according to the ge offered by PADS  
conducted procedure,

**3.5** At the end of each remote control program  
PADS displays the message "Programming \_\_\_\_\_"  
"successful" with the following message  
Programming a new remote control, ma \_\_\_\_\_  
maximum 4 remote controls (\*\*\*),

**(\*\*\*) The keyless control unit switches between**  
programming a remote control and  
the other has 5 seconds of time available.

End of the remote control programming process.



## TABLE OF CONTENTS

ENGINE FROM THE VEHICLE

MOT DRIVE

This section describes the operations to be carried out to remove the engine from the vehicle.

## Removal of complete exhaust

- Remove the right and left running boards.

- Unscrew the four fastening screws  
and remove the heat protection.

### ANNOTATION


**It is NOT necessary to remove the running boards just to dismantle the end piece.**



- The metal clamp between the exhaust tailpipe and  
Loosen the manifold.



- The three exhaust mounting screws  
Remove tailpipe.



- Remove the exhaust pipe end piece by  
pulls it off the manifold.

### DANGER

**IF ONLY REMOVING THE EXHAUST PIPE IS REQUIRED,  
ALWAYS A NEW GRAPHITE GASKET  
PLACE A BETWEEN THE PIPE PIECE AND THE END  
PIECE.**





## MP3 530 hpe

Engine out of the vehicle

- Release the lambda sensor cable connector and cut him off.

### **DANGER**


**CLEAR THE LAMBDA SENSOR WIRING BEFORE REMOVAL OF THE EXHAUST. WILL BE THIS CABLING WITH TOO HIGH VOLTAGE CAN BE DAMAGED.**



- The fixing screw of the pipe of the rear  
Unscrew the wheel brake from the frame.



- Remove the right nut of the exhaust flange.



- Remove the left nut of the exhaust flange.


### **ANNOTATION**

**To make the dismantling work easier, the Spark plug cables must be separated to provide greater freedom of movement.**





- Remove the exhaust manifold while keeping it on top
- Pay attention to the lambda sensor wiring harness to pull out.



### INSTALLATION OF COMPLETE EXHAUST


- If necessary, the lambda sensor on the exhaust install manifold.

### **Torque guide values (N\*m)**


**Fastening lambda probe  $25 \pm 5$**



- Install the exhaust manifold on the vehicle,
- Pay attention to the lambda sensor when in not to damage the installation.
- Screw on the two nuts of the exhaust flange ben.



- Connect the lambda sensor cable connector and attach it to the appropriate bracket.



## MP3 530 hpe

Engine out of the vehicle

- The rear brake tube back in position

bring and the appropriate fastening

Tighten screw on frame.



- Install the end piece on the exhaust manifold.

### **DANGER**

**ALWAYS REPLACE THE GRAPHITE GASKET BETWEEN THE END PIECE AND THE EXHAUST MANIFOLD.**




- Insert the three fastening screws and

Tighten with the specified torque.

### **Torque guide values (N\*m)**

**Exhaust end part fastening screw  $28.5 \pm 1,5$**



- The two exhaust mounting nuts

flange with the specified torque

pull.

### **Torque guide values (N\*m)**

**Fastening nut exhaust flange  $17 \pm 1$**



- The metal clamp between the exhaust tailpipe and  
Loosen the manifold.

**Torque guide values (N\*m)****Metal clamp  $13 \pm 1$** 

- Install the heat protection on the exhaust pipe end  
animals and make sure that the pen is in the ent  
speaking rubber bushing on the end piece  
is set.



- The four fixing screws of the heat protection  
with the specified tightening torque  
pull.

**Torque guide values (N\*m)****Fastening screw heat protection  $4.5 \pm 0.5$** 

TABLE OF CONTENTS

MOTOR	AGAINST
-------	---------



This section describes the work on the engine and the tools required for it.

---

## Automatic drive

---

### Gearbox cover

---

- Unscrew the 4 fastening screws.
- Remove the outer plastic drive cover.



- Use a screwdriver to open the cover

Remove the driven pulley axle.




- The special tool in the designated areas

Install slots and the nut of the output

Unscrew the disc axle.

- Remove the nut and the two washers distant.

- Remove the special tool.



### Special tool

021022Y Stop guided pulley

## MP3 530 hpe

Motor

- Remove the drive cover screws.

**7 screws M6**



- The screws on the right side of the lid remove.

**2 screws M8x70**

Remove the screws on the middle part.

**2 screws M8x100**



- Remove the drive cover.

- Check whether the bearing rotates freely. Otherwise must it needs to be replaced.



## Air baffle



- Remove the drive cover.
- Unscrew the two fixing screws shown in the illustration and remove the air baffle mount.

---

**Torque guide values (N\*m)**

Air baffle screws  $7.0 \pm 1.0$  Nm

---

**Removing the shaft bearing of the guided pulley**

---

- Remove the drive cover.
- Remove the seeger ring.



- The drive cover with a wooden plate and the Support special tools.
- Remove the bearing using the special tool.

**ANNOTATION**

THE BASKET MUST BE PLACED UNDER THE INSIDE OF THE LID NEAR THE BEARING SEAT AND THE WOODEN SUPPORT BECAUSE WITHOUT THE BASKET THERE IS A RISK THAT THE ENTIRE COVER STRUCTURE WILL BEND, NOT JUST IN THE STIFFER AREA. NOT ONLY IN THE STIFFER AREAS.

**Special tool**

001467Y002 Basket for bearings with external diameter  $\varnothing$  73 mm

020376Y Handle for adapter

020375Y Adapter 28 x 30 mm

020439Y Guide 17 mm



---

**Installation of shaft bearing guided pulley**

---

- The inside of the drive cover with a Heat the heat gun.

**ANNOTATION**

TO AVOID DAMAGE THE PAINTED EXTERNAL SURFACE, MAKE SURE NOT TO HEAT THE LID TOO HOT.

**Special tool**

020151Y hot air gun





- Place the bearing on the special tool and attach with a little fat.
- Insert the new bearing with the special tool build.

### ANNOTATION

**TO NOT DAMAGE THE PAINT SURFACE,  
PLACE THE LID ON A SUITABLE SURFACE.**

### Special tool

020376Y Handle for adapter

020358Y Adapter 37 x40 mm

020439Y Guide 17 mm



## Removal of guided pulley

- Remove the clutch basket, if necessary with one screwdriver and a plastic mallet.



- Remove the fixed drive belt half pulley in.
- The assembly guided pulley together pull it off with the belt.



---

## Check clutch basket

- Check that the clutch basket is not worn or otherwise damaged.
- The inner diameter of the clutch basket measure.

### ANNOTATION

THE MEASURED ECCENTRICITY MUST NOT BE MORE THAN MAXIMUM 0.2 MM.

### Technical specifications

#### Permissible limit:

160,5 mm

#### Default value:

160,2 mm



---


## Dismantling the clutch

- To remove the entire clutch from the the guided pulley must be the special work stuff can be used.
- The special tool with the in position «E» of medium-length pin attached to the inside equip.

### Special tool

#### 020444Y Tool for attaching and removing the Clutch on the guided pulley

- Attach the adapter ring as shown in the picture Insert the clutch unit.



- The assembly guided pulley on  
Attach special tool. They have to  
Pins inserted into the ventilation holes  
the.

- Tighten the rear fixing screw as shown in the  
figure until it stops  
Attach the guided pulley.

**DANGER**

**THE TOOL MUST BE FIXED WITH THE APPROPRIATE EXTENSION  
VICE CAN BE USED. IN ORDER TO NOT CAUSE PERMANENT DEFORMATION  
TO CAUSE TOOL, THE REAR MOUNTING SCREW MUST NOT TIGHTEN  
BE TIGHTENED.**

**- REMOVE THE FASTENING THREADED RING WITH THE APPROPRIATE 55MM WRENCH.**

**- UNSCREW THE SCREW ON THE TOOL AND DISASSEMBLE THE GUIDED BELT PULLEY,  
CLUTCH AND SPRING ASSEMBLY WITH PROTECTIVE COVER.**

**Checking the clutch**

- Measure the thickness of the abrasive material on the coupling masses.

**Technical specifications**

**Smallest permissible thickness:**

1 mm

- The masses must not show any traces of lubricant. Otherwise the assembly seals  
Check guided pulley.

**ANNOTATION**

**DURING THE RUN-IN PERIOD THE COUPLING MASSES MUST HAVE CENTRAL CONTACT  
SURFACES. THEY MUST ALL BE THE SAME. DIFFERENT CONDITIONS WILL CAUSE THE  
CLUTCH TO TEAR.**

- Do not open the clutch masses with tools in  
order to change the spring tension  
To avoid return spring.



## Tenon collar ring

---

- Remove the collar using 2 screwdrivers pull it off.



- 
- Remove the 4 guide pins.
  - Pull off the movable belt half pulley.



---

## Control fixed guided belt half pulley

---

- The contact surface with the belt on ver check wear.
- The outside diameter of the pulleys measure socket.

### Technical specifications

#### Smallest permissible diameter:

49,91 mm

#### Standard diameter:

50,00 -0,015 -0,035 mm

---



---

## Removal of bearing guided belt half pulley

---

- Check the bushing for signs of wear and damage.

If necessary, replace the fixed guided belt half pulley.

- Remove the locking ring using a suitable one Remove pliers.



- With the attached in the roller bearing

Remove the ball bearing using a special tool to drive.

### ANNOTATION

IN ORDER TO NOT DAMAGE THE THREAD, THE BELT PULLEY MUST BE PLACED ON A SUITABLE SURFACE.

### Special tool

020376Y Handle for adapter

020456Y Adapter Ø 24 mm

020363Y Guide 20 mm

### ANNOTATION

IF THE BEARING REVISION IS CARRIED OUT WITH A GUIDED PULLEY ASSEMBLY INSTALLED, THE ASSEMBLY MUST BE SUPPORTED WITH THE BASKET.

### Special tool

001467Y002 Basket for bearings with outer diameter Ø 73 mm

- The roller bearing with the specified special remove tool. The straps must be there Half disc can be supported with the basket.

### Special tool

020376Y Handle for adapter

020375Y Adapter 28 x 30 mm

020364Y Guide 25 mm

001467Y002 Basket for bearings with external diameter Ø 73 mm




---

## Control movable guided belt half pulley

---

- The contact surface with the belt on ver  
check wear.
- Remove the 2 inner sealing rings and the 2 outer  
O-rings.
- The inner diameter of the bushing of the movable  
Measure the belt half pulley.



### Technical specifications

#### Maximum permissible diameter:

50,05 mm

#### Standard diameter:

50,00 +0,035 0,00 mm

---

## Installation of bearing guided belt half pulley

- Install a new roller bearing using the specified special tool.

### ANNOTATION

**INSTALL BEARING WITH LABEL AND OIL SEAL INSTALLED SO THAT THEY FACE OUTSIDE.**

- In order not to damage the thread, the pulley must be placed on a suitable surface  
be placed.

When working with the assembled assembly of the guided pulley, the spe  
target tool can be used.

---

### Special tool

**020478Y Punch mandrel for needle sleeve**

**001467Y002 Basket for bearings with external  
diameter Ø 73 mm**



- Install a new ball bearing using the specified special tool.

**Special tool****020376Y Handle for adapter****020477Y Adapter 37 mm****020363Y Guide 20 mm**

- Insert the circlip.
- 

**Assembling the guided pulley**

- Insert the new shaft seals.
- Insert the new O-rings.

**ANNOTATION**

**THE TWO O-RINGS ARE DIFFERENT SIZES. THE LARGE O-RING IS PLACED ON THE CIRCUMFERENCE OF THE WORKING END ON THE BASE OF THE BELT HALF-PULLEY.**

---

- Place the belt half pulley onto the bushing

Zen. Be sure to make sure that the above right sealing ring is not damaged.

- Check the pins and collar ring for wear check and install.



Using a curved nozzle grease gun, grease the guided pulley assembly with approximately 10g grease. The grease is inserted into the inside of the bushing through one of the holes until it begins to emerge on the opposite side. This step is necessary to ensure that no grease gets behind the O-rings.

**Recommended products**

**Lubricating grease with molybdenum disulfide Lithium grease with the consistency of a paste, contains molybdenum disulfide.**

Grey-black grease

---



---

### Check the compression spring

The free length of the compression spring between the clutch and the guided pulley half measures its.

#### Technical specifications

**Standard length:**

**146,5 mm**

**Maximum permissible length according to use:**


**137,0 mm**



---

### Installation of the clutch

- The special tool as used for removal  
Equip additional parts.
- The assembly guided pulley together temporarily assemble the men with the belt.  
Pay attention to the running direction of the belt.
- The assembly guided pulley, the spring with protective cover and the clutch in the factory use stuff.



#### Special tool

**020444Y Tool for attaching and removing the Clutch on the guided pulley**

- Compress the spring and insert the coupling into the bushing of the guided pulley was

#### ANNOTATION

**MAKE SURE THAT THE PROTECTIVE COVER AND THE THREADED PART OF THE SOCKET TO BE DAMAGED.**

- Tighten and tighten the threaded ring manually closing with the specified special work with the specified torque tighten.

#### Special tool

**020444Y Tool for attaching and removing the Clutch on the guided pulley**

**Torque guide values (N\*m)**

**Threaded ring coupling 65 - 75**



- To facilitate installation on the engine, turn the guided movable pulley and the Insert the belt at the smallest diameter.

---

### Installation guided pulley

- The assembly guided pulley together  
Insert the men with the belt.



---

### drive belt

- Check that the drive belt is not damaged  
is right.
- Measure the belt width.


#### Technical specifications

##### Minimum width

27,5 mm

##### Total width

28,7 mm




---

### Removing the drive pulley


- Assemble the special tool by  
first attach the two retaining straps to the strap  
disc attaches so that the notch is complete  
rests.

#### Special tool

020474Y Key to block the on  
drive pulley



- 
- The 2 fastening screws can also be tightened by hand screw the main tool.



- 
- Use a 27 mm wrench to tighten the center  
Unscrew the drive belt pulley nut  
ben.



- Remove the washers.
- Remove the fixed drive belt half pulley  
in.

- 
- The assembly guided pulley together  
pull it off with the belt.



- 
- Remove the connecting washer to the socket  
with.



- The mobile drive belt half pulley with the
- Pull out the associated socket while doing so make sure that the rollers do not fall out.



- Pull out the rear washer.



- The drive side housing is now free



---

## Check roll container

- Check that the internal bearing bushes do not show excessive wear. The inside measure diameter.

### **DANGER**

- **DO NOT LUBRICATE OR CLEAN THE BEARING BUSHINGS.**

### **Technical specifications**

#### **Maximum permissible diameter:**


30,12 mm

#### **Standard diameter:**

30,021 mm

- The outside diameter of the pulleys

Measure the liner as shown in the figure.



### Technical specifications

#### Smallest permissible diameter:

Ø 29,95 mm

#### Standard diameter:

Ø 29,959 mm

- Check that the rollers are not damaged or worn.

### Technical specifications

#### Smallest permissible diameter:

Ø 24,5 mm

#### Standard diameter:

Ø 24,9 mm

---

- Put the running shoes on the roller stop plate

Check wear.

- The wear condition of the grooves (roller seats) and the belt treads on both belts

Check half washers.





### Install drive pulley

#### Installation of roller containers

- Insert the spacer with the inner bevel in the installation direction.



- Check that the running shoes fit the rollers striking plate are not worn.
- The wear condition of the grooves (roller seats) and the belt treads on both belts

Check half washers.

- The rollers as shown in the picture
- Attach half washer.
- The closed side must be on the inside rest on the pressure side of the roll container.



- The belt half pulley with roller stop and running shoes.



- The bushing and drive belt half pulley insert.



- 
- Place the drive belt on the guided belt mount the disc.




---

#### Installation of fixed drive belt half pulley

- Insert the spacer.



- Insert the fixed drive belt half pulley and check that they have the spacer and the liner of the movable drive belt half disk touches.



- The flat washer and the plate washer Attach as shown in the picture.





- The nut in the same installation position as attach beforehand (mother side contact Tel disk).



- Assemble the special tool by first attach the two retaining straps to the strap disc attaches so that the notch is complete rests.
- The 2 fastening screws can also be tightened by hand screw the main tool.



### **Special tool**

**020474Y Key to block the on drive pulley**

- Fasten with a 27mm wrench Drive pulley nut with the specified one Tighten the specified torque.
- Remove the special tool.



### **Torque guide values (N\*m)**

**Nut drive pulley 160 - 175**

---

## **Installing the gearbox cover**

- Put on the drive cover.



**DANGER****WARNING**

THE FOUR M8 SCREWS OF THE DRIVE COVER HAVE DIFFERENT LENGTHS: THE TWO LONG SCREWS ARE MOUNTED IN THE MIDDLE PART, THE TWO SHORT SCREWS IN THE RIGHT PART.



- Tighten the screws on the middle part.

**2 screws M8x100**

**Torque guide values (N\*m)**

Fasteners M8 drive cover 23 ÷ 26 Nm (17 ÷ 19 lb\*ft)



- Tighten the screws on the right part.

**2 screws M8x70**

**Torque guide values (N\*m)**

Fasteners M8 drive cover 23 ÷ 26 Nm (17 ÷ 19 lb\*ft)



- Screw on the drive cover screws

ben.

**7 screws M6**

**Torque guide values (N\*m)**

Fasteners M6 drive cover 11 ÷ 13 Nm (8 ÷ 10 lb\*ft)



## MP3 530 hpe

Motor

- The washers on the shaft of the guided  
Put on the th belt pulley.

**ANNOTATION**

**FIRST PUT ON THE WASHER WITH THE SMALLER OUTER  
DIAMETER AND THEN THE LARGER ONE.**



- Place the special tool in the designated areas  
Insert slots, rotate the shaft if necessary,  
to be able to fully introduce it.

**Special tool**

**021022Y Stop guided pulley**




- Install the driven pulley axle nut.



- The mother with the prescribed suit  
tighten moment.

**Torque guide values (N\*m)**

**Nut guided pulley 92 ÷ 100 Nm (68 ÷ 74 lb\*ft)**





- 
- Remove the special tool.



- 
- Install the drive pulley axle lock
- animals.



#### ANNOTATION

**CHECK THAT THE AIR INLET AND AIR OUTLETS ARE COMPLETELY CLEAR.**

- 
- Put on the outer plastic drive cover.
  - The 4 fastening screws with the indicated
- tighten to the desired torque.

#### **Torque guide values (N\*m)**

Noise protection cover - drive cover  $7.0 \pm 1.0$  Nm



---

### Rear wheel transmission

---

**Removing the rear wheel gear cover**

---

- The rear wheel gear oil through the drain screw be drained at the bottom of the engine.



- The hub cover fastening screws remove.

**4 long screws**


**3 short screws**

**ANNOTATION**

THE FASTENING SCREWS ARE DIFFERENT IN LONG.  
DO NOT CERTAIN YOUR RESPECTIVE INSTALLATION  
POSITIONS.



- The hub cover together with the associated remove the seal.




---

**Removing the rear wheel axle**

---

- Remove the countershaft.
- Remove the wheel axle complete with gear.



## Removing rear wheel gearbox bearing housing

---

- The condition of all bearings (wear, play and Check noise development).

If errors are found, proceed as follows.

The following tools are required to remove the wheel axle bearing from the housing of the rear wheel transmission.



### Special tool

**001467Y014 Pliers for removing bearings  
Ø 15 mm**

**001467Y031 Pliers for removing bearings with  
Ø 15 mm**

**001467Y031 Korb**

---


- To remove the countershaft bearing

The motor housing must have the corresponding off pulling device can be used.

### Special tool

**001467Y006 Pliers for removing bearings with  
20 mm**

**001467Y035 Basket for bearings with external  
diameter Ø 47 mm**



- The rear gearbox cover with the columns support sentence.


- Remove the bearing using the special tool.

### Special tool

**020476Y screw bolt**

**001467Y006 Pliers for removing bearings with  
20 mm**

**001467Y007 Basket for bearings with external  
diameter Ø 54 mm**



## Wheel axle bearing removal

---

- The circlip from the outside of the lid remove.



- The rear gearbox cover with the columns support sentence.
- Remove the bearing using the special tool.

### Special tool

**020476Y screw bolt**

**020376Y Handle for adapter**

**020477Y Adapter 37 mm**

**020483Y Guide (30 mm)**



- Remove the shaft seal with a screwdriver remove.



---

## Removing the shaft bearing of the guided pulley

---


- Must the shaft of the guided pulley, the corresponding bearing and the shaft seal To be removed, the drive must first be removed cover and the clutch unit as in chapter "Automatic transmission" described who removed it the.
- The shaft of the guided pulley from the Pull bearing.







- Remove the shaft seal with a screwdriver from inside the rear wheel housing expand the drive.
- Remove the circlip shown in the illustration distant.

- Using the specified special tool, la ger of the shaft of the guided pulley Remove the motor housing.

**Special tool****020376Y Handle for adapter****020358Y Adapter 37 x40 mm****020364Y Guide 25 mm**

## Checking the rear gear shafts

- Check that the 3 waves are on the tooth surface when, the bearing surfaces and the shaft seal rings are not worn or deformed.
- If abnormalities are detected, the be Replace damaged components.

**Technical specifications****Countershaft running surface diameter:****A =  $\varnothing$  20 - 0,01 -0,02 mm****Technical specifications****Wheel axle tread diameter:****B =  $\varnothing$  30 - 0,010 -0,023 mm****C =  $\varnothing$  15 - 0,01 -0,02 mm**


**Technical specifications**

**Diameter of running surface of shaft guided pulley:**

**D** = Ø 15 - 0.01 -0.02 mm

**E** = Ø 20 - 0.01 -0.02 mm

**F** = Ø 25 - 0,01 -0,02 mm

**Checking the rear gearbox cover**

- Check that the mating surfaces are not scratched or warped.
- Check the bearing surfaces.

**If damage is found, the rear gearbox cover must be replaced.**

**Installing the shaft bearing of the guided pulley**

- Heat the housing with the heat gun.

**Special tool**

**020151Y hot air gun**



- Remove the bearing of the shaft of the guided pulley using the specified special tool
- Insert it into its seat until it stops.

**ANNOTATION**


**THE BALLS MUST BE VISIBLE FROM THE REAR GEAR (THIS REQUIREMENT APPLIES TO ALL BEARINGS WITH PLASTIC CONTAINERS).**

**Special tool**

**020376Y Handle for adapter**

**020360Y Adapter 52 x 55 mm**

**020364Y Guide 25 mm**



- Heat the countershaft bearing seat.
  - The bearing of the countershaft with the specified
- Use the specified special tool.

**ANNOTATION**


THE BALLS MUST BE VISIBLE FROM THE REAR GEAR  
(THIS REQUIREMENT APPLIES TO ALL BEARINGS WITH  
PLASTIC CONTAINERS).

**Special tool**

**020376Y** Handle for adapter

**020359Y** Adapter 42 x 47 mm

**020363Y** Guide 20 mm



- The bearing seat of the wheel axle bearing on the housing
- heat.

- Remove the wheel axle bearing with the special tool
- Insert the upper seat on the housing.

**ANNOTATION**

THE BALLS MUST BE VISIBLE FROM THE REAR GEAR  
(THIS REQUIREMENT APPLIES TO ALL BEARINGS WITH  
PLASTIC CONTAINERS).

**Special tool**

**020376Y** Handle for adapter

**020359Y** Adapter 42 x 47 mm

**020412Y** Guide 15 mm



- Install the circlip of the bearing of the guided
- pulley shaft.

**ANNOTATION**

NOTE THE INSTALLATION POSITION SHOWN IN THE  
ILLUSTRATION.



- The shaft seal of the guided belt pulley
- Insert it from the drive side.



---

## Installing the bearings in the rear gearbox cover

---

- The bearing seats on the rear wheel gear cover


Heat with a heat gun.

- The rear gearbox cover with the columns support sentence.

### Special tool

**020151Y** hot air gun

**020476Y** screw bolt



- The bearing of the countershaft with the specified

Use a special tool in the rear wheel gear insert cover.

### ANNOTATION


THE BALLS MUST EXIT FROM THE REAR WHEEL GEAR BE VISIBLE (THIS REQUIREMENT APPLIES TO ALL WAREHOUSES WITH PLASTIC CONTAINERS).

### Special tool

**020376Y** Handle for adapter

**020360Y** Adapter 52 x 55 mm

**020363Y** Guide 20 mm



- The bearing seat of the wheel axle bearing from the Au

Heat the outside of the rear wheel gear cover.

- The wheel axle bearing with a suitable blow mandrel into the rear wheel gear as far as it will go insert cover.

### Special tool

**020376Y** Handle for adapter

**020360Y** Adapter 52 x 55 mm

**020483Y** Guide (30mm)



- Install the snap ring.



- The rear gearbox cover with the columns support sentence.
- The shaft seal of the wheel axle with the sealing lip towards the inside of the rear wheel gear  
Install cover.
- Allow the shaft seal to be flush with the rear wheel gear cover.



### Special tool

**020376Y Handle for adapter**

**020360Y Adapter 52 x 55 mm**

**020476Y screw bolt**

## Installation of rear wheel gears

- Attach the 3 shafts as shown in the picture bring.



## Installing the rear gearbox cover

- Correct attachment of the centering pins check.
- Install a new gasket.
- Install the cover. Pay attention to the correct positioning of the ventilation line.



## MP3 530 hpe

Motor

- The fastening screws according to the  
Use the position noted when dismantling.

**4 long screws**

**3 short screws**

- The screws with the specified rotation  
Tighten momentarily and adjust to position  
the retaining clamps of the ventilation line  
pay attention as shown in the figure.



### Torque guide values (N\*m)

**Screws cover rear wheel gearbox. 24÷27**

- The rear gear oil drain plug  
insert and with the prescribed rotation  
tighten moment.
- The rear wheel transmission up to its maximum level  
Fill with the specified oil.



### Suggested products

**Gear oil 80W-90 lubricant for gears  
and drives.**

SAE 80W-90; API GL-4

### Torque guide values (N\*m)

**Rear gearbox oil drain plug 15 ÷ 17 (11  
÷ 12.5 lb\*ft)**

## Alternator cover

- To make the alternator cover easier to remove  
To be able to build, you need the 4 in the picture  
hose clamps shown removed and the Muf  
fe of the supply line on the cylinder and the return line  
removed from the pump cover.

### ANNOTATION

**THE CLAMPS NEED TO BE REPLACED.  
THEY CAN BE OPENED WITH A SCREWDRIVER OR CUT  
THROUGH FOR REMOVAL.  
MAKE SURE THAT THE PLASTIC CONNECTIONS ARE  
NOT DAMAGED.**





## Removing the alternator cover

- Drain the engine oil via the oil drain plug its.
- A suitable container to collect the  
Place the engine oil under the drain plug.



- Remove the pre-filter.



- The filter with a suitable filter band  
Remove key or filter key.



- The 13 mounting screws of the alternator  
Unscrew the lid, paying attention to the various parts  
which lengths pay attention to:  
**1 medium screw 75 mm**  
**9 medium length screws 40 mm**  
**3 short screws 31 mm**

### ANNOTATION

**THE FASTENING SCREWS ARE DIFFERENT IN LONG.  
DO NOT CERTAIN YOUR RESPECTIVE INSTALLATION  
POSITIONS.**





- The alternator cover together with the associated seal and the holder for the Remove the cooling system sleeves.

**DANGER**

KEEP IT ON WHEN REMOVAL OF THE ALTERNATOR COVER  
MAKE SURE THAT THE STATOR AND THE ROTOR  
DO NOT JUMP.

**DANGER**

BE CAREFUL THAT THE SMALL BY PASS LINE VALVE  
AND ASSOCIATED SPRING DO NOT FALL OUT.



## Dismantling the alternator cover components

- Unscrew the fixing screws and remove the water pump cover.

**6 Torx screws T25**




- Remove the by-pass and the associated spring with.
- Remove the gasket.




## Dismantling the stator

- Remove the 2 fixing screws and the cable guide.



- 
- Unscrew the 3 fastening screws and  
Remove the stator completely with cables.



---

### Check the lid components

- 
- Unscrew the 2 fixing screws and  
the holder of the reed valve with separating plate  
remove.




- 
- The reed valve of the blow-by line together  
Remove the men with the associated seal.



- 
- Unscrew the fixing screw and remove the oil vapor  
pipe together with the associated O-ring.



- Check that the mating surfaces on the housing are not worn or deformed.
- The seat of the by-pass valve, the running surface of the Torque limiter and the running surface of the Water pump shaft for signs of wear check.

**Technical specifications****Diameter seat by-pass:**

13,9 mm


**Diameter of starter shaft running surface:**

12 mm

**Diameter running surface water pump shaft:**

8 mm

- Check that the mating surface and the oil fill The connection is not worn or deformed are.



- Check the stator and the associated cables for damage.



- The current continuity between the 3 phases

check.

#### ANNOTATION

THE VALUES STATED REFER TO MEASUREMENTS AT ROOM TEMPERATURE. WILL BE THE STATOR CHECKED AT OPERATING TEMPERATURE, HIGHER THAN THE STATED VALUES ARE MEASURED.

### Electrical information

#### Resistance:

$0.2 \div 1 \, \Omega$



- Check that each phase is iso to ground

is latched.

- If different values are measured, this must be done

the cabling must be checked carefully. The


Wiring consists of 2 different cables

beln: Stiff cables near the stator and

soft cables up to the cable connector.



- Check that the windings are properly attached are that they are the heads of the fastening screw Don't touch Ben.



## Installation of the stator

- Install the stator and the 3 fasteners

screw with the specified torque


ment tighten.

#### ANNOTATION

THE RUBBER SEALING OF THE CABLE BUNDLE MUST BE IN THE APPROPRIATE SEAT WILL BE PLACED ON THE HOUSING.

### Torque guide values (N\*m)


Fasteners stator 8 - 10



- Install the cable guide and secure the 2 fastening screws with the specified one
- Tighten torque.

**Torque guide values (N\*m)**


**Cable guide fixing screws**  
**Stator 3 - 4**

**Installing the alternator cover components**


- Before installation, all components must be cleaned thoroughly be cleaned.
- All lubrication lines must be on the cover housing checked. Particularly:
- The 3 by-pass lubrication channels.



- Supply line to the oil pressure sensor.



- Oil vapor outlet from the decanter chamber.





- The closure on the inspection opening for the phase adjustment of the valve control and the oil in Filler plug/dipstick for the engine oil provisionally attach correctly.
- The blow-by line with a new O-ring insert.
- The screw with the specified rotation tighten moment.



### Torque guide values (N\*m)

#### Fastening screws for the blow-by line

3 - 4

- The spring and the by-pass valve in the light Insert machine cover.

#### ANNOTATION

LUBRICATE THE BY-PASS VALVE.



- The blow-by reed valve with a new one Reinstall the seal.
- Reinstall the bracket with separating plate and the fastening screws with the given Tighten the specified torque.



### Torque guide values (N\*m)

Fixing screws bracket with separator plate 0.3 ÷ 0.4

- Insert the new O-ring carefully. The O-ring must not come into contact with grease and oil.

**FAILURE TO FOLLOW THIS INSTRUCTION WILL RESULT IN PERMANENT DEFORMATION OF THE O-RING.**

- Attach the water pump cover and the 6 Fastening screws with the specified tighten to a certain torque.

### Torque guide values (N\*m)

Pump cover fixing screws: 3 ÷ 4



## Installation of alternator cover

- Install a new oil filter, the gasket

Lubricate by hand until it stops

screw and then with the provided

Tighten the specified torque.

### Torque guide values (N\*m)

Engine oil filter 12 ÷ 16



- The sleeve of the supply line on the cylinder and the

Reattach the return line to the pump cover

and fasten with new clamps.

### ANNOTATION

**THE CLAMPS MUST BE WITH THE APPROPRIATE  
CLAMP PLIERS MUST BE INSTALLED  
MAKE SURE THAT ON THE ONE HAND  
HOSES ARE NOT PRESSED TOO STRONG, BUT  
ARE FIXED SUFFICIENTLY.**



- The pre-filter and the oil drain plug again

attach and with the prescribed rotation

tighten moment.

- Fill the specified engine oil into the engine.

### Suggested products

**Motor oil 5W-40 synthetic-based lubricant for 4-stroke engines.**

SAE 5W-40; JASO MA, MA2; API SL; ACEA A3

### Torque guide values (N\*m)

Oil drain plug engine oil 24 ÷ 30



- The seat of the intermediate gear with torque

ment limiter on the alternator cover

lubricate.

- The drive of the water pump on a Markie

Alignment and the alternator cover


as described in the alternator cover chapter

install.





- Install a new gasket on the engine housing gen.
- Make sure the 3 centering pins are present are.



- Turn the crankshaft until the drive the countershaft to a mark on the gear house is aligned (see illustration).



- The water pump shaft on the same mark Align the connection on the housing.

**ANNOTATION**

**THESE PROVISIONS ARE PARTICULARLY USEFUL IF THIS WORK IS CARRIED OUT WITH THE WATER PUMP COVER IN PLACE.**



- Install the alternator cover, making sure that the stator and rotor are not in contact jam.

**WARNING**


**FAILURE TO FOLLOW THIS INSTRUCTION MAY RESULT IN THE BREAKAGE OF THE CERAMIC MAGNETS LEAD.**

- The alternator mounting screws  
nenlid according to the position noted during removal  
position, ensuring correct assembly  
the cable routing of the oil pressure sensor and the  
Pay attention to the holder of the sleeve.

**1 medium screw 75 mm**

**9 medium length screws 40 mm**

**3 short screws 31 mm**



## Torque guide values (N\*m)

Alternator cover screws 11 ÷ 13 Nm (8 ÷ 10 lb\*ft)

## Alternator and starter system

- To make the alternator cover easier to remove


To be able to build, the three in the illustration must

The clamps shown in the diagram are removed and the socket  
the supply line on the cylinder and the return line on

Pump cover must be removed.

### ANNOTATION

**THE CLAMPS NEED TO BE REPLACED.  
THEY CAN BE OPENED WITH A SCREWDRIVER  
OR CUT THROUGH FOR REMOVAL.  
MAKE SURE THAT THE PLASTIC CONNECTIONS  
ARE NOT DAMAGED.**



The starter motor is sold complete.

Before replacing the starter motor,  
the following must be checked:

### 1 - Battery

Measure the battery voltage in idle state

(rest for a few hours): Voltage

> 12.5 V.

Check the electrolyte density in each battery element  
fen:

Baby = 30 ÷ 32

Specific gravity: 1.25 ÷ 1.26

YES point 2 NO point 3

2 - The correct connection of the negative terminals

(negative terminal of the battery and ground connection of the  
starter motor) with each other and with the yard  
check menu.

YES - point 4 NO point 5

3 - Charge or change the battery if necessary.

4 - Connect the diagnostic tester (see chapter «Injection»).

The induction clamp of an ammeter on the positive cable of the starter motor power supply  
connect.

Remove fuse No. 12 with 10 A (see chapter "Fuses").

With the switch in "RUN" and the side stand raised, set it to "ON".

Select the «PARAMETER» function from the menu.



Only operate the starter switch (the engine cannot start) until the speed and the current consumption of the starter motor can be measured.

**ANNOTATION**

**THE SPEED VALUE STATED IS THE VALUE DISPLAYED BY THE DIAGNOSTIC TEST EQUIPMENT. THE ACTUAL RPM IS NOT RECORDED, BUT THE VALUE IS VALID FOR THE CHECKS.**

**Special tool**

020922Y Diagnose-Instrument

**Electrical information**

**Current consumption at driving speed:**

80 ÷ 120 A

**Speed =**

~ 300 ÷ 400 U/Min

YES point 6 NO point 7 NO point 8 NO point 9 \_\_\_\_\_

5 - Reconnect the connections.

6 - **The values are OK.**

As a final confirmation, check the current consumption without load.

Remove the starter motor (see Alternator and Starter System chapter).

Reconnect ground and plus and check.

**Electrical information**

**Current consumption without load:**

<40 A

YES point 10 NO point 11

7 - **Low driving speed**

**High current consumption**

Check the engine rotation (example: damage to the crankshaft bearing), if no errors are found, the starter motor needs to be replaced.

8 - **Low driving speed**

**Low power consumption**

Repeat the check, bridging or, better yet, replacing the connections on the remote relay schen.

Check the new values.

YES point 12 NO point 13

9 - **High driving speed**

**Low power consumption**

The engine turns too easily, check the pressure at the end of compression.

If the values differ, proceed as indicated.

10 - The starter motor is OK.

11 - Check the armature rotation.

12 - Definitely replace the starter remote relay.

13 - Check the battery again and replace the starter motor if necessary.

**ANNOTATION**

**IF THE CRANKSHAFT DRIVE SPEED IS LOW AND UNUSUAL NOISE IS PRODUCED AT THE SAME TIME, THE FREEWHEEL AND TORQUE LIMITER MUST BE CHECKED (SEE CHAPTER "ALTERNATOR AND STARTING SYSTEM").**

**STARTER MOTOR**

Technical information	Description/Value
Type	Mitsuba sm13d
Performance	0,9 kW

**BATTERY**

Technical information	Description/Value
capacity	14 Ah
Starting current	125 A

**REMOTE STARTER RELAY**

Technical information	Description/Value
Type	MAINTENANCE FREE
payload	150 A constantly

**STARTER TRANSMISSION**

Technical information:	Description/Value
gear ring and freewheel coaxial with the flywheel.	Intermediate gear integrated with torque limiter.

The starter system consists of a drive between the starter motor armature and the crankshaft

Freewheel mounted coaxially to the flywheel and torque limiter on the intermediate shaft.

The torque limiter is calibrated to 10 kgm (100 N m). This component is used to protect the

Conditions of the engine and the starter gear in the event of an incorrect starting process with rotation in Ge direction.

The freewheel enables sufficiently quiet starting.

The start signal (triggering of the remote relay) is via the start release switches on the side stand and

The emergency stop switch is released (OFF/RUN), meaning the vehicle cannot be started in the event of danger become.

The starter control circuit is not monitored by the immobilizer system. Before the occasion

If the power system is somehow bypassed, the immobilizer should first enable the start be checked.

For checking the circuits for start release, see the "Electrical system" chapter. For the

Checks for driving the crankshaft as described in the "Alternator and starter system" chapter ben proceed.

**Removing the starter motor****ANNOTATION**

**THE STARTER MOTOR CAN BE REMOVED EVEN WITH THE ALTERNATOR COVER INSTALLED.**

- Unscrew the fastening screws.


**2 screws**

- Remove the ground cable and the cable retaining bracket, then the complete starter motor pull out gate.




## Removing the flywheel magneto

- Align the two holes on the flywheel with the openings on the housing so that the special tool is attached can be.




- The bushing belonging to the locking tool onto the thread for the extractor screw.



- Attach the special tool as shown in the illustration. Make sure that the pins are perfectly aligned with each other  
Openings are inserted and that the tool is inserted up to the stop (almost flush with the flywheel) is attached.

**Special tool**

**020472Y Key to block the alternator**





- The fastening nut of the flywheel magnet  
Unscrew the igniter.

- The special tool, the fastening nut  
and remove the washer underneath  
with.

- Put the nut back on so far that the  
Wave is just covered, and so that the  
space previously used by the washer  
remains free.

**DANGER**


**THIS STEP IS NECESSARY BECAUSE THE MAGNETIC IGNITION IS VERY STRONG IS BLOCKED. WHEN REMOVING THE CONICAL PART, THE ROTOR COULD FALL OUT AND THE MAGNETS COULD BE DAMAGED.**

- Apply the specified puller.
  - With a 27 mm key and a 19 mm
- Loosen the flywheel magneto socket.

**Special tool**

**020467Y Flywheel puller**

- Remove the puller.
- Remove the nut and the flywheel magnet  
Pull out the igniter complete with starter ring.
- Remove the key from the crankshaft.



- To remove the starter ring from the freewheel
- To be able to do this, it must be turned counterclockwise rotated and removed.



- 
- Unscrew the 6 fixing screws and the freewheel from the flywheel magneto Remove.


**IF THE FREEWHEEL IS TO BE REMOVED, THE 6 FASTENING SCREWS SHOULD ALREADY BE INCLUDED STILL ATTACHED TO THE CRANKSHAFT FLYWHEEL TO BE LOOSED.**



- 
- The freewheel is designed with the highest precision Flywheel fitted. In case of difficulties During removal, 2 screws can be removed (see Figure) as starting points and pull-out device must be attached.



- 
- The intermediate gear with torque limitation pull off.



---

## Check components of the flywheel magneto

- 
- Check the magnets for completeness.
  - Check that the magnet holders are not are deformed or damaged.
  - Check that the riveting of the swing wheel is not loosened.





---

**Starter wreath**

- The «rollers» of the freewheel and the hub of the An for signs of wear and tear


Check prints.

- Measure the outside diameter of the hub.

**Technical specifications**

**Hub outer diameter:**

Ø 45,665 + 0,008 +0,005 mm



- The inner diameter of the bearing bush on An welderkranz knives.

- Check the teeth on the starter ring for wear check.

**Technical specifications**

**Inner diameter of the bearing bush:**

Ø 27 + 0,020 +0,041 mm

**ANNOTATION**

**IF ANY TRACES OF WEAR OR DAMAGE ARE FOUND ON THE HUB, SHOULD THE STARTER GEAR AND FREEWHEEL ARE REPLACED.**

**IF THERE ARE TRACES OF WEAR ONLY ON THE BEARING BUSH, THE STARTER GEAR CAN BE COMPLETELY REPLACED. IN THIS CASE, THE DIAMETER OF THE BEARING RUNNING SURFACE ON THE CRANKSHAFT SHOULD ALSO BE MEASURED. IF THE VALUES ARE DIFFERENT, THE CRANKSHAFT MUST BE REPLACED.**

---


**intermediate gear**

- Check the teeth for wear.
- Measuring the diameter of the two treads its.

**Technical specifications**

**Diameter of gear running surface:**

Ø 12 - 0 - 0,011 mm



Also the diameter of the treads

Alternator cover and on the engine housing  
measure.


### Technical specifications

**Diameter of the running surface on the alternator cover:**

Ø 12 + 0,034 -0,016 mm

**Diameter of the running surface on the engine housing  
with:**

Ø 12 + 0,034 -0,016 mm



### ANNOTATION

**THE TORQUE LIMITER HAS 4 GEARS WHICH PERFORM THE FUNCTION OF CLUTCH GUIDE DISKS.**

The guided discs consist of 4 discs  
with a notched profile. The structure of this assembly  
enables the transmission of torque  
of less than 10 kgm.

If incorrect starting maneuvers are carried out, the  
torque limiter prevents kickbacks

Reversal of the direction of rotation of the crankshaft and there  
caused by damage to the engine.



No revision can be made to the torque limiter. Are there any damages?

Visible on the toothed washers, the entire assembly should be replaced.

---

### Installation of freewheel

- Check that the freewheel contact surfaces are in good condition.
- Thoroughly clean the freewheel of any LOCTITE residue.
- Degrease the threads on the freewheel holes and the screws.
- Attach the recommended product to the screw ends.

### Suggested products

**Loctite 243 Medium strength thread locking sealant.**

Colour blue

- 
- Attach the freewheel to the flywheel magneto.

Make sure that the ground side rests on the flywheel. i.e. the circlip of the Freewheel remains visible.


- The 6 fastening screws crosswise  
Tighten to the specified torque.

**Torque guide values (N\*m)**

**Fastening screws freewheel to flywheel  $13 \div 15$**



- 
- Lubricate the freewheel "rollers".



---

**Installation of intermediate gear**

- 
- Grease the gear seat on the motor housing.



- 
- The intermediate gear with torque limitation insert.



- 
- The inside of the liner and the hub of the  
Oil the starter ring.



- 
- Turn the starter ring clockwise and  
insert into the flywheel at the same time.



---

## Installation of flywheel magneto

- 
- Insert the key into the crankshaft.
  - Attach the flywheel magneto. Included  
at the same time ensure that the wedge is inserted correctly  
pay attention and the teeth of the torque limiter  
and starter ring mesh correctly.



- 
- The washer and the nut on the Kur  
Attach bell shaft.



- The guide bushing, which is part of the tool  
Blocking of the flywheel magneto is until  
Screw it on until it stops and then turn it around  
Loosen  $\frac{1}{4}$  turn.

**ANNOTATION**


**IF THIS INSTRUCTION IS NOT OBSERVED, THE  
GUIDE WILL STAY ON THE FLYWHEEL.**

**Special tool**

**020472Y Key to block the light  
machine**



- The 2 located on the flywheel magneto  
Align the holes with the openings on the housing  
so that the special tool is attached  
can be.



- Attach the special tool. To ensure,  
that the pins fit perfectly into each other  
aligned openings are inserted.

**Special tool**


**020472Y Key to block the light  
machine**



- The fastening nut of the flywheel magnet  
igniter with the specified torque  
screw tight.

**Torque guide values (N\*m)**

**Fastening nut flywheel 115 - 125**





## Installation of starter motor

---

- Check the condition of the O-ring and this lubricate.
- Insert the starter motor.
- The fastening screws with the ground cable and mount the cable retaining bracket, as shown shown in the photo.

### **2 screws**

- The screws with the specified rotation tighten moment.



## **Torque guide values (N\*m)**

**Starter motor fixing screws 11 ÷ 13**

---

## Thermal unit and valve control

---

- Remove the outer and inner drive covers with.



- The alternator cover, the flywheel and remove the torque limiter.



---

### Removing the intake manifold

- Unscrew the 3 fastening screws.
- Completely remove the intake manifold assembly with.



---

### Removing the valve tappet cover

- Unscrew the 4 flange screws to  
Remove valve cover.




- Lift the valve cover and onto the gasket  
regard.





## Removing the valve control drive

- Turn the engine until the inlet valve are closed.



- The central nut and the valve holding basket lifting mass with the specified special mechanism remove stuff.

### Special tool

**020565Y Face wrench for blocking the alternator**




- The return spring and the valve lifter mass are closed. Remove together with the stop washer.
- The markings on the crown of the vein. The timing chain and the cylinder head meet each other align as shown in the photo.

### ANNOTATION

**MAKE SURE THAT THE SPRING AND WASHER DO NOT PASS THROUGH THE CHAIN COMPARTMENT ENGINE FALLS.**



- In preparation for the next work step must be the central screw of the chain tensioner be solved.
- Unscrew the 2 fixing screws and the chain tensioner together with the associated one. Remove the seal.



Remove the Allen screw and counterweight (see illustration).



- Remove the valve timing chain sprocket from No
- remove the crankshaft.
- Remove the valve timing chain sprocket.



### Removing the camshaft

- Unscrew the 3 fastening screws and
- Remove the camshaft mounting bracket
- with.

#### ANNOTATION


**MOUNTING SCREWS MAY BE DIFFICULT TO REMOVE. PAY ATTENTION TO THE INSIDE NOT TO DAMAGE HEXAGON. POSSIBLY. FIRST LOOSEN THE THREADS.**



- Remove the camshaft.



- The pins and the rocker arms through the hole
- Remove the connectors on the gearbox side.



## Cylinder head removal

- Remove the spark plugs.
- The sleeve at the outlet of the cooling system is complete remove with thermostat.



- The 2 nuts on the cylinder head, one on the outlet side and one on the inlet side, are distant.



- The two side M6 fasteners in the valve compartment and the M6 fastener on the ignition

Remove the candle side completely with the thermostat holder.



### ANNOTATION


**IF NECESSARY, THE CYLINDER HEAD CAN BE REMOVED COMPLETELY WITH THE CAMSHAFT, SWINGARM PIN AND BRACKET.**



- Loosen the 4 cylinder head - cylinder fastening screws in 2 - 3 passes in a criss-cross pattern.
- The cylinder head, the 2 centering pins, you Remove the cable and the lower chain guide.

**ANNOTATION**

**IF THE CENTERING PINS ARE CLAMPED TIGHTLY INTO THEIR SEAT, THERE IS NO REMOVAL.**

**DANGER**

**A SUITABLE CONTAINER MUST BE PROVIDED FOR REMOVAL OF THE CYLINDER HEAD BECAUSE THE CYLINDER HEAD CONTAINS COOLANT.**

**Removing the valves**

- With the specified special tool that comes with be equipped with the appropriate adapter must, the half cones, spring plates, springs and the Remove valves.

**Special tool**

**020382Y Tool for removing the valve  
Half cone equipped with part 012**

**020382Y012 Cylindrical spacer  
(Tool for removing the valves)**

**DANGER**

**SET THE VALVES Aside SO THAT THEIR ORIGINAL INSTALLATION POSITION CAN BE RECOGNIZED DURING LATER INSTALLATION (ALTERNATOR SIDE, DRIVE SIDE).**

- The oil seals with the specified special remove tool.

**Special tool**


**020431Y Oil seal valve puller**



- Remove the spring supports.

**ANNOTATION**

TO EASIER REMOVAL OF THE SPRING PADS, COMPRESSED AIR CAN BE BLOWED INTO THE SEATS.



## Cylinder - piston removal

- Remove the valve timing chain.
- Unscrew the fastening screw and the Spacer and the chain tension shoe distant.

**ANNOTATION**

THE VALVE TIMING CHAIN SHOULD BE MARKED SO THAT THE ORIGINAL RUNNING DIRECTION CAN BE MAINTAINED.




- The cylinder with the associated seal and pull off the centering pin.

**ANNOTATION**

THE SECOND CENTERING PIN IS FIRMLY PRESSED INTO THE CYLINDER.

**DANGER**

TO AVOID DAMAGE TO THE PISTON, THE SER MUST BE HELD WHEN REMOVAL OF THE CYLINDER.



- Remove the 2 piston pin circlips via the corresponding grooves.
- Pull out the piston pin and the piston Remove.

**ANNOTATION**

SEAL THE CYLINDER OPENING ON THE ENGINE CASE WITH PAPER OR A CLOTH SO THAT THE TWO SNAP RINGS OF THE PISTON PIN CANNOT FALL INTO THE ENGINE INSIDE.



- The piston rings and the oil scraper from the col remove ben.

**DANGER**

WRITE DOWN THE INSTALLATION POSITION OF THE PISTON RINGS SO THAT THEY CANNOT BE MIXED UP IN ANY WAY OF INSTALLATION.

**ANNOTATION**


ENSURE THAT THE PISTON RINGS ARE NOT DAMAGED DURING DISASSEMBLY.



## Checking the connecting rod head

- Use an internal bore gauge to determine the diameter. Measure the connecting rod base and check whether the value is within the **"Technical Data"** section given limits.

- If the measured value is incorrect, the crank shaft as **described in the "Crankshaft"** chapter **"build"** described, exchange.



## Check piston pin

Check that the operating limits of the piston pin are within the values specified in Section **"Technical data"** are given. If the measured values are not correct, the col ben bolts need to be replaced.

## Check piston

- Check that the operating limits of the piston and the coupling values with the cylinder are within the values specified in the **"Technical data"** section . If the measured values are not are correct, the piston and/or cylinder must be replaced.
- Check that the coating on the cylinder is not deformed or peeled off.
- Check that the mating surfaces with the cylinder head are not worn or deformed.

**ANNOTATION**

**Pistons and cylinders must be coupled taking the classes into account. It is not possible to assemble components of different classes.**



---

## Check piston rings

- Place the 3 piston rings one after the other in the area of the cylinder, where it still has its position original diameter. The piston rings using the piston at right angles to the cylinder Insert axle.
- Check that every single piston ring is the same lies moderately against the cylinder liner. Abnormal wear of the piston ring is a sign that this is not the case. Replace.
- The opening of the piston ring joints as shown in Fig education shown measuring with a dial gauge.
- If the values are higher than those in the section "**Technical data**" stated, drive continue with the replacement of the segments.



---

## Installation of pistons

- The piston and the piston pin on the connecting rod attach head. Attach the piston so that the arrow points to the outlet opening.



- Insert the piston pin circlip into the Use the specified special tool.

**S** = links

**D** = right

- Remove the piston pin circlip with a Install punch mandrel.



- The piston pin retaining ring as shown in  
Install with a mandrel shown in the illustration.


**Special tool****020470Y Assembly tool for piston pin retainers****ANNOTATION****THE TOOL FOR INSTALLING THE CIRCUIT RINGS-PISTON PIN MUST BE USED MANUALLY.****DANGER****IF A HAMMER IS USED, THE SEATS OF THE COCK RINGS MAY BE DAMAGED.****Selection of seal**

- The cylinder temporarily without the cylinder base seal  
Attach the device to the piston.
- A dial gauge with the short connection on  
Attach special tool (see illustration).

**Special tool****020475Y Tool for checking piston position**

- The dial indicator on a support surface with a  
Set the preload of a few mm to zero.

- Tighten the dial indicator definitely.
- Check that the button works correctly.
- Attach the tool to the cylinder without the  
Change the position of the dial indicator.
- The tool with the original cylinder head nuts  
fasten tern.
- Turn crankshaft to TDC. (reversal point of  
dial indicator rotation).
- Measure the deviation from the zero point.



- Use the table in the “**Technical data**” section to determine the thickness of the cylinder base gasket,  
which must be used for reinstallation. Only if the strength of the cylinder is correctly determined  
The correct compression ratio is maintained in the base seal.
- Remove the special tool and the cylinder.

**ANNOTATION**

**DEVIATIONS (OVERHANGING OR SETTING BACK) ARE MEASURED CLOSE TO ONE CATEGORY LIMIT, THE MEASUREMENT MUST BE FROM THE OPPOSITE PAGE TO BE RUN AGAIN. FOR THIS PURPOSE, THE POSITION MUST BE SWAPED WHEN ASSEMBLYING THE TOOL.**

## Installation of piston rings

- Attach the oil scraper spring to the piston

gen.

- Install the oil scraper so that its opening is

The spring connection is opposite and

the lettering Top faces the piston crown. On

In all cases the processing edge must go to the col

show benboden.

- The second piston ring with the code letter

ben or the lettering Top so that

these point towards the piston crown. Absolutely allowed

the processing edge does not face the piston crown

show.

- When installing the first piston ring (compression ring),

use the installation position specified by the seat

Observe the instructions.

- A ge. should be used to attach the piston rings

A suitable attachment device must be used.

**ANNOTATION**

**THE 2 PISTON RINGS ARE MANUFACTURED WITH A CONICAL CONTACT SURFACE TO THE CYLINDER BEEN. THIS ENSURE BETTER BREAK-IN.**

- Install the piston ring joints offset by 120° (see illustration).

- Lubricate all components with engine oil.

- In this engine, the first piston ring has an L-shaped cross section.




**Installation of cylinders**

- Install the cylinder base gasket with the previously determined thickness.
- Using the fork to place the piston and the clamp, fix the cylinder as shown in the picture install.

**ANNOTATION**

**BEFORE INSTALLING THE CYLINDER, THOROUGHLY BLOW THROUGH THE LUBRICATION LINES AND OIL THE CYLINDER TUBE. MAKE SURE THE TWO CENTERING PINS ARE PRESENT.**

**Special tool**

020468Y Clamp for piston installation

020512Y Fork for installing the piston

---

**Check cylinder head**

- Using a smoothly ground rod and a blade gauge, check that the cylinder head bearing surface is not worn or deformed.

**Technical specifications****Maximum permissible deviation:**

0,1 mm

- If abnormalities are found, the cylinder should be the head needs to be replaced.
  - The sealing surfaces with the intake port and check the exhaust manifold.
  - The running surfaces of the camshaft and the
- Check rocker arm bolts for wear.
- The contact surface of the cylinder head cover
- Check wear.
- Check the coolant seal buffer for oxidation
- check traces.



## Checking the valve control components

- Check whether the chain tensioner pad and the chain tensioner is not excessively worn are.


- The unit drive sprocket camshaft and

Check crankshaft pinion for wear.

- If there is any wear and tear, the appropriate ones must be taken into account

Components are replaced. When worn

Chain or sprocket must be the entire unit be replaced...



### ANNOTATION

**IF THE PINION HAS BEEN DAMAGED BY THE CHAIN, THE CRANKSHAFT MUST BE REPLACED. SEE INSTRUCTIONS IN THE CHAPTER "ENGINE CASE AND CRANK SHAFT".**

### Chain tensioner

- Remove the middle screw and the Unver

Check seal integrity.



### Chain tensioner

- Make sure that the mechanism does not shows wear and that the chain tensioner correctly when turning with a screwdriver can be activated or deactivated.

- If wear or malfunctions are detected the chain tensioner must be replaced the.



**Check valve tightness**

- Carry out a visual inspection of the valve sealing surfaces.

**DANGER**

**DO NOT MIX THE INSTALLATION POSITION OF THE VALVES (RIGHT - LEFT).**

---

- If the sealing surface of the valve is interrupted or irregular at one or more points, the valve must be replaced.



- Insert the valves into the cylinder head.
  - Check the inlet and outlet valves alternately.
  - The valves can be opened by simply pressing with a fin
- Hold the ger firmly, pour petrol into the nozzles and check that no petrol comes out of the sealing surface from the valves.



---

**Check wear of the valve seats**

- Clean the seats and valves of any combustion residues.
  - Check that the operating limits are within the values specified in the "**Technical data**" section.
- 
- If the impression on the valve seat is wider than the specified value, the valve seat must be cut with a 45° milling cutter processed and then ground out.
  - If there is excessive wear or damage, the cylinder head must be replaced.
- 

**Checking the valves**

Check that the operating limits of the valves are within the values specified in the "**Technical Data**". If the measured values are not correct, the part in question must be replaced be replaced.


---



### Check the fitting clearance of the valve guide

Verify that the operating limits of the valve guides are within the values specified in Section "Technical data" are given. If the measured values are not correct, the relevant part must be replaced.

- Check that there is no wear on the contact surface with the joint part of the adjusting screw traces are visible.



- Were subject to the checks described above

no irregularities were found

the same valves are reinstalled. Around

To achieve greater tightness, they should

Valves are ground with valve grinding paste

the. Be very careful when doing this work


and use a very fine valve grinding paste.

When grinding in the cylinder head with the veins

Keep the tilt axes horizontal. This avoids

that residues of the valve grinding paste get into the valve guide

(see illustration).



#### **DANGER**

**TO AVOID SCRATCHES ON THE CONTACT SURFACE, DO NOT ROTATE THE VALVES WHILE GRINDING WHEN THE VALVE GRINDING PASTE IS APPLIED. THOROUGHLY CLEAN THE CYLINDER HEAD AND VALVES WITH A ZUR WASH A PRODUCT SUITABLE FOR REMOVAL OF THE VALVE GRINDING PASTE.**


#### **DANGER**

**DO NOT MIX THE INSTALLATION POSITION OF THE VALVES (RIGHT - LEFT).**

## Check springs and half cones

---

- Check that the upper and lower spring plates, the half cones and the oil seals are not abnormal are worn out. Otherwise, this must be the case corresponding component must be changed.



- Measure the free spring length.

### Technical specifications

#### Standard length:

44,4 mm

#### Permissible limit value after use:

42,4 mm



---

## Installation of valves

- The rests of the valve springs in the cylinder head insert.
- With the specified special tool  
Insert the 4 valve sealing rings alternately.
- The valve sealing rings and the valve guides lubricate.



### Special tool

**020306Y Impact mandrel for installing the valve sealing rings**

- The valves, the springs and the spring plates lead. With the specified special tool and adapter compress the springs and attach the half cones to their seats.

### Special tool

**020382Y Tool for removing the valve  
Half cone equipped with part 012**

**020382Y012 Cylindrical spacer  
(Tool for removing the valves)**



**ANNOTATION**

**DO NOT MIX THE INSTALLATION POSITION OF THE VALVES. INSTALL THE VALVE SPRINGS SO THAT THE MARKING COLOR POINTS TOWARDS THE HALF-CONES (SPIRALS WITH LARGER SPACING).**

## Check camshaft

- Check the running surfaces of the camshaft with a microphone measurerometer.

- Measure the cam height with a gauge.

- If abnormal wear or other


Values than those in the "**Technical data**" section

specified, the No. must be determined

Camshaft needs to be replaced.

- The groove and the corresponding retaining plate

Check for wear (see illustration).



- Check that the cam for the automatic

Valve lifter and the end stop roller no Ver show wear.

- The spring of the valve lifter for overstretching check.

- In case of wear and tear, the appropriate construction must be carried out parts need to be replaced.



- Check the rocker arm pins for scratches and wear.

## Technical specifications

### Standard diameter:

Ø 13 - 0,010 -0,018 mm

- The inside diameter on each rocker arm measure.

## Technical specifications

### Standard diameter:

Ø 13 + 0,026 + 0,015 mm



- Check that the contact shoe with the cam and the joint part of the adjusting screws are not damaged show signs of wear.


- If wear is detected, the corresponding component must be replaced.

## Installation of cylinder head and valve control components

- Insert the chain guide shoe.
- The centering pins for the cylinder head and cylinder insert.
- Install the cylinder head gasket.




The cylinder head gasket is made of steel and has a standard thickness.



### ANNOTATION

THE PICTURE SHOWS THE INSTALLATION OF THE TWO CENTERING PINS BETWEEN THE CYLINDER HEAD AND THE CYLINDER. THE INSTALLATION POSITION OF THE SEAL IS DETERMINED BY THE TWO CENTERING PINS.


- The cylinder head must be checked before installing whether the lubrication channels are really clean. If necessary, use a jet of compressed air blow.
- Mount the cylinder head.
- Lubricate the four stud screws and the 4 nuts ren.



- Tighten the fixing nuts in a criss-cross sequence as indicated in the figure to the prescribed torque.

### Torque guide values (N\*m)

Fastening nuts cylinder head - cylinder  
13 Nm + 90° + 90°



\*\*\* First apply a pre-torque of 13 Nm in a crisscross sequence.

- tighten 90° in a crisscross sequence.
- tighten again by 90° in a crisscross sequence.

- The mounting screws on the inlet side and on the outlet side with the prescribed tighten to a certain torque.

### **Torque guide values (N\*m)**

**Fastening nuts cylinder head exhaust/ Entrance 10 - 12**



- The 3 side fastening screws with the Tighten to specified torque.

### **Torque guide values (N\*m)**

**Cylinder head fastening screws 10 - 12**




- Using a 22 mm wrench, mount the sensor coolant temperature with the relevant washer, locking it to the prescribed torque row.

### **DANGER**

**IF THE SPECIFIED TORQUE IS NOT MAINTAINED, THE SENSOR MAY BE DAMAGED.**

### **Torque guide values (N\*m)**

**Sensor coolant temperature - cylinder head 22.0 ± 1.0**



- Fit the spark plugs, tightening them to the prescribed torque.

### **Torque guide values (N\*m)**

**Spark plug 11.0 ± 1.0**



## MP3 530 hpe

Motor

- Attach the valve timing chain to the crankshaft  
gen. The original direction of rotation of the chain  
must be adhered to.

- Insert the chain tension shoe with spacer  
put the recommended product on the screw  
attach and the fastening screw with the  
Tighten to specified torque.



### Suggested products

**Loctite 243 Medium strength thread locking sealant.**

Colour blue

### Torque guide values (N\*m)

**Fastening screw chain tensioner pad  
10 - 14**

- The rocker arm pins and the rocker arms  
Insert from the alternator side.  
  
- The 2 rocker arms through the upper holes  
lubricate.



- The camshaft and especially the groove of the  
Retaining plate with small bursts of compressed air  
nigen.  
  
- Lubricate the 2 running surfaces.  
  
- Insert the camshaft into the cylinder head  
zen that the cams are on the opposite side  
on the opposite side to the rocker arms.



- Any remaining LOCTITE from the reinforcements  
camshaft bracket fixing screws  
remove with a brush.  
  
- Attach the recommended product to the fastening screws  
and secure them with the specified  
Tighten the specified torque.

### Suggested products





**Loctite 243 Medium strength thread locking sealant.**

Colour blue

- Insert the camshaft bracket (the beveled part must be visible) and the 3 fasteners

Tighten the connection screws to the specified torque. Make sure that the Allen key screw is not damaged.

## Torque guide values (N\*m)

**Camshaft bracket fixing screws:  $4 \div 6$**

- The intermediate gear with torque limitation

Zer, the fly magneto and the light

machine cover as in the chapters - Lichtma

engine and starter system and chapter -

Install the alternator cover as described.

### ANNOTATION

**IT IS EASIER TO INSTALL THE ALTERNATOR COVER WITHOUT THE COOLING SYSTEM HOSES.**



- Connect the chain to the valve control sprocket  
put on the camshaft.

- The valve timing gear ring on the cams  
put on the shaft. The two Marks have to do this

ations remain aligned with one another.

### ANNOTATION

**WHILE CHECKING THE PHASE ALIGNMENT, THE CHAIN MUST BE KEPT UNDER TENSION BY PRESSURE FROM THE TENSIONER ROOM.**



- Use a TORX key to tighten the lock

the inspection opening for phase adjustment  
with.

- Keep the chain slightly taut and the crank

Turn the shaft over the drive belt pulley as far as possible

until the mark on the magnet holder

on the marking on the alternator cover

is directed.



- Remove the counterweight.
- With the basket fixing screw in the middle align.
- The fastening screw with the specified tighten to the desired torque. The emp Attach foaled product.

**Suggested products**

**Loctite 243 Medium strength thread locking sealant.**


Colour blue

**Torque guide values (N\*m)****Counterweight screw 7 ÷ 8.5**

- Remove the middle screw.
- Install the valve lifter mass. Care must be taken to ensure that the stop ring is correctly positioned is attached.
- Lubricate the valve lifter compound and decompressor control pin.
- Install the return spring and approximately  $\frac{3}{4}$  Tighten one revolution.



- Turn the engine and the marks as in shown in the illustration upwards (end suction phase).
- The valve lifter mass retaining bell set.
- The fastening screw with the specified tighten to the desired torque. The emp Attach foaled product.
- Make sure the valve lifter mass is free and is reset by the return spring.

**ANNOTATION**

**THE ORIENTATION OF THE RESTRAINT BELL IS GIVEN BY THE COUNTERWEIGHT FIXING SCREW.**

**Special tool**

020565Y Face wrench for blocking the alternator

### Recommended products

**Loctite 243 Medium strength thread locking sealant.**

Colour blue

### Torque guide values (N\*m)

**Fastening screws retaining bell**

**Ventilhebermasse 30 ÷ 35 Nm (22 ÷ 26 lb\*ft)**

- Set the tensioner rotor to the rest position position. While doing this, press the retaining bar hold.



- The tensioning device with a new seal install on the cylinder.
- The two fastening screws with the attached Tighten to the specified torque.

### Torque guide values (N\*m)

**Fixing screws clamping device**


13



- The spring with the middle screw and the Insert washer.
- The middle screw with the prescribed one Tighten torque.

### Torque guide values (N\*m)

**Chain tensioner screw 5 ÷ 6**




- Turn the engine until the valve timing markings line up with the valve setting Markings on the cylinder head are aligned.
- Measure the clearance between the valve and the rocker arm using a gauge.

**REQUIRED PLAY:**

Technical information	Description/Value
inlet	0.15 mm (when engine is cold)
outlet	0.15 mm (when engine is cold)

- If different values are measured, this must be done the valve clearance can be adjusted. In addition, the con Loosen the nut and tighten the adjusting screw with a Adjust screwdriver (see illustration).

**Installing the chain and adjusting the valve timing**

The ignition timing is advanced (pre-ignition) based on the ignition electronics averaged parameters. For this reason, reference values based on engine speed cannot be used be specified.

The pre-ignition values can be determined at any time using the diagnostic test device.

A stroboscope lamp can be used to check whether the preset specified by the injection system

The ignition timing position corresponds to the actual ignition timing on the engine.

**Special tool**

**020922Y Diagnose-Instrument**

**020330Y Strobe lamp to check the ignition setting**

Proceed as follows:

- As described in the "Automatic transmission" chapter remove the drive cover.



- The lock on the inspection opening for the TDC mark between the alternator and the housing  
Remove the water cover. See chapter "Alternator cover".



- The motor via the nut on the drive belt
- Turn the disc until the two markings for OT are aligned with each other.



- The markings on the drive belt sheave
- Align the drive cover and drive cover with each other.



- Reinstall the lock on the inspection opening on the alternator side.
- Connect the diagnostic test device.
- Start the engine.
- Select the «Parameters» function from the menu.
- Set the strobe lamp control to the position of a traditional 4-stroke engine (1 spark = 2 revolutions).
- The values specified on the diagnostic test device for advancing the ignition timing with the compare actual values.

## Special tool

### 020922Y Diagnose-Instrument

If the values differ from each other, the following must be checked:

- Ignition adjustment
  - Speed phase sensor
  - Injection control electronics
-

## Installation of tappet cover

---

- Check the condition of the seal.



- The valve cover with the specified one  
Secure torque.

### **Torque guide values (N\*m)**

**Valve cover fixing screws 7 ÷ 9 Nm (5.2 ÷ 6.6 lb\*ft)**



---

## Installation of intake manifold

---

- Attach the intake manifold to the engine.
- Insert the 3 fastening screws. One  
The mounting screws have a fastening  
clamp for the cooling line hose. The  
Fastening screws with the specified  
tighten to a certain torque.

### **Torque guide values (N\*m)**

**Screws intake manifold 11 ÷ 13**



---

## Engine housing and crankshaft

- The outer and inner drive covers and the drive pulley complete, as in chapter  
Remove the “automatic transmission” as described.
- The alternator cover with the hoses of the cooling system as described in the chapter «End of the alternator  
Remove the lid as described.
- Install the flywheel magneto with starter as described in the “Alternator and starter system” chapter  
dismantle the writing.



- The thermal unit (cylinder, cylinder head, piston) as in chapter «Thermal unit and valves

Remove the tilt control as described.

- Before separating the housing halves, the axial play of the crankshaft should be checked.

For this purpose, a sheet metal (e.g. the special tool) and a holder with a dial gauge (special tool).

### Special tool

**020262Y Plate for housing separation**

**020335Y Magnetic holder for dial indicator**


### Technical specifications

**Standard installation clearance:**

0,10 ÷ 0,50 mm

**Permissible limit value after use:**

0,60 mm



- Larger values are signs of wear on the crankshaft running surfaces on the housing.
- For correct measurement, the clearance must be adjusted in both directions via the gap between the engine housing and the crankshaft.

## Separating the housing halves


- The motor mount mounting screw on the housing side on the alternator side screw off.



- The 14 fastening screws of the housing half unscrew.

### ANNOTATION

**THE FASTENING SCREWS HAVE 3 DIFFERENT LENGTHS. WRITE DOWN THE INSTALLATION POSITION OF THE INDIVIDUAL SCREWS.**



## MP3 530 hpe

Motor

- Separate the housing halves. The must  
Crankshaft in the housing half on the light  
remain on the machine side.

- Remove the housing gasket.

### ANNOTATION

**THE LINERS CAN REMAIN IN THE HOUSING HALF ON  
THE ALTERNATOR SIDE.**



## Removing the crankshaft

- Before removing the crankshaft, the phase  
Alignment with the countershaft checked  
become. The crankshaft must be checked for this check  
be turned until the two holes  
on the crankshaft to the hole on the gear  
the countershaft are aligned.  
This position is also ideal for expanding the  
Crankshaft.



- The crankshaft together with the scraper disc  
Remove on the alternator side.

### DANGER

**WHEN SEPARATING THE HOUSING HALFS AND REMOVAL  
OF THE CRANKSHAFT, MAKE SURE THAT THE  
THREADED PART OF THE CRANKSHAFT DOES NOT  
DAMAGE THE CRANKSHAFT BEARINGS. FAILURE TO  
COMPLY WITH THIS REGULATION MAY RESULT IN THIS  
CAUSE THE CRANKSHAFT BEARINGS TO BE DAMAGED.**



## Removing the countershaft drive gear and oil pump

- To remove the drive gear, you must  
4 fastening screws must be loosened.

**Only remove the gear if it is loose**  
**thing is required.**

### DANGER

**THE SCREWS ARE COUNTERSUNK HEAD SCREWS  
WHICH THREADS ARE BLOCKED WITH LOCTITE. ON THAT OH  
ENSURE THAT THE ALLEN INSERT WILL NOT BE  
DAMAGED. IF POSSIBLE, USE A SOCKET WRENCH  
WITH A BUS ATTACHMENT.**



---

## Removing the countershaft

---

- Attach the special tool as shown in the illustration.

### Special tool

**020479Y Tool for locking the countershaft**



- The nut together with the washer remove.



- Remove the special tool and follow the instructions laying shaft complete with drive gear pull.



---


## Replacing countershaft bearings

---

- The bearings for noise development and above check moderate play. If necessary change.

### Housing half on alternator side


- Remove the circlip from the inside of the housing take out the half.



- Turn the housing half over.
- Remove the bearing from the housing half on the alternator side using the specified special tool and remove with a rubber mallet.

**Special tool****020376Y Handle for adapter****020358Y Adapter 37 x40 mm****020439Y Guide 17 mm**

- The bearing from the housing half on the drive side
- Remove with the specified special tool in.

**Special tool****001467Y008 Pliers for removing bearings  
Ø 17 mm****001467Y007 Basket for bearings with external  
diameter Ø 54 mm**

- Before installing a new bearing, the housing must be outer half alternator side with the indicated heated using a special tool.
- Place the housing half on a wooden base only.

**Special tool****020151Y hot air gun**


- Grease the guide seat and install a new bearing
- Attach the specified special tool.
- The new bearing in the housing half with the
- Install the specified special tool.

**ANNOTATION**

**IF A BEARING WITH A PLASTIC CAGE IS INSTALLED, IT MUST BE INSERTED SO THAT THE VISIBLE SIDE WITH THE BALLS SHOWS TOWARDS THE INSIDE OF THE HOUSING.**

**Special tool****020376Y Handle for adapter****020359Y Adapter 42 x 47 mm****020439Y Guide 17 mm**

- Install the circlip.



- Before installing a new bearing in the drive side housing half, the bearing seat must be heated using the specified special tool.

### Special tool

**020151Y hot air gun**



- Grease the guide seat and install a new bearing. Attach the specified special tool.
- The new bearing in the housing half with the. Install the specified special tool.

### ANNOTATION

**IF A BEARING WITH A PLASTIC CAGE IS INSTALLED, IT MUST BE INSERTED SO THAT THE VISIBLE SIDE WITH THE BALLS IS TOWARDS THE INSIDE OF THE HOUSING.**



### Special tool

**020376Y Handle for adapter**

**020359Y Adapter 42 x 47 mm**

**020439Y Guide 17 mm**

## Checking the crankshaft components

- Check that the axial and diametric clearances of the connecting rod are within the values reported in the "Data" section technicians".
- Check that the internal surfaces of the crankshaft shoulders do not have scratches. By means of a gauge, check the overall width of the crankshaft shoulders.

### ANNOTATION

**WHEN MEASUREMENT, MAKE SURE THAT THE MEASUREMENT RESULTS ARE NOT FALSED BY THE ROUNDED REDUCTION RADIUS WITH THE RUNNING SURFACES OF THE CRANKSHAFT.**

## Technical specifications



**Crankshaft width**

65,45 ÷ 65,6 mm

**DANGER**


**THE CRANKSHAFT CAN BE REUSED IF THE WIDTH MATCHES STANDARD VALUES AND THE SURFACES ARE NOT SCRATCHED.**

**Rasamento**

- Check the overall dimension of the crankshaft-shim-gear assembly.

**Technical specifications****Standard size**

XXX ÷ XXX mm



- Check that the scraper disk is not scratched.

**ANNOTATION**

**IF REUSED, KEEP THE ORIGINAL INSTALLATION POSITION.**

**Special tool****020074Y Holding device for checking crankshaft alignment**


- Is the axial play between the crankshaft and the engine housing larger than the normal values, but the crankshaft knows  
If there are no abnormalities, the problem is certainly due to wear or incorrect processing on the engine housing.

- Check, according to the axes and planes indicated in figure, that the diameters of both flow rates of the the crankshaft falls within the values reported in the "Technical Data" section .

- The half-shafts are classified into two categories: "Class 1" and "Class 2" and the diameters of the flow rates

are shown in the Car coupling table

ter - Crankshaft - Main bearing halves.

**DANGER**

**If anomalies or values that do not comply with those specified are found, proceed with replacing the complete crankshaft.**

**Check alignment of the crankshaft**

- Install the crankshaft on the special bracket and check that the eccentricity values are in  
are within the values specified in the “**Technical data**” section .

**Special tool****020074Y Holding device for checking crankshaft alignment**



- The condition of the crankshaft cone, the locking tongue seat, the running surface of the oil seal, the Check the grooved part and the threaded end parts.
- If there are any abnormalities, the crankshaft must be replaced.

**ANNOTATION**

**THE CRANKSHAFT BEARING RUNNING SURFACES CANNOT BE GRINDED.**


The connecting rod cannot be replaced. For checking the diameter of the connecting rod head see chapter "Thermal unit and valve control".

- When cleaning the crankshaft, make sure that no dirt gets into the lubrication openings reaches the crankshaft.

**ANNOTATION**

WHEN REPLACING A CRANKSHAFT COMPOSED OF HALF-SHAFTS OF DIFFERENT CATEGORY, THE TWO HOUSING HALVES MUST ALSO BE REPLACED AND THEN COMPONENTS OF THE SAME CATEGORY (CRANKSHAFT AND HOUSING) TO BE INSTALLED.

- For checking the gear on the crank wave see chapter «Thermal unit and vein Tile control».



---


## Check the motor housing halves

- Before checking the housing halves all surfaces and lubrication lines thoroughly getting cleaned.
- On the housing half on the drive side Pay particular attention to the crankshaft bearings Cooling nozzle on the drive side (see illustration) and pay attention to the lubrication line.



**ANNOTATION**

THE NOZZLE IS SUPPLIED VIA THE CRANKSHAFT BEARINGS. A GOOD FUNCTIONING OF THIS COMPONENT IMPROVES PISTON BOTTOM COOLING. IS IF THIS NOZZLE IS CLOGGED, IT WILL CAUSE EFFECTS THAT ARE DIFFICULT TO DETECT (RISE IN TEMPERATURE ON THE PISTON). IF THE NOZZLE IS MISSING, OR IF IT FALLS OUT, THE LUBRICANT PRESSURE ON THE CRANKSHAFT BEARING AND ON THE CONNECTING PLEU DRASTICALLY DROPS.




- On the housing half on the alternator

Page must pay particular attention to the lubrication lines

the crankshaft bearing, the pump room and

the lines to the pump and on the lines

Pay attention to the by-pass on the alternator cover become.

**ANNOTATION**

AS ALREADY DESCRIBED IN THE LUBRICATION SYSTEM CHAPTER, IT IS PARTICULARLY IMPORTANT THAT THE SEAT OF THE BY-PASS ON THE ALTERNATOR COVER SHOWS NO SYMPTOMS OF WEAR THAT COULD AFFECT THE SEALING OF THE PISTON FOR LUBRICATION PRESSURE REGULATION. THE LUBRICATION CHANNEL FOR THE CYLINDER HEAD IS WITH A THROTTLE NOZZLE EQUIPPED. THIS NOZZLE TAKES CARE FOR LOW-PRESSURE LUBRICATION OF THE CYLINDER HEAD. THIS CHOICE WAS MADE TO KEEP THE OIL TEMPERATURE IN THE PAN LOW.

Clogging of this nozzle impairs the lubrication of the cylinder head and the components

Valve control.

A missing nozzle leads to a drop in the lubricating pressure on the crankshaft bearings and on

connecting rod.

- Check the mating surfaces of the housing halves and cylinder housings for dents or deformations fen.

- Any damage to the housing seal or mating surfaces (see installation with alternator cover) can lead to a loss of oil under pressure and thus the lubricating pressure on the

Affect crankshaft bearings and connecting rod.


- Check the running surfaces for wear to limit the axial play. For the measurements

The values for axial play and dimensions on the crankshaft apply.

## Checking the crankshaft bearings

- To ensure good lubrication of the crankshaft bearings

To achieve this, both the lubricating pressure (4 bar) must be optimally adjusted and a sufficient oil supply must be guaranteed. In that together  
It is also important that the crankshaft bearings are installed correctly and no  
Throttle lubrication channels.



- The crankshaft bearings consist of 2 half shells  
len, of which 1 is solid and 1 with holes and  
Grooves for lubrication.

- The massive half bearing must absorb and contain the pressure resulting from combustion  
therefore opposite the cylinder.
- To ensure that the lubrication channels are not throttled, the mating surface of the two half bearings must be aligned  
exactly perpendicular to the cylinder axis (see illustration).
- The cross section of the lubrication channels is also related to the installation depth of the crankshaft bearings  
on the plane to limit the axial play of the crankshaft.

### ANNOTATION

**SO THAT THE CRANKSHAFT BEARINGS MAINTAIN THIS INSTALLATION POSITION, THIS IS DONE  
INSTALLATION BY PRESSING INTO THE CAST IRON RINGS IN BOTH HALF OF THE HOUSING  
ARE ALLOWED.**


- The diameter of the crankshaft bearings  
three directions shown in the figure  
check.

- Also the diameter of the other crank

Check shaft bearing half. See illustration.

### ANNOTATION

**DO NOT MATCH THE DIAMETER ON THE MATCHING SURFACES OF THE  
MEASURE 2 BEARING HALFS AS THESE ARE FOR THE BETTER  
ARE SANDED FOR INSTALLATION.**



- Before assembling, check whether there is clearance between the bearing bushes of the housing and the  
Crankshaft are within the values specified in the "**Technical Data**" section.
- The standard diameter of the crankshaft bearings is depending on the installation category selected  
different.
- The bearing seats of the crankshaft bearings are divided into 3 categories and the crankshaft into 2 categories  
Splits.
- The bearing bushes are divided into 4 categories depending on their thickness (see table in Fig  
section "**Technical data**").

---

## countershaft

- Using a micrometer, check the 2 running surfaces of the front Measure layshaft (see illustration).

### Technical specifications

#### Standard diameter:

17 - 0,01 - 0,02 mm



- Check that the water pump driver shows no signs of wear.

---

## Installation of crankshaft

- Check that the drive gear of the countershaft and oil pump is not damaged or damaged is formed. Replace if necessary.

### ANNOTATION

**IF THE COUNTERSHAFT DRIVE GEAR AND OIL PUMP IS REPLACED, THE COUNTERSHAFT GEAR MUST ALSO BE REPLACED.**

- Before installing the gear on the crankshaft

The mating surfaces must be carefully cleaned and Remove LOCTITE residue from the holes with a brush removed.



Blow through the mounting holes on both surfaces with compressed air and degrease so that the new LOCTITE finds support.

Attach the recommended product to the holes again.

### Recommended products

**Loctite 243 Medium strength thread locking sealant.**

Colour blue

- Repeat the same steps on the 4 fastening screws.
- Place the drive gear on the crankshaft. The bevel with the holes must be visible be cash.
- Tighten the 4 fastening screws to the specified torque.

### ANNOTATION

**BE CAREFUL NOT TO DAMAGE THE ALLEN INSERT. IF POSSIBLE, USE A SOCKET WITH A SOCKET ATTACHMENT.**

**Torque guide values (N\*m)****Fastening screws gear to crankshaft 10 -12**

- The crankshaft bearing on the housing half  
Lubricate alternator side.
- Grease the compensating disk.
- The crankshaft and the balance disk in  
Insert original position.
- Insert a bolt with an 8 mm diameter into the opening  
Insert voltage on the countershaft.



- Place the crankshaft on the mandrel (carefully done).  
hen) and then into the crankshaft bearing  
insert.
- Before the crankshaft is fully inserted  
the gears of the oil pump and that  
Drive gear aligned with each other  
the.
- Finish inserting and remove the bolt.

**ANNOTATION**

**WHEN INSERTING THE CRANKSHAFT INTO THE HOUSING HALF, MAKE SURE THAT THE  
THREADED PART OF THE CRANKSHAFT AND THE VALVE TIMING PINION THE CRANKSHAFT  
BEARINGS NOT DAMAGED.**

- Insert the partition wall to the oil pump room.
- The 2 flanged screws with the provided  
Tighten the specified torque.

**Torque guide values (N\*m)****Screws for oil pump compartment partition wall 8 - 10**

**Assembling the case**

---

- Put the shaft seal on the housing half
- Remove drive side with a screwdriver.



- Lubricate and add a new shaft seal
- Install using the specified special tool.
- The shaft seal must be 0.5 mm below the Ge house surface can be used.

**DANGER**

**INCORRECT INSTALLATION DEPTH OF THE SHAFT SEAL AFFECTS THE CIRCULATION OF THE LUBRICANT OIL.**

**Special tool**

**020360Y Adapter 52 x 55 mm**

**020376Y Handle for adapter**



- The seal on the housing half of the alternator put on the inside.



- The crankshaft bearing on the housing half
- Lubricate drive side.

- Put the two housing halves together

**Zen. Make sure that this is the case**


**Crankshaft bearing on the housing half drive side not through the threaded part of the Crankshaft is damaged.**

- The motor mount mounting screw on the alternator side housing half put but do not tighten yet.





- The 14 fastening screws according to the Use the position noted when dismantling.
- Tighten the screws until they stop and then with the prescribed torque tighten.
- Check whether the crankshaft rotates easily leaves.

**ANNOTATION**

**TO ENSURE A BETTER SEAL,  
ANY PROJECTING SEAL PARTS MAY NEED TO BE REMOVED  
BETWEEN ENGINE HOUSING AND CYLINDER.**

**Torque guide values (N\*m)****Motor case connecting screws 11 ÷ 13**

- The thermal unit (cylinder, cylinder head, piston) as in chapter «Thermal unit and valves  
Install the tilt control as described.
- Install the flywheel magneto with starter as described in the “Alternator and starter system” chapter  
install writing.
- The alternator cover with the hoses of the cooling system as described in the chapter «End of the alternator  
Install the lid as described.
- The complete drive pulley, the outer drive cover and the drive cover, complete  
Install with line filter as described in the “Automatic transmission” chapter.

## Lubrication

**TECHNICAL SPECIFICATIONS****OIL PAN CAPACITY**

Technical information	Description/Value
Revision	1,7 Liter
Engine oil and filter change	1,5 Liter

**RECOMMENDED ENGINE OIL**

Product	Description	Declarations
Engine oil 5W-40	Synthetic-based lubricant for The 4-Stroke Engine.	SAE 5W-40; JASO MA, MA2; API SL; THAT A3

**OIL PUMP**

Technical information	Description/Value
Type	Trochoidal
Rotor strength	8 mm
Built-in games	Wing end parts 0.05÷0.008 mm
Radial play of outer rotor	0,05 ÷ 0,12 mm
Axial play of the rotors	0,025÷0,065 mm

**MP3 530 hpe**

Motor

**BY-PASS**

Technical information	Description/Value
Type	With piston
Piston diameter	Ø 13,9 -0,039 -0,057 mm
Free spring length	62,5 mm
Calibration pressure	4 bar

**FORFILTER**

Technical information	Description/Value
Type	With plastic net

**OIL FILTER**

Technical information	Description/Value
Type	Paper with bypass pressure relief and shut-off

**MINIMUM OIL PRESSURE INDICATOR**

Technical information	Description/Value
calibration	0,3 ÷ 0,6 bar

**CYLINDER HEAD LUBRICATION NOZZLE**

Technical information	Description/Value
diameter	Ø 1 ± 0,05 mm


*Tightening torque 5±7 N m***COOLING NOZZLE PISTON LUBRICATION**

Technical information	Description/Value
diameter	Ø 0,8 ± 0,05 mm

**OIL PAN BREATHER**

Technical information	Description/Value
contraption	Metal reed valve and decanter chamber

Schematic circuit diagram



SCHEMATIC CIRCUIT DIAGRAM

Technical information	Description/Value
A	camshaft
B	Cylinder - cylinder head mating surface
C	Cylinder - housing mating surface
D	Impeller water pump
E	Oil pressure sensor
F	Oil filter cartridge
G	To the oil pan
H	By-Pass Ventil
L	Oil pump
M	Mains pre-filter
N	crankshaft
O	connecting rod

General technical information

The lubrication system is divided into two areas:

- High pressure
- Low pressure

All components on the engine housing belong to the high pressure area. The low pressure area only concerns the thermal unit.

The trochoid pump is installed in the oil pan and is driven by a pair of gears.

To avoid damage to the pump, a pre-filter is used.

The pre-filter is removable and the associated screw plug is also the drain plug the engine oil.

The supply line to the pump is connected through a by-pass with a piston to regulate the pressure to 4 bar controlled. The by-pass is installed in front of the filter cartridge. Both parts are located on the Lichtma rail cover. The filter seal is therefore exposed to the same pressure as the lubricating pressure.

The by-pass installed in front of the filter cartridge particularly improves the working conditions of the filter

This is the case with cold oil.

The filter is equipped with a drain protection valve and a pressure relief valve. The above pressure valve is triggered when the filter mass causes a pressure drop of more than  $1 \pm 0.2$  bar. Of course, this condition only occurs when the oil is cold and at high engine speeds or when the engine is dirty Filter reached.

The filtered engine oil is used to lubricate the water pump shaft. After it's the engine

Once it has reached the housing, it is used to lubricate the crankshaft bearings, the connecting rod base and the cooling nozzle of the piston, which is located on the running surface on the drive side.

The running surface of the crankshaft bearing has a shaft seal and an oil return line.

The supply line to the valve control branches off from the running surface on the alternator side.

The supply line to the cylinder head is controlled by the nozzle screwed into the engine housing.

The valve control components are lubricated with low pressure.

The running surfaces of the camshaft are machined directly from the aluminum of the cylinder head.

The axial play of the camshaft is partly due to the smaller diameter running surface routed lubricating oil balanced.

The rocker arms are lubricated via corresponding lubrication holes on the camshaft.

These lubrication holes are installed in such a way that lubrication continues even after the vehicle is parked stuff is ensured. This result is achieved by the camshaft position, which the shaft with is most likely to occur when the engine is switched off.

The oil used to lubricate the cylinder head is transported through a channel through the chain space returned to the oil pan, where it also lubricates the chain.

In order to avoid that the oil vapors returned from the oil pan transport quantities of oil,

A check valve and a decanter chamber are used. The check valve is a metal reed valve. The Decanter chamber has a drain opening. If the drain opening is clogged, oil can get into the intake reach.

Excessive amounts of oil vapor can clog the lines on the throttle housing.

An oil pressure switch is used to indicate when the minimum oil pressure has been reached. This oil pressure The switch is located directly behind the filter outlet.

The lubrication circuit does not affect the countershaft. The countershaft is lubricated by the oil transported by the gears or the oil transported by the centrifugal force from the crank wave drips.

The same applies to the piston and the piston pin, although in this case the cooling nozzle is one plays a special role.

## Troubleshooting

1 - The oil pressure control switches on when the engine is warm.

CONTINUE - point 2

2 - Disconnect the cable connector from the oil pressure switch.

Check whether the oil pressure control switches off.

YES point 3 NO point 11

3 - Check actual oil pressure.

CONTINUE - point 4

4 - Remove the oil pressure switch and use the specified special tool together with the included

Attach the corresponding seal.

## Special tool

**020193Y Pressure gauge for oil pressure control**

**020434Y Connection for oil pressure control**

- Remove the filler plug with dipstick and use one for the temperature sensor

Attach the fastener prepared using a special tool. Insert the probe until it comes into contact with

If you notice it on the bottom of the case, then move it back a few millimeters.

## Special tool

**020331Y Digital Multimeter**

CONTINUE - point 5



5 - Measure the oil pressure with the engine cold and idling.

## DEFAULT VALUES

Technical information	Description/Value
20°C temperature	
1400 U/Min	

~ 4,5 bar

## ANNOTATION

THE SPEED CAN BE DETERMINED BOTH VIA THE EMISSION MEASUREMENT DEVICE AND VIA THE DIAGNOSIS TEST DEVICE TO BE MEASURED

## Special tool

**020922Y Diagnose-Instrument**

YES point 6 NO point 12

6 - Warm up the engine and repeat the oil pressure check when the engine is warm.

### DEFAULT VALUES

Technical information	Description/Value
80°C temperature	
1400 U/Min	

~ 1,5 bar

YES point 7 NO point 8

7 - Replace the oil pressure switch.

8 - An oil pressure of less than  $1.3 \div 1.5$  bar is measured.

CONTINUE point 9

9 - Change the oil filter and repeat the oil pressure check at a temperature of 80°C.

YES point 10 NO point 13

10 - The error is fixed.

Point out compliance with maintenance intervals.

11 - Check and repair the electrical system.

12 - An oil pressure of less than 4 bar is measured.

CONTINUE point 9

13 - Remove the alternator cover and check the function of the by-pass and the gasket check exterior. Proceed as described in the alternator cover chapter.

YES point 14 NO point 15

14 - Check the crankshaft for excessive play:

- Axial play (see engine housing and crankshaft chapter)
- Radial play, especially towards the cylinder axis
- Play in direction of rotation with balanced connecting rod

YES point 16 NO point 17

15 - Replace the damaged components (alternator cover chapter).

16 - Carry out an engine overhaul (chapter engine housing and crankshaft).

17 - Open the engine case and remove the oil pump. As in chapter engine housing and crank proceed as indicated on the shaft.

- Check the oil pump as described below.
- Check the correct installation of the cooling nozzle and the valve control supply nozzle.
- Carry out a visual and measuring check of the fitting clearances on the crankshaft (chapter engine housing and crankshaft).

#### **ANNOTATION**

**ERRORS IN THE FITTING CLEARANCES AND VALVE CONTROL COMPONENTS CANNOT BE DETECTED BY CHECKING THE OIL PRESSURE. THESE CAN BE NOTIFIED BY INCREASED NOISE.**

#### **ANNOTATION**



IF THERE IS ANY DEVIATION FROM THE PRESCRIBED OIL PRESSURE IN THE OIL PAN, A VISUAL AND MEASUREMENT CHECK OF THE VALVE CONTROL COMPONENTS SHOULD BE CARRIED OUT (SEE CHAPTER THERMAL UNIT AND VALVE CONTROL).

---

## Oil pressure control

1 - If oil leaks from the seal on the alternator cover or the oil filter, the lubrication pressure must be increased being checked.

CONTINUE point 2

2 - Install the special tool.

### Special tool

**020193Y Pressure gauge for oil pressure control**

**020434Y Connection for oil pressure control**

CONTINUE point 3

3 - Check the oil pressure with the engine cold and at medium and high speeds.

Standard pressure < 6 bar

YES - point 4 NO point 5

4 - Replace the damaged components.

5 - Check the function of the by-pass oil pressure control (see chapter alternator cover) and set it to run correctly again.

### ANNOTATION

**THE STANDARD OIL PRESSURE VALUES ARE OBTAINED WHEN AN ENGINE OIL OF THE DESIGNED VISCOSITY IS USED. WITH HIGHER VISCOSITY, THE OIL PRESSURE IN THE SYSTEM INCREASES.**

1 - If the oil consumption is over 250 g/1000 km when the engine is running in, proceed as follows become.

CONTINUE point 2

2 - Check if there is oil in the return line on the filter housing.

YES point 3 NO point 4

3 - Check the check valve (reed valve) and the drain opening on the decanter chamber.

YES point 5 NO point 4

4 - Check the thermal unit seals (piston rings, valve guides and oil seals),

see chapter Thermal unit and valve control.

5 - Repair the check valve or expose the drain hole.

---

## Oil pump

---

### expansion

- The 2 fastening screws together with the  
Remove the associated washers and remove the  
partition wall to the oil pump room.



- Check the oil pump mounting screws  
Unscrew the eyelets on the gearbox.


**2 screws**




- The oil pump complete with gear and seal  
Remove



- The two screws and the oil cap  
remove pump.




- 
- Turn the snap ring of the inner rotor until the opening is on the joint of the oil pump shaft and can be removed.



- 
- Remove the wheels and thoroughly with Ben Clean zinc and compressed air.
  - The oil pump shaft complete with gear build. The condition of the shaft and wear check.



- 
- Put the impellers back into the pump housing install. The two markers must remain visible.
  - Insert the oil pump shaft with gear  
Attach the snap ring and the opening on the dem  
Rotate the grinding side on the opposite side.
  - Check for excessive play between the oil pump shaft and check pump housing.



- 
- Use a blade gauge to measure the distance between the rotors  
Measure the position specified (see fig content).



### Technical specifications

#### Max. allowable clearance:

0,012 mm

- The distance between the outer rotor and the pump housing (see illustration).

**Technical specifications****Max. allowable clearance:**


0,25 mm



- The axial play of the rotors with a ground measuring stick as a reference plane as in the figure
- Check the information shown.

**Technical specifications****Permissible limit:**

0,1 mm

**Installation**

- Make sure the seal is correctly attached
- is brought.

**ANNOTATION**

**THE GASKET GEARS MUST BE FITTED IN THE APPROPRIATE SEAT.**



- Lubricate the internal rotors.
  - Check that the pump cover is not off used or scratched.
  - Are different values measured or
- Scratches or wear are found, the Pump needs to be replaced.
- Attach the pump cover so that the drill
- The rungs for attaching the fastening screws to the housing are aligned with one another.
- Tighten the two fastening screws to the specified torque.



**Torque guide values (N\*m)****Oil pump cover screws  $0.7 \div 0.9$** 


- Insert the oil pump complete with gear.
- Insert the 2 screws through the slotted holes on the gear and with the prescribed rotation

tighten moment

**ANNOTATION**


**THE OIL PUMP INSTALLATION IS DONE BY INSTALLING THE SCREWS SPECIFIED.**

If the specified torque is not set hold, this can affect the passing clearance of the rotors change the pump housing.

**Torque guide values (N\*m)****Oil pump fastening screws to the housing with  $5 \div 6$** 

- The countershaft together with the gear into the housing half on the alternator side insert.


- The special tool as shown in the picture shows attach.

**Special tool****020479Y Tool for locking the countershaft**

- Hold the countershaft in position and insert the nut and washer.
- The nut with the prescribed torque ment tighten. The recommended product attach.
- Remove the special tool.

**Suggested products****Loctite 243 Medium strength thread locking sealant.**

Colour blue

**Torque guide values (N\*m)****Countershaft fixing nut  $25 \div 29$** 

## water pump

### expansion

#### Special tool

##### 020661Y Kit for replacing the integral seal of the water pump

- Using a screwdriver, remove the six  
Remove screws and the pump cover.



- With an 8mm wrench, the impeller of the Was  
Unscrew the water pump.



- Use two flat head screwdrivers. The  
screwdriver as shown in the illustration  
put so that it can be levered on the edge of the housing  
the can, and the integral seal that is on the  
If the impeller shaft is pressed on, destroy it.

#### **DANGER**

**FOR PROTECTION, APPLY TEFLON TAPE AS SHOWN IN  
THE PICTURE TO COVER THE SEALING SURFACE  
DO NOT DAMAGE WATER PUMP COVER.  
POSSIBLE SMALL IMPRINTS ON THE EDGE OF THE SUPPORT  
WILL NOT CAUSE MALFUNCTION.**





- If necessary, the position of the screw change here.
- When dismantling the seal it can happen that the ceramic breaks.



- Clean all parts thoroughly before pulling out.



- The puller complete with pin on the static Attach part of the ceramic seal.
- Without changing the position of the puller, with the pin and a hammer three holes on the sta Attach the table part of the seal.

**ANNOTATION**

**THE HOLES MUST BE MADE WITH A STRONG PUNCH.**

**LIGHT AND REPEATED IMPACT MAY CAUSE DEFORMATION WITHOUT MAKING HOLES.**



- The puller with the screw included in the tool on the static part of the seal attach.

**DANGER**

**THE TOOL MUST BE WELL FIXED, WITHOUT TO "TEAR" THE SHEET.**



## MP3 530 hpe

Motor

- Complete the tool by installing the bracket, screw and nut.



- Hold the screw firmly and the nut as far as possible rotate until the static part of the seal is full constantly moved out.
- The puller complete with the static part remove the ceramic seal.



### Installation

#### Special tool

020661Y Kit for replacing the integral seal of the water pump

##### PRESSING IN THE INTEGRAL SEAL

**DANGER**

CLEAN ALL COMPONENTS THOROUGHLY.

**DANGER**

LUBRICATE THE IMPELLER SHAFT WITH ENGINE OIL.



- Screw the threaded bolt onto the impeller shaft.

**DANGER****SCREW IN MANUALLY UNTIL THE STOP.**

- Attach the integral seal to the shaft.



- Attach the calibrated striking mandrel (with preload measurement).
- Attach the nut to the threaded bolt.
- Hold the threaded bolt firmly and tighten the nut screw tight until it stops.
- The tool is used to press the static seat into the housing and the movable seat onto the shaft and at the same time the ceramic seal correctly pre-tensioned.



- Screw the impeller tight.

**Torque guide values (N\*m)****Water pump impeller 4 ÷ 5**

- Install the pump cover with a new gasket. The seal must be lubricated with Vaseline grease before installation.
- Attach the six screws to the cover and Tighten to the specified torque hen.

**ANNOTATION**

**TO AVOID DEFORMATION, DO NOT LUBRICATE THE O-RING WITH MINERAL GREASE.**

**Torque guide values (N\*m)****Water pump cover screws 3 ÷ 4**



## Reverse gear

### REVERSE GEAR ADJUSTMENT ASSEMBLY

---

To remove the group of the adjusting device

Reverse gear, the screws of the protection

Remove the direction of the drive cover (4 screws  
ben).



The drive cover protection device is removed  
distant.



To make it easier to get to the components, at Be  
the fastenings of the filter housing (2  
Remove screws) and lift it slightly.



The coil is mounted in the middle part of the drive  
which controls the engagement of reverse gear  
are.

In addition, the linear sensor is present, which...

Position of the lever for insertion is determined and  
activates reverse gear.



The screw on the wiring retaining plate unscrew and remove this.



The fastenings of the assembly of the Stellvor  
Remove direction of reverse gear (3 screws).



Disconnect the cable connector and the assembly remove.

**DANGER**

**WARNING**



**TO EXPOSE THE CABLE CONNECTOR ATTACHMENT TOOTH, PRESS IT AS SHOWN IN THE PHOTO.**



At the top left is the contact housing of the Pluska attached to the engine for reverse gear.



## REMOVAL OF ENGINE AND REVERSE GEARS

## MP3 530 hpe

Motor

Unscrew the nuts of the retaining plate, this one  
Remove and the positive cable of the motor for the  
Release reverse gear.



Use a screwdriver to open the closure  
the axis of the guided pulley  
with.




Place the special tool in the designated areas  
Insert slots.

### Special tool

021022Y Stop guided pulley



Nut shaft guided pulley.





Remove the nut.



- Remove the special tool.



Remove the two washers.



Remove the drive cover screws (7  
M6 screws).



## MP3 530 hpe

Motor

Remove the screws on the right part of the cover

(2 screws M8).



Remove the screws on the middle part (2

M8 screws).



Remove the drive cover.



The engine mounting screws for the

Remove reverse gear (2 screws).




---

Remove the spacers.



---

- A suitable container for draining the  
Set up gear oil.  
Remove the motor and the cable from the  
Pull out the slot in the housing.  
Turn the lid of the housing over to open the inside  
Drain the oil contained in the reverse gear system  
its.



---

The screws inside the cover cover the tooth  
Remove the reverse gear wheels (5 screws).  
ben).



---

- Remove the outer screw.






## MP3 530 hpe

Motor

To remove the lid, apply leverage to the projections shown in the photo.

Only if high resistance is encountered, heat the area to stop the process facilitate.



- The reverse gear cover lose weight.



- Remove the spring.



Remove the first gear.



Remove the second gear.



Remove the shaft.



Remove the drive bushing.



#### ANNOTATION

A SAFETY SYSTEM IS INSTALLED ON THE DRIVE SOCKET, WHICH WILL CAUSE IF A AT A CERTAIN SPEED, THE GUIDED BELT PULLEY MECHANICALLY PREVENTS THE RETURN GEAR INSERTION.



The fork group to control the ride and the  
Remove the selector switch by lifting it evenly  
distant.



Remove the control bushing.



The special tool on the outside of the An  
Put on the drive cover.

### Special tool

**021024Y Key for blocking the tax  
bushing**



Pay attention to the protrusion on the tool  
the inner cavity is inserted, as in the photo  
you can see.





The tool has the dual function of holding the control socket and acting as a holder for it  
To serve as drive cover during removal.



The other part of the special tool on one  
Attach vise.

### Special tool

021024Y Key for blocking the tax  
bushing



Clamp the drive cover in the vise,  
by fitting the two parts of the tool into each other  
be set.



Use a pin puller to remove the locking tooth of the block  
Bend the idler disk downwards.



Place the special tool on the ring nut  
zen and the teeth of the tool into the slots  
insert the ring nut.

**Special tool****021023Y Key to lock the ring nut**

Loosen the threaded ring.



Take the drive cover out of the vice  
Remove the men and the special tools.



The control socket on the inside of the lid  
support, unscrew the ring nut and  
Remove blocking disk.



Remove the control bushing.



#### INSTALLING THE REVERSE GEARS AND MOTOR

##### ANNOTATION

BEFORE INSTALLING THE CONTROL BUSHING, THE FLAT LUBRICATE THE SEALING RING IN THE GEAR COVER AND THE CLUTCH SURFACE OF THE BUSHING.

##### Suggested products

Gear oil 80W-90 lubricant for gears and drives.

SAE 80W-90 API GL-4



The control socket from the inside of the An drive cover and the blocking disk from the ge insert on the opposite page.



Tighten the ring nut by hand.





The special tool on the outside of the An  
Put on the drive cover.

**Special tool**

**021024Y Key for blocking the tax  
bushing**



Pay attention to the protrusion on the tool  
the inner cavity is inserted, as in the photo  
you can see.



The other part of the special tool on one  
Attach vise.

**Special tool**

**021024Y Key for blocking the tax  
bushing**



Clamp the drive cover in the vise,  
by fitting the two parts of the tool into each other  
be set.



Place the special tool on the ring nut  
zen and the teeth of the tool into the slots  
insert the ring nut.

### Special tool

**021023Y Key to lock the ring nut**



The ring nut with the specified size  
Tighten torque.

**DANGER**  
**WARNING**



AFTER TIGHTENING, BEND ONE TOOTH OF THE  
LOCKING WASHER INTO ONE OF THE OUTER CAVITIES  
OF THE RING NUT.



### Torque guide values (N\*m)

**Reverse gear control bushing ring nut  $66 \div 74$   
Nm ( $49 \div 55$  lb\*ft)**

Take the drive cover out of the vice  
Remove the men and the special tools.



The fork group assembly for control  
the drive and the selector switch together  
build.

### ANNOTATION

**LUBRICATE THE FORK PINION AREA TO CONTROL  
TRAVEL.**

### Suggested products

**Gear oil 80W-90 lubricant for gears  
and drives.**

SAE 80W-90 API GL-4



## MP3 530 hpe

Motor

Mount the assembly on the control socket.

### ANNOTATION

**BEFORE INSTALLING, APPLY THE RECOMMENDED OIL BETWEEN THE TIMING BUSHING (CUTTER) AND THE GEAR SELECTOR.**

### Suggested products

**Gear oil 80W-90 lubricant for gears and drives.**

SAE 80W-90 API GL-4




Install the drive bushing.



Assemble the shaft.



The first gear with puf pointing downwards  
Mount the remote side as shown in the photo.





Install the second gear.



Insert the spring.



**DANGER**

**WARNING**

**ANNOTATION**



**MAKE SURE THAT THERE IS NO SECURING MEANS ON THE OUTSIDE OF THE GUIDE  
DRILLING OF THE CONTROLLER IS APPLIED.**

Clean the mating surface, the specific safety

Apply solvent and remove the drive cover

Attach reverse gear.

### **Suggested products**

**THREE BOND TB1207B liquid gasket**

Liquid gasket Three Bond TB1207B



Screw on the inner screws of the cover


(5 screws).

**Torque guide values (N\*m)**

**Screws of the cover of the gears of the  
Reverse gear  $11 \div 13 \text{ Nm}$  ( $8 \div 10 \text{ lb*ft}$ )**



Position the motor with the cable through  
the slot used for this purpose.



The passage of the motor cable and the posi-  
tion of the cap as shown in the figure  
to target.



- Insert the spacers.



Tighten the three motor mounting screws  
screw (2 screws).

**Torque guide values (N\*m)**

**Reverse motor mounting screws  $11 \div 13$  Nm  
( $8 \div 10$  lb\*ft)**



Insert the drive cover.



**DANGER**  
**WARNING**



THE FOUR M8 SCREWS OF THE DRIVE COVER HAVE  
DIFFERENT LENGTHS: THE TWO LONG SCREWS  
ARE MOUNTED IN THE MIDDLE PART, THE TWO  
SHORT SCREWS IN THE RIGHT PART.



Screw on the screws in the middle part (2  
long screws M8).

**Torque guide values (N\*m)**

**Fasteners M8 drive cover  $23 \div 26$  Nm ( $17 \div 19$   
lb\*ft)**





Screw on the screws in the right part (2 short M8 screws).

**Torque guide values (N\*m)**

Fasteners M8 drive cover  $23 \div 26$  Nm ( $17 \div 19$  lb\*ft)



Tighten the drive cover screws

(7 M6 screws).

**Torque guide values (N\*m)**

Fasteners M6 drive cover  $11 \div 13$  Nm ( $8 \div 10$  lb\*ft)



Install the two washers as per the photo  
ren; first the one with the smaller diameter,  
then the one with the larger diameter.



Place the special tool in the designated areas  
Insert slots, rotate the shaft if necessary,  
to be able to fully introduce it.

**Special tool**

021022Y Stop guided pulley



The nut of the shaft of the guided pulley  
be assembled.



The mother with the prescribed dress code  
ment tighten.

### **Torque guide values (N\*m)**

**Nut guided pulley 92 ÷ 100 Nm (68 ÷  
74 lb\*ft)**



Remove the special tool.



The closure of the shaft of the guided belts  
mount the disc.



The positive cable of the motor for reverse gear connect, position the retaining plate and with fasten with the corresponding nuts.

**DANGER**

**WARNING**



**CHECK AND CLEAN THE CONTACTS: POOR MAINTENANCE CONDITION COULD LEAD TO FUNCTIONAL MALFUNCTIONS AND A FIRE HAZARD.**



Fill the system via the filling opening.

### **Suggested products**

**Gear oil 80W-90 lubricant for gears and drives.**

SAE 80W-90 API GL-4

**Technical information Oil  
for reverse gear system**

90 cm<sup>3</sup>

**Torque guidelines (N\*m) Reverse  
system oil filler plug 15 ÷ 17 Nm (11 ÷ 13 lb\*ft)**





TABLE OF CONTENTS

BRAKE SYSTEM	BRAKE
--------------	-------

## Rear brake caliper

---

### expansion


- In preparation, remove the exhaust end part ren.
- The two fastening screws of the rear  
Remove brake caliper.



- Remove the brake caliper from its seat on the bracket take.

#### ANNOTATION

IF THE BRAKE DISC IS REPLACED OR OVERHAUL THE CIRCUIT IN CONJECTION MUST BE CLOSED DRAIN AND LOOSEN THE FASTENING OF THE OIL CONNECTOR BEFORE REMOVING THE BRAKE CALIPER FASTENERS TO THE HOLDER.




### Installation

- The brake caliper in its seat on the bracket to install.
- Clean the threads of the fastening screws and apply "LOCTITE 243" thread locking agent  
Apply sealant and with the specified  
Tighten torque.
- Install the exhaust end part.

#### Torque guide values (N\*m)

Fastening screw brake caliper rear wheel brake  $42.5 \pm 2.5$




## Brake caliper front brake

---

---

## expansion

- The specified work steps refer on one brake caliper, but apply to both.
- Remove the wheel.
- Unscrew the two fastening screws on the bracket and remove the brake caliper with.




---

## Installation

- When installing the front brake calipers in reverse Proceed in the reverse order as for removal.
  - Clean the threads of the fastening screws
- gen and "LOCTITE 243" thread locking
- Apply sealant and with the specified
- Tighten torque.

### Torque guide values (N\*m)

Fastening screw brake caliper front wheel brake  $22.5 \pm 2.5$



---

## Front brake pads

---

## expansion

- Remove the brake caliper.
- Remove the R-split from the brake caliper bolt with.



- Pull out the bolt and make sure that the retaining spring of the brake pads is on is maintained.




- Remove the brake pads from the brake caliper with.

### Technical specifications

**Minimum thickness of abrasive material**

1,5 mm



### Installation

- Insert the brake pads.



- Install the brake pad retaining spring and insert the bolt into the brake caliper.



- Insert the R-split on the brake caliper bolt was
- Reinstall the brake caliper.



## Rear brake pads

### Installation

- For mounting the brake pads in reverse
- Proceed in the same order as for removal.
- Clean the threads of the brake pad pins and "LOCTITE 243" thread locking sealant
- Apply and with the specified torque put on.

### Torque guide values (N\*m)

Brake pad pin  $17.5 \pm 2.5$






**Parking brake****EXPANSION**

- In preparation, remove the exhaust end part ren.

- The two right-hand fastening screws

Remove fender.



- Loosen the brake control cable adjusting nut  
sen, then the cable from the corresponding lever  
remove.




- The two fastening screws of the mecha

Remove the niche brake caliper.

- Lift the rear fender slightly and

Remove the brake caliper from its seat on the retaining bracket  
men.



- After removing the back of the shield, the cable

to switch on the protection device from the

Remove and separate your own seat.

- When reinstalling, as shown in the photo, special

different to the correct insertion of the cylindrical

Make sure the metal end fits into its seat.






- The cable connector from the control button
- Disconnect parking brake light.




- The three screws securing the lever to the
- Unscrew the frame.




- The steering brake control cable
- disconnect the lever.

**ANNOTATION**

**WHEN THE CONTROL LEVER IS REMOVED, WITHOUT REMOVING THE BRAKE CALIPER, DISCONNECT THE CABLE FROM THE BRAKE CALIPER REMOVE THE LEVER.**

**INSTALLATION**

- For assembling the locking components
- brake in the reverse order as with
- proceed with expansion.
- The threads of the fastening screws of the
- Clean the brake caliper and "LOCTITE 243" thread
- Apply anti-locking sealant and seal with the
- Tighten the specified torque.

**Torque guide values (N\*m)**

**Screw brake caliper parking brake  $25.5 \pm 1.5$**

### CHANGING THE BRAKE PADS

- Remove the mechanical brake caliper.
- Remove the two fixing pins and the  
Remove the brake pads from the brake caliper  
Make sure you have the appropriate retaining spring to withdraw.
- Check that the thickness of the friction material is greater than the minimum value, otherwise replace the brake pads.



### Technical specifications

#### Minimum thickness of abrasive material

1,5 mm

- To install the brake pads, proceed in the reverse order of removal.
- Clean the threads of the brake pad pins and apply  
"LOCTITE 243" thread locking sealant and to the specified torque  
put on.




#### Torque guide values (N\*m)

Brake pad pin  $17.5 \pm 2.5$

TABLE OF CONTENTS

COOLING SYSTEM	COOL
----------------	------

**circuit diagram**

The cooling system is a pressurized water circuit with a coolant pump and constant ventilation.

Cooling takes place via a centrifugal pump that is driven by the countershaft.

The coolant is routed from the pump to the thermal unit.

The bracket for the 2-way thermostat is attached to the outlet of the cylinder head, one of which to the pump, the other to the cooler (with horizontal circulation).

The cooler output is connected directly to the pump.

The expansion tank is connected in parallel to the radiator.

The hot radiator housing is connected to the upper part of the expansion tank (air).

The cold radiator housing is connected to the lower part of the expansion tank (liquid).

When the engine is cold, the thermostat output to the radiator is closed, even if a small flow to the ventilation is ensured through the opening on the closing plate.

In this case, the internal circulation in the thermal unit is activated to ensure a uniform

Ensure warming.

After reaching the operating temperature, the main circulation is at the cooler and at the expansion joint barrel activated.

When the thermostat opens, there is a flow overlap (recirculation and main flow).

At higher temperatures, circulation via the thermostat is excluded in order to

To promote main circulation.

In this case there is also a considerable flow in the expansion tank, which ensures the constant

Self-venting ensures.

To vent the system when filling the circuit, there is a be. on the upper part of the cylinder head

A special connection is provided (see filling instructions).

A cooling fan is required to ensure adequate cooling even when there is no wind provided, which is controlled via the injection system.

### TECHNICAL SPECIFICATIONS

Technical information	Description/Value
Capacity of the cooling system	1,8 Liter
Recommended coolant	50% mixture of water and liquid for closed ones Circuits
sealing pressure	Closure calibrated to 0.9 bar

### THERMOSTAT

Technical information	Description/Value
Opening start type	with wax and branching 95 ± 2°C

### COOLING FAN

Technical information	Description/Value
Type	With piston
Turning on the cooling fan	107°C
Turning off the cooling fan	103°C

### WATER PUMP

Technical information	Description/Value
Type	centrifugal force
steering	Coaxial to the countershaft

### COOLER

Technical information	Description/Value
Type	Made of aluminum, with horizontal circulation

### EXPANSION VESSEL

Technical information	Description/Value
calibration	Self-venting, parallel to the radiator

TABLE OF CONTENTS

BODY	IN THE WARS
------	-------------



This section è is dedicated to work on the vehicle body.

## Bench

### EXPANSION

- Raise the seat.
- Disconnect the driver position sensor connector with.




- The petrol ring from the pneumatic cylinder seat remove easily.



- Keep the plastic disc and the
- Remove the pneumatic cylinder from the corresponding pin distant.



- The two hinge mounting screws
- remove the seat.



- Remove the seat from the vehicle.




### INSTALLATION


- Position the seat on the vehicle.



- Hold the seat and lift the rear part  
ben, then the two fastening screws  
Install hinge.



- The pneumatic cylinder on the corresponding pin  
insert and install the plastic washer.



- The petrol ring on the pneumatic cylinder bolt install easily.



- The driver presence cable connector connect sors.



## Rear handlebar fairing

### EXPANSION

- Remove the upper handlebar cover.
- The cable connector shown in the illustration separate.



- Remove the rear fixing screw.





- Remove the two side fastening screws distant.



- Remove the handlebar cover from the vehicle  
men, paying attention to the cabling  
Do not strain the process.



### INSTALLATION

- Install the handlebar cover on the vehicle.

### ANNOTATION

Route the wiring harness through from the front of the handlebars.



- Install the rear mounting screw.



- The two side fastening screws in stall.




- The cable connector shown in the illustration connect.



## Instrument unit

### EXPANSION

- Remove the front of the shield.
  - Remove the handlebar covers.
  - Remove the shield back panel.
  - The six mounting screws of the Armatu
- Remove the protective boards on the back of the shield.



- The cable connector of the PMP3 control electronics split off.



- The cable connector shown in the illustration separate.



- Disconnect the instrument cluster cable connector clamps.



- Cut the plastic clamp and the Verka release the cable.



- The dashboard complete with instruments unit and PMP3 control unit from the vehicle Remove.





- Adjust the dashboard to a suitable position  
lay the side table.
- Unscrew the two fastening screws  
and the PMP3 control unit from the fittings  
remove board.



- From the inside of the dashboard  
go and remove the two fastening screws  
Unscrew the frame of the instrument unit.




- Press the frame fastening tabs,  
one at a time to remove them from the fittings  
to solve the board.



- The frame of the instrument unit from the Ar  
Remove tire board.



- The four mounting screws for the instruments  
Unscrew the unit.




- The instrument cluster from the dashboard  
remove.



#### INSTALLATION

- The instrument unit in the dashboard  
Insert and from the inside with the four screws  
attach.



- The frame of the instrument unit on the Arma  
Install door panel. Ensure that the Be  
fastening tabs correctly into their respective seats  
are used.



- The two mounting screws of the yardarm  
Tighten the instrument unit.



- The PMP3 control unit on the mounting brackets po  
position, then the appropriate fasteners  
Tighten the connection screws.



- The dashboard complete with instruments  
unit and PMP3 control unit on the vehicle  
situate.



- The wiring on the dashboard with a  
Attach the plastic clamp as shown in the illustration  
shown.






- Connect to instrument unit cable connector the.



- The cable connector shown in the illustration connect.



- The cable connector of the PMP3 control electronics connect.



- The six mounting screws of the Armatu  
Install renbretts on the back of the shield and  
tighten.
- Install the shield back cover.
- Install the handlebar covers.
- Install the shield front.



## Front handlebar fairing

### EXPANSION

- Remove both rear-view mirrors.
- Unscrew the two fixing screws shown in the illustration.



- Lift the handlebar cover up and off
- Remove vehicle.



### INSTALLATION

- Place the upper handlebar cover in its seat and make sure they are properly connected to the lower steering to connect the cover.



- The two fasteners shown in the picture
- Insert and tighten the connection screws.
- Install the rearview mirrors.




## Headlight unit

### HEADLIGHT

#### EXPANSION

- Remove the front of the shield from the vehicle men.
- Unscrew the three fastening screws «A» ben.
- Unscrew the four fastening screws "B". ben and the headlight from the front of the shield remove page.



#### INSTALLATION

- Place the headlight in the appropriate seat Install on the front of the shield.
- Install the fixing screws "B" .
- Install the fixing screws "A" .

### FLASHING

#### EXPANSION

- The lower indicator mounting screws screw off.



- The middle fixing screws of the Blink unscrew it first.






- The turn signal upper mounting screws screw off.



- Remove the indicator from the vehicle and...  
Disconnect cable connector.
- On the opposite page the events  
Repeat to remove turn signal.



- The two indicator mounting screws remove.



- Remove the indicator from the plastic holder with.



The indicators are LED type, so they are maintenance-free.  
In the event of a defect, the entire component must be replaced.



#### INSTALLATION

- To reassemble, carry out the disassembly in the reverse order, taking care  
It is important that the indicators are correctly inserted into their seats.

## Medium fairing

### EXPANSION

- Remove the side panels.
- Remove the seat.
- Remove the back of the shield.
- Remove the two fixing screws shown in the figure on both sides.



- Temporarily remove the fuel cap and the underlying rubber carpet from the tank remove box.



- The driver presence sensor wiring pull out the middle cover.



- Lift the cover from the frame.
- Separate the cable jacket from its seat.



- Disconnect the cable from the door opening control and the center cover from the vehicle remove.



#### INSTALLATION

- To reassemble, reverse the disassembly procedures and then Make sure that the door opening control cable and the presence sensor wiring are connected driver must be inserted correctly.

---

## Front shield

#### EXPANSION

- The two front grill mounting screws remove.



- Remove the front grill from the front of the shield with.



## MP3 530 hpe

body

- The front headlight cable connector  
pull it off.



- The two side mounting screws  
Remove the front spoiler.



- The middle fastening screw of the front  
remove spoilers.



- Remove the front spoiler from the vehicle.





- Unscrew the two fastening screws and remove the bracket from the vehicle.



- The lower indicator mounting screws screw off.



- The middle fixing screws of the Blink unscrew it first.



- The turn signal upper mounting screws screw off.



- Remove the indicator from the vehicle and...

Disconnect cable connector.

- On the opposite page the events

Repeat to remove turn signal.



- Remove the two middle fastening screws distant.



- The side, lower, fastening screw of remove both sides.



- The side, top, fixing screw of remove both sides.






- The front section of the shield front from Remove vehicle.



- Work from the inside of the wheel arch and the three fastening screws of the side Ab Remove section of shield.



- Raise the side section to the three Fastening straps from the back of the shield disconnect, then remove the component from the vehicle distant.
- The work for the side section on the ge repeat on opposite side.



## ASSEMBLY


- Install the side section of the front shield hours on the vehicle, inserting the three tabs from above fastening to the back shield. Make sure of the correct to coupling between the two components.



## MP3 530 hpe

body

- Working from the inside of the wheel arch, install loosen the three fixing screws of the side section of the shield.
- Repeat the operations for the section on the opposite side place.



- Install the front section of the front shield hours on the vehicle.




- Install the lateral, upper fixing screw, on both sides.



- Install the side, bottom, fixing screw on both sides.



- Install the central fixing screws.



- Connect the connector and install the indicator direction on the vehicle.



- Install the upper fixing screw of the indicator direction indicator.



- Install the intermediate fixing screw of the index direction indicator.





- Install the two lower fixing screws.
- Repeat the operations relating to the opposite side giving the installation of the direction indicator.



- Install the front spoiler fixing bracket
- and tighten the relative fixing screws.

### ANNOTATION

The long screw faces towards the front of the vehicle, the short one towards the rear.



- Install the front spoiler on the relative bracket
- fixing.



- Install the central spoiler fixing screw
- front.



- Install the spoiler side fixing screws front.



- Connect the front headlight connector.



- Install the front shield mask in the relevant office.



- Install the two fixing screws of the mask front.




## Shield back

### EXPANSION


- Remove the front of the shield.
- Remove the handlebar covers.
- Remove the two cushions from the back of the shield away and pull outwards.



- The two panel mounting screws  
Unscrew "A".
- Lift panel "A" and disconnect the cable connectors and remove it from the vehicle.
- The work for the panel on the opposite side repeat on the following page.



- The three fasteners shown in the picture  
Unscrew the connection screws on both sides.



- The cover of the back of the shield from the vehicle  
remove stuff.






- The six mounting screws of the Armatu
- Remove the protective boards on the back of the shield.
- Then the dashboard of the instruments

Remove the device from the vehicle.

#### ANNOTATION


The procedure for removing the instrument cluster is described in the relevant section of the manual.




- Remove the running board inspection flap.
- The fastening shown in the picture remove screw.



- The fastening shown in the picture remove screw.



- Remove the side cover of the running board with.
  - Work for the cover on the counter
- Repeat on opposite side.



- The two lower fastening screws

Remove back of shield.



- From the inside of the front wheel arch ar

work, on both sides those in the picture

Remove specified screw.



- The middle fixing screw of the shield

Remove back.



- The cable connector of the seat opening adjusting device

disconnect voltage.



- Disconnect the transmission cable from the seat opening adjusting device.



- The wiring from the cable passage on the  
Separate the inside of the back of the shield.



- Remove the back of the shield from the vehicle  
with.



---

#### INSTALLATION

- Install the shield back on the vehicle.





- Attach the wiring to the corresponding cable gland on the inside of the back of the sign.



- The transmission cable to the adjusting device  
Connect seat opening.



- The cable connector of the seat opening adjusting device  
connection.



- The middle fixing screw of the shield  
Install back.



- From the inside of the front wheel arch ar  
work, on both sides those in the picture  
Install specified screw.



- The two lower fastening screws  
Install shield back.



- On the vehicle, the side cover of the step  
Install boards.

**ANNOTATION**

**Make sure the mounting pins are correctly inserted and locked into their seats.**



- The fastening shown in the picture  
install screw.






- The fastening shown in the picture install screw.
- Install the inspection hatch on the running board.
- The installation work of the running board cover repeat on the opposite side.



- The dashboard of the instrument cluster on Install vehicle.
- The six mounting screws of the Armatu Install renbretts on the back of the shield.

**ANNOTATION**


The procedure for installing the instrument cluster is described in the relevant section of the manual.




- The cover of the back of the shield on the vehicle install stuff.



- The three fasteners shown in the picture Install connection screws on both sides.



- Connect the cable connectors of the cabling and install panel "A" on the back of the shield.
- Tighten the two fixing screws and repeat the work for the panel on the opposite side.




- Install both cushions on the back of the shield and make sure the mounting pins are correct are used properly.
- Install the handlebar covers.
- Install the shield front.



## Front wheel housing

### EXPANSION

- Remove the front of the shield.
- The two upper fastening screws of the shield. Remove the wheel housing on both sides.



- The lower fastening screw on both sides remove ten.



- Remove the wheel arch from the vehicle.




#### INSTALLATION

- Install the wheel arch on the vehicle and make sure that it is correctly connected to the borders fits the plastics.



- The two upper fastening screws of the wheel housing on both sides. Install the wheel housing on both sides.



- The lower fastening screw on both sides install ten.





## Rear light unit

- Remove both side parts.
- Disconnect the cable connector and unplug the

Remove the headlight unit from the retaining bracket.



- Remove the two fixing screws.



- Remove the taillight unit from the vehicle in.



## running boards

### INSTALLATION

- Install the running board on the vehicle.

### ANNOTATION

The work steps described refer to one side of the vehicle, but apply to both in order to assemble the running board from the vehicle.



- The four fasteners shown in the picture install screws.



- Install the top mounting screw.



- Install the lower mounting screw.



- Install the rubber footboard on the running board, Make sure the "centering pins" are correctly in place Use sitting.






- The fastening caps of the rubber cover to install.



- Proceed on the right side of the footboard: the pedal on Attach the brake lever and then the corresponding one Tighten the end fastening screws. After Complete the installation the rubber clamps like attach it to the brake lever.



- Install the passenger footboard on the vehicle and partly the screws "B", with washer tighten washers.
- Install the fixing screws "A", then tighten screws "B".
- The central cover of the frame and all Reinstall previously removed components.




## DISASSEMBLY

- Remove the central cover of the frame.
- Open the passenger footrest and unscrew the screw "A".
- Unscrew screws "B", collect the washers and remove remove the passenger footboard from the vehicle.

### ANNOTATION

The operations described refer to one side of the vehicle, but are to be considered valid for both, for the purposes of removing the footrest from the vehicle.



- Operating on the right platform: lift the ceiling rubber screw, unscrew the two fixing screws of the brake pedal and remove the pedal from the vehicle colo.



- Remove the cover fixing caps eraser.



- Remove the rubber cover from the footboard.



- Remove the lower fixing screw.



- 
- Remove the upper fixing screw.



- 
- Remove the four fixing screws indicated in figure.




- 
- Remove the footrest from the vehicle.



---


#### Helmet compartment

- 
- Remove the seat.
  - Disconnect and remove the battery.
  - Remove both running boards.
  - Pull the starter remote relay out of its seat.







- Open the two safety tabs and the  
Pull the relay base out of the seat.



- The two securing screws  
Unscrew the retainer and remove the fuse  
Remove holder from its seat.




- The OBD2 socket "A" and "B" from the ent  
Remove speaking seats.



- The cabling and components like that  
have just been removed, on the right vehicle  
move page. Make sure there are no comms  
components.



- The rear brake mounting screw  
Unscrew the oil container.




- Place the rear wheel brake oil container in the corresponding  
Attach the end opening in the helmet compartment.



- Remove the two fastening screws  
and attach the ignition coil to the frame tube.



- Proceed to the rear of the vehicle and  
Remove the right additional light connector.






- The two cables from the seat lock switch remove.



- The two side fastening screws  
Unscrew the helmet compartment.
- The process on the opposite side repeat.



- Remove the front fixing screw.




- Remove the two rear mounting screws distant.



- Lift the rear part of the helmet compartment to act on the seat lock cables can.
- The cable lock with a screwdriver remove.



- Push the cable jacket outwards to seal it from the holder and the cable from the corresponding cylindrical end on the seat Release opening control.
- Repeat the steps for the second cable.



- Remove the helmet compartment from the vehicle.



## **A**

Dashboard: 82

## **B**

Battery:

## **AND**

Recommended products: 49

## **F**

Chassis and engine number: 23

Vehicle: 18, 120

## **G**

Gear oil: 51

## **K**

The control: 11

## **L**

Lamps: 84

Air filter: 52

## **M**

Unit of measurement:

Engine oil: 54

## **S**

Headlight unit: 273

Fuses: 85

Bench: 262

## **T**

Technical information: 216

## **IN**

Maintenance: 46

## **WITH**

Spark plug: 50

## **HE**

Oil filter: