


GENUINE



XS 400 H/SH

Service Manual





YAMAHA

**XS400H
XS400SH**

Supplementary

Service Manual H/S

INDEX

This manual has been combined with previous service manuals to provide complete service information for: **XS400H/SH.**

Please read and give special consideration to the "NOTICE" on the preceding page for your safety.

XS400H/SH SUPPLEMENT

H/

XS360C SERVICE MANUAL

FOREWORD

This Supplementary Service Manual has been prepared to introduce new *service and new data* for the XS400H/XS400SH.

For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manuals:

XS360C Service Manual (LIT-11616-00-49)
XS400F/XS400-2F Supplementary Service Manual (LIT-11616-01-19)
XS400G/XS400SG Supplementary Service Manual (LIT-11616-01-87)

SERVICE DEPT.
INTERNATIONAL DIVISION
YAMAHA MOTOR CO., LTD.

NOTE:

This Supplementary Service Manual contains information regarding periodic maintenance to the emissions control system for the XS400H/XS400SH. Please read this material carefully.

NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent to motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit for use and/or unsafe.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the motorcycle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his motorcycle and to conform with federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

Particularly important information is distinguished in this manual by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedure that must be followed to avoid damage to the motorcycle.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

Starting Serial Number

XS400H	4R5-000101
--------	------------



XS400SH	4R4-000101
---------	------------



MAINTENANCE AND LUBRICATION CHART

Periodic maintenance emission control system

No.	ITEM	REMARKS	INITIAL BREAK-IN		THEREAFTER EVERY	
			1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)
1.*	Valve Clearance	Check and adjust valve clearance when engine is cold.	○	○		○
2.	Spark Plugs	Check condition. Adjust gap. Clean. Replace after initial 13,000 km (8,000 mi).		○	○	Replace every 12,000 km or 18 months (7,500 mi)
3.*	Crankcase Ventilation System	Check ventilation hose for cracks or damage. Replace if necessary.		○		○
4.*	Fuel Hose	Check fuel hose for cracks or damage. Replace if necessary.		○		○
5.*	Exhaust System	Check for leakage. Retighten as necessary. Replace gasket(s) if necessary.		○	○	
6.*	Carburetor Synchronization	Adjust synchronization of carburetors.		○	○	
7.*	Idle Speed	Check and adjust engine idle speed. Adjust cable free play if necessary.		○	○	

* It is recommended that these items be inspected and serviced by a Yamaha Dealer or other qualified mechanic.

General maintenance/lubrication

No.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY		
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)
1.	Engine Oil	Warm-up engine before draining	Refer to NOTE	○	○	○		
2.	Oil Filter	Replace	—	○	○		○	
3.*	Air Filter	Dry type filter. Clean with compressed air.	—		○		○	
4.*	Brake system	Adjust free play. Replace pads (disc brake) or shoes (drum brake) if necessary.	—	○	○	○		
5.*	Clutch	Adjust free play	—	○	○	○		
6.	Drive Chain	Check chain condition. Adjust and lubricate chain thoroughly.	Yamaha chain and cable lube or SAE 10W/30 motor oil	CHECK CHAIN TENSION AND LUBE EVERY 500 km (300 mi).				
7.	Control and Meter Cable	Apply cable lube thoroughly.	Yamaha chain and cable lube or 10W/30 motor oil	○	○	○		
8.	Rear Arm Pivot Shaft	Apply cable lube lightly.	Lithium soap base grease		○		○	

No.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY			
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)	
9.	Stand Shaft Pivots/ Brake Pedal Shaft/ Charge Pedal Shaft/Kick Crank Boss	Apply cable lube lightly.	Yamaha chain and cable lube or SAE 10W/30 motor oil.		○	○			
10.*	Front Fork Oil	Drain completely. Refill to specification	Yamaha fork oil 20wt or equivalent						○
11.*	Steering Bearings	Check bearings assembly for looseness. Moderately repack every 16,000 km (10,000 mi)	Medium weight wheel bearing grease.		○	○			Repack
12.*	Wheel Bearings	Check bearings for smooth rotation.	—		○	○			
13.	Battery	Check specific gravity. Check breather pipe for proper operation.	—		○	○			
14.	Brake/ Clutch Lever Pivot Shafts	Apply cable lube lightly.	Yamaha chain and cable lube or SAE 10W/30 motor oil		○	○			

* It is recommended that these items be inspected and serviced by a Yamaha dealer or other qualified mechanic.

NOTE: _____

Engine oil type:

- a. If temperature does not go below 5°C (41°F): YAMALUBE 4-cycle oil or SAE 20W/40 type "SE" motor oil.
- b. If temperature does not go above 15°C (59°F): SAE 10W/30 type "SE" motor oil

NEW SERVICE

*ENGINE

A. FUEL LEVEL

The carburetor is furnished with a drain screw to provide easy access to service work. Thus, the following "Fuel level measurement" should be added.


Fuel level measurement

NOTE:

Before checking the fuel level, note the following:

1. Place the motorcycle on a level surface.
2. Adjust the motorcycle position by placing a suitable stand or a garage jack under the engine so that the carburetor is positioned vertically.

1. Connect the level gauge (special tool) or a vinyl pipe of 6 mm (0.24 in) in inside diameter to the float bowl nozzle left or right side carburetor.
2. Set the gauge as shown and loosen the drain screw.




1. Level gauge 2. Drain screw

3. Start the engine and stop it after a few minutes of run. This procedure is necessary to obtain the correct fuel level.

NOTE:

Make sure the fuel petcock is "ON" or "RES" position.


4. Note the fuel level and bring the gauge to the other end of the carburetor line and repeat step 3. Note the fuel level again compare it with the previous gauge reading. They should be equal. If not, place a suitable size of wooden piece or the like under the center stand and adjust.




5. Check the fuel level one by one. The level should be in the specified range.

Fuel level:

3 ± 1 mm (0.12 ± 0.04 in) below from the carburetor mixing chamber body edge.



6. If the fuel level is incorrect, remove the carburetor assembly from the motorcycle and check the fuel valve (s) and float assembly (s) for damage.
7. If no damage is found, correct the fuel level by slightly bending the float arm tang. Recheck the fuel level.




1. Float arm tang

*CHASSIS

A. METHOD OF MOUNTING THE ENGINE

The method of mounting the engine assembly is changed from a rigid to an elastic type. Thus, the tightening torque should be changed accordingly as follows.




A

Tightening torque (Upper):
1.8 m·kg (13.0 ft·lb)


B

Tightening torque (Front, under): 3.0 m·kg (21.7 ft·lb)



C

Tightening torque (Rear, under): 3.0 m·kg (21.7 ft·lb)




B. BRAKE LINING

The brake lining indicator is modified for easier maintenance. Thus, the following "Brake lining inspection" should be changed.

Brake lining inspection

1. Front brake lining (For XS400H)


To check, see the wear indicator position while pulling the brake lever. If the indicator reaches to the wear limit line, replace the shoes.



1. Wear limit 2. Wear indicator

2. Rear brake lining (For XS400H/XS400SH)

To check, see the wear indicator position while depressing the brake pedal. If the indicator reaches the wear limit line, replace the shoes.



1. Wear limit 2. Wear indicator

ELECTRICAL

A. STARTING CIRCUIT CUT-OFF SYSTEM

The starting circuit cut-off system is employed. Hence, the following description.

Description

This model is equipped with a starting circuit cut-off switch. The starter motor is so designed that it can be started only when the transmission is in Neutral or the clutch is disengaged.


Accordingly, the starter motor will not start when the transmission is shifted into any position other than neutral, unless the clutch lever is pulled in.

Function of the Diode in the Relay

When the transmission is in a position other than Neutral:

Turning on the clutch lever switch (Clutch is disengaged by pulling the clutch lever) makes the safety relay to turn on.

In this case, the diode interrupts the flow of current from the main switch to the neutral indicator light and to the relay, and thus the light will not come on.



Operation

1. When the transmission is in Neutral:

Neutral switch	ON
Clutch lever switch	OFF or ON

- When the main switch is turned on while the transmission is in neutral the starting circuit cut-off relay circuit is closed and the relay is actuated.
 - When the "START" button is pressed, the circuit from the main switch to the relay — starter switch assembly — "START" (button) is closed, and the starter switch assembly is turned on, thus causing the starter motor to start.
2. When the clutch lever is released while the transmission is in position other than neutral:

Neutral switch	OFF
Clutch lever switch	OFF

- Since the starting circuit cut-off is kept open, the relay is not actuated, and it is impossible to turn on the starter switch assembly by pushing the "START" button.
As a result, the starter motor does not run.
3. When the clutch lever is disengaged by pulling in the clutch lever while the transmission is in a position other than neutral:

Neutral switch	OFF
Clutch lever switch	ON

- Since the clutch lever switch is on while the neutral switch is off, the following circuit — main switch — starting circuit cut-off relay — clutch lever switch is closed and the relay is actuated.

The subsequent operation is the same as 3.

SPECIFICATIONS

General Specifications

	XS400SH	XS400H
Basic color	BLACK RED or CARDINAL RED	NEW CATALINE BLUE
Dimensions:		
Overall length	2,070 mm (81.5 in)	←
Overall width	870 mm (34.3 in)	860 mm (33.9 in)
Overall height	1,140 mm (44.9 in)	1,105 mm (43.5 in)
Seat height	770 mm (30.3 in)	←
Wheelbase	1,375 mm (54.1 in)	←
Minimum ground clearance	135 mm (5.3 in)	←
Caster (steering head angle)	27°30'	←
Trail	87 mm (3.43 in)	←
Weight:		
Net	170 kg (375 lb)	167 kg (368 lb)
Engine:		
Type	4 stroke air-cooled, gasoline	←
Bore × stroke × cylinders	69 × 52.4 mm × 2 (2.717 × 2.063 in × 2)	←
Displacement	391 cc (23.86 cu. in)	←
Compression ratio	9.3 : 1	←
Lubrication:		
Lubrication system	Pressure lubricated, wet sump	←
Delivery pump type	Trochoid	←
Carburetion:		
Manufacturer	MIKUNI	←
Type	BS34, constant velocity	←
Air filter:	Dry type element	←
Ignition:		
Type	Battery ignition (Full transistor ignition)	←
Spark plug	BP7ES (NGK) or N-7Y (CHAMPION)	←
Charging:		
Type	Three-phase, regulated alternator	←
Manufacturer, I.D. No.	ND 021000-778	←
Maximum output	14.5V, 12A	←
Battery type	12N12A-4A	←
Battery dimensions	134 × 160 × 80 mm (5.28 × 6.30 × 3.15 in)	←
Rectifier	DE3804-1 or DS10TEY-L full wave	←
Regulator	026000-3280 IC type	←
Regulating voltage (No. load)	14.0 ~ 14.7 V	←
Starting:	Electric and kick starter	←
Primary drive:		
Type	Gear	←
Teeth, ratio	78/24 (3.250)	←
Clutch:	Wet, multiple disc	←
Transmission:		
Type	Constant mesh, 6-speed, drum	←

	XS400SH	XS400H
Teeth, ratio 1st	35/14 (2.500)	←
2nd	32/18 (1.777)	←
3rd	29/21 (1.380)	←
4th	27/24 (1.125)	←
5th	25/26 (0.961)	←
6th	26/30 (0.866)	←
Secondary drive:		
Type	Chain DID 50DS-102L	←
Teeth, ratio	37/16 (2.312)	←
Chassis:		
Frame	Tubular steel, semi-double cradle	←
Suspension: Front	Telescopic fork	←
Rear	Swing arm	←
Tires: Front	3.00S 18-4PR (Tubeless)	3.00S 18-4PR
Rear	120/90-16 63S (Tubeless)	120/90-16 63S
Brakes: Front	Hydraulic disc	Drum brake
Rear	Drum brake	←
Fuel tank: Total	14.0 lit (3.67 US. gal)	←
Reserve	3.3 lit (0.87 US. gal)	←
Wheels: Front	Cast wheel	Spoke wheel
Rear	Cast wheel	Spoke wheel

Maintenance Specifications

1. Engine

Engine oil capacity:	
Dry	2.6 lit (2.7 US. qt)
Oil and filter change	2.3 lit (2.4 US. qt)
Oil change	2.0 lit (2.1 US. qt)
Recommended lubricant:	
If temperature does not go below 5°C (40°F)	YAMALUBE 4-cycle oil or SAE 20W/40 SE motor oil
If temperature does not go above 15°C (60°F)	SAE 10W/30 SE motor oil
Cranking pressure (at seal level)	11 kg/cm ² (156 psi)
Maximum difference between cylinders	1 kg/cm ² (14 psi)




YAMAHA MOTOR CO.,LTD.

IWATA, JAPAN



STOPPING DISTANCE

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system.



ACCELERATION AND PASSING ABILITY

This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below. The low-speed pass assumes an initial speed of 20 mph. and a limiting speed of 35 mph. This high-speed pass assumes an initial speed of 50 mph. and a limiting speed of 80 mph.



SUMMARY

Low-speed pass. 353.0 feet: 7.2 seconds (XS400H/XS400SH)

High-speed pass 1,053.6 feet: 10.6 seconds (XS400H/XS400SH)

CONVERSION TABLES

METRIC TO INCH SYSTEM			
	KNOWN	MULTIPLIER	RESULT
TORQUE	m-kg	7.233	ft-lb
	m-kg	86.80	in-lb
	cm-kg	0.0723	ft-lb
	cm-kg	0.8680	in-lb
WT.	kg	2.205	lb
	g	0.03527	oz
FLOW/DISTANCE	km/lit	2.352	mpg
	km/hr	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
VOL. CAPACITY	cc (cm ³)	0.03382	oz (US liq)
	cc (cm ³)	0.06102	cu. in
	lit (liter)	2.1134	pt (US liq)
	lit (liter)	1.057	qt (US liq)
	lit (liter)	0.2642	gal (US liq)
MISC.	kg/mm	56.007	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade(°C)	9/5(°C)+32	Fahrenheit(°F)

INCH TO METRIC SYSTEM			
	KNOWN	MULTIPLIER	RESULT
TORQUE	ft-lb	0.13826	m-kg
	in-lb	0.01152	m-kg
	ft-lb	13.831	cm-kg
	in-lb	1.1521	cm-kg
WT.	lb	0.4535	kg
	oz	28.352	g
FLOW/DISTANCE	mpg	0.4252	km/lit
	mph	1.609	km/hr
	mi	1.609	km
	ft	0.3048	m
	yd	0.9141	m
	in	2.54	cm
	in	25.4	mm
VOL. CAPACITY	oz (US liq)	29.57	cc (cm ³)
	cu. in	16.387	cc (cm ³)
	pt (US liq)	0.4732	lit (liter)
	qt (US liq)	0.9461	lit (liter)
	gal (US liq)	3.785	lit (liter)
MISC.	lb/in	0.017855	kg/mm
	psi (lb/in ²)	0.07031	kg/cm ²
	Fahrenheit(°C)	5/9(°F-32)	Centigrade(°F)

DEFINITION OF TERMS:

m-kg	=	Meter-kilogram(s) (usually torque)
g	=	Gram(s)
kg	=	Kilogram(s) (1,000 grams)
lit	=	Liter(s)
km/lit	=	Kilometer(s) per liter (fuel consumption)
cc	=	Cubic centimeter(s) (cm ³) (volume or capacity)
kg/mm	=	Kilogram(s) per millimeter (usually spring compression rate)
kg/cm ²	=	Kilogram(s) per square centimeter (pressure)

CONSUMER INFORMATION


Notice

The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.

General Torque Specifications

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a

crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.



A (Nut)	B (Bolt)	General torque specifications	
		m-kg	ft-lb
10 mm	6 mm	0.6	4.5
12 mm	8 mm	1.5	11
14 mm	10 mm	3.0	22
17 mm	12 mm	5.5	40
19 mm	14 mm	8.5	61
22 mm	16 mm	13.0	94

Torque Specifications

	Tightening torque		Remarks
	m-kg	ft-lb	
Engine:			
Cylinder head cover and cylinder head 8 mm bolt	2.2	15.9	
6 mm bolt	1.0	7.2	
Cylinder head 10 mm nut	3.3	23.9	Apply oil
6 mm bolt	1.0	7.2	
Cylinder head cover (Tappet cover) 32 mm	1.2	8.7	
Spark plug	2.0	14.5	
Tappet adjusting screw lock nut 6 mm nut	1.4	10.1	
Cam sprocket 7 mm bolt	2.0	14.5	
Connecting rod 8 mm nut	3.6	26.0	Apply molybdenum disulfide grease
Generator (rotor) 10 mm bolt	3.3	23.9	
Starter clutch 8 mm bolt	3.0	21.7	Use LOCTITE
Reluctor 6 mm bolt	1.0	7.2	
Drain plug (engine oil)	3.8	27.5	
Oil filter	1.5	10.8	Apply oil
Strainer cover 5 mm bolt	0.7	5.1	
Oil pressure switch	1.8	13.0	Use LOCTITE
Crankcase 8 mm bolt	2.2	16.0	
Crankcase 6 mm bolt	1.0	7.2	
Clutch spring screw 6 mm bolt	1.0	7.2	
Primary drive gear 10 mm bolt	4.8	34.7	
Change pedal 6 mm bolt	1.0	7.2	
Neutral switch	2.0	14.5	
Exhaust pipe 8 mm nut	2.2	16.0	
Chassis:			
Engine mounting Front, under 10 mm bolt/nut	3.0	21.7	
Engine mounting Rear, under 10 mm bolt/nut	3.0	21.7	
Engine mounting Upper 8 mm bolt/nut	1.8	13.0	
Engine mount stay Rear upper 8 mm bolt	1.8	13.0	
Engine mount stay Upper 8 mm bolt/nut	1.8	13.0	
Handle crown and steering shaft 14 mm bolt	5.4	39.1	
Handle crown and inner tube 8 mm bolt/nut	1.1	8.0	
Handle crown and handle holder 10 mm nut	2.3	16.6	
Under bracket and inner tube 10 mm bolt	3.5	25.3	
Rear shock absorber and frame 10 mm bolt	3.0	21.7	
Rear shock absorber and rear arm 10 mm nut	3.0	21.7	
Front wheel axle 14 mm nut	10.7	77.4	
Front fork and axle holder 8 mm nut	2.0	14.5	
Pivot shaft 14 mm nut	6.5	47.0	
Rear wheel axle 14 mm nut	10.7	77.4	
Sprocket wheel 12 mm nut	4.5	32.5	
Tension bar and brake plate 8 mm bolt/nut	1.4	10.1	
Tension bar and rear arm 8 mm bolt/nut	1.4	10.1	
Brake cam lever and cam shaft 6 mm bolt	1.0	7.2	
Brake disc and hub (front) 8 mm bolt (XS400SH only)	2.0	14.5	Use lock plate
Caliper and brake hose (XS400SH only)	2.6	18.8	
Caliper and bleed screw (XS400SH only)	0.6	4.3	
Master cylinder and brake hose (XS400SH only)	2.6	18.8	
Caliper and caliper bracket 8 mm bolt (XS400SH only)	2.5	18.1	Use LOCTITE
Handlebar upper holder 8 mm bolt	1.8	13.0	
Rear stay (Grab bar) and rear shock absorber 10 mm nut	3.0	21.7	
Rear stay (Grab bar) and frame 8 mm bolt	2.3	16.6	


Spark plug: Type Electrode gap	BP7ES (NGK) or N-7Y (CHAMPION) 0.7 ~ 0.8 mm (0.023 ~ 0.032 in)
Spark plug cap resistance:	10k Ω
Pick-up coil: Resistance	700 Ω \pm 20% at 20°C (68°F)
Ignition coil type: Spark gap Primary resistance Secondary resistance	HITACHI CM11-54 6 mm (0.24 in) or more at 500 r/min (10 kV/100 r/min, 15 kV/9,500 r/min) 3.0 Ω \pm 10% at 20°C (68°F) 8.6k Ω \pm 20% at 20°C (68°F)
Starter motor type: Armature coil resistance Field coil resistance Brush length: standard minimum Brush spring pressure Armature mica undercut	MITSUBA SM-223B 0.005 Ω at 20°C (68°F) 0.011 Ω at 20°C (68°F) 11.0 mm (0.433 in) 6.0 mm (0.236 in) 550 \pm 55g (19.40 \pm 1.94 oz) 0.7 mm (0.028 in)
Battery type: Charging rate	GS 12N12A-4A 1.2 Amps for 10 Hours
Generator type: Output Field (inner) coil resistance Stator (outer) coil resistance	ND 021000-778 14.5V 12A at 5,000 r/min 4.0 Ω \pm 10% at 20°C (68°F) 0.72 Ω \pm 10% at 20°C (68°F)
Regulator type: Regulated voltage	ND 026000-3280 14.35 \pm 0.35V
Starter relay switch: Cut-in voltage Winding resistance	HITACHI A104-70 6.5V 3.5 Ω at 20°C (68°F)
Lighting system: Headlight Tail/brake light Flasher light Licence light Pilot lights Flasher High beam Neutral Oil pressure Meter light	12V, 50W/35W 12V, 8W (3CP1)/27W (32CP) \times 2 12V, 27W (32CP) \times 4 12V, 3.8W \times 2 12V, 3.4W \times 1 12V, 3.4W \times 1 12V, 3.4W \times 1 12V, 3.4W \times 1 12V, 3.4W \times 2

Brakes: Front brake ***: Type Disc size (Outside dia. × thickness) Disc wear limit Pad wear limit Master cylinder inside dia. Caliper cylinder inside dia. Brake fluid type/quantity Front brake **: Type Actuating method Brake drum I.D. Brake shoe dia. × width Lining thickness/wear limit Shoe spring free length Rear brake: Type Actuating method Brake drum I.D. Brake shoe dia. × width Lining thickness/wear limit Shoe spring free length	Hydraulic disc type $267 \times 5.0 \text{ mm } (10.51 \times 0.20 \text{ in})$ 4.5 mm (0.18 in) 6.5 mm (0.26 in) 14.00 mm (0.551 in) 42.85 mm (1.687 in) DOT #3 Brake fluid/24 cc (0.81 oz) Drum brake (Two leading) Wire 180 mm (7.09 in) $180 \times 30 \text{ mm } (7.09 \times 1.18 \text{ in})$ 4 mm/2 mm (0.16 in/0.08 in) 68 mm (2.68 in) Drum brake (Leading trailing) Link rod 160 mm (6.30 in) $160 \times 30 \text{ mm } (6.30 \times 1.18 \text{ in})$ 4 mm/2 mm (0.16 in/0.08 in) 68 mm (2.68 in)
Front forks: Travel Spring free length Spring preload length Spring rate: 0 ~ 100 mm (0 ~ 3.94 in) 100 ~ 140 mm (3.94 ~ 5.51 in) Fork oil capacity (each side) Oil type	140 mm (5.51 in) 502 mm (19.76 in) 472 mm (18.58 in) 0.4 kg/mm (22.4 lb/in) 0.575 kg/mm (32.2 lb/in) 142 cc (4.80 oz) Yamaha Fork Oil 20 Wt or equivalent
Rear shock absorbers: Spring free length Spring preload length Spring rate: 0 ~ 55 mm (0 ~ 2.17 in) 55 ~ 80 mm (2.17 ~ 3.15 in) Travel	216 mm (8.50 in) 204 mm (8.03 in) 1.7 kg/mm (95.2 lb/in) 2.10 kg/mm (117.6 lb/in) 100 mm (3.94 in)

4. Electrical

Ignition timing retarded: Ignition timing advance:	10° at 1,200 r/min <p>2,700 r/min</p> <p>3,400 r/min</p> <p>(× 1,000 r/min)</p>
---	--

LUBRICATION CHART



2. Carburetion

Manufacturer	MIKUNI BS34	Fuel level	$3 \pm 1 \text{ mm}$ ($0.12 \pm 0.004 \text{ in}$)
Model I.D. No.	3F9-00	Pilot screw	Preset
Main jet	#135	Air jet, Main	#45
Needle jet	Y-2	Air jet, Pilot	#155
Pilot jet	#42.5	Float valve seat	$\phi 2.0$
Starter jet	#35	Engine idle speed	1,200 r/min
Jet needle	5GZ9		




*: Total weight of accessories, etc. excepting motorcycle

** : XS400SH only



***: XS400SH only

3. Chassis

Wheels and tires:		
Rim run-out: vertical	2.0 mm (0.079 in)	
horizontal	2.0 mm (0.079 in)	
Tire pressure (cold):	Front	Rear
Up to 90 kg (198 lb) load*	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) ~ 159 kg (351 lb) load*	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

Piston rings: Design	Top	2nd	Oil
			
End gap (installed): standard	0.2 ~ 0.4 mm (0.0078 ~ 0.016 in)	0.2 ~ 0.4 mm (0.0078 ~ 0.016 in)	0.2 ~ 0.9 mm (0.0078 ~ 0.035 in)
limit	1.0 mm (0.0394 in)	1.0 mm (0.0394 in)	1.5 mm (0.0591 in)
Side clearance: standard	0.04 ~ 0.08 mm (0.0016 ~ 0.0031 in)	0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)	—
limit	0.15 mm (0.0059 in)	0.15 mm (0.0059 in)	—
Crankshaft: Crank journal/bearing oil clearance Main journal run-out (maximum)	0.020 ~ 0.044 mm (0.0008 ~ 0.0017 in) 0.030 mm (0.0012 in)		
Connection rods: Rod bearing oil clearance	0.021 ~ 0.045 mm (0.0008 ~ 0.0018 in)		
Oil pump: Housing-to-outer rotor clearance Outer rotor-to-inner rotor clearance	0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in)		
Clutch: Friction plate thickness: standard minimum Clutch plate: thickness warp limit Clutch spring length: standard minimum Spring rate Clutch lever free play (at lever pivot point)	3.0 mm (0.12 in) 2.8 mm (0.11 in) 1.6 mm (0.06 in) 0.05 mm (0.0020 in) 34.6 mm (1.362 in) 33.6 mm (1.323 in) 2.6 kg/mm (146 lb/in) 2 ~ 3 mm (0.08 ~ 0.12 in)		
Transmission shaft run-out (maximum)	0.08 mm (0.0031 in)		
Oil pump: Type Housing inside diameter Housing depth Rotor diameter Rotor thickness Rotor and housing clearance Side clearance Tip clearance Bypass valve opening pressure Oil filter type	Trochoid pump 40.66 ~ 40.71 mm (1.6008 ~ 1.6028 in) 12.03 ~ 12.07 mm (0.4736 ~ 0.4752 in) 40.53 ~ 40.56 mm (1.597 ~ 1.5968 in) 11.98 ~ 12.00 mm (0.4717 ~ 0.4724 in) 0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 1.0 kg/cm ² (14.2 lb/in ²) Paper type		

Valve:



INTAKE

Clearance (Cold engine)	0.10 mm (0.0039 in)
"A" head diameter	35.5 ± 0.1 mm (1.398 ± 0.0039 in)
"B" face width	2.3 mm (0.091 in)
"C" seat width	1.0 ± 0.1 mm (0.039 ± 0.0039 in)
"D" margin thickness (minimum)	1.0 ± 0.2 mm (0.039 ± 0.0079 in)
Stem diameter (O.D.)	7 ^{-0.010} / _{-0.025} mm (0.276 ^{-0.0004} / _{-0.0010} in)
Guide diameter (I.D.)	7 ^{+0.012} / ₀ mm (0.276 ^{+0.0005} / ₀ in)
Stem-to-guide clearance	0.010 - 0.037 mm (0.0004 - 0.0015 in)

EXHAUST

Clearance (Cold engine)	0.18 mm (0.0071 in)
"A" head diameter	30.0 ± 0.1 mm (1.18 ± 0.004 in)
"B" face width	2.3 mm (0.91 in)
"C" seat width	1 ± 0.1 mm (0.039 ± 0.004 in)
"D" margin thickness (minimum)	1 ± 0.2 mm (0.039 ± 0.008 in)
Stem diameter (O.D.)	7 ^{-0.030} / _{-0.045} mm (0.276 ^{-0.0011} / _{-0.0018} in)
Guide diameter (I.D.)	7 ^{+0.012} / ₀ mm (0.276 ^{+0.0005} / ₀ in)
Stem-to-guide clearance	0.030 - 0.057 mm (0.0012 - 0.0022 in)

Cylinder and piston:

Cylinder material

Cylinder liner

Bore size: standard

wear limit

Cylinder taper limit

Cylinder out-of-round limit

Piston clearance: standard

maximum

Piston weight (include rings, pin and clips)

Aluminum alloy

Pressed in; special cast iron

69.00 mm (2.717 in)

70.10 mm (2.760 in)

0.05 mm (0.0020 in)


0.01 mm (0.0004 in)

0.030 - 0.050 mm (0.0012 - 0.0020 in)

0.1 mm (0.0039 in)

186.1 g (6.56 oz)

Camshafts:



Camshaft bearing surface diameter

Camshaft-to-cap clearance:

Standard

Maximum

Camshaft run-out limit

Valve timing:

Intake: Open

Close

Duration

Exhaust: Open

Close

Duration

Valve overlap


Rocker arm and rocker shaft:

Rocker arm bearing dia. (I.D.)

Rocker arm shaft dia. (O.D.)

Clearance

Valve spring:



Direction of windings
(Top to bottom)

Valve stem run-out maximum

Valve seat width standard/maximum

Dimensions		Standard size	Wear limit
Intake	A	39.53 ± 0.05 mm (1.556 ± 0.002 in)	39.38 mm (1.550 in)
	B	32.27 ± 0.05 mm (1.270 ± 0.002 in)	32.12 mm (1.265 in)
	C	7.53 mm (0.296 in)	—
Exhaust	A	39.57 ± 0.05 mm (1.558 ± 0.002 in)	39.42 mm (1.552 in)
	B	32.12 ± 0.05 mm (1.265 ± 0.002 in)	31.97 mm (1.259 in)
	C	7.57 mm (0.298 in)	—

22.967 ~ 22.980 mm (0.9042 ~ 0.9047 in)

0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in)

0.160 mm (0.006 in)

0.1 mm (0.004 in)

BTDC 30°

ABDC 70°

280°

BBDC 70°

ATDC 30°

280°

60°

13.000 ~ 13.018 mm (0.5118 ~ 0.5125 in)

12.985 ~ 12.991 mm (0.5112 ~ 0.5115 in)

0.009 ~ 0.033 mm (0.00035 ~ 0.00130 in)

	Inner Intake/Exhaust	Outer Intake/Exhaust
Free length	39.3 mm (1.547 in)	42.8 mm (1.685 in)
Spring rate	$K_1 = 1.93 \text{ kg/mm}$ (108 lb/in) $K_2 = 2.47 \text{ kg/mm}$ (138 lb/in)	$K_1 = 4.19 \text{ kg/mm}$ (235 lb/in) $K_2 = 5.49 \text{ kg/mm}$ (307 lb/in)
Installed length (valve closed)	33.0 mm (1.299 in)	37.0 mm (1.457 in)
Installed pressure (valve closed)	12.1 ± 1.2 kg (26.7 ± 2.6 lb)	24.4 ± 1.7 kg (53.8 ± 3.7 lb)
Compressed length (valve open)	25.0 mm (0.984 in)	29.0 mm (1.142 in)
Wire diameter	3.0 mm (0.118 in)	4.4 mm (0.173 in)
Number of windings	7.75	6.25
Winding O.D.	22.4 mm (0.882 in)	32.0 mm (1.260 in)

0.03 mm (0.0012 in)

1.1 mm (0.043 in)/2.0 mm (0.080 in)

FOREWORD

This Service Manual has been written to acquaint the mechanic with the disassembly, reassembly, maintenance, and troubleshooting procedures required to provide optimum performance and longevity of the unit.

The information enclosed should be closely studied to avoid unnecessary repairs and to provide the owner with a sound, safe, dependable machine. Other information is produced by the U.S. distributor, YAMAHA INTERNATIONAL CORPORATION, and is necessary to provide total technical coverage regarding the product.

NOTE:

The Research and Engineering Departments of Yamaha are continually striving to further perfect all models. Improvements and modifications are therefore inevitable.

In light of this fact, all specifications within this manual are subject to change without notice. Information regarding significant changes is forwarded to all Authorized Yamaha Dealers as soon as available.

NOTICE

This manual has been written by Yamaha Motor Company for use by Authorized Yamaha Dealers and their qualified mechanics. In light of this purpose it has been assumed that certain basic mechanical precepts and procedures inherent to our product are already known and understood by the reader.

Without such basic knowledge, repairs or service to this model may render the machine unsafe and for this reason we must advise that all repairs and/or service be performed by an Authorized Yamaha Dealer who is in possession of the requisite basic product knowledge.

The Research, Engineering, and Service Departments of Yamaha are continually striving to further improve all models manufactured by the company. Modifications are therefore inevitable and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha Dealers and will, where applicable, appear in future editions of this manual.

YAMAHA MOTOR CO., LTD.
INTERNATIONAL DIVISION

INDEX

XS360C

GENERAL INFORMATION

1

**PERIODIC INSPECTIONS AND
ADJUSTMENTS**

2

ENGINE OVERHAULING

3

CARBURETION

4

CHASSIS

5

ELECTRICAL

6

APPENDICES

7

XS360-2D SUPPLEMENT

8

XS400D SUPPLEMENT

9

XS400E SUPPLEMENT

10

XS400-2E SUPPLEMENT

11

XS400F/2F SUPPLEMENT

12

XS400G/400SG SUPPLEMENT

13

XS360C

CHAPTER I. GENERAL INFORMATION

1-1. MACHINE IDENTIFICATION	5
1-2. SPECIAL TOOLS	6

CHAPTER 1. GENERAL INFORMATION


1-1. MACHINE IDENTIFICATION

The frame serial number is located on the right-hand side of the headstock assembly. The first three digits identify the model. This is followed by a dash. The remaining digits identify the production number of the unit.


The engine serial number is located on a raised boss on the upper rear, right-hand side of the engine. Engine identification follows the same code as frame identification.

Starting Serial Number

XS360C	1L9-000101
--------	------------




Frame serial number




Engine serial number


1-2. SPECIAL TOOLS




16



17



18



19

No.	Description	Tool No.
1.	Armature puller bolt	90890-01111
2.	Valve seat cutter set	90890-01248
3.	Valve guide remover	90890-01225
4.	Valve guide installer	90890-01226
5.	Compression gauge	90890-03081
6.	Point checker	90890-03064
7.	Steering nut wrench	90890-01051
8.	Valve spring compressor	90890-01095
9.	Hand reamer	90890-01211
10.	Cylinder cup installer	90890-01240
11.	Drive chain cutter	90890-01081
12.	Fork spring guide wrench	90890-01212
13.	Shock puller bolt	90890-01083
14.	Shock puller weight	90890-01084
15.	Dial gauge	90890-01173
16.	Electro tester	90890-03021
17.	Pocket tester	90890-03043
18.	Vacuum gauge	90890-03048
19.	Clutch adjusting tool	90890-01127

CHAPTER 2.

PERIODIC INSPECTIONS AND ADJUSTMENTS

2-1. MAINTENANCE AND LUBRICATION CHART	9
2-2. ENGINE	11
A. Carburetor	11
B. Air Filter	12
C. Float Level	13
D. Engine Oil	13
E. Engine Oil and Filter Replacement	14
F. Clutch Adjustment	14
G. Valve Clearance Adjustment	15
H. Cam Chain Adjustment	15
2-3. CHASSIS	15
A. Fuel Petcock	15
B. Front Brake and Wheel	16
C. Rear Brake and Wheel	16
D. Drive Chain Tension Check	17
E. Drive Chain Tension Adjustment	17
F. Drive Chain Lubrication	17
G. Front Fork Oil Change	18
H. Suspension, Steering and Swing Arm	18
2-4. ELECTRICAL	19
A. Ignition Timing	19
B. Spark Plug	20
C. Battery	21
D. Headlight	21

CHAPTER. 2

PERIODIC INSPECTION AND ADJUSTMENTS

2-1. MAINTENANCE AND LUBRICATION CHART

The following charts should be considered strictly as a guide to general maintenance and lubrication intervals. You must take into consideration that weather, terrain, geographical location and a variety of individual uses all tend to demand that each owner after this time schedule to match his environment. For example, if the motorcycle is continually operated in an area of high humidity, then all parts must be lubricated much more frequently than shown on the chart to avoid damage caused by water to metal parts.

The number in parentheses (1) after an item refers to the recommended lubricant. See list at the end of this chart.

Unit: mile (km)

Unit: mile (km)

Page	Item	Period							As required
		Initial				Thereafter every			
		250 (400)	500 (800)	1,000 (1,600)	2,000 (3,200)	1,000 (1,600)	2,000 (3,200)	4,000 (6,400)	
ENGINE									
14	Change engine oil	x(1)		x			x		
14	Change oil filter	x						x	
30, 55	Clean oil strainer	x						x	
15	Adjust valves	x			x				x
	Check compression	x						x	x
25, 50	Check cylinder head bolt torque	x						x	
14	Adjust clutch	x		x					x
11	Check and adjust carburetors	x		x					x
58	Clean carburetors								x
	Inspect exhaust system	x						x	x
25, 49	Check rotor nut torque	x							x
	Check oil pressure	x						x	
12	Clean air filter	x			x		x		
12	Replace air filter								x
CHASSIS									
16	Adjust brake (front and rear)	x			x		x		x
73	Check front fork	x			x				x
18	Change fork oil	x(4)						10,000 (16,000)	
76	Check rear shock absorber	x		x			x		
18, 75	Check swing arm	x		x			x		
76	Check and adjust controls and cables	x		x			x		
76	Lubricate cables		x(2)		x		x		
73	Check steering head	x			x		x		
75	Lubricate swing arm pivot				x(3)		x		
	Check rim runout	x			x		x		
69	Check spoke tension	x			x		x		

Unit: mile (km)

Page	Item	Period							As required
		Initial				Thereafter every			
		250 (400)	500 (800)	1,000 (1,600)	2,000 (3,200)	1,000 (1,600)	2,000 (3,200)	4,000 (6,400)	
62	Check wheel bearing				x		x		x
17	Check drive chain tension and alignment		x		x		x		x
17	Clean and lubricate drive chain		x (2)			x			x
70	Replace drive chain								x
15	Clean petcock			x			x		x
ELECTRICAL									
19	Check breaker points		x				x		
19	Check and adjust ignition timing		x				x		x
	Check wiring connections							x	x
20, 79	Check spark plug	x					x		
20, 79	Replace spark plug				x		x		x

NOTES:

NO. 1 At ambient temperature above 5°C (41°F), use YAMALUBE 4-cycle oil, or SAE 20W-40 type "SE" motor oil.

At ambient temperature below 15°C (59°F), use SAE 10W-30 type "SE" motor oil. Do not use "additives" in oil.

No. 2 Use SAE 10W-30 type "SE" motor oil. (If desired, specialty lubricants of quality manufacture such as YAMAHA CHAIN AND CABLE LUBE, may be used.

No. 3 Use lithium soap base grease.

No. 4 Use YAMAHA FORK OIL or another quality fork oil.

2-2. ENGINE

A. Carburetor

1. Idle mixture

The idle mixture is set at the factory by the use of special equipment. No attempt should be made to change this adjustment by the dealer.

2. Idle speed adjustment

NOTE:

Carburetors must be synchronized before setting final idle speed. The idle speed adjustment is made by turning only one throttle stop screw.

- The engine must be warmed up before setting idle speed.
- Set engine idle speed by turning the throttle stop screw in (to increase engine speed) or out (to decrease speed).


NOTE:

To reduce exhaust emissions, the air screw should be tightened or loosened $1/8$ turn from the specified position in the following table, and the maximum number of turns is controlled by the idle limiter.

Pilot screw:

Back out $1\frac{1}{2} \pm \frac{1}{2}$ turns

Idle speed: $1,200 \pm 50$ rpm



1. Throttle stop screw


2. Throttle cable adjustment

NOTE:

Idle speed should be set before making this adjustment.

The throttle grip should have a play of 3 – 5 mm (0.12 ~ 0.20 in) in the turning direction at the grip flange. If the play is not this range, take the following steps for adjustment:

- Loosen the adjuster lock nut on the throttle cable 1, and turn the adjuster in or out so the play is correct. After the adjustment, tighten the locknut.



1. Adjustor lock nut 2. Adjustor



3. Synchronizing carburetors

Both cylinders will not operate evenly unless the carburetion system for each side is identical. If one carburetor slide is higher than the other slide, overall poor engine performance will result.

- Install the vacuum gauge. To install, remove both right and left vacuum synchronizing tubes and set the vacuum gauge.




1. Pilot screw



NOTE: _____

Avoid keeping the rubber damper too tight by screwing in the serration.

- b. Remove fuel tank and make an adjustment by loosening or tightening the synchronizing screw of carburetors are almost on the same level.




Vacuum reading:
Within 5 cmHg/1,200 rpm

NOTE: _____

- a. If the vacuum gauge needle deflects excessively, make the damper tight by tightening the serration. If the damper is too effective, the gauge readings will be incorrect, showing a rather low value. Both dampers should be so adjusted that both needles show the same degrees of deflection.
- b. When both vacuum gauge needles deflect evenly and the readings are the same, they are considered to be synchronized.
- c. If the gauge readings are more than 5 cmHg, check the ignition timing, tappet clearance, compression pressure and spark plugs.


B. Air filter

1. Remove side cover and element case holder.



1. Element case cover

2. Remove bolts and separate the element case.



3. The air cleaner should be cleaned by blowing with compressed air, and/or by lightly tapping so that the dust may be removed.

NOTE: _____

The element is foam rubber and should be kept away from water and oil.


C. Float Level

1. Using a vernier caliper, measure the distance of float arm from the top of the float chamber gasket seat (gasket removed) to the float.

Float level :
 26.6 ± 2.5 mm
 $(1.047 \pm 0.098$ in)

NOTE: _____

The float should be just resting on, but not depressing, the spring loaded inlet needle.



1. Float level

2. To correct float level, bend the tang a slight amount as required.

NOTE: _____

Both the right and left of the float should measure identically. Correct as required by bending float tang.




D. Engine Oil

1. Oil level measurement.

- a. Place the machine on a level place and then on the center stand.
- b. Remove the oil filler cap, and check the oil level.

NOTE: _____

When checking, do not screw the oil level gauge into the crankcase. Insert the gauge gently. For accuracy, check with the machine held upright.



1. Level gauge

- c. If the oil level is between the maximum to minimum level lines marked on the oil level gauge, you may start the engine.

Oil Capacity

- a. Regular oil replacement:
2.0 lit (2.1 US qt)
- b. Oil and oil filter replacement:
2.3 lit (2.4 US qt)
- c. Engine overhauling:
2.6 lit (2.7 US qt)

Recommended Oil

- a. Yamalube 4-cycle oil or SAE 20W/40 type "SE" motor oil. (more than 5°C, 41°F)

- b. SAE 10W/30 type "SE" motor oil.
(below 15°C, 59°F)


E. Engine Oil and Oil Filter Replacement

1. Oil filter replacement.


NOTE:

When replacing the engine oil after the break-in period, clean the oil strainer at the bottom of the engine.


- Start the engine. After a few minutes of warm-up stop the engine.
- Remove the oil filler cap and drain plug and drain the engine oil.
- Remove the oil strainer at the bottom of the engine, and clean.



1. Drain plug 2. Oil filter cap



- Remove the oil filter cap, and replace the filter element.




- Install the drain bolt, oil filter, and oil filter cap.
- Add 2.0 liters (2.1 US.qt) of engine oil. Install the oil filler cap and tighten. Use 20W/40 type "SE" oil.
- Start the engine and allow a few minutes of warm up. While warming up, check for oil leakage. If oil leaks, stop the engine immediately, and check for the cause.
- After warm up, stop the engine and check the oil level. (Refer to D-1 "Engine Oil".)

F. Clutch Adjustment

This model has two clutch cable length adjustors and a clutch mechanism adjustor. Cable length adjustors are used to take up slack from cable stretch and to provide sufficient free play for proper clutch operation under various operating conditions. The clutch mechanism adjustor is used to provide the correct amount of clutch "throw" for proper disengagement. Normally, once the mechanism is properly adjusted, the only adjustment required is maintenance of free play at the clutch handle lever.


1. Mechanism Adjustment

- Remove the cover cap on left crankcase cover and loosen the adjusting screw lock nut.
- Using a Phillips-head screwdriver, slowly screw in the adjusting screw until resistance is felt. That is, the play of the push rod has been removed. From this position, back out the adjusting screw about $\frac{1}{4}$ turn, and tighten the lock nut.



2. Freeplay Adjustment


Loosen either the handle lever adjuster lock nut or the cable in-line length adjuster lock nut. Next, turn the length adjuster either in or out until proper lever free play is achieved.



1. Adjuster locknut 2. Adjustor

Valve clearance (cold):

Intake	0.08 – 0.12 mm (0.003 – 0.005 in)
exhaust	0.16 – 0.20 mm (0.006 – 0.008 in)



- Loosen the valve adjuster lock nut. Turn the adjuster in or out to obtain the correct clearance. Hold the adjuster to prevent it from moving and thoroughly tighten the lock nut.

Recheck the clearance after tightening.

NOTE:

Valve clearance check and adjustment should be done when the engine is cold.

G. Valve Clearance adjustment

- Turn the fuel petcock to "RES" position and disconnect fuel pipe and fuel cock vacuum pipe.
- Remove fuel tank
- Remove intake and exhaust tappet covers and left generator cover.
- At first adjust LEFT side ignition timing. Align the "LT" mark on the rotor with the timing mark on the crankcase. This places the piston at top dead center. The valve clearance should be checked and adjusted at T.D.C. on the compression stroke. (When the valve adjusters have clearance.)
- Use a feeler gauge to determine the clearance.

H. Cam Chain Adjustment

The cam chain tension is automatically adjusted. Therefore, cam chain adjustment is not required.

2-3 CHASSIS

A. Fuel Petcock

- First, set the petcock lever to the "RES" position and remove the fuel pipe.
- Loosen the petcock securing nut and remove the petcock assembly from fuel tank.
- Clean the attached filter with solvent. Examine the filter and replace if damaged.
- Inspect the gasket, replace if damaged and install the outlet fitting.

B. Front Brake


1. Brake adjustment

The brake can be adjusted by simply adjusting the distance that the brake lever and pedal can travel. (The piston in the caliper moves forward as the brake pad wears out, automatically adjusting the clearance between the brake pad and the brake disc.)

a. Front brake

1) Loosen the adjusting screw locknut.


2) By turning the adjusting screw in or out, adjust the play of the brake lever and then tighten the locknut.




1. Lock nut 2. Adjustor

2. Brake pad check

The pads are provided with a wear indicator for checking the condition of the brake without the need for disassembly.




To check, open the wear indicator cap and if any pad is worn to the red line, replace pads.



enter the brake system, possibly causing the brake to become ineffective. Check the brake fluid level and replenish when necessary and observe these precautions.

a. Use only the designated quality brake fluid; otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.



1. Lower level

Recommended brake fluids:
DOT #3 with 240°C (464°F)
boiling point

b. Refill with the same type and brand of brake fluid; mixing fluids may result in a harmful chemical reaction and lead to poor performance.

c. Be careful that water or other contamination does not enter the master cylinder when refilling. Water will significantly lower the boiling point and may result in vapor lock.


C. Rear Brake

1. Adjust rear brake pedal play to suit, pro-

viding a minimum of 20 – 30 mm (0.8 – 1.2 in) freeplay. Turn the adjustor on the rear brake rod in or out until brake pedal free play is suitable.

NOTE:

Rear brake pedal adjustment must be checked anytime chain is adjusted or rear wheel is removed and then reinstalled.



D. Drive Chain Tension Check

Inspect the drive chain with both tires touching the ground and with rider on the seat. Check the tension at the position shown in the illustration. The normal vertical deflection is approximately 15 mm (0.6 in). If the deflection exceeds 20 mm (0.8 in), adjust the chain tension



E. Drive Chain Tension Adjustment

1. Loosen the rear brake adjustor.
2. Loosen the rear wheel axle nut.
3. Loosen the adjustor lock nuts on each side.

4. To tighten chain turn chain puller adjustor clockwise. To loosen chain turn adjustors counter-clockwise and push wheel forward. Turn each bolt exactly the same amount to maintain correct axle alignment.


There are marks on each side of rear arm and on each chain puller; use them to check for proper alignment.

Drive chain slack:

10 ~ 20 mm (0.4 ~ 0.8 in)

Rider on machine

Both wheels on ground



- | | |
|----------------------|----------------|
| 1. Rear axle nut | 4. Adjustor |
| 2. Cotter pin | 5. Align marks |
| 3. Adjustor lock nut | |

NOTE:

Before adjusting, rotate rear wheel through several revolutions and check tension several times to find the tightest point. Adjust chain tension with rear wheel in this "right chain" position.

4. After adjusting be sure to tighten the lock nuts and the rear wheel axle nut.
5. In the final step, adjust the play in the brake pedal.

F. Drive Chain Lubrication


1. First, remove dirt and mud from the chain with a brush or cloth and then spray the lubricant between both rows of side plates and on all center rollers.
2. To clean the entire chain, first remove

the chain from the motorcycle, dip it in solvent and clean with stiff brush. Then take the chain out of the solvent and dry it. Immediately, lubricate the chain to prevent the formation of rust.


Recommended lubricant:
YAMAHA CHAIN AND CABLE
LUBE, or SAE 10W/30 type
"SE" motor oil

G. Front Fork Oil Change.

1. Elevate front wheel by placing a suitable stand *under* the engine.
2. Remove snap rings and fork caps from inner fork tubes.



3. Remove drain screw from each outer tube with open container under each drain hole.




1. Drain screw
4. After most of oil has drained, slowly raise and lower outer tubes to pump out remaining oil.
5. Replace drain screw.

NOTE:
Check gasket, replace if damaged.


6. Measure correct amount of oil and pour each leg.

Recommended oil:
20 WT Fork Oil
Quantity per leg:
130 cc (4.4 oz)

NOTE: _____
Select the weight oil that suits local conditions and your preference (lighter for less damping; heavier for more damping).




7. After filling, slowly pump the outer tubes up and down to distribute the oil.
8. Inspect O-ring on fork caps and replace if damaged.



H. Suspension, steering and swing arm

1. Steering head adjustment
The steering assembly should be checked periodically for looseness.
Do this as follows:
 - a. Block machine up so that front wheel is off the ground.
 - b. Grasp bottom of forks and gently rock

fork assembly backward and forward, checking for looseness in the steering assembly bearings.




- c. If steering head needs adjustment, loosen steering fitting bolt.



1. Fitting bolt

- d. Using steering nut wrench, adjust steering head fitting nut until steering head is tight without binding when forks are turned.



NOTE:

Excessive tightening of this nut will cause rapid wear of ball bearings and races. Re-check for looseness and freedom of movement.

- e. Tighten steering fitting bolt and crown pinch bolt in that order.

NOTE:

After completing steering adjustment, make certain forks pivot from stop to stop without binding. If binding is noticed, repeat adjustment.

2. Suspension

- Check all suspension components for proper operation.
- Check all suspension components for proper tightness.
- Check rear shocks (right and left) for identical adjustment.

3. Swing arm

- Check for freedom of up and down movement.
- Check side to side freeplay.

Swing arm freeplay:

1 mm (0.04 in) at end of swing arm

- Check all securing bolts for proper tightness.
- Grease swing arm periodically.


2-4. ELECTRICAL

A. Ignition Timing


- Adjust point gap (at widest opening) by moving the contact breaker assembly.

Point gap:


0.3 – 0.4 mm
(0.012 - 0.016 in.)



2. Rotate the crankshaft counterclockwise, align "LF" mark on the rotor and match mark on the case cover.



3. Switch on point checker and adjust.
4. Connect point checker terminals to point assembly.
Positive (Red) lead to orange terminal for left-hand cylinder.
Negative (Black) lead to a good ground.



5. Rotate breaker plate assembly (L) so that the point checker needle should swing from "CLOSED" to "OPEN" position, indicating the contact breaker has just begun to open.

NOTE:

Adjust ignition points by slightly loosening Philips head screws and carefully rotating contact breaker plate assembly with a slotted screwdriver. Make small adjustment and retighten Philips head screw before rechecking timing.

6. Right hand cylinder ignition timing
Right hand ignition timing is set in the same manner as left hand cylinder.
For R.H. side use gray wire terminal for point checker red (positive) wire.

B. Spark Plug

The spark plug indicates how the engine is operating. If the engine is operating correctly, and the machine is being ridden properly, the tip of the white insulator around the positive electrode of the spark plug will be a medium tan color. If the insulator is very dark brown or black color, then a plug with a hotter heat range might be required. This situation is quite common during the engine break-in period.

If the insulator tip shows a very light tan or white color or is actually pure white and glazed or if electrodes show signs of melting, then a spark plug with a colder heat range is required. Remember, the insulator area surrounding the positive electrode of the spark plug must be a medium tan color. If it is not, check carburetion, timing and ignition adjustments.

The spark plug must be removed and checked. Check electrode wear, insulator color, and electrode gap.

Spark plug gap:

0.7 ~ 0.8 mm (0.028 ~ 0.031 in)

Engine heat and combustion chamber deposits will cause any spark plug to slowly break down and erode. If the electrodes


finally become too worn, or if for any reason you believe the spark plug is not functioning correctly, replace it. When installing the plug, always clean the gasket surface, use a new gasket, wipe off any grime that might be present on the surface of the spark plug, and torque the spark plug properly.

Standard spark plug	Tightening torque
NGK BP-6ES or Champion N-7Y	1.8 - 2.2 m·kg (13 ~ 16 ft·lb)

C. Battery

A poorly maintained battery will deteriorate quickly. The battery fluid should be checked at least once a month.

1. The level should be between the upper and lower level marks. Use only distilled water for refilling. Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.
2. Always make sure the connections are correct when installing the battery. The red lead is for the + terminal and the black lead is for the - terminal. Make sure the breather pipe is properly connected and is not damaged or obstructed.



NOTE:

After filling new battery with diluted to sulfuric acid (electrolyte), it is advisable to charge the battery much as possible before using to insure maximum performance. This initial charge will prolong the life of the battery.

Charging current:	1.2A
Charging time:	10hrs.

D. Headlight

1. Headlight beam adjustment

When necessary, adjust the headlight beam as follows.

- a. Adjust horizontally by tightening or loosening the adjust screw.



To adjust to the right:
tighten the screw

To adjust to the left:
loosen the screw

b. Adjust vertically as follows:

- 1) Remove the anchor screw holding the headlight rim and remove the rim by prying lightly with a screwdriver at the gap provided at the bottom of the headlight.

NOTE:

Take care not to damage the headlight.

- 2) Slightly loosen the two headlight mounting nuts and refit the rim to the headlight body.




NOTE: _____

Do not tighten the anchor screw yet.

3) Next, adjust vertically by moving the headlight body. When adjustment is complete, hold the body in place, remove the rim and tighten the two mounting nuts. Then refit the rim to the headlight body.

2. Replacing the headlight bulb

- a. Remove bolts and pull the defective unit out of the shell.



- b. Slip a new unit into position and install bolts.

- c. Adjust headlight beam.

NOTE: _____

Take care not to damage the headlight. It is very fragile.

CHAPTER 3. ENGINE OVERHAUL

3-1. REMOVAL	25
A. Preparation for Removal	25
B. Removal	27
3-2. DISASSEMBLY	27
A. Cylinder Head Cover	27
B. Cylinder Head	27
C. Cylinder	28
D. Piston Pin and Piston	28
E. Kick Crank	28
F. Crankcase Cover (R)	28
G. Clutch Assembly and Drive Gear	29
H. Crankcase Cover (L)	29
I. Oil Strainer Assembly	30
J. Crankcase	30
3-3. INSPECTION AND REPAIRING	31
A. Cylinder Head Cover	31
B. Cylinder Head	32
C. Valve, Valve Springs, Valve Guides and Valve Seats	32
D. Camshaft and Sprocket	36
E. Cylinder	37
F. Piston and Piston Rings	38
G. Piston Pin	39
H. Crankshaft	39
I. Oil Pump	42
J. Primary Drive	44
K. Clutch	44
L. Transmission	45
M. Kick Starter	46
N. Bearings and Oil Seals	47
O. Neutral Switch	47
P. Crankcase	47
3-4. ENGINE ASSEMBLING AND ADJUSTMENT	47
A. Transmission and Shifter Installation	47
B. Crankshaft Installation	48
C. Crankcase	49
D. Crankcase Cover (L)	49
E. Piston	50
F. Cylinder	50
G. Cylinder Head	50
H. Camshaft and Sprocket	51
I. Cylinder Head Cover	52

J. Drive Sprocket	53
K. Contact Breaker	53
L. Kick Starter Assembly	54
M. Clutch	55
N. Oil Pump	55
O. Crankcase Cover	55
P. Oil Strainer	55
3-5. MOUNTING	55

CHAPTER 3. ENGINE OVERHAUL

ENGINE SECTION TIGHTENING TORQUE CHART

Unit: m·kg (ft·lb)

Tightening point	(mm) Stud dia.	Q'ty	Torque	
Cylinder head	10	8	3.0 – 3.5 (21.7 – 25.32)	Apply engine oil
	6	2	0.8 – 1.2 (6.0 – 8.5)	
Tappet cover	32	4	1.0 – 1.4 (7.0 – 10.0)	
Rocker plug	16	2	1.2 – 2.0 (8.5 – 14.5)	
Spark plug	14	2	1.8 – 2.2 (13.0 – 16.0)	
Con-rod cap	8	4	3.3 – 3.8 (24.0 – 27.5)	Apply molybdenum grease
Valve adj. screw	6	4	1.2 – 1.5 (8.5 – 11.0)	
Cam sprocket bolt	7	2	1.8 – 2.2 (13.0 – 16.0)	
Oil filter cover	20	1	1.3 – 1.7 (9.5 – 12.0)	
Exhaust pipe ring nut	8	4	2.0 – 2.4 (14.5 – 17.0)	
Crankcase	8	7	2.0 – 2.4 (14.5 – 17.0)	
	6	14	0.8 – 1.2 (6.0 – 8.5)	
Oil drain bolt	14	1	3.5 – 4.0 (25.0 – 29.0)	
Spring screw	6	4	0.8 – 1.2 (6.0 – 8.5)	
Primary drive gear	10	1	4.0 – 4.5 (29.0 – 33.0)	
Drive sprocket	18	1	5.0 – 8.0 (36.0 – 58.0)	
Kick crank	8	1	1.5 – 2.5 (11.0 – 18.0)	
Cam stopper screw	8	1	1.2 – 2.0 (9.0 – 14.5)	
Governor	6	1	0.8 – 1.2 (6.0 – 8.5)	
ACG rotor bolt	10	1	3.0 – 3.5 (21.0 – 25.0)	
Oil pressure switch	1/8"	1	1.6 – 1.9 (7.0 – 11.0)	Apply NEJI Lock super # 20
Neutral switch	5	3	0.25 – 0.45 (2.0 – 3.0)	

3-1. REMOVAL

NOTE:

The engine components above the cylinder can be serviced without demounting the engine.

A. Preparation for Removal


1. All dirt, mud, dust and foreign material should be thoroughly removed from the exterior of the engine before removal and disassembly. This will prevent any harmful foreign material from entering the interior of engine assembly.
2. Before engine removal and disassembly, be sure you have proper tools and clean-

ing equipment so you can perform a clean and efficient job.


3. During disassembly of the engine, clean and place all parts in trays in order of disassembly. This will ease and speed assembly time and help insure correct re-installation of engine parts.
4. Start the engine and warm it for a few minutes; turn off and drain engine oil.
5. Remove fuel tank.
Disconnect vacuum pipe and fuel pipe.
6. Remove air filter elements and air filter joints.



7. Remove carburetors and disconnect throttle cable.




h. Ignition primary lead and generator lead (couplers).



8. Remove the following parts.


- a. Mufflers.
- b. Footrests.
- c. Brake pedal.
- d. Spark plug caps.
- e. Gear change lever.
- f. Tachometer cable.



i. Starter motor lead.



g. Crankcase cover, clutch cable and oil filter cover.



j. Ground lead.

k. Drive sprocket.


- 1) Bend down lock tab.
- 2) Put transmission in.
- 3) Apply rear brake.
- 4) Loosen sprocket securing nut.

l. If necessary, disconnect the chain as follows:

- 1) Bring master link clip slightly forward on the sprocket wheel and remove the clip.
- 2) Set the chain cutter (special tool) on


the chain, and remove the chain joint plate.

- 3) Separate the chain.



B. Removal

1. Remove engine mounting bolts.




3-2 Disassembly

A. Cylinder Head Cover

1. Remove spark plugs.
2. Remove the cylinder head cover retaining bolts.

NOTE:

Loosen the bolts in the order indicated in the following.



3. Remove the cover.


NOTE:

Tap around the edges with a rubber hammer or give the crankshaft approximately one turn to free the cover if necessary.

Never use a metal head hammer.

B. Cylinder Head


1. Remove the cam chain tensioner assembly. Note the location of each part.





2. Remove the cam sprocket securing bolt and remove the camshaft and sprocket.

NOTE:


- a. When removing the cam sprocket, it is not necessary to separate the cam chain.
- b. Attach a wire to a chain link. Do this before removing the cam sprocket to prevent the chain from dropping into the crankcase. After removing the cam sprocket, anchor retaining wire to prevent the chain from dropping down.



3. Remove the chain guides.



4. Remove the cylinder head holding nuts and bolts and then remove the cylinder head.



- C. Cylinder**
Remove the cylinder.



D. Piston Pin and Piston

1. Remove piston pin clip (1) from piston.
NOTE: _____

Before removing the piston pin clip, cover the crankcase with a clean rag so you will not accidentally drop the clip into the crankcase.



2. Push piston pin from opposite side, then pull out.

NOTE: _____
Before removing piston pin, deburr clip groove and pin hole area.


E. Kick Crank

Remove kick crank securing bolt and kick crank.

NOTE: _____
The bolt must be completely removed from the kick crank.

F. Crankcase Cover (Right)

Remove crankcase cover holding bolts and the cover.





TORQUE


0.8 ~ 1.2 kg-m

G. Clutch Assembly and Drive Gear


1. Remove spring screws, clutch springs, pressure plate, push rod and circlip.




2. Remove clutch housing and clutch boss.
3. Remove oil pump assembly.



7. Remove cam stopper plate and change lever guide.




4. Remove the kick axle assembly by pulling toward you.




5. Remove circlip from left end of change shaft and pull shaft and shift lever 1 out from the right hand side.
6. Remove the change lever 2 and the change lever 3 as an assembly.

H. Crankcase Cover (L)


1. Remove generator lead wire holder.
2. Disconnect neutral switch lead and oil pressure switch lead.




3. Remove crankcase cover (L).
4. Remove rotor and key.



5. Remove starter motor cover, starter motor and breather cover.




6. Remove sprocket guide, chain guide and starter sprockets.





I. Oil Strainer Assembly

1. Remove oil strainer cover holding bolts.
2. Remove oil strainer.




J. Crankcase


1. Remove crankcase holding bolts. Loosen each bolt $\frac{1}{4}$ turn and proceed to the next. Then follow sequence again; this time completely remove all bolts.




2. Split crank case by lightly striking the front and rear parts of the upper crank case.
3. Remove crankshaft and transmission gears.
4. Remove shift fork bar circlip and shift fork bars.
(Push the guide bar grommets out.)



5. Remove shift cam stopper plate.




6. Remove baffle plate. (Pull the holding bar out.)



3-3. INSPECTION AND REPAIRING

A. Cylinder Head Cover


1. Remove two rocker shaft covers and grommets.



2. Insert a 8 mm screw into the rocker shaft, and withdraw the rocker shaft. It should slide out easily.

NOTE:

If does not slide out easily, use the special tool as shown.



3. Rocker arm and rocker shaft

- a. The rocker arm usually wears at two locations: (1) at the rocker shaft hole, (2) at the cam lobe contacting surface.
b. Measure the rocker shaft hole in the rocker arm.

Standard size:

$$13 \begin{smallmatrix} +0.018 \\ 0 \end{smallmatrix} \text{ mm} \\ (0.512 \begin{smallmatrix} +0.0007 \\ 0 \end{smallmatrix} \text{ in})$$

- c. The shaft has been hardened and should not wear excessively. If a groove has developed in this surface that can be felt, or if it shows a blue discoloration, then the shaft should be replaced and the lubrication system (pump and passages) checked.

Standard shaft diameter:

$$13 \begin{smallmatrix} -0.016 \\ -0.036 \end{smallmatrix} \text{ mm} \\ (0.512 \begin{smallmatrix} -0.00063 \\ -0.0014 \end{smallmatrix} \text{ in})$$



- d. Standard clearance between the rocker shaft and hole should be 0.016 – 0.054 mm (0.00063 – 0.00212 in). If measure-

ment shows more than 0.1 mm (0.0015 in) clearance, replace either or both parts as necessary.


B. Cylinder Head

1. Compress the valve spring and then remove both retainer locks.

Remove the compressor and lift off the retainer and springs.

NOTE:

The retainer locks might be partially stuck in the retainer. Use a rubber hammer to tap the edge of the retainer a few times to loosen the retainer locks.



1. Valve spring compressor

2. Pull the valve out. If the stem tip or retainer lock groove edges are slightly expanded, causing difficult removal, the surface might be damaged. First, use a fine file to remove any lip that exists on the stem and then remove the valve.

NOTE:

Be sure to remove the valve stem seal before removing the valve. Otherwise the seal could be damaged.

3. Decarbonization of the head and components:

Carbon deposits build up in the combustion chambers, on the valves, and in the exhaust ports. Thoroughly clean all parts with a blunt scraper, then wash in solvent and dry with compressed air. The parts can then be examined and measured for wear.

C. Valves, Valve Springs, Valve Guides and Valve Seats


1. Check the intake and exhaust valve stems for bending and grooved wear. Check the stem ends for wear. Measurements should be done in three positions, upper, middle, and lower.

Intake valve stem diameter:

$7 \begin{smallmatrix} -0.010 \\ -0.025 \end{smallmatrix} \text{ mm}$
(0.275 $\begin{smallmatrix} -0.0004 \\ -0.001 \end{smallmatrix}$ in)

Exhaust valve stem diameter:



$7 \begin{smallmatrix} -0.030 \\ -0.045 \end{smallmatrix} \text{ mm}$
(0.275 $\begin{smallmatrix} -0.0012 \\ -0.0018 \end{smallmatrix}$ in)



2. Checking the valve springs.
 - a. This engine uses two springs of different sizes to prevent valve float or surging. The chart below shows the basic valve characteristics.

	Outer (IN & EX)	Inner (IN & EX)
Free length	42.8 mm (1.685 in)	39.3 mm (1.547 in)
Installed length (Valve closed)	37.0 mm (1.457 in)	33.0 mm (1.299 in)
Installed pressure	24.4 ± 1.7 kg (53.8 ± 3.8 lb)	12.1 ± 1.2 kg (26.7 ± 2.6 lb)
Compressed length (Valve open)	29.8 mm (1.17 in)	25.8 mm (1.02 in)
Compressed pressure	63.9 ± 4.5 kg (141 ± 9.9 lb)	29.9 ± 2.2 kg (65.9 ± 4.9 lb)

b. Even though the spring is constructed of durable spring steel, it gradually loses some of its tension. This is evidenced one way by a gradual shortening of free length. Use a vernier caliper to measure spring free length. If the free length of any spring has decreased more than 2 mm (0.080 in) from its specification, replace it.



c. Another symptom of a fatigued spring is insufficient spring pressure when compressed. This can be checked using a valve spring compression rate gauge. Test each spring individually. Place it in the gauge and compress the spring first to the specified compressed length with the valve closed (all spring specifications can be found in previous section, Valve Spring) then to length with the valve open. Note the poundage indicated on the scale at each setting. Use this procedure on the outer springs, then the inner springs.

NOTE:

All valve springs must be installed with greater pitch upward as shown below.




3. Valve Leakage Check

After all work has been performed on the valves and valve seats and all head parts have been assembled, check for proper valve/valve seat sealing by pouring solvent into each of the intake ports, then the exhaust ports. There should be no leakage by the seat. If this fluid leaks, disassemble and continue to lap with fine lapping compound. Clean all parts thoroughly, reassemble and check again with solvent. Repeat this procedure as often as necessary to obtain a satisfactory seal.

4. Valve Stem Seal

This seal slips down over the valve stem to prevent excessive amounts of oil from passing down stem and into the combustion chamber. If this seal is cracked, split, or hardened, replace it.



1. Valve stem seal


5. Valve Guide

- a. If the valve guide inside diameter is beyond serviceable limits, replace with an oversize valve guide.

	Standard	Limit
Guide diameter (I.D.) (IN & EX)	$7^{+0.012}_0$ mm ($0.2756^{+0.00047}_0$ in)	7.03 mm (0.2767 in)

- b. Measuring the clearance between valve and valve guide.

- 1) Insert the valve into the valve guide in the cylinder head and measure the clearance in both the X and Y axes, using a small dial gauge.



1. Valve guide installer

- 2) If the measured clearance is greater than 0.08 mm (0.003 in) for the inlet valve or 0.1 mm (0.004 in) for the exhaust valve, both the valve and valve guide should be replaced. The replace-


ment valve guide should be one that is oversize.

Standard guide diameter (IN, EX):
12.50 $^{+0.052}_{+0.040}$ mm (0.492 $^{+0.0020}_{+0.0016}$ in)

Valve guide oversize:

Part No.	Size (O.D.)
1L9-11733-12 (IN)	12.50 $^{+0.078}_{+0.090}$ mm
1L9-11734-12 (EX)	(0.492 $^{+0.0031}_{+0.0035}$ in)

Identification method




There is a groove around the upper part of the valve guide.


- c. To ease guide removal and reinstallation, and to maintain the correct interference fit, heat the head to 100°C (212°F). Use an oven to avoid any possibility of head warpage due to uneven heating.
- d. Use the appropriate shouldered drive (special tool) to drive the old guide out and the new guide in.

NOTE:

When a valve guide is replaced, the O-ring should also be replaced.



- e. After installing the valve guide, use 7mm reamer (special tool) to obtain the proper valve clearance.
 - f. After fitting the valve guide into the cylinder head, be sure to grind the valve seat, and perform valve lapping. The valve must be replaced by a new one.
6. Grinding the Valve Seat
- a. The valve seat is subject to severe wear similar to the valve face. Whenever the valve face is resurfaced, the valve seat should also be resurfaced at a 45° angle. In addition, if a new valve guide has been installed (without any valve repair), the valve seat should be checked to guarantee complete sealing between the valve face and seat.



CAUTION:

If the valve seat is obviously pitted or worn, it should be cleaned with a valve seat cutter. Use the 45° cutter, and when twisting the cutter, keep an even downward pressure to prevent chatter marks.

If cutting section "A" of the intake valve seat, use "FLAT" cutter (radius cutter). If cutting section "A" of the exhaust valve seat, use "FLAT" cutter (also radius).


If cutting section "B", use the 30° cutter. If cutting section "C", use the 45° cutter.

- b. Measure valve seat width. Apply mechanic's bluing dye (such as Dykem) to the

valve face, apply a very small amount of fine grinding compound around the surface of the valve seat, insert the valve into position, and spin the valve quickly back and forth. Lift the valve, clean off all grinding compound, and check valve seat width. The valve seat will have removed the bluing wherever it contacted the valve face. Measure the seat width with vernier calipers. It should measure approximately 1.0 mm (0.04 in). Also, the seat should be uniform in contact area. If valve seat width varies, or if pits still exist, then continue to cut with the 45° cutter. Remove just enough material to achieve a satisfactory seat.

	Standard width	Wear limit
Seat width (IN, EX)	1.0 ± 0.1 mm (0.04 ± 0.004 in)	1.5 mm (0.06 in)

- c. If the valve seat is uniform around the perimeter of the valve face, but is too wide or not centered on the valve face, it must be altered. Use either the "FLAT", 45°, or 30° cutters to correct the improper seat location in the manner described below :



- (1) If the valve face shows that the valve seat is centered on the valve face, but too wide, then lightly use both the "FLAT" and the 30° cutters to reduce the seat width to 1.0 mm (0.04 in).
- (2) If the seat shows to be in the middle

of the valve face, but too narrow, use the 45° cutter until the width equals 1.0 mm (0.04 in).

(3) If the seat is too narrow, and right up near the valve margin, then first use the "FLAT" cutter and then the 45° cutter to get the correct seat width.

(4) If the seat is too narrow and down near to bottom edge of the valve face, then first use the 30° cutter and then the 45° cutter.


7. Lapping the Valve/Valve Seat Assembly

a. The valve/valve seat assembly should be lapped if, (1) neither the seat nor the valve face are severely worn, or: (2) if the valve face and valve seat have been resurfaced and now require a final light grinding operation for perfect sealing.

b. Apply a small amount of coarse lapping compound to the valve face. Insert the valve into the head. Rotate the valve until there is a burnished spot all the way around the valve face. Clean off the coarse compound, then follow the same procedure with fine compound.

Continue lapping until the valve face shows a complete and smooth surface all the way around. Clean off all compound material.

Apply bluing dye to the valve face and rotate the valve face for full seat contact which is indicated by a shiny surface all around the valve face where the bluing has been rubbed away.



D. Camshaft and Sprocket


1. Camshaft

a. The cam lobe metal-surface may have a blue discoloration due to excessive friction. The metal surface could also start to flake off or become pitted. This is due to poor lubrication, incorrect clearances, or normal wear.

b. If any of the above wear conditions are readily visible, the camshaft should be replaced.


c. Even though the cam lobe surface appears to be in satisfactory condition, the lobes should be measured with a micrometer. Cam lobe wear can occur without scarring the surface. If this wear exceeds a predetermined amount, valve timing and lift are affected. Replace the camshaft if wear exceeds the limits.

Wear limit	A	B
Intake	38.70 mm (1.523 in)	32.08 mm (1.263 in)
Exhaust	38.74 mm (1.525 in)	31.90 mm (1.256 in)



2. Cam sprocket and cam drive sprocket

Check the cam sprocket and cam drive sprocket for wear.






Piston size		Cylinder size	
A	66 -0.020 or less -0.031 or more	A	66 $+0.020$ or less $+0.011$ or more
	(2.598 -0.00079 or less) -0.00122 or more		(2.598 $+0.00079$ or less) $+0.00043$ or more
B	66 -0.030 or less -0.040 or more	B	66 $+0.010$ or less 0
	(2.598 -0.00118 or less) -0.00157 or more		(2.598 $+0.00039$ or less) 0

E. Cylinder

1. Visually check the cylinder walls for scratches. If vertical scratches are evident, the cylinder wall should be rebored or the cylinder should be replaced.


2. Measure cylinder wall wear in the manner as shown. If wear is excessive, compression pressure will decrease, and engine trouble will occur. Rebore the cylinder wall, and replace the piston and piston rings.

Cylinder wear should be measured at three depths by placing the measuring instrument in parallel to, and at right angles to the crankshaft. (See the illustration.)



3. Types of cylinder

The cylinder is available in two sizes, having the mark A or B on it. When replacing the cylinder, it is necessary to replace the piston with a new one having the identical mark.



	Standard
Cylinder bore	66.00 ~ 66.02 mm (2.598 ~ 2.599 in)
Cylinder taper	0.05 mm (0.002 in)


If the cylinder wall is worn more than wear limit, it should be rebored.

F. Piston and Piston Rings

1. Piston

- Using the micrometer, measure the outside diameter of the piston at the piston skirt.

Measurement should be made at a point 11 mm (0.43 in) above the bottom edge of the piston by placing the micrometer in parallel to, and at right angles to, the piston pin.



	Size
Standard	66.00 mm
Oversize 1	66.25 mm
Oversize 2	66.50 mm
Oversize 3	66.75 mm
Oversize 4	67.00 mm

Piston clearance:
0.030 ~ 0.050 mm
(0.0012 ~ 0.0020 in)

- Piston ring/ring groove fit must have correct clearance. If the piston and ring have already been used in the engine, the ring must be removed, the ring groove cleaned of carbon. And then the ring should be reinstalled. Use a feeler, gauge to measure the gap between the ring and the land.

Side clearance	Top	0.04 – 0.08 mm (0.0016 – 0.0031 in)
	2nd	0.03 – 0.07 mm (0.0012 – 0.0028 in)



2. Piston ring

- a. The oversize top and middle ring sizes are stamped on top of the ring.

	Oversize Dia.	Stamped Mark
Oversize 1	$66 + 0.25 \text{ mm}$	25
Oversize 2	$66 + 0.50 \text{ mm}$	50
Oversize 3	$66 + 0.75 \text{ mm}$	75
Oversize 4	$66 + 1.00 \text{ mm}$	100

- b. Expander spacer of the bottom ring (oil control ring) is color-coded to identify sizes. The color mark is painted on the expander spacer.


Size	Color
STD	Red
Oversize 1	Brown
Oversize 2	Blue
Oversize 3	Black
Oversize 4	Yellow

- c. Push the ring into the bore (with an inverted piston to make sure it is not cocked), check and gap clearance with a feeler gauge.

NOTE:


The end gap on the expander spacer of the oil control ring is unmeasurable. If the oil control ring rails show excessive gap all three components should be replaced.

	Standard	Limit
Top/2nd ring	$0.2 - 0.4 \text{ mm}$ ($0.012 - 0.016 \text{ in}$)	0.7 mm (0.025 in)
Oil control (Rails)	$0.2 - 0.9 \text{ mm}$ ($0.008 - 0.035 \text{ in}$)	—



G. Piston Pin

1. Apply a light film of oil to pin. Install in connecting rod small end. Check for play. There should be no noticeable vertical play. If play exists, check connecting rod small end for wear. Replace pin and connecting rod as required.



2. The piston pin should have no noticeable freeplay in piston. If the piston pin is loose, replace the pin and/or the piston.




H. Crankshaft

1. Check connecting rod axial play at small end (to determine the amount of wear of crank pin and bearing at big end).

If small end play exceeds tolerance, disassemble the crankshaft, check connecting rod, crank pin and big end bearing. Replace defective parts. Play after re-assembly should be within specification.


Rod axial clearance	
Minimum	Maximum
0.30 mm (0.012 in)	0.50 mm (0.019 in)



2. Check the connecting rod side clearance at big end.


If axial play exceeds tolerance, disassemble the connecting rod and replace any worn parts. Big end axial play should be within specification.

Rod side clearance	
Minimum	Maximum
0.160 mm (0.0063 in)	0.264 mm (0.0104 in)



3. Check crankshaft assembly runout. Dial gauge readings should be within specifications.


Deflection tolerance :
0.02 mm (0.0008 in)



4. Crankshaft assembly
a. Assembling the connecting rods.

NOTE:

Use bearings of identical color for assembly.
(For both connecting rod and journal bearings)




- 1) Selection of big end bearing inserts.

Con-rod insert No =

Con-rod housing No - Crankpin Dia. No


Beg end bearing housing Nos.	Crank pin Dia. Nos.	Con-rod insert Nos. (Color codes)
3	1	1 (Blue)
4	2	2 (Black)
5		3 (Green)
		4 (Green)

Con-rod housing No.




CAUTION:

Install the both connecting rods with the "YAMAHA" mark to the left side.



NOTE:

If both connecting rods are to be replaced, the new ones should have the identical marks.



2) Weight of connecting rod

If either one of connecting rods is to be replaced, the new one must have the same stamped mark.

If both are to be replaced, the difference of weight between the two rods should be 5 gr (0.18 oz) at a maximum.

Con-rod cap tightening torque:


3.3 ~ 3.8 m·kg (24 ~ 27.5 ft·lb)

NOTE:

When assembling the con-rod, apply molybdenum disulfide to the threaded portions of bolts, nuts and nut seats.

NOTE:

Install the connecting rod with the bearing protuberance on the rear side. (inlet side)



3) Checking big end bearings

The big end bearings are vitally important parts for the engine.

The following parts should be checked.

- Grooved wear on bearing inserts.
- Scratches resulting from dusts.
- Damage to connecting rods, bolts and nuts.

4) Measuring the oil clearance:

Place plasti gauge in the center of bearing cap and tighten housing with specified torque.

Determine the oil clearance by measuring thickness of flattened plasti gauge.



NOTE: _____

Do not turn con-rod during measurment.

b. Installing the crankshaft.


- 1) Check crankshaft journals for damage and grooved wear.
If necessary, replace inserts.

2) Selection of journal bearing inserts.


$$\begin{array}{|c|} \hline \text{Bearing insert No} \\ \hline \end{array} = \begin{array}{|c|c|} \hline \text{Crankcase No} & - \text{Crank journal Dia No} \\ \hline \end{array}$$

Crankcase No.	Crank journal No.	Journal bearing No
3	1	1 (Blue)
4	2	2 (Black)
5		3 (Brown)
		4 (Green)

Crankcase No.



Crank journal No.




NOTE: _____

This selection procedure is necessary to provide proper oil clearance.


Standard oil clearance:
0.020 ~ 0.044 mm (0.0008 ~ 0.0017 in)

I. Oil Pump



1. Pump assembly
2. Cover fitting bolt
3. Reduction gear
4. Pump cover

XS360 Lubrication Diagram




1. Trochoidal Pump Rotor Width

12 mm (0.472 in)

2. Rotor Dimensions-Inner and Outer

Clearance between A and B
Standard:

0.03 – 0.09 mm
(0.0001 – 0.0002 in)



J. Primary Drive

The drive gear is mounted on the crankshaft and the driven gear is integral with the clutch assembly and mounted on the transmission main shaft.

Primary reduction ratio		
No. of teeth		Ratio
Drive	Driven	
24	78	3.25



1. Check the drive gear and driven gear for obvious signs of wear or damage from foreign material within the primary case.
2. If primary drive gears exhibit excessive noise during operation, gear lash may be incorrect.

Numbers are scribed on the side of each gear. Add these numbers. If their total exceed tolerance, replace with a numbered gear that will bring total within specification.

NOTE:

This procedure is rarely required. However, if a gear must be replaced due to damage, it is always advisable to pay strict attention to the lash numbers during replacement.


	Lash numbers (symbol)	
Primary drive gear	A – D	
Primary driven gear	C – F	
Lash tolerance	Drive	Driven
	A	C
	B	D
	C	E
	D	F



K. Clutch

1. Checking friction plates


The friction plates are liable to wear. The standard thickness of the friction plate is 3.0 mm (0.12 in). If it is worn more than 0.3 mm (0.012 in) or has uneven wear, it should be replaced.




2. Measure clutch plates

Check clutch plate warpage, and if warpage is more than specified, the clutch plate should be replaced.

Clutch plate warpage limit:
0.05 mm (0.002 in)



3. Checking the clutch housing assembly
Insert the main axle into the primary driven gear hub, and check for wear and scratches. If scratches exist, the clutch tends to drag. Smooth out with oil stone or fine grain sandpaper. If excessively worn, noise will result, so replacement is necessary.




4. Checking clutch springs

Using the vernier caliper, measure the free length of each spring. If it measures 1.0 mm (0.04 in) less than specified, it should be replaced.

Clutch spring specifications:


Number of springs	4
Free length	34.6 mm (1.36 in)
Spring rate	2.6 kg/mm (145.5 lb/in)



5. Checking the push rod


Roll the push rod over the "V" block as shown below, and check for bends. If any bend is found, replace the push rod.

Bend Limit:
0.2 mm (0.008 in)




L. Transmission


1. Inspect each shift fork for signs of galling-on gear contact surfaces. Check for bending. Make sure each fork slides freely on its guide bar.



2. Roll the guide bars across a surface plate. If any bar is bent, replace.
3. Check the shift cam grooves for signs of wear or damage. If any profile has excessive wear and/or any damage, replace cam.
4. Check the cam followers on each shift fork for wear. The follower should fit snugly into its seat in the shift fork, but not over-tight.
Check the ends that ride in the grooves in the shift cam. If they are worn or damaged, replace.
5. Check shift cam dowel pins and side plate for looseness, damage, or wear. Repair as required.
6. Check the transmission shafts using a centering device and dial gauge. If any shaft is bent, replace.
7. Carefully inspect each gear. Look for signs of obvious heat damage (blue discoloration). Check the teeth for signs of pitting, galling, or other extreme wear. Replace as required.




8. Check to see that each gear moves freely on its shaft.
9. Check to see that all washers and clips are properly installed and undamaged. Replace bent or loose clips and bent washers.
10. Check to see that each gear properly engages its counterpart on the shaft. Check the mating dogs for rounded edges, cracks, or missing portions. Replace as required.



M. Kick Starter

- a) The pressure of the kick clip is 2.2 kg. If above pressure is too strong, spring wear and kick starter slipping will result. On the other hand, if it is too weak, the same slippage will occur particularly at low temperatures. Do not try to bend the clip.
- b) Check the clip for damage and wear, and determine whether or not, it should be replaced taking the above (item 2) into consideration.

Standard tension: 0.8 – 1.3 kg



N. Bearings and Oil Seals

1. Inspection

- a. After cleaning and lubrication bearings, rotate inner race with a finger. If rough spots are noticed, replace the bearing.
- b. Check oil seal lips for damage and wear. Replace as required.

2. Removal

- a. Pry oil seal(s) out of place using a slot head screwdriver.


Always replace all oil seal when overhauling engine.

NOTE:

Place a piece of wood under the slot head screwdriver to prevent damage to case.

O. Neutral Switch

1. Check O-ring, replace if damaged.
2. Check neutral point for wear. Replace as required.



P. Crankcase

1. Thoroughly wash the case halves in mild solvent.
2. Clean all gasket mating surfaces and crankcase mating surface thoroughly.
3. Visually inspect case halves for any cracks, road damage, etc.
4. Check all fittings not previously removed for signs of loosening or damage.
5. Check bearing seats for signs of damage (such as the bearing spinning in the seat, etc.)
6. Check oil delivery passages for signs of blockage.

3-4. ENGINE ASSEMBLING AND ADJUSTMENT

A. Transmission and shifter installation


1. Install shift cam and stopper plate.

NOTE:


- 1) Position of stopper plate.




- 2) Position of stopper plate circlip.




2. Install shift forks, guide bars, circlip and blind plugs.






NOTE: _____

Check blind plug, replace if damaged.



- 3 Install half circle retainer on the drive axle, and main axle.




1. Shift fork 1 3. Shift fork
2. Shift fork 2 4. Shift fork 1

4. Install oil seal on axle before installing axle in case.

NOTE: _____

Exercise care not to damage oil seal lip when installing transmission into case.

5. Install baffle plate.



5. Fit transmission into lower case and install drive sprocket.

NOTE: _____

- 1) Be sure axle circlips are fitted to bearings and circlips have been positioned in circlip grooves.
- 2) Transmission installation is easier if shift cam is rotated to neutral position.

6. Install cam stopper plate, change lever guide and shift cam stopper assembly.

NOTE: _____

Apply LOCK-TITE to threads of change lever guide and cam stopper plate securing screws.


Cam stopper plate securing
screw torque:
0.9 – 1.3 m-kg
(6.5 – 9.4 ft-lb)

Change lever guide securing
screw torque:
0.3 – 0.4 m-kg
(2.2 – 2.9 ft-lb)

B. Crankshaft installation.


1. Install cam chain to the crankshaft.
2. Installing crankshaft.

Before installing crankshaft, apply a light coat of engine oil to each bearing surfaces.



C. Crankcase


1. Apply YAMAHA BOND #4 to the mating surfaces of both case halves. Apply thoroughly over all mating surfaces.
2. Set the crankcase half onto lower case half. Install the crankcase holding bolts and nuts. Tighten all crankcase holding bolts gradually until proper torque is reached.




3. Check crankshaft and transmission shafts for proper operation and freedom of movement.

D. Crankcase Cover (L)

1. Install starter motor.
2. Install the starter wheel assembly and starter chain. Install the rotor key on the crankshaft.



3. Install the rotor assembly by turning starter sprocket. (Starter clutch rollers must be rolled into position.)




NOTE:

When tightening the rotor bolt, place a rag over the cylinder sealing surface to protect it against scratches. For easy operation, it is advisable to insert an iron rod into the connecting rod small end.


Rotor bolt tightening torque:
3.0 – 3.5 m·kg (22 – 25 ft·lb)

4. Install crankcase cover (L) and route generator lead wires and clamp them in place.



E. Piston

1. Mount the piston (rings installed) onto the connecting rod. Be sure the arrow stamped on the piston crown points forward.
2. Install new piston pin clips in their grooves.
3. During reassembly, coat the piston ring grooves, piston skirt areas, piston pin with 4-stroke engine oil.




F. Cylinder


1. Install a new cylinder base gasket.
2. Check the small "O" ring around the oil delivery passage and cylinder sleeve O-ring. Replace if damaged.



3. Off-set the three ring end gaps as shown.




4. Install the cylinder.




NOTE:

Make sure the "O" ring and knock pin are in place.



G. Cylinder Head

1. Install the cylinder head gasket and cylinder head.
2. Tighten the cylinder head temporarily. (final tightening to follow.)





TORQUE M6 — 0.8 ~ 1.2 kg-m M10 — 3.0 ~ 3.5 kg-m



H. Cam shaft and Sprocket


1. Setting the valve timing
 - a. Pull cam chain up through cam chain hole in the cylinder and cylinder head.
2. Fit chain sprocket over cam shaft.




NOTE:

Attach a wire to cam chain to prevent from dropping into case.

3. Set cam shaft on cylinder head. Locating pin should face upward.



4. Align timing mark on cam shaft sprocket with cylinder head surface line.





5. Install cam chain onto cam sprocket with fasten chain front side.



6. Align cam sprocket hole with cam shaft holes and tighten sprocket fitting bolts.



Tightening torque:

1.8 — 2.2 m-kg (13.0 — 16.0 ft-lb)



7. Installing chain tensioner and guides


- a. Install tensioner and guides as illustrated then fully compress tensioner spring, hold sleeve with something bolt.



- b. Install tensioner assembly and tighten bolts, then remove bolt.


Tightening torque:

0.8 – 1.2 m·kg (6.0 – 8.5 ft·lb)



NOTE:

- 1) When installing the chain guide , turn the camshaft to keep the chain tight.
- 2) Do not remove BOLT before installing.




I. Cylinder Head Cover


1. Install rocker arm, rocker shafts, and rocker shaft plugs.

NOTE:

When installing rocker arm, be sure to face the thread hole to outward engine.




2. Coat the head and cover mating surfaces with a YAMAHA Herme Seal and slip the head cover into position on the head.



3. Install nuts and bolts and tighten to the specified torque. Use a crisscross tightening pattern.

Tightening torque:

8 mm bolt: 2.0 – 2.4 m·kg
(14.5 – 17.0 ft·lb)
6 mm bolt: 0.8 – 1.2 m·kg
(6 – 8.5 ft·lb)



TORQUE M6 – 0.8 ~ 1.2 kg·m M8 – 2.0 ~ 2.4 kg·m

4. Install the rocker shaft plugs and tighten.
5. Adjust valve clearance.
6. Install the intake and exhaust tappet covers.

J. Drive Sprocket

Apply a coat of grease to "O" ring and oil seal lip.

Install the collar, drive sprocket, lock washer and lock nut in that order. Tighten to the specified torque.

Tightening torque:


5.0 – 8.0 m·kg (36 – 58 ft·lb)

K. Contact Breaker


1. Install governor assembly.
Align slot in the governor with locating pin.

Tightening torque:


0.8 – 1.2 m·kg (6.0 – 8.5 ft·lb)



2. Install contact breaker assembly and pass lead wire through cylinder head fins. install breaker cover.



3. Install starter motor cover and breather cover.




L. Kick Starter Assembly

1. Set kick gear clip in groove of crankcase.
2. Rotate kick spring clockwise and hook it on kick spring stopper.


NOTE:

Make sure that kick stopper is stopped at projection of crankcase.



1. Kick gear clip 2. Kick spring


3. Check whether kick starter acts correctly and whether it returns to its home position.
4. Install change lever assembly, and change shaft assembly.
5. In each gear, check for proper centering. Change adjustment on screw as required.



NOTE:

If change lever is adjusted, apply LOCK-TITE to threads of adjusting screw.

6. With change pedal in place on the change shaft, push down, then up. There should be no freeplay. If free play is evident, shift return spring is fatigued, replace.
7. Check return spring for change levers (3). If it will not hold change lever (3) firmly against shift cam dowel pins, replace spring.




8. Check to see that all parts move freely prior to installing upper case half. Check for correct transmission operation and make certain that all loose shims are


in place. At the same time check for complete engagement of all engaging dogs into appropriate gear slots.

M. Clutch


1. Install clutch housing, thrust plate, clutch boss and hold clutch boss with circlip.



2. Install clutch plates, steel ball, (push (1), pressure plate, clutch springs and spring screws.




NOTE: _____
When installing the pressure plate, align "ARROW" mark on the clutch boss and pressure plate.



N. Oil Pump

Backlash adjustment

1. Install oil pump assembly and adjust backlash between primary drive gear and idle gear.
2. Lightly tighten each bolts (A—C) and install thickness plate between primary drive gear and pump idle gear.



O. Crankcase Cover

Install crankcase cover(R) and tighten fitting bolts.

P. Oil Strainer

1. Install oil strainer into the crankcase.
2. Install the oil strainer cover to the crankcase with new gasket.

Tightening Torque: 0.6 – 0.8 m·kg
(4.5 – 6.0 ft·lb)


NOTE: _____
Tighten the bolts using crisscross pattern.

3-5 MOUNTING

Refer to Chapter 3. "Removal" and mount the engine in the frame as follows:

1. Place the engine in the frame from right side.
2. Install engine mounting bolts and nuts with proper tightening torque.

Tightening torque	
Bolt size	Torque
10 mm nut	2.7 – 4.2 m·kg (17.5 – 30 ft·lb)
8 mm nut	1.3 – 2.1 m·kg (9.5 – 21 ft·lb)
8 mm bolt	1.3 – 2.1 m·kg (9.5 – 21 ft·lb)



12. Add engine oil and start engine. Check oil leakage.

3. Connect starter motor lead wire.
4. Connect ground lead wire.
5. Connect two couplers from generator to the wire harness.
6. Install oil filter.

Tightening torque:
1.3 – 1.7 m·kg (9.5 – 12.0 ft·lb)

7. Install tachometer cable and exhaust pipes.
8. Connect the ignition primary lead wire and plug cap.
9. Install the throttle cable to carburetor then install carburetors.
10. Install fuel tank and connect petcock vacuum pipe and fuel pipe.
11. Install the following parts:
 - footrests.
 - brake pedal
 - drive sprocket
 - drive chain
 - case cover (L)
 - change pedal
 - air filters
 - side covers.

CHAPTER 4. CARBURETION

4-1. CARBURETOR	58
A. Disassembly and Inspection	58
B. Float level	59

4-1. CARBURETOR

A. Disassembly and Inspection



(for replacement or cleaning)

1. The vacuum chamber cover on top is held in place by four screws. Remove these screws and lift off the chamber cover.


NOTE:

When installing the set screws, be sure to correctly position the throttle cable anchor bracket.


2. Once the cover has been removed, the spring, jet needle retainer, jet needle, and vacuum piston can be removed.



3. Installation of the vacuum piston is accomplished by inserting it into the carburetor body and lining up the small projection on the outer edge of the rubber diaphragm with the corresponding notch in the outer edge of the carburetor top mating surface.




4. With top removed, the inlet passage (#1) and air passage to the starter jet (#2) are visible.






1. Inlet passage 2. Air passage to the starter jet

5. The starter jet housing mounts to the left side of the carburetor. It is held by three screws. A gasket fits between the starter jet housing and main housing.



6. The float bowl mounts to the bottom of the main housing. Remove the four retaining screw and then remove the float bowl.


7. Both the pilot jet and the main jet are screwed into orifices in the float bowl. The pilot jet is removed from the inside, the main jet is removed from the bottom, after first removing the cover screw.



8. Turn the carburetor upside down, pull out the float pivot pin, and remove the float.


CAUTION:

Directly beneath the float adjustment tang is the float valve. Remove this part immediately to prevent its loss.



9. The needle jet fits into the main housing from the bottom. If removal is required, pull it down and out by hand. Reverse this procedure to install the needle jet.

10. Inspect needle and seat for signs of excessive wear or foreign particles. Replace as required. Always replace inlet needle and valve seat as an assembly.



B. Float Level

Refer to CHAPTER 2. Section 2-2. C for "Float Level" adjustment procedure.

CHAPTER 5. CHASSIS

5-1. FRONT WHEEL	62
A. Removal	62
B. Front Axle	62
C. Replacing Wheel Bearings	62
D. Front Wheel Installation	62
5-2. REAR WHEEL	63
A. Removing the Rear Wheel	63
B. Checking Brake Shoe Wear	63
C. Brake Drum	63
D. Brake shoe Plate	63
E. Replacing Wheel Bearings	63
F. Installing Rear Wheel	63
5-3. DISC BRAKES	63
A. Disc Brake Disassembly	63
B. Disc Brake Inspection	66
C. Disc Brake Assembly	67
5-4. RIM AND SPOKES	69
A. Checking for Loose Spokes	69
5-5. TIRES AND TUBES	70
A. Removal	70
B. Inspection	70
5-6. DRIVE CHAIN AND SPROCKETS	70
A. Drive Sprocket	70
B. Driven Sprocket	71
C. Chain Inspection	71
D. Chain Maintenance	72
5-7. FRONT FORKS	72
A. Disassembly	72
B. Assembly	73
5-8. STEERING HEAD	73
A. Adjustment	73
B. Disassembly	73
C. Inspection	74
D. Installation	74

5-9. SWING ARM	75
A. Swing Arm Inspection	75
B. Swing Arm Lubrication	75
C. Swing Arm Removal	75
5-10. REAR SHOCK ABSORBER	76
A. Removal	76
B. Inspection	76
5-11. CABLES AND FITTINGS	76
A. Cable Maintenance	76

CHAPTER 5. CHASSIS

5-1. FRONT WHEEL

A. Removal

1. Disconnect the brake cable at the front brake lever.
2. Remove cotter pin from front axle.
3. Remove the front axle nut.
4. Loosen the two axle holder nuts at the bottom of the right-hand fork leg.
5. Remove the front wheel axle by simultaneously twisting and pulling out on the axle. Then remove the wheel assembly.

NOTE:

Raise the front of the machine by placing a suitable stand under the engine.


B. Front Axle

Remove any corrosion from axle with emery cloth. Then place it on a surface plate and check for bending. If bent, replace.

C. Replacing Wheel Bearings

If the bearings allow play in the wheel hub or if wheel does not turn smoothly, replace the bearings as follows:

1. First clean the outside of the wheel hub.
2. Drive the bearing out by pushing the spacer aside (the spacer "floats" between the bearings) and tapping around the perimeter of the bearing inner race with a soft metal drift pin and hammer. Either or both bearings can be removed in this manner.



3. To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation. Use a socket that matches the outside race of the bearing as a tool to drive in the bearing.

D. Front Wheel Installation

When installing front wheel, reverse the removal procedure taking care of the following points:

1. Check for proper engagement of the boss on the outer fork tube with the locating slot on the brake shoe plate.
2. Always secure the front wheel axle as follows:
 - a. Torque the axle nut.

Axle nut torque:


7.0 – 10.0 m-kg
(50.6 – 72.3 ft-lb)

- b. Install a new cotter pin; discard old pin.
- c. Install the axle holder as shown.

First tighten the nut on the front end of the axle holder, then tighten the nut on the rear end.

Axle holder nut torque:

1.5 – 2.5 m-kg
(11.0 – 18.0 ft-lb)



1. Install with arrow forward.

5-2. REAR WHEEL

A. Removing the Rear Wheel

1. Remove the tension bar and the brake rod from the brake shoe plate. The tension bar can be removed by removing the cotter pin and nut from the tension bar bolt. The brake rod can be removed by removing the adjust nut.
2. Loosen the lock nuts of the right and left chain pullers and loosen the adjust bolts.
3. Remove the drive chain.

To remove, use the chain cutter (special tool). See Chapter 3, "Engine Overhaul", page 25.


NOTE: _____

The chain joint should be replaced each time the chain is cut.

4. Remove the rear wheel axle nut.
5. The rear wheel assembly, the collar, the chain puller(s), etc., can be removed from the motorcycle by pulling the axle.

B. Checking Brake Shoe Wear

1. Measure the outside diameter at the brake shoes with slide calipers.



Rear brake shoe diameter:
160 mm (6.30 in)
Replacement limit:
156 mm (6.14 in) min.

2. Remove any glazed areas from brake shoes using coarse sand paper.

C. Brake Drum

Oil or scratches on the inner surface or the brake drum will impair braking performance or result in abnormal noises.

Remove oil by wiping with a rag soaked in lacquer thinner or solvent.

Remove scratches by lightly and evenly polishing with emery cloth.

D. Brake Shoe Plate

Remove the camshaft and grease. If the cam face is worn, replace.

NOTE: _____

Before removing the cam lever, put a match mark on the cam lever and camshaft to indicate their positions for easy assembly.

E. Replacing Wheel Bearings

See front wheel section, "Replacing Wheel Bearings".

F. Installing Rear Wheel

1. Install wheel and axle.

Axle nut torque:
7 – 10 m·kg
(50 – 72 ft·lb)

2. Connect drive chain, brake rod and tension bar.
3. Adjust drive chain.
(See chapter 2, "Drive chain tension adjustment".)
4. Tighten rear axle nut.
Install a new cotter pin.
5. Adjust rear brake. (See chapter 2, "Rear brake and wheel".)

5-3. DISC BRAKES

A. Disc Brake Disassembly


Avoid disassembling the disc brake whenever possible. Trouble that has nothing to do with the brake cam and should be fixed without disassembling the brake.

CAUTION:

Brake fluid will damage painted and other surfaces. Use caution whenever working with brake fluid.

1. Caliper assembly.**a. Removing caliper assembly.**


- 1) Remove brake hose from caliper.
- 2) Wrap up brake hose with clean vinyl sheet or clean cloth.
- 3) Keep front brake lever pulled in. This prevents fluid from dripping.
- 4) Remove caliper securing bolts and nuts, and remove caliper.



1. Caliper securing bolts
2. Union bolts
3. Support bolts

b. Removing the pads.

Remove the pads from the caliper. If difficult to remove, push the piston to the bottom of the cylinder using the piston pushing tool, and remove.

**c. Removing the piston seal.**

- 1) Remove the support bolts.




- 2) Remove the Phillips head screw and pad spring.

NOTE:

The support bolt and Phillips head screw heads are painted in yellow to keep the user from touching them. The user should be instructed not to attempt turn these bolts and screws.

- 3) Remove the dust seal and retaining ring.




1. Dust seal
2. Retaining ring
3. Piston

- 4) Feed compressed air into the brake fluid inlet to force out the piston. Never attempt to pry it out with a screwdriver.

CAUTION:


When doing above procedure care should be taken so that piston does not hit your face or body.



- 5) Remove the piston seal from the caliper body.

CAUTION: _____


Keep the removed parts free from gasoline, kerosene and engine oil. Otherwise, all seals will swell up and deteriorate. The piston seals and dust seals should be replaced every two years.




1. Piston seal
2. Piston

b. Master cylinder disassembly.

- 1) Remove master cylinder boot.



- 2) Remove snap ring using circlip pliers.




- 3) Remove piston. (Note that spring remains in master cylinder.)
4) Remove return spring and stopper valve.
5) Remove stopper plate.
6) Remove cylinder cup.

2. Master cylinder.

a. Removing the master cylinder.

- 1) Disconnect front stop switch lead wire.
- 2) Remove the brake lever. (Be careful not to lose the brake lever return spring.)
- 3) Remove the brake hose.
- 4) Remove the two bolts securing the master cylinder from the handlebar. Remove the reservoir cap, and remove the brake fluid.



1. Snap ring
2. Piston
3. Cylinder cup 2
4. Shim
5. Cylinder cup 1
6. Piston cup spacer
7. Return spring

B. Disc Brake Inspection

1. Caliper

a. Piston


If the piston has scratches on its outer surface, it should be replaced.

b. Pads

- 1) If any pad is worn beyond limits, it should be replaced.


Pad thickness:	11 mm (0.43 in)
Wear limit:	6.0 mm (0.24 in)

Check wear on disc brake pad




2. When checking the brake pads, be sure to replace the following parts:

- a. The following five parts should be replaced as a set:



- 1) Piston seal
- 2) Piston boot
- 3) Dust cover clip
- 4) Bushing boot
- 5) Bleeder screw

- b. When replacing a brake pad, be sure to replace the following five parts as an assembly.



1. Pad
2. Pad spring
3. Pad screw
4. Retainer

NOTE:

Grease the contact surface of the shim with the pad, and as illustrated, bend each tab of the shim over the brake pad (attached to the piston), and install the shim to the brake pad.

c. Piston seal and dust seal

If piston seal or dust seal is scratched or damaged, it should be replaced. Whether or not it is scratched or damaged, it should be replaced every two years.

d. Bridge bolts

Bridge bolts should be replaced every time the caliper is removed, whether damaged or not.

2. Master cylinder

a. Master cylinder body


- 1) If the master cylinder has scratches or worn spots, replace it.
- 2) If the outlet edge is scratched or damaged, replace it.
- 3) Check the port for clogging. Clean as required.
- 4) Check the cylinder and breather for excessive wear.

3. Brake hose

- a. Check the brake hose, and if damaged or leaky, replace.
- c. Replace brake hose every four years.

4. Disc

- a. The deflection of the disc assembly should be less than 0.15 mm. If deflection exceeds 0.15 mm, check the deflection of the disc and the wheel bearing.



- b. If the disc is worn excessively or damaged, replace it.

Disc thickness:	5.0 mm (0.197 in)
Wear limit:	4.5 mm (0.177 in)

C. Disc Brake Assembly

1. Cleaning

All disassembled parts should be washed in the following manner before they are assembled.

- a. Be sure to use new brake fluid for washing. (Do not use mineral oil; it will cause rubber parts to swell up. Also avoid using alcohol.)
- b. If any other mineral oil other than brake fluid is used on rubber parts, they should be replaced. Metallic parts should also be washed in brake fluid.

2. Caliper

a. Installing the piston

- 1) Fit the piston seal in the groove in the caliper cylinder.
- 2) Coat at caliper cylinder and piston with new brake fluid.
- 3) Insert the piston into the caliper cylinder. Take care not to twist the piston.

b. Assembling of caliper and support bracket

- 1) Fit the dust seals in the piston groove and over the caliper, and install the retaining rings.
- 2) Install the pad spring, and tighten the Phillips head screw.

Tightening torque:

0.2 – 0.4 m·kg
(1.5 – 3.0 ft·lb)

- 3) Put together the caliper and support bracket with the support bolts.

NOTE:

Now the brake pads can be installed.

Support bolt tightening torque:

1.5 – 2.0 m·kg
(11 – 15 ft·lb)

Always use new bolts and tighten to specification.

c. Pad installation

- 1) The pads may be installed when the caliper or bridge bolts are tightened.

- 2) When the pads alone are to be replaced, it is necessary to push the piston so that the pads can be placed in position. When the piston is pushed back, the brake fluid level in the master cylinder reservoir increases. It may be necessary to loosen the bleed screw to let out some of the brake fluid.

d. Caliper installation

- 1) The caliper can be installed by reversing the removal procedure. Install caliper (front and rear).

Tightening torque:
3.0 – 4.0 m·kg
(21 – 29 ft·lb)


- 2) Install the brake hoses (front and rear).

Tightening torque:
Union bolt:
2.5 – 3.5 m·kg
(18 – 25 ft·lb)

3. Master cylinder

a. Cylinder cup installation

- 1) After soaking the cup in new brake fluid, assemble the cup and piston. Take care not to scratch the cup or piston. (Use cylinder cup installer.)
(P/No. 90890-01240)



- 2) Install the stopper plate.
3) Insert the spring and valve into the master cylinder body.

b. Piston installation

- 1) Check the outer surface of the piston for scratches. Carefully insert the piston into the cylinder. Take care not to scratch the inner wall of the cylinder. If scratched, fluid leakage may result.
2) Install the snap ring.
3) Firmly fit the boot in the grooves of the master cylinder and piston.
c. Installing the master cylinder on the handlebar
1) Install the master cylinder on the handlebar.
2) Connect brake hose to master cylinder with union bolt.

Tightening torque:
(front and rear master cylinder)
2.3 – 2.8 m·kg (17 – 20 ft·lb)

NOTE:

If gasket is damaged, replace it

- 3) Connect reservoir hose to rear master cylinder.
4) Fill the reservoir with brake fluid (DOT #3) and air. (Refer to "Air bleeding".)
d. Disc

- 1) The disc bolts should be tightened to specification.

Tightening torque:
1.7 – 2.2 m·kg
(12 – 16 ft·lb)

- 2) The deflection of the disc assembly should be within limits.

Deflection limit: 0.15 mm (0.006 in)


e. Air bleeding

If any of the parts relating to the brake fluid have been removed, air must be bled after reassembly.

- 1) Add brake fluid (DOT #3) to the

reservoir.

- 2) Install the diaphragm. Be careful not to loose brake fluid because of overflow.
- 3) Connect a vinyl tube tightly to the caliper bleed screw.
- 4) Put the end of the vinyl tube into a container.
- 5) Apply the brake lever and pedal several times. With the brake lever drawn in, loosen the bleed screw.



NOTE:


The brake lever should be squeezed gently; otherwise, air will form very small bubbles, and air bleeding will become difficult.

- 6) When the brake lever and pedal comes in contact with the handlebar grip and foot rest arm, tighten the bleed screw.
- 7) Continue operations from 5) and 6) until air bubbles disappear completely.

Bleed screw tightening torque:
0.4 – 0.7 m·kg (3 ~ 5 ft·lb)

- 8) Add brake fluid to the level line on the reservoir.
- 9) The reservoir is air-tight. When the brake pads are worn, the fluid level will lower, but it is automatically adjusted by the shift of the diaphragm. Therefore, when the brake fluid is added, the diaphragm must be set in its original position.

- 10) The disc trailing torque should be within the specified amount after it is assembled.



Torque: 1.0 kg or less (7.2 lb)

If torque exceeds this limit, check the disc run-out.

NOTE:

A slight drag on the disc is normal and will not develop into a worse condition.

5-4 RIMS AND SPOKES (FRONT AND REAR WHEELS)

A. Checking for Loose Spokes

Loose spokes can be checked by bracing the machine off the ground so that the wheel can spin freely.

Slowly rotate the wheel and at the same time let the metal shaft of a fairly heavy screwdriver bounce off each spoke. If all the spokes are tightened approximately the same, then the sound given off by the screwdriver hitting the spokes should sound the same. If one spoke makes a dull flat sound, then check it for looseness. (See chapter 2, "Front brake and wheel".)

5-5. TIRES AND TUBES

A. Removal

1. Remove valve cap, core, and valve stem lock nut. Loosen bead spacer(s), (rim locks).
2. When all air is out of tube, separate tire bead from rim (both sides), by stepping on tire with your foot.
3. Use two tire removal irons (with rounded edges) to work the tire bead over the edge of the rim, starting 180° opposite the tube stem. Take care to avoid pinching the tube as you do this.
4. After you have worked one side of the tire completely off the rim, then you can slip the tube out. Be very careful not to damage the stem while pushing it back out of the rim hole.

NOTE:

If you are changing the tire itself, then finish the removal by working the second bead off the rim.

B. Installation

Reinstalling the tire and tube can be accomplished by reversing the disassembly procedure. The only difference in procedure would be right after the tubes has been installed, but before the tire has been completely slipped onto the rim, momentarily inflate the tube. This removes any creases that might exist. Release the air and continue with re-assembly. Also, right after the tire has been completely slipped onto the rim, check to make sure that the stem comes out of the hole in the rim at a right angle to the rim.

Finally, inflate the tire and tighten the bead spacer securing nut(s).

Tire Pressure (Normal Riding)

Front: 1.8 kg/cm² (26 Psi)

Rear: 2.0 kg/cm² (29 Psi)

5-6. DRIVE CHAIN AND SPROCKETS


NOTE:

Please refer to *Maintenance Intervals* and *Lubrication Intervals* charts for additional information.

A. Drive Sprocket


With the left crankcase cover removed, proceed as follows:

1. Using a blunt chisel, flatten the drive sprocket lock washer tab.
2. With the drive chain in place, transmission in gear firmly apply the rear brake. Remove the sprocket securing nut. Remove the sprocket.
3. Check sprocket wear. Replace if wear decreases tooth width as shown.



1. $\frac{1}{4}$ tooth
2. Correct
3. Roller
4. Sprocket

4. Replace if tooth wear shows a pattern such as that in the illustration, or as precaution and common sense dictate.



1. Slip off
2. Bent teeth

- During reassembly, make sure the lock washer splines are properly seated on the drive shaft splines. Tighten securing nut throughly to specified torque value. Bend lock washer tab fully against securing nut flats.

Drive Sprocket

Securing Nut Torque:

5.0 – 8.0 m·kg
(36 – 58 ft·lb)

B. Driven Sprocket

With the rear wheel removed, proceed as follows:

- Using a blunt chisel, flatten the securing nut lock washer tabs.
Remove the securing nuts. Remove the lock washers and sprocket.
- Check the sprocket wear using procedures for the drive sprocket.
- Check the sprocket to see that it runs true. If bent, replace.
- During reassembly, make sure that sprocket and sprocket seat are clean.
Tighten the securing nuts in a crisscross pattern.
Bend the tabs of the lock washers fully against the securing nut flats.


Driven Sprocket

Securing Nut Torque:


4.0 – 5.0 m·kg
(29 – 36 ft·lb)

C. Chain Inspection


- With the chain installed on the machine, excessive wear may be roughly determined by attempting to pull the chain away from the rear sprocket. If the chain will lift away more than one-half the length of the sprocket teeth, remove and inspect. (See page 27 for chain removal.)
If any portion of the chain shows signs of damage, or if either sprocket shows signs of excessive wear, remove and inspect.



1. 1/2 tooth 2. Pull



- Check the chain for stiffness. Hold as illustrated. If stiff, soak in solvent solution, clean with wire brush, dry with high pressure air. Oil chain thoroughly and attempt to work out kinks. If still stiff, replace, chain.
- Check the side plate for damage. Check to see if excessive play exists in pins and rollers. Check for damaged rollers. Replace as required.



D. Chain Maintenance

The chain should be lubricated according to the recommendations given in the Maintenance and Lubrication Intervals charts, or more often if possible. (Preferably after every use.) See "Chassis and Suspension. Swing Arm", for additional information regarding chain guide.

1. Wipe off dirt with shop rag. If accumulation is severe, use wire brush, then rag.
2. Apply lubricant between roller and side plates on both inside and outside of chain. Don't skip a portion as this will cause uneven wear. Apply thoroughly. Wipe off excess.

Recommended lubricant:
YAMAHA CHAIN AND CABLE
LUBE, or SAE 10W/30 type
"SE" motor oil.

3. Periodically, remove the chain. Wipe and/or brush excess dirt off. Blow off with high pressure air.
4. Soak chain in solvent, brushing off remaining dirt. Dry with high pressure air. Lubricate thoroughly to make sure lubricant penetrates. Wipe off excess. Reinstall.

5-7. FRONT FORKS

A. Disassembly

1. With the front wheel and front fender removed, the fork legs can be removed from the upper and lower brackets by loosening upper and lower pinch bolts.




1. Pinch bolt 2. Cap bolt



NOTE:

When removing right fork leg, brake hose and pipe must be removed at front fork and top of caliper.


2. Remove the caps and drain the oil from both fork tubes.
3. Remove the internal hexagonal bolt from bottom of outer tubes using fork spring guide wrench.



4. Remove inner tube and damper assembly from outer tube.
5. Remove clip from bottom of inner tube and pull out fork piston assembly inspect and replace if damaged.



6. To replace fork seal, remove wire clip, and cover washer from outer tubes.
7. Carefully pry out old seal, without damaging fork tube.



8. Insert new seal "open" side down.

B. Assembly

1. When assembling the front fork, reverse the order of disassembly

NOTE: _____

Fork springs must be installed with great-pitch down.

2. Installing the front forks.
 - a. Insert the front fork tubes to the correct position and partially tighten the under-bracket mounting bolt.
 - b. Pour specified amount of oil into the inner tube through the upper end opening. Use Yamaha fork oil 10W, 20W, 30W.

NOTE: _____

Yamaha fork Oil is recommended. Specialty type fork oils of quality manufacture may be used.

Fork oil capacity:
130 cc (4.39 oz)
each side

Fork oil level:
(below the top of the fork)
 450 ± 10 mm each side
(17.7 ± 0.4 in)

- d. Tighten all pinch bolts.

Pinch bolt torque:

Upper - 0.9 – 1.4 m·kg
(6.5 – 10 ft·lb)

Lower - 3.0 – 4.0 m·kg
(22 – 29 ft·lb)

3. Install brake hose and pipe and bleed air.
(Refer to 5-3-C-3-f.)

5-8 STEERING HEAD

A. Adjustment

Refer to Chapter 2, Section 2-3, paragraph H for steering head adjustment procedure.

B. Disassembly

1. After removing front forks, remove headlight bracket.
2. Disconnect electrical wires between headlight body and main wiring harness of frame.

NOTE: _____

Removal of fuel tank will aid in disconnecting wiring.

3. Disconnect any electrical wires between handlebar switches and main wiring harness in headlight body.
4. Disconnect clutch and throttle cables at handlebars.
5. Disconnect tachometer and speedometer cables at instruments.
6. Loosen stem pinch bolt.
7. Remove stem fitting bolt and crown washer.

- c. Install the inner tube caps.



8. Remove handle crown (upper bracket) and instruments, as an assembly.

NOTE: _____

Hold headlight body to keep it from falling.

9. Remove steering ring nut with steering nut wrench.

Caution: _____

Support "under bracket" so that the loose bearings will not fall out.

10. Still supporting the under bracket, carefully lift off the bearing cover.
11. Lift off the top bearing race and remove all of the ball bearings from the upper bearing assembly.

Ball size/quantity: 1/4 in./19 pcs.

12. Remove under bracket, be very careful not to lose any bearings from the lower assembly.

Ball size/quantity: 1/4 in. / 19 pcs.

13. Remove races from head pipe using drift punch and hammer. Work the race out gradually by tapping lightly around its complete backside diameter.
14. Remove the bearing race from the lower bracket by tapping around its backside diameter with a drift punch and hammer.
15. Remove dust seal.

C. Inspection

1. Examine all the balls for pits or partial flatness. If any one is found defective, the entire set (including both races) should be replaced. If either race is pitted, shows rust spots, or is damaged in any way, replace both races and all balls.
2. Examine dust seal under lowest race and replace if damaged.

D. Installation

1. If pressed-in races have been removed, tap in new races.
2. Grease the lower ball race of the bottom assembly and arrange the balls around it. Then apply more grease.
3. Grease the lower ball race of the upper assembly and arrange the balls around it. Then apply more grease and set the top race into place.

NOTE: _____

Use medium-weight wheel bearing grease of quality manufacture, preferably water-proof.

4. Carefully slip the under bracket stem up into the steering head. Hold the top bearing assembly in place so the stem does not knock any balls out of position.
5. Set the upper bearing cover on and install the ring nut. Tighten the ring nut so all free play is taken up, but so the bracket can still pivot freely from lock to lock. Recheck for free play after the entire fork unit has been installed. (Refer to Chapter 2-3-H, for Steering head adjustment.)
6. Install the fork tubes into the under bracket to ease headlight body installation.
7. Install the headlight body and stays onto the fork tubes with rubber and steel spacing washers properly in place.
8. Install the upper fork bracket. Tighten steering fitting nut, then tighten stem pinch bolt. Torque to specifications.

Steering fitting nut:
3.5 – 4.0 m·kg
(25.5 – 29.0 ft·lb)

Stem pinch bolt:
1.4 – 2.2 m·kg
(10.0 – 16.0 ft·lb)

9. Tighten upper fork tube pinch bolts and torque to specification.

Upper fork tube pinch bolt torque:
1.4 – 2.2 m·kg
(10.0 – 16.0 ft·lb)

NOTE: _____

Make certain that tops of fork tubes are adjusted to the same level. If necessary, loosen under bracket pinch bolts and adjust.

10. Install handlebars and torque to specification.

CAUTION: _____

Tighten bolts in stages to maintain an equal gap on each side of the handlebar holder.

Handlebar mounting bolt torque:
1.4 – 2.2 m·kg
(10.0 – 16.0 ft·lb)

11. Reconnect all electrical wiring and check operation.
12. Install headlight bracket and check headlight operation.
13. Install front wheel.
14. Reconnect speedometer and tachometer cables.
15. Reconnect clutch and throttle cables and check operation and adjustment.

5-9. SWING ARM

A. Swing Arm Inspection

1. With rear wheel and shock absorbers removed, grasp the ends of the arm and move from right to left to check for free play.

Swing arm free play:
1 mm (0.04 in)

2. If free play is excessive, remove swing arm and replace swing arm bushing.

B. Swing Arm Lubrication

1. Apply grease to grease fitting on top of pivot with low pressure hand operated gun. Apply until fresh grease appears at both ends of pivot shaft.

Recommended lubricant:
Smooth chassis lube grease

2. Wipe off excess grease.

C. Swing Arm Removal

1. Remove nut on swing arm pivot bolt and tap out bolt with a long aluminum or brass rod.

NOTE: _____

Carefully remove the arm while noting the location of spacing washers and shims. They must be reinstalled in the same positions.

Pivot bolt torque:
5.0 – 8.0 m·kg
(36 – 58 ft·lb)

2. Tap out old bushing from each side of pivot using the long rod.
3. Install new bushings using a press.

NOTE: _____

Do not tap on bushing. Press in new bushings.

5-10 REAR SHOCK ABSORBER

A. Removal

1. Remove the rear shock absorber from the machine.
2. Push down the spring, remove the spring retainer, and remove the spring.

B. Inspection

1. Check the rod, and if it is bent or damaged, replace the shock absorber.
2. Check for oil leakage. If oil leakage is evident, replace the shock absorber.
3. At proper position, operate shock absorber rod to check damping.
Slight resistance should be felt on the compression (down) stroke and considerable resistance should be felt on the return (up) stroke.
4. Install the spring, and install the shock absorber on the machine.

Rear shock absorber

Tightening torque:

2.3 – 3.7 m·kg

(19.6 – 26.8 ft·lb)

5-11. CABLES AND FITTINGS

A. Cable maintenance

NOTE:

See Maintenance and Lubrication intervals charts for additional information. Cable maintenance is primarily concerned with preventing deterioration through rust and weathering and providing for proper lubrication to allow the cable to move freely within its housing. Cable removal is straight-forward and uncomplicated. Removal will not be discussed within this section. For details, see the individual maintenance section for which the cable is an integral part.

WARNING:

Cable routing is very important, for details of cable routing, see the cable routing

diagrams of XS360C Assembly Manual. Improperly routed, assembled or adjusted cables may render the vehicle unsafe for operation.

1. Remove the cable.
2. Check for free movement of cable within its housing. If movement is obstructed, check for fraying or kinking of cable strands. If damage is evident, replace the cable assembly.

CHAPTER 6. ELECTRICAL

6-1. Ignition System	78
A. Ignition Timing	78
B. Spark Gap Test	78
C. Ignition Coil	78
D. Condenser Test	79
E. Spark Plug	79
6-2. Charging System	80
A. AC Generator	80
B. Regulator	81
C. Checking Silicon Rectifier	83
6-3. Battery	83
A. Checking	83
B. Service Life	83
C. Storage	84
6-4. Starter Motor	84
A. Servicing and Troubleshooting	84
6-5. Lighting and Signal System	85
A. Lighting Tests and Checks	85
B. Flasher Self Canceling System	86

CHAPTER 6. ELECTRICAL C.

6-1. IGNITION SYSTEM


A. Ignition Timing

Refer to Chapter 2-5, B. for ignition timing procedure.

B. Spark Gas Test

The entire ignition system can be checked for misfire and weak spark using the Electro Tester. If the Ignition system will fire across a sufficient gap, the engine ignition system can be considered good. If not, proceed with individual component tests until the problem is found.

1. Warm up engine thoroughly so that all electrical components are at operation temperature.
2. Stop engine and connect tester as shown.



1. Electro tester
2. Plug wire from coil
3. Spark plug


3. Start engine and increase spark gap until misfire occurs. (Test at various rpm's between idle and red line.)

Minimum spark gap:
6 mm (0.24 in)

4. If minimum spark gap cannot be reached without misfire, replace spark plug and repeat test. If the problem persists proceed with individual component testing.

C. Ignition Coil

1. Coil spark gap test.
 - a. Remove fuel tank and disconnect ignition coil from wire harness and spark plug.
 - b. Connect Electro Tester as shown.



1. Electro tester
2. Ignition coil
3. Red/White
4. Orange

- c. Connect fully charged battery to tester.
- d. Turn on spark gap switch and increase gap until misfire occurs.


Minimum spark gap:
6 mm (0.24 in)

2. Direct current resistance test.
Use a pocket tester or equivalent ohmmeter resistance and continuity of primary and secondary coil windings.

Standard values:

Primary coil resistance:
 $4.0\Omega \pm 10\%$ at 20°C (68°F)

Secondary coil resistance:
 $9.5\text{k}\Omega \pm 20\%$ at 20°C (68°F)



1. Pocket-Tester
2. Set the tester on the "Resistance" position
3. Ignition coil

D. Capacitor Test


1. Capacitor test

If the contact points show excessive wear, or the spark is weak (but the ignition coil is in good condition), check the condenser.

Capacity test (use electro tester).

- a. Calibrate capacity scale.
- b. Connect tester.
- c. Meter needle will deflect and return to center as condenser is charged. After needle stops, note reading on " μF " scale.

Condenser capacity: $0.24 \mu F$




4. Red/White
5. Orange (L) Gray (R)

nect ohmmeter as shown right.

- c. Resistance reading should be "Infinity" or very close to it.

Minimum resistance: $3M\Omega$.



1. Capacity range 2. Condenser 3. Battery

CAUTION:

After this measurement, the condenser should be discharged by connecting the positive and negative sides with a thick wire to prevent shock.

E. Spark Plug

The life of a spark plug and its discoloring vary according to the habits of the rider. At each periodic inspection, replace burned or fouled plugs with suitable ones determined by the color and condition of the bad plugs. One machine may be ridden only in urban areas at low speeds;


2. Insulation test

- a. Set ohmmeter to highest resistance scale ($\Omega \times 1,000$ or higher).
- b. Remove condenser from engine and con-


another may be ridden for hours at high speed. Confirm what the present plugs indicate by asking the rider how long and how fast he rides. Recommend a hot, standard, or cold plug type accordingly. It is actually economical to install new plugs often since it will tend to keep the engine in good condition and prevent excessive fuel consumption.

1. How to "read" a spark plug (condition)


- a. Best condition: When the porcelain around the center electrode is a light tan color.



- b. If the electrodes and porcelain are black and somewhat oily, replace the plug with a hotter type for low speed riding.



- c. If the porcelain is burned white and/or the electrodes are partially burned away, replace the plug with a colder type for high speed riding.



2. Inspection

Instruct the rider to:

- a. Inspect and clean the spark plug at least once per month or every 1,600 km (1,000 mi.).
- b. Clean the electrodes of carbon and adjust the electrode gap.
- c. Be sure to use the proper reach plug as a replacement to avoid overheating, fouling or piston damage.

Spark plug type: BP-6ES NGK or N-7Y Champion
--


Spark plug gap: 0.7 — 0.8 mm (0.027 — 0.031 in)
--

6-2. CHARGING SYSTEM

A. A.C. Generator

1. Checking method

- a. Connect D.C. voltmeter to the battery terminals.



- b. Start engine.
- c. Accelerate engine to approximately 2,000 rpm or more and check generated voltage.

Generated voltage: $14.5 \pm 0.3V$

- d. If the indicated voltage cannot be reached then perform the tests in step 2.

NOTE:


Never disconnect wires from the battery while the generator is in operation. If the battery is disconnected, the voltage across the generator terminals will increase, damaging the semiconductors.

2. Resistance test of field coil and armature coil.

Check the resistance between terminals U-V, V-W, W-U, and $F_1 - F_2$. If resistance is out of specification, coil is broken. Check the coil connections. If the coil connections are good, then the coil is broken inside and it should be replaced.

Field coil resistance: $F_1 - F_2$
 $4.0 \Omega \pm 15\%$ at $20^\circ C$ ($68^\circ F$)

Armature coil resistance:
 (U-V, V-W, W-U)
 Each $0.72 \Omega \pm 10\%$
 at $20^\circ C$ ($68^\circ F$)



B. Regulator

1. General


This circuit consists of the battery which first provides voltage to the rotor field windings, regulator, ACG (alternating current generator), rectifier and main switch.

- a. The regulator's function is to pass a controlled amount of voltage to the rotor windings which creates a magnetic field that produces charging voltage in the stator.




- b. The regulator operates as a magnetic switch. As charging voltage rises, part of this voltage is routed through an electro-magnet in the regulator. Rising voltage creates greater regulator magnetism, which in turn pulls the central contact

point through different positions. Different resistors are switched into the circuit as this central contact point moves. These resistors cut down the amount of voltage passing, to the rotor windings, which reduces the charging voltage output.




2. Adjustment

- a. Charging voltage output can be controlled at the regulator. Inside the housing is a screw that pushes against a flat spring steel plate. This is the adjusting screw.



- b. Start the engine. Disconnect the fuse box wire leading to the battery and hook up a voltmeter from the fuse box to ground. Accelerate the engine to 2,500 rpm. The voltmeter should read 14.5 – 15 volts DC. If it varies from this amount, twist the adjusting screw in to raise the charging voltage or out to reduce the voltage.




Checking resistance

Hook up ohmmeter (0 – 200 ohms).


One probe attached to the black wire and one attached to the regulator base.

STANDARD RESISTANCE:
 $10.5 \pm 2 \Omega$ at 20°C (68°F)




Hook one probe to brown wire and other probe to green wire.

STANDARD RESISTANCE:
 $140 \pm 10 \text{ ohm}$ at 20°C (68°F)



C. Checking Silicon Rectifier

1. Check silicon rectifier as specified using Yamaha Pocket Tester.



Checking element	Pocket test connecting point		Good	Replace element (shorted)	Replace element (open)
	(+) (red)	(-) (black)			
D ₁	B	U	○	○	×
	U	B	×	○	×
D ₂	B	V	○	○	×
	V	B	×	○	×
D ₃	B	W	○	○	×
	W	B	×	○	×
D ₄	U	E	○	○	×
	E	U	×	○	×
D ₅	V	E	○	○	×
	E	V	×	○	×
D ₆	W	E	○	○	×
	E	W	×	○	×

○ Continuity × Discontinuity (∞)

Even if one of elements is broken, replace assembly.

CAUTION: _____

The silicon rectifier can be damaged if subject to overcharging. Special care should be taken to avoid a short circuit and/or incorrect connection of the posi-

tive and negative leads at the battery. Never connect the rectifier directly to the battery to make a continuity check.

6-3. BATTERY

A. Checking

1. If battery sulfation (white accumulations) occurs on plates due to lack of battery electrolyte, the battery should be replaced.
2. If the bottoms of the cells are filled with corrosive material falling off the plates, the battery should be replaced.
3. If the battery shows the following defects, it should be replaced:
 - a. The voltage will not rise to a specific value even after many hours of charging.
 - b. No gas formation occurs in any cell.
 - c. The battery requires a charging voltage of more than regulating voltage in order to supply a current of 1.20A for 10 hours.

B. Service Life

The service life of a battery is usually 2 to 3 years, but lack of care as described below will shorten the life of the battery.

1. Negligence in keeping battery topped off with distilled water.
2. Battery being left discharged.
3. Over-charging with heavy charge.
4. Freezing.
5. Filling with water or sulfuric acid containing impurities.
6. Improper charging voltage/current on new battery.

Battery	12V, 12AH
Electrolyte	Specific gravity: 1.28 Quantity: 800 cc
Initial charging current	1.20A/25 hours (new battery)
Recharging current	0.55/10 hours (or until specific gravity reaches 1.28)
Refill fluid	Distilled water (to maximum level line)
Refill period	Check once per month (or more often, as required)

C. Storage

If the motorcycle is not to be used for a long time, remove the battery and have it stored. The following instructions should be observed by shops equipped with charger.

1. Recharge the battery.
2. Store the battery in a cool, and dry place.
3. Recharge the battery before reinstallation.

6-4. Starter motor

A. Servicing and Troubleshooting

1. Armature

- a) If the commutator surface is dirty, clean with #600 grit sandpaper as shown in the drawing below.

After sanding, wash thoroughly with electrical contact cleaner and dry with high-pressure air.

- b) The mica insulation between commutator segments should be 0.5 – 0.8 mm, below the segment level. If not, scrape to proper limits with appropriately shaped tool, (A hacksaw blade can be ground to fit).

- c) Each commutator segment should show zero ohm resistance to the others seg-

ments and at least three million ohms resistance to the core. If there is less than 00 ohms resistance to the core, or one of the segments is open, replace the armature.

In addition, the armature can be placed on a "growler" (testing device) and checked magnetically for internal shorts. Follow manufacturer's test recommendations.

- d) If the commutator surface shows heavy scoring, it can be turned down on a lathe or commutator turning machine. Check the specification chart for minimum allowable commutator diameter. Recheck mica insulation depth (undercut) and scrape to proper limits.

NOTE: _____

Should turning be required, check the condition of the cover bearings, armature electrical properties starter amperage draw and rpm and, finally, carbon brushes.

Cover bearings.

Replace as necessary.

2. Carbon brushes

- a) Check brush length and replace if at or near limits.
- b) Check brush spring pressure. Replace if over/under specs.

NOTE: _____

Spring pressure is measured with a nominal length brush installed. Lift until spring starts to lift off brush and note reading on scale. (Nominal: 800 gr.)

- c) Clean the brush holders thoroughly. Use clean solvent, a soft-bristled brush, and dry with high-pressure air.


3. Yoke

- a) If the yoke area is dirty, clean with clean solvent and dry with high-pressure air.
- b) Yoke coil resistance is 0.05 ohm.
If coil resistance is more than 0.055 ohm

or less than 0.045 ohm, replace it.
If the yoke shows leakage to ground (resistance is less than 0.1 million ohms) replace it. (20°C)

NOTE:

Immediately after cleaning, the yoke may show some insulation leakage. Wait for it to thoroughly dry before checking or reinstalling.



4. Covers

- a) Check oil seals for hardening, cracking, worn lips. Replace as necessary.

NOTE:


During reassembly, pre-lube the lips of all seals with "white" grease. (lithium soap base grease)

- b) Clean the bearings thoroughly, lightly oil each and check for hard spots during rotation, cracked or broken balls and/or races, etc.

Replace as necessary.

NOTE:

During reassembly, all non-sealed bearings should be given a light coating of 20W. or 30W. "SD" (MS) motor oil.



6-5. LIGHTING AND SIGNAL SYSTEMS

A. Lighting tests and checks

The battery provides power for operation of the horn, taillight, stoplight neutral light and flasher light. If none of the above operates, always check battery voltage before proceeding further. Low battery voltage indicates either a faulty battery, low battery water, or a defective charging system. See section, 6-2, charging system, for checks of battery and charging system.

1. Horn does not work.
 - a. Check for 12V on brown wire to horn.
 - b. Check for good grounding of horn (pink wire) when horn button is pressed.
2. Brake light does not work.
 - a. Check bulb.
 - b. Check for 12V on yellow wire to brake light.
 - c. Check for 12V on brown wire to each brake light switch (front brake and rear brake switches).
3. Taillight does not work.
 - a. Check bulb.
 - b. Check for 12V on blue wire.
 - c. Check for ground on black wire to tail/brake light assembly.

4. Flasher light(s) do not work.

a. Check bulb.

b. Right circuit:

1) Check for 12V on dark green wire to light.

2) Check for ground on black wire to light assembly.

c. Left circuit:

1) Check for 12V on dark brown wire to light.

2) Check for ground on black wire to light assembly.

d. Right and left circuits do not work:

1) Check for 12V on brown/white wire to flasher switch on left handlebar.

2) Check for 12V on brown wire to flasher relay.

3) Replace flasher relay.

4) Replace flasher switch.

e. Check flasher self canceling system. (Refer to flasher self canceling system.)

5. Neutral light does not work.

a. Check bulb.

b. Check for 12V on sky blue wire to neutral switch.

c. Replace neutral switch.

6. Oil caution light does not work.

a. Place shift lever in neutral to check bulb.

b. Replace bulb.

c. Check for 12V on black/red wire to oil level switch.

d. Replace oil level switch.

B. Flasher Self Canceling System

1. Description

This system automatically turns the flasher light off after you have changed course or turned corner so you can safely forget about turning off the signal. It is electronically operated depending on the time lapsed or the distance travelled after the handle switch has been applied.

In other words, the signal is automatically turned off when the vehicle has travelled over a certain distance at low speeds or while the signal light at an intersection is "red", or after a short lapse of time from

when you changed course at high speeds.


2. Operation

The handle switch lever has the following three positions; L (left), OFF and R (right). The switch lever is pushed back to its home position by spring force when it is released from your finger, but the signal continues to light up over a certain time or distance as noted already.

If the switch lever is depressed into OFF, the signal will turn off immediately, independent of the flasher canceling unit. At normal operation, therefore, the switch lever should be pushed into OFF as soon as you have turned a corner or changed course.

The flasher canceling unit is reset each time the switch lever is turned to R or L and begins to count time or distance. If the turn signal is required to continue turning on more than 100 meters (328 feet) or 10 seconds, the switch lever must be kept in the position to which it is turned or repeatedly turned to the same position.

In other words, both time and distance are calculated from the moment that the handle switch lever is applied, and therefore, the handle switch can be turned on and off as often as possible.



3. Inspection

If the flasher auto canceling system should become inoperative, proceed as follows:

- 1) Pull off the 6-p connector from the flasher canceling unit, and operate the handle switch.

If the signal operates normally in L, R and OFF:

- | | |
|--------------------------------|-------------------------|
| a) Flasher unit | } are in good condition |
| b) Bulb | |
| c) Lighting circuit | |
| d) Handle switch light circuit | |

Therefore, any one of the following is considered to be defective:


- a) Flasher canceling unit
 - b) Handle switch reset circuit
 - c) Speedometer sensor circuit
- 2) Pull off the 6-p connector from the flasher canceling unit, and connect a tester ($\Omega \times 100$ range) across the white/green and the black lead wires on the wire harness side. Turn the speedometer shaft, and if the tester needle swings back and forth four times between 0 and $\infty\Omega$, the speedometer sensor circuit is in good condi-

tion. If not, check the sender and wire-harness, and replace any of these as necessary.

- 3) Pull off the 6-p connector from the flasher canceling unit, and check if there is continuity between the yellow/red lead wire on the wireharness side and the chassis.

Flasher switch OFF..... $\infty\Omega$
Flasher switch L or R 0Ω

If the tester needle does not swing as indicated above, check the handle switch circuit and wire harness.



1. Flasher cancelling unit B: Black Br: Brown
W/G: White/Green Y/G: Yellow/Green
Y/R: Yellow/Red

- 4) If no defect is found with the above three check-ups and the flasher canceling systems is still inoperative, replace the flasher canceling unit.
- 5) If the signal flashes only when the handle switch lever is turned to L or R and it turns off immediately when the handle switch lever is turned to OFF, replace the flasher canceling unit.

4. Notes on handling

- 1) The flasher canceling system does not always operate at a proper time, because it is so designed that only when the requirements of both time and distance are met, it functions. It is advisable to make it a habit to turn the handle switch to OFF with your finger each time it is used.
- 2) Current continues to flow through the flasher relay after the signal is turned off automatically, therefore, it should preferably be turned off manually each time.
- 3) If the handle switch is turned on with wrong wiring, the system may become inoperative. Check for correct wiring after it is re-connected.
- 4) The signal can be used with the flasher canceling unit being disconnected. It can be operated manually. Should the system fail to operate, pull off the connector and the turn signal can be operated manually.

CHAPTER 7. APPENDICES

7-1. TROUBLESHOOTING GUIDE	90
7-2. SPECIFICATION	92
A. General	92
B. Engine	92
C. Chassis	99
D. Electrical	102

CHAPTER 7. APPENDICES

7-1. TROUBLESHOOTING GUIDE

The following guide is not complete in itself. If a problem is found within an individual component mentioned in the chart, refer to the section or chapter involved for inspection procedures.

1. Will not start or difficult to start
 - a. Ignition system

Possible cause	Remedy
No spark	<ol style="list-style-type: none">1. Check ignition main switch.2. Check engine stop switch.3. Check points assembly.4. Check condenser.5. Check wiring.6. Check ignition coil.7. Check high tension lead.8. Check spark plug.9. Check ignition timing.
Weak or Intermittent spark	<ol style="list-style-type: none">1. Use Electro Tester, spark gap test2. Check spark plug.3. Check high tension lead.4. Check ignition assembly.

b. Air/Fuel systems

Possible cause	Remedy
No fuel	<ol style="list-style-type: none">1. Check fuel tank.2. Check petcock.3. Remove fuel pipe, check fuel flow.
Intermittent or poor fuel flow	<ol style="list-style-type: none">1. Clean fuel tank, check cap vent.2. Clean petcock.3. Remove carburetor, service.
Bad fuel	<ol style="list-style-type: none">1. Flush fuel system, complete.2. Add fresh fuel, proper grade.
Blocked air intake or malfunction	<ol style="list-style-type: none">1. Clean and lube filter.2. Check reed valve assembly.

c. Engine/Exhaust systems.

Possible cause	Remedy
Incorrect compression pressure	<ol style="list-style-type: none">1. If compression is too high, check for excessive carbon buildup.2. No compression or low compression, check:<ol style="list-style-type: none">a. Cylinder head gasket.b. Valve clearance.c. Worn valve seat.d. Piston, rings, cylinder.
Blocked exhaust system	<ol style="list-style-type: none">1. Check muffler/sbrk arrester silencer.2. Check exhaust pipe for internal damage.

2. Poor idle and/or low speed performance

a. Ignition system

Possible cause	Remedy
Spark plug fouled or incorrect gap	Clean and gap, or replace if necessary.
Contact points bad	Clean and gap, or replace if necessary.
Incorrect ignition timing	Reset timing.
Weak spark	Check ignition coil and condenser.

b. Air/Fuel systems

Possible cause	Remedy
Tank cap vent plugged.	Clean or repair as necessary.
Fuel petcock plugged	Clean or repair as necessary.
Carburetor slow speed system inoperative	Clean or repair as necessary.
Pilot screw out of adjustment or plugged	Adjust or clean as necessary.
Carburetor float level incorrect	Measure and adjust as required.
Starter lever on	Push lever off.
Air leak	Repair.
Carburetor not level	Level.

c. Engine/Exhaust system. See "No start" section.

3. Poor mid-range and high speed performance

a. Ignition systems

Possible cause	Remedy
Spark plug gap incorrect	Clean and gap or change spark plug if necessary.
Ignition timing incorrect	Reset.
Points set too close	Regap/Reset timing.

b. Air/Fuel systems

Possible cause	Remedy
Dirty air filter element	Clean.
Carburetor float level incorrect	Measure and adjust if required.
Incorrect main jet size	Remove jet and check size.
Incorrect jet needle clip position	Check position of clip in needle.
Carburetor not level	Level.

7-2. SPECIFICATION

A. GENERAL

1. MODEL	
1) Model (I.B.M. No.)	XS360C (1L9)
2) Frame I.D. and Starting Number	1L9-000101
3) Engine I.D. and Starting Number	1L9-000101
2. DIMENSION	
1) Overall Length	2,045 mm (80.5 in)
2) Overall Width	845 mm (33.3 in)
3) Overall Height	1,100 mm (43.3 in)
4) Seat Height	800 mm (31.5 in)
5) Wheelbase	1,340 mm (52.8 in)
6) Minimum Ground Clearance	155 mm (6.1 in)
3. WEIGHT	
1) Net Weight	159 kg (350 lb)
4. PERFORMANCE	
1) Climbing Ability	28°
2) Minimum Turning Radius	2,200 mm (86.6 in)
3) 0 - 400 mm Acceleration Time	15.2 sec
4) Braking Distance	14 m @ 50 km/h (45.9 ft @ 31 mph)
5) Fuel Consumption	36 km/lit @ 60 km/h (84.7 mi/gal @ 37 mph)


B. ENGINE

1. DESCRIPTION	
1) Engine Type	Air cooled, 4-stroke, SOHC Twin, parallel forward incline
2) Engine Model	1L9
3) Displacement	358 cc (21.85 cu.in)
4) Bore x Stroke	66 x 52.4 mm (2.528 x 2.063 in)
5) Compression Ratio	8.7 : 1
6) Starting System	Kick and electric starter
7) Ignition System	Battery ignition
8) Lubrication System	Wet sump
2. CYLINDER HEAD	
1) Combustion Chamber Volume	23.3 cc (1.189 cu.in) BP6ES
2) Combustion Chamber Type	Dome + Squish
3) Head Gasket Thickness	1.0 mm (0.04 in)
4) Tightening Torque:	
Cylinder Head Holding Nut (M10P1.25)	3.0 - 3.5 m-kp
Bolt (M6P1.0)	0.8 - 1.2 m-kp (6 - 8.5 ft-lb)

Spark Plug (M14P1.25)		1.8 - 2.2 m-kg (5.8 - 8.7 ft-lb)											
3. CYLINDER													
1) Material		Aluminum alloy with cast iron sleeve											
2) Bore Size		66 $+0.02$ mm (2.59 $+0.0008$ in)											
3) Taper Limit		0.05 mm (0.002 in)											
4) Out of Round Limit		0.01 mm (0.0004 in)											
4. PISTON													
1) Piston Skirt Clearance		0.030 - 0.050 mm (0.0012 - 0.0019 in)											
2) Piston Oversize		<table><tr><td>66.25mm (2.608 in)</td><td>66.50mm (2.618 in)</td><td>66.75mm (2.628 in)</td><td>67.00mm (2.638 in)</td></tr></table>				66.25mm (2.608 in)	66.50mm (2.618 in)	66.75mm (2.628 in)	67.00mm (2.638 in)				
66.25mm (2.608 in)	66.50mm (2.618 in)	66.75mm (2.628 in)	67.00mm (2.638 in)										
3) Piston Pin Outside Diameter x Length		16 -0.005 mm x 54.5 -0.3 mm (0.63 -0.0002 in x 2.146 -0.0116 in)											
5. PISTON RING													
1) Piston Ring Design (Top)		Plain Ring (1.5 mm)(0.059 in)											
(2nd)		Plain Ring (1.5 mm)(0.059 in)											
(Oil ring)		With Expander (2.45 mm)(0.096 in)											
2) Ring End Gap (Installed, Top)		0.2 - 0.4 mm (0.008 - 0.016 in)											
(Installed, 2nd)		0.2 - 0.4 mm (0.008 - 0.016 in)											
(Installed, Oil)		0.2 - 0.9 mm (0.008 - 0.035 in)											
3) Ring Groove Side Clearance (Top)		0.04 - 0.08 mm (0.0016 - 0.0032 in)											
(2nd)		0.03 - 0.07 mm (0.0012 - 0.0028 in)											
(Oil)		—											
6. BIG END BEARING													
1) Type		Plain Bearing											
2) Oil Clearance		0.021 - 0.045 mm (0.0008 - 0.0018 in)											
3) Bearing Size		<table><tr><td>1.(Blue)</td><td>15 $+0.004$ mm (0.591 $+0.00016$ in)</td></tr><tr><td>2.(Black)</td><td>15 -0.004 mm (0.591 -0.00016 in)</td></tr><tr><td>3.(Brown)</td><td>15 -0.004 mm (0.591 -0.00016 in)</td></tr><tr><td>4.(Green)</td><td>15 -0.008 mm (0.591 -0.00031 in)</td></tr></table>	1.(Blue)	15 $+0.004$ mm (0.591 $+0.00016$ in)	2.(Black)	15 -0.004 mm (0.591 -0.00016 in)	3.(Brown)	15 -0.004 mm (0.591 -0.00016 in)	4.(Green)	15 -0.008 mm (0.591 -0.00031 in)			
1.(Blue)	15 $+0.004$ mm (0.591 $+0.00016$ in)												
2.(Black)	15 -0.004 mm (0.591 -0.00016 in)												
3.(Brown)	15 -0.004 mm (0.591 -0.00016 in)												
4.(Green)	15 -0.008 mm (0.591 -0.00031 in)												
7. CAMSHAFT													
1) Cam Drive Type		Chain (Center Side)											
2) Number & Type of Bearing		3 Bearings, Cylinder Head Direct Support											
3) Bearing Dimensions		<table><tr><td>Cap I.D.</td><td>Shaft O.D.</td><td>Clearance</td></tr><tr><td>23 $+0.021$ mm (0.906 $+0.0082$ in)</td><td>23 -0.020 mm (0.906 -0.00130 in)</td><td>0.020 - 0.054 mm (0.00079 - 0.00213 in)</td></tr></table>	Cap I.D.	Shaft O.D.	Clearance	23 $+0.021$ mm (0.906 $+0.0082$ in)	23 -0.020 mm (0.906 -0.00130 in)	0.020 - 0.054 mm (0.00079 - 0.00213 in)					
Cap I.D.	Shaft O.D.	Clearance											
23 $+0.021$ mm (0.906 $+0.0082$ in)	23 -0.020 mm (0.906 -0.00130 in)	0.020 - 0.054 mm (0.00079 - 0.00213 in)											

4) Cam Dimensions

	Cam Height "A"	Limit	Base Circle "B"	Limit	Lift "C"
IN	38.85 ± 0.05 mm (1.529 ± 0.0019 in)	38.70 mm (1.527 in)	32.23 ± 0.05 mm (1.269 ± 0.0019 in)	32.08 mm (1.263 in)	6.85 mm (0.269 in)
EX	38.89 ± 0.05 mm (1.531 ± 0.0019 in)	38.74 mm (1.525 in)	32.05 ± 0.05 mm (1.262 ± 0.0019 in)	31.90 mm (1.256 in)	6.89 mm (0.271 in)



5) Valve Timing

	OPEN	CLOSE	DURATION	OVERLAP
IN	BTDC 24°	ABDC 60°	264°	50°
EX	BBDC 58°	ATDC 26°	264°	

6) Camshaft Deflection Limit 0.03 mm (0.0012 in)

7) Cam Chain


Type	TSUBAKIMOTO BF05M
Pitch/Number of Links	7.774 mm (0.3060 in) / 92L
Sprocket Ratio (Teeth)	34/17

9. ROCKER ARM & ROCKET SHAFT

1) Rocker Arm Inner Diameter	13 ± 0.018 mm (0.512 ± 0.0007 in)
2) Rocker Arm Shaft Diameter	13 ± 0.018 mm (0.512 ± 0.0007 in)
3) Clearance	0.016 - 0.054 mm (0.00063 - 0.00212 in)
4) Lift Ratio	X : Y = 32.05 : 33.62 mm (1.262 : 1.324 in)

10. VALVE, VALVE SEAT & VALVE GUIDE

1) Valve Per Cylinder	2 pcs.
2) Valve Clearance (In Cold Engine)	IN : 0.08 - 0.12 mm (0.0031 - 0.0047 in) EX : 0.16 - 0.20 mm (0.0063 - 0.0078 in)
3) Dimensions	
Valve Head Diameter "A"	IN: 35.5 ± 0.1 mm (1.398 ± 0.004 in) EX: 30 ± 0.1 mm (1.181 ± 0.004 in)
Valve Face Width "B"	IN: 2.3 mm (0.091 in) EX: 2.3 mm (0.091 in)
Valve Seat Width "C"	IN: 1 0.1 mm (0.039 \pm 0.0039 in) EX: 1 0.1 mm (0.039 \pm 0.0039 in)
Valve Margin Thickness "D"	IN: 1 0.2 mm (0.039 \pm 0.0079 in) EX: 1 0.2 mm (0.039 \pm 0.0079 in)



Valve Stem Diameter	IN: $7 \begin{smallmatrix} -0.010 \\ -0.025 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} -0.0004 \\ -0.0009 \end{smallmatrix}$ in)
Valve Guide Diameter	EX: $7 \begin{smallmatrix} -0.030 \\ -0.045 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} -0.0012 \\ -0.0018 \end{smallmatrix}$ in)
Valve-Stem-to-Stem Clearance	IN: $7 \begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} +0.0005 \\ 0 \end{smallmatrix}$ in)
	EX: $7 \begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} +0.0005 \\ 0 \end{smallmatrix}$ in)
4) Valve Face Runout Limit	IN: 0.010 - 0.037 mm (0.00039 - 0.00145 in) EX: 0.030 - 0.057 mm (0.0012 - 0.0022 in) IN & EX 0.03 mm or less (0.0012 in)
11. VALVE SPRING	
1) Free Length	INNER (IN & EX): 39.3 mm (1.547 in) OUTER("): 42.8 mm (1.685 in)
2) Spring Rate (kg/mm)	INNER ("): $k_1 = 1.93$ $k_2 = 2.47$ OUTER("): $k_1 = 4.19$ $k_2 = 5.49$
3) Installed Length (Valve Closed)	INNER ("): 33.0 mm (1.299 in) OUTER("): 37.0 mm (1.457 in)
4) Installed Pressure (Valve Closed)	INNER ("): 12.1 ± 1.2 kg (26.7 2.6 lb) OUTER("): 24.4 ± 1.7 kg (53.8 3.8 lb)
5) Compressed Length (Valve Open)	INNER ("): 25.8 mm (1.015 in) OUTER("): 29.8 mm (1.173 in)
6) Compressed Pressure (Valve Open)	INNER ("): 29.9 ± 2.2 kg (65.9 \pm 4.85 lb) OUTER("): 63.9 ± 4.5 kg (141 \pm 9.92 lb)
7) Wire Diameter (Valve Open)	INNER ("): 3.0 mm (0.118 in) OUTER("): 4.4 mm (0.173 in)
8) Winding O.D. (Valve Open)	INNER ("): 22.4 mm (0.882 in) OUTER("): 32.0 mm (1.260 in)
9) Number of Windings (Valve Open)	INNER ("): 7.75 turns OUTER("): 6.25 turns
10) Tilt Limit (Valve Open)	INNER ("): 1.7 mm, 2.5° (0.067 in) OUTER("): 1.9 mm, 2.5° (0.075 in)
12. CRANKSHAFT	
1) Crankshaft Deflection	0.02 mm (0.0008 in)
2) Con-Rod Large End Clearance	0.160 - 0.264 mm (0.0063 - 0.0104 in)
3) Clearance between Crank & Crankcase	0.05 - 0.25 mm (0.002 - 0.010 in)

<p>13. CONNECTING ROD</p> <p>1) Big End I.D.</p> <p>2) Small End I.D.</p> <p>3) Difference of Each Rod Weight</p> <p>14. CRANK BEARING</p> <p>1) Oil Clearance</p> <p>2) Bearing Size</p>	<p>41 $+0.024$ mm (1.614 $+0.0009$ in)</p> <p>16 $+0.028$ mm (0.630 $+0.0011$ in)</p> <p>5 gr or less</p> <p>0.020 - 0.044 mm (0.00079 - 0.00157 in)</p> <p>1. (Blue) 15 $+0.012$ mm (0.591 $+0.00047$ in)</p> <p>2. (Black) 15 $+0.008$ mm (0.591 $+0.00031$ in)</p> <p>3. (Brown) 15 $+0.004$ mm (0.591 $+0.00016$ in)</p> <p>4. (Green) 15 -0.004 mm (0.591 -0.00016 in)</p>
<p>15. CLUTCH</p> <p>1) Clutch Type</p> <p>2) Clutch Operating Mechanism</p> <p>3) Primary Reduction Ratio and Method</p> <p>4) Primary Reduction Gear Backlash Tolerance</p> <p>5) Friction Plate - Thickness/Quantity - Wear Limit</p> <p>6) Clutch Plate - Thickness/Quantity - Warp Limit</p> <p>7) Clutch Spring - Free Length/Quantity - Minimum Length</p> <p>8) Clutch Housing Radial Play (Wear Limit)</p> <p>9) Push Rod Bending Limit</p> <p>10) Tightening Torque Primary Drive Gear (M10P1.25) Clutch Spring Screw(M6P1.0)</p>	<p>Wet, Multiple Type</p> <p>Inner Push Type, Screw Push System</p> <p>78/24 (3.250), Spar Gear</p> <p>A-C, B-D, C-E, D-F</p> <p>3 mm (0.12 in) / 7 pcs</p> <p>2.7 mm (0.11 in)</p> <p>1.6 mm (0.063 in) / 6 pcs</p> <p>0.05 mm (0.002 in)</p> <p>34.6 mm (1.362 in) / 4 pcs</p> <p>33.6 mm (1.323 in)</p> <p>0.009 - 0.043 mm (0.00035 - 0.00169 in)</p> <p>0.2 mm (0.008 in)</p> <p>4.0 - 4.5 m·kg (29 - 33 ft·lb)</p> <p>0.8 - 1.2 m·kg (6 - 8.5 ft·lb)</p>
<p>16. TRANSMISSION</p> <p>1) Type</p> <p>2) Gear Ratio 1st 2nd 3rd 4th 5th 6th</p> <p>3) Bearing Type - Main Axle (Left)</p>	<p>Constant mesh, 6-speed forward</p> <p>35/14 2.500</p> <p>32/88 1.777</p> <p>29/21 1.380</p> <p>27/24 1.125</p> <p>25/26 0.961</p> <p>26/30 0.866</p> <p>Needle Bearing (φ 20 - φ 30 - 15)</p>

<ul style="list-style-type: none"> - Main Axle (Right) - Drive Axle (Left) - Drive Axle (Right) - Drive Axle (Left) <p>4) Oil Seal Type</p> <p>5) Secondary Reduction Ratio and Method</p> <p>6) Tightening Torque - Drive Sprocket</p>	<p>Ball Bearing (5205)</p> <p>Ball Bearing (6305N Special)</p> <p>Needle Bearing (ϕ 20 - ϕ 33 - 15)</p> <p>SD-35-62-6</p> <p>40/16 2.500</p> <p>5 - 8 m-kG (36 - 58 ft-lb)</p>
<p>17. SHIFTING MECHANISM</p> <p>1) Type</p> <p>2) Oil Seal Type (Change Lever)</p> <p>3) Tightening Torque - Change Pedal (M6P1.0)</p>	<p>Cam Drum, Return Type</p> <p>S-12-22-5</p> <p>0.8 - 1.2 m-kG (6 - 8.5 ft-lb)</p>
<p>18. KICK STARTER</p> <p>1) Type</p> <p>2) Oil Seal Type (Kick Axle)</p> <p>3) Kick Clip Friction Tension</p> <p>4) Tightening Torque - Kick Crank (M8P1.25)</p>	<p>Bendix Type</p> <p>SD-20-30-7</p> <p>0.8 - 1.2 kg (1.8 - 3.1 lb)</p> <p>1.5 - 2.5 m-kG (11 - 18 ft-lb)</p>
<p>19. CRANKCASE</p> <p>1) Tightenign Torque</p> <p style="padding-left: 40px;">- (M8P1.25)</p> <p style="padding-left: 40px;">- (M6P1.0)</p>	<p>2.0 - 2.4 m-kG (14.5 - 17 ft-lb)</p> <p>0.8 - 1.2 m-kG (6 - 8.5 ft-lb)</p>
<p>20. INTAKE</p> <p>1) Air Cleaner - Type/Quantity</p> <p>2) Cleaner Cleaning Interval</p> <p>3) Valve Clearance</p>	<p>Dry, Foam Rubber / 2 pcs</p> <p>Every 8,000 km (5,000 mile)</p> <p>See No.10 - 2) Valve, Valve Seat & Valve Guide</p>
<p>21. CARBURETOR</p> <p>1) Type and Manufacturer / Quantity</p> <p>2) I.D. Mark</p> <p>3) Main Jet (MJ)</p> <p>4) Air Jet (AJ)</p> <p>5) Jet Needle-Clip Position (JN)</p> <p>6) Needle Jet (NJ)</p> <p>7) Throttle Valve (Th.V)</p> <p>8) Pilot Jet (PJ)</p>	<p>BS34 MIKUNI / 2 pcs</p> <p># 135</p> <p>ϕ 0.6</p> <p>4FP21-3</p> <p>X-6</p> <p># 145</p> <p># 17.5</p>

9) Air Screw (Turns Out) (AS)	1-1/2 ± 1/2
10) Starter Jet (GS)	GS ₁ : #40, GS ₂ : φ 0.6, AB ₁ : φ0.7
11) Float Level (FL)	26.6 ± 2.5 mm (1.047 ± 0.098 in)
12) Vacuum Synchronization (—)	5 mmHg or less
13) Idling Engine Speed (—)	1,200 ± 50 rpm
22. LUBRICATION	
1) Engine Sump Oil Q'ty (Exchange)	Oil Exchange : 2.0 lit (2.1 qt) Filter & Oil Exchange : 2.3 lit (2.4 qt) Engine Overhaulint : 2.6 lit (2.7 qt)
2) Oil Grade	Shell X-100 or Yamalube 4-cycle
3) Oil Type	SAE 20W/40 (more than 5°C [41°F]) SAE 10W/30 (below 15°C [59°F])
4) Oil Pump Type	Trochoid Pump
5) Trochoid Pump Specifications	
- Top Clearance	0.10 - 0.18 (0.0039 - 0.0071 in)
- Tip Clearance	0.03 - 0.09 mm (0.0012 - 0.0035 in)
- Side Clearance	0.03 - 0.09 mm (0.0012 - 0.0035 in)
- Oil Pump Volume	1.2 lit/min at 500 rpm
6) Relief Valve Operating Pressure	5 ± 0.5 kg/cm ² (71 ± 7 psi)
7) Bypass a Valve Setting Pressure	1 ± 0.2 kg/cm ² (14 ± 3 psi)
8) Lubrication Chart	

C. CHASSIS

<p>1. FRAME</p> <p>1) Frame Design</p> <p>2) Tightening Torque</p> <p>- Engine Mounting Bolt (M8P1.25)</p> <p>- " (M10P1.25)</p>	<p>Semi Double Cradle, High Tensil Tube Frame</p> <p>1.3 - 2.1 m-kG (9.5 - 15 ft-lb)</p> <p>2.7 - 4.2 m-kG (19.5 - 30 ft-lb)</p>
<p>2. STEERING SYSTEM</p> <p>1) Caster</p> <p>2) Trail</p> <p>3) Number & Size of Balls in Steering Head</p> <p>- Upper Race</p> <p>- Lower Race</p> <p>4) Steering Lock to Lock</p> <p>5) Tightening Torque</p> <p>- Steering Shaft Fitting Nut (M14P1.25)</p> <p>- (M25P1.0)</p> <p>- Stem Pinch Bolt (M8P1.25)</p> <p>- Handle Bar Mounting Bolt (M10P1.25)</p>	<p>63°30'</p> <p>81 mm (3.19 in)</p> <p>19 pcs., 1/4 in</p> <p>19 pcs., 1/4 in</p> <p>43° each (L and R)</p> <p>4.2 - 6.5 m-kG (30 - 47 ft-lb)</p> <p>3.5 - 4.0 m-kG (25 - 29 ft-lb)</p> <p>0.9 - 1.4 m-kG (6.5 - 10 ft-lb)</p> <p>1.8 - 2.8 m-kG (13 - 20 ft-lb)</p>
<p>3. FRONT SUSPENSION</p> <p>1) Type</p> <p>2) Damper Type</p> <p>3) Front Fork Spring</p> <p>- Free Length</p> <p>- Wire Diameter x Winding Diameter</p> <p>- Spring Constant</p> <p>4) Front Fork Travel</p> <p>5) Inner Tube O.D.</p> <p>6) Oil Seal Type</p> <p>7) Front Fork Oil Q'ty & Type</p> <p>8) Tightening Torque</p> <p>- Under Bracket and Inner Tube</p> <p>- (M10P1.25)</p> <p>- Handle Crown and Inner Tube</p> <p>(M8P1.25)</p>	<p>Telescopic Fork</p> <p>Oil Damper, Coil Spring</p> <p>484 mm (19.05 in)</p> <p>3.8 mm x 23 mm (0.15 x 0.91 in)</p> <p>k = 0.4 kg/mm (0 - 100 mm)</p> <p>k = 0.475 kg/mm (100 - 140 mm)</p> <p>140 mm (5.5 in)</p> <p>33 mm (1.30 in)</p> <p>SD 33-46-10.5</p> <p>130 cc (4.4 oz) each leg</p> <p>Yamaha Fork Oil or SAE10W/30 Motor Oil</p> <p>3.0 - 4.0 m-kG (21 - 29 ft-lb)</p> <p>0.9 - 1.3 m-kG (6.5 - 9.5 ft-lb)</p>
<p>4. REAR SUSPENSION</p> <p>1) Type</p> <p>2) Damper Type</p>	<p>Swing Arm</p> <p>Oil Damper, Coil Spring</p>

3) Shock Absorber Travel	80 mm (3.15 in)
4) Shock Absorber Spring	
- Set Length	193 mm (7.6 in)
- Free Length	205 mm (8.1 in)
- Wire Diameter x Winding Diameter	7.0 mm (0.27 in) x 56.5 mm (2.22 in)
- Spring Constant	K = 1.6 kg/mm
5) Swing Arm Free Play (Limit)	1 mm (0.04 in)
6) Pivot Shaft - Outside Diameter	16 mm (0.63 in)
7) Tightening Torque:	
- Rear Shock Absorber (Upper)	2.2 - 3.5 m·kg (16 - 25 ft·lb)
(M10P 1.25)	
- Rear Shock Absorber (Under)	2.2 - 3.5 m·kg (16 - 25 ft·lb)
(M10P 1.25)	
- Pivot Shaft (M14P 1.5)	5.0 - 8.0 m·kg (36 - 58 ft·lb)
5. FUEL TANK	
1) Capacity	11 liter (2.9 US. gal)
2) Fuel Grade	Regular Gasoline (90 octane)
6. WHEEL	
1) Type (Front and Rear)	Spoke Wheel
2) Tire Size (Front)	3.00S18 - 4PR
(Rear)	3.50S18 - 4PR
3) Tire Pressure (Front)	1.8 kg/cm ² (26 psi)
(Normal riding)	
(Rear)	2.0 kg/cm (28 psi)
4) Rim Run Out Limit (Front/Rear):	
- Vertical	2 mm (0.08 in)
- Lateral	2 mm (0.08 in)
5) Rim Size (Front)	1.85 x 18
(Rear)	1.85 x 18
6) Spoke O.D.	
- Length/Q'ty (Front)	Inner 3.5 x 175.5 / 18 pcs
	Outer 3.5 x 175.0 / 18 pcs
- Length /Q'ty (Rear)	Inner 3.2 - 3.5 x 157.5 / 18 pcs
	Outer 3.2 - 3.5 x 157.0 / 18 pcs
7) Bearing Type	
- Front Wheel (Left)	6302LU/3A
- Front Wheel (Right)	6302LU/3A
- Rear Wheel (Left)	6304RS
- Rear Wheel (Right)	6303LU C3/3A


<p>8) Oil Seal Type:</p> <ul style="list-style-type: none"> - Front Wheel (Left) - Front Wheel (Right) - Rear Wheel (Left) - Rear Wheel (Right) <p>9) Secondary Drive Chain Type:</p> <ul style="list-style-type: none"> - Type - Number of Links - Chain Pitch - Chain Free Play <p>10) Tightening Torque:</p> <ul style="list-style-type: none"> - Front Wheel Axle (M14P 1.5) - Front Axle Holder (M8P 1.25) - Rear Wheel Axle (M14P 1.5) 	<p>SDD-45-56-6 SD-22-42-7 SD-27-52-5 —</p> <p>DK530DS 99L + Joint 15.875 mm (5/8 in) 10 - 20 mm (0.4 - 0.8 in)</p> <p>7.0 - 10 m-kG (50 - 72 ft-lb) 1.5 - 2.5 m-kG (11 - 18 ft-lb) 7.0 - 10.0 m-kG (50 - 72 ft-lb)</p>
<p>7. BRAKE</p> <p>1) Front Brake</p> <ul style="list-style-type: none"> - Type - Disc Size (Outside Dia. x Thickness) - Disc Wear Limit - Disc Pad Thickness - Pad Wear Limit - Master Cylinder Inside Dia. - Caliper Cylinder Inside Dia. - Brake Fluid Type/Q'ty <p>2) Brake Disc & Hub (M8P 1.25)</p> <ul style="list-style-type: none"> - Caliper & Support Bracket (M8P 1.25) - Caliper & Pad (M5P 0.8) - Caliper & Bleed Screw (M8P 1.25) - Support Bracket & Front Fork (M10P 1.25) - Caliper & Brake Hose - Master Cylinder & Brake Hose (M10P 1.25) <p>3) Rear Brake</p> <ul style="list-style-type: none"> - Type - Actuating Method - Brake Drum I.D. - Brake Show Dia. x Width - Lining Thickness / Wear Limit - Show Spring Free Length 	<p>Hydraulic disc type 267 mm (10.5 in) x 5 mm (0.2 in) 4.5 mm (0.18 in) 11 mm (0.43 in) 6.0 mm (0.24 in) 14.0 mm (0.55 in) 38.1 mm (1.5 in) DOT #3/30 cc (1.01 oz) 1.7 - 2.2 m-pkg (12 - 16 ft-lb) 1.5 - 2.0 m-kG (11 - 15 ft-lb) 0.2 - 0.4 m-kG (1.5 - 3.0 ft-lb) 0.4 - 0.7 m-kG (3.0 - 5.0 ft-lb) 2.5 - 4.0 m-kG (18 - 29 ft-lb) 2.5 - 3.5 m-kG (18 - 25 ft-lb) 2.3 - 2.8 (17 - 20 ft-lb)</p> <p>Dram Brake Leading Trailing 160 mm (6.3 in) 160 x 30 mm (6.3 x 1.2 in) 4 mm (0.16 in) / 2 mm (0.08 in) 68 mm (2.68 in)</p>

D. ELECTRICAL

<p>1. IGNITION SYSTEM</p> <p>1) Battery (AC Generator)</p> <ul style="list-style-type: none"> - Model / Manufacturer - Voltage - Taper Dia. At Large End - Rotor Tightening Torque (M10P 1.25) <p>2) Ignition Timing, STD Ignition Timing (B.T.D.C.)</p> <p>3) Ignition Coil</p> <ul style="list-style-type: none"> - Model / Manufacturer - Spark Gap - Primary Winding Resistance - Secondary Winding Resistance <p>4) Spark Plug</p> <ul style="list-style-type: none"> - Type / Quantity - Spark Plug Gap <p>5) Contact Breaker</p> <ul style="list-style-type: none"> - Manufacture / Quantity - Point Gap - Point Spring Pressure - Cam Closing Angle <p>6) Condenser</p> <ul style="list-style-type: none"> - Capacity - Insulation Resistance - Q'ty 	<p>021000 - 5840 / NIPPON DENSO</p> <p>12V</p> <p>25 mm (0.98 in)</p> <p>3.0 - 3.5 m-kG (21 - 25 ft-lb)</p> <p>10° - 36°</p> <p>029700-4130 / NIPPON DENSO</p> <p>6 mm or more / 500 rpm</p> <p>4.0Ω ± 10% at 20°C</p> <p>9.5 kΩ ± 20% at 20°C</p> <p>NGK BP-6ES / 2 pcs (or CHAMPION N-7Y)</p> <p>0.7 - 0.8 mm (0.027 - 0.031 in)</p> <p>NIPPON DENSO / 2 pcs.</p> <p>0.30 - 0.40 mm (0.012 - 0.016 in)</p> <p>800 ± 100 g</p> <p>105°</p> <p>0.24 μF</p> <p>10MΩ (500V megger used)</p> <p>2 pcs.</p>
<p>2. CHARGING SYSTEM</p> <p>1) AC Generator</p> <ul style="list-style-type: none"> - Charging Output - Rotor Coil Resistance (Filed coil) - Stator Coil Resistance <p>2) Rectifier</p> <ul style="list-style-type: none"> - Type - Model / Manufacturer - Capacity - Withstand Voltage <p>3) Regulator</p> <ul style="list-style-type: none"> - Type - Model / Manufacture - Regulating Voltage 	<p>14.5 V 13A / 5,000 rpm</p> <p>4.04Ω ± 10% at 20°C</p> <p>0.72Ω 10% at 20°C</p> <p>6 - Element Type (Full Wave)</p> <p>DS10TEY - L/MITSUBISHI or DE3804 / STANLEY</p> <p>12A</p> <p>400AV</p> <p>Tillil Type</p> <p>026000 - 2790 / NIPPON DENSO</p> <p>14.5 ± 0.5V</p>

<p>4) Voltage Regulator</p> <ul style="list-style-type: none"> - Core Gap - Yoke Gap - Point Gap - Voltage Coil - Resistor <p>5) Battery</p> <ul style="list-style-type: none"> - Model / Manufacture / Q'ty - Capacity - Charging Rate - Specific Gravity / Q'ty 	<p>MIN. 0.2 mm (0.008 in)</p> <p>MIN. 0.1 mm (0.004 in)</p> <p>0.25 - 0.5 mm (0.01 - 0.02 in)</p> <p>$10.5 \pm \frac{1}{2} \Omega$ at 20 C (68 F)</p> <p>$140 \pm 10 \Omega$ at 20 C (68 F)</p> <p>12N12-4A-1 / F.B. or YUASA / 1 pc.</p> <p>12V, 12AH</p> <p>1.2A 10 hours</p> <p>1.28/20°C, 800 cc (Total)</p>
<p>3. STARTER</p> <p>1) Starter Motor</p> <ul style="list-style-type: none"> - Type - Manufacturer - Model - Output - Armature Coil Resistance - Field Coil Resistance - Brush Size / Q'ty Wear Limit Spring Pressure - Commutator O.D. / Wear Limit - Mica Undercut - Reduction System / Ratio <p>2) Starter Switch</p> <ul style="list-style-type: none"> - Manufacturer - Model - Amparage Rating - Cut-in Voltage - Winding Resistance 	<p>Constant Mesh Type</p> <p>MITSUBA ELEC.</p> <p>SM223B</p> <p>0.5 KW</p> <p>$0.011 \Omega \pm 10\%$ at 20 C (68 F)</p> <p>$0.011 \Omega \pm 10\%$ at 20 C (68 F)</p> <p>$11 \pm \frac{1}{2} \text{ mm } (0.43 \pm \frac{0.06}{8} \text{ in}) / 2 \text{ pcs.}$</p> <p>6 mm</p> <p>$550 \pm 55 \text{ g}$</p> <p>28 mm (1.1 in) / 27 mm (1.06 in)</p> <p>0.7 mm (0.027 in)</p> <p>Planetary Gear / 6.45</p> <p>HITACHI</p> <p>A104-70</p> <p>100A</p> <p>6.5V or less</p> <p>$3.5 \Omega \pm 10\%$</p>
<p>4. LIGHTING SYSTEM</p> <p>1) Head Light Type</p> <p>2) Bulb Wattage / Q'ty:</p> <ul style="list-style-type: none"> - Head Light Wattage - Tail/Stoplight Wattage - Licence Light Wattage - Flasher Light Wattage 	<p>Sealed Beam</p> <p>12V, 40W/30W x 1 pc.</p> <p>12V, 8W/27W x 2 pcs.</p> <p>12V, 8W x 2 pcs.</p> <p>12V, 27W x 2 pcs.</p>

<ul style="list-style-type: none"> - Flasher Pilot Light Wattage - Meter Light Wattage - High Beam Indicator Light Wattage - Neutral Light Wattage - Oil Level Indicator Light Wattage - Parking Light (Front) (Rear) 	<p>12V, 3W x 2 pcs. 12V, 3W x 4 pcs. 12V, 3W x 1 pc. 12V, 3.4W x 1 pc. 12V, 3.4W x 1 pc. 12V, 3W x 1 pc. 12V, 8W x 2 pcs.</p>
<p>3) Horn</p> <ul style="list-style-type: none"> - Model / Manufacturer - Maximum Amperage 	<p>CF3-12 / NIKKO 2.5A</p>
<p>4) Flasher Relay</p> <ul style="list-style-type: none"> - Type - Model / Manufacturer - Flasher Frequency - Capacity 	<p>Condenser Type 061300-4810 6 NIPPON DENSO 85 ± 10 cycle/min. 27W x 2 + 3.4W</p>
<p>5) Flasher Canceling Unit</p> <ul style="list-style-type: none"> - Model - Voltage 	<p>EVH-AC518 DC9V - 16V</p>
<p>6) Fuse</p> <ul style="list-style-type: none"> - Rating/Q'ty 	<p>MAIN (Red) 20A HEAD. L (Red/Yellow) 10A SIGNAL (Brown) 10A IGNITION (Red/White) 10A</p>



XS360-2D

SUPPLEMENT

8

FOREWORD

This Supplementary Service Manual for XS360-2D has been published to supplement the Service Manual for the XS360C.

For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with the Service Manual for the XS360C.

The following are the main differences between XS360-2D and XS360C.

	XS360C	XS360-2D
Front brake type	Disc brake	Drum brake
Main stand	Fitted	Not fitted
Rear footrest	Fitted	Not fitted
Starter motor	Fitted	Not fitted
Starter switch	Fitted	Not fitted
Flasher self canceling system	Fitted	Not fitted
Battery	12V, 12AH	12V, 7AH

For details, see below.

(PAGE 5)

1-1. MACHINE IDENTIFICATION

Specifications should be read as follows.

Starting Serial Number: 1T6-000101


(PAGE 16)

B. Front brake

1. Brake adjustment

The front brake should be adjusted to suit rider preference with a minimum cable slack of 5 ~ 8 mm (0.2 ~ 0.3 in) play at the brake lever pivot point. Adjustment is accomplished at one of two places; either the handle lever holder or the front brake hub.

- Loosen the locknut.
- Turn the cable length adjuster in or out until adjustment is suitable.
- Tighten the locknut.



1. Adjuster

2. Locknut



1. Adjuster

2. Locknut

2. Brake pad check

Delete the whole paragraph.

(PAGE 21)

C. Battery

Specifications should be read as follows.

Charging current: 0.7A

Charging time: 10 hrs.

(PAGE 62)

D. Front wheel installation

Please add the following after "D. Front wheel installation".

E. Checking brake shoe wear

See "Checking brake shoe wear" for the rear wheel.

Specifications should be read as follows.

Front brake shoe diameter:

180 mm (7.09 in)

Replacement limit:

176 mm (6.93 in)

F. Brake drum

See "Brake drum" for the rear wheel.

G. Brake shoe plate

See "Brake shoe plate" for the rear wheel.

(PAGE 63 to 69)

5-3. DISC BRAKES

Delete the whole section.

(PAGE 83)**6-3. BATTERY**

The battery used in the XS360-2D has been changed from 12V, 10AH to 12V, 7AH. Specifications should be read as follows.

Battery	12V, 7AH
Electrolyte	Specific gravity: 1.28 Quantity: 550 cc (18.6 oz)
Recharging current	0.7A/10 hours (or until specific gravity reaches 1.28)
Refill fluid	Distilled water (to maximum level line)
Refill period	Check once per month (or more often, as required)

(PAGE 92 to 104)**7-2. SPECIFICATION****A. General**

1. MODEL	
1) Model (I.B.M. No.)	XS360-2D (1T6)
2) Frame I.D. and starting number	1T6-000101
3) Engine I.D. and starting number	1T6-000101
3. WEIGHT	
1) Net weight	153 kg (337 lb)
4. PERFORMANCE	
1) Climbing ability	28°
2) Minimum turning radius	2,200 mm (86.6 in)

B. Engine

1. DESCRIPTION	
2) Engine model	1T6
8) Lubrication system	Pressure lubricated, wet sump
2. CYLINDER HEAD	
4) Tightening torque: Cylinder head holding nut (M10 P1.25)	3.0 ~ 3.5 m·kg (21.7 ~ 25.3 ft·lb)
22. LUBRICATION	
3) Oil type	a. Yamalube 20W/40 or equivalent [if temperature does not go below 5°C (40°F)] b. 10W/30 "SE" motor oil [if temperature does not go above 15°C (60°F)]

(PAGE 84 and 85)**6-4. Starter motor**

Delete the whole section.

(PAGE 86)

4. Flasher light(s) do not work.
- e. Delete the whole paragraph.

(PAGE 86 to 88)**B. Flasher self canceling system**


Delete the whole section.

C. CHASSIS

3. FRONT SUSPENSION 7) Front fork oil quantity and type	130 cc (4.4 oz) each leg Yamaha fork oil 20 Wt. or SAE 10W/30 motor oil
6. WHEEL 3) Tire pressure Front: Normal riding Front: High speed riding (above 100 km/h or 60 mph) or with passenger Rear: Normal riding Rear: High speed riding (above 100 km/h or 60 mph) or with passenger 6) Spoke O.D. Length/Quantity (Front) Length/Quantity (Rear) 7) Bearing type Front wheel (Left) Front wheel (Right) Rear wheel (Left) Rear wheel (Right) 8) Oil seal type Front wheel (Left) Front wheel (Right) Rear wheel (Left) Rear wheel (Right)	1.8 kg/cm ² (25.6 psi) 2.0 kg/cm ² (28.4 psi) 2.0 kg/cm ² (28.4 psi) 2.3 kg/cm ² (32.7 psi) Inner: 3.5 × 153.0/18 pcs. Outer: 3.5 × 152.5/18 pcs. Inner: 3.2-3.5 × 157.5/18 pcs. Outer: 3.2-3.5 × 157.0/18 pcs. 6302RS 6302RS 6304RS (6304LU/3A) 6303LU C3/3A SDD-53-65-7 SD22-42-7-1 SD-27-52-5
7. BRAKE 1) Front brake Type Actuating method Brake drum I.D. Brake shoe dia. × width Lining thickness/Wear limit Shoe spring free length	Drum brake Two leading 180 mm (7.1 in) 180 × 30 mm (7.1 × 1.2 in) 4 mm (0.16 in)/2 mm (0.08 in) 68 mm (2.68 in)

D. Electrical

2. CHARGING SYSTEM 5) Battery Model/Manufacture/Quantity Capacity Charging rate Specific gravity/Quantity	12N7-3B-1/G.S./1 pc. 12V, 7AH 0.7A 10 hours 1.28 at 20°C/550 cc (18.6 oz)
3. STARTER Delete the whole section	_____
4. LIGHTING SYSTEM 5) Flasher canceling unit Delete the whole paragraph	_____



XS400D

SUPPLEMENT

9

FOREWORD

This Supplementary Service Manual for XS400D has been published to supplement the Service Manual for the XS360C and includes changes in specifications and addition to the data.

For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with the Service Manual for the XS360C.

Page numbers shown in brackets correspond to page numbers of the XS360C Service Manual.

(PAGE 5)

1-1. MACHINE IDENTIFICATION

Specification should be read as follows:

Starting Serial Number
XS400D 2A2-000101

(PAGE 9, 10)

2-1. MAINTENANCE AND LUBRICATION CHART

A. Maintenance intervals for new machines

1. Initial 400 km (250 miles):
 - Spark plug inspection
 - Wheel and tire inspection
 - Fuel petcock cleaning
 - Battery maintenance
 - Lights, signals check
 - Fittings, fasteners tightening
2. Initial 800 km (500 miles):
 - Carburetor adjustment
 - Brake system inspection
 - Wheel and tire inspection
 - Battery maintenance
 - Ignition timing check
 - Lights, signals check
 - Fittings, fasteners tightening
3. Initial 1,600 km (1,000 miles):
 - Valve clearance check
 - Air filter cleaning
 - Brake system inspection
 - Wheel and tire inspection
 - Fuel petcock cleaning
 - Battery maintenance
 - Ignition timing check
 - Lights, signals check
 - Fittings, fasteners tightening
4. Initial 3,200 km (2,000 miles):
 - Cylinder compression check
 - Valve clearance check
 - Spark plugs inspection and cleaning
 - Carburetor adjustment
 - Battery maintenance

B. Routine maintenance intervals

1. Every 1,600 km (1,000 miles):
 - Brake system inspection
 - Wheels and tires inspection
 - Battery maintenance
 - Lights, signals check
 - Fittings, fasteners tightening
2. Every 3,200 km (2,000 miles):
 - Spark plug inspection
 - Air filter cleaning
 - Carburetor adjustment
 - Fuel petcock cleaning
 - Ignition timing check
3. Every 6,400 km (4,000 miles):
 - Cylinder compression check
 - Valve clearance check

C. Lubrication intervals for new machines

1. Initial 400 km (250 miles):
 - Replace engine oil
 - Check brake fluid
 - Replace oil filter
 - Lubricate drive chain
(Every 400 km or 250 miles)
2. Initial 800 km (500 miles):
 - Check brake fluid
3. Initial 1,600 km (1,000 miles):
 - Lubricate control/meter cables
 - Check brake fluid
 - Lubricate point cam lubrication wicks
 - Lubricate brake pedal shaft
 - Lubricate change pedal shaft
4. Initial 3,200 km (2,000 miles):
 - Replace engine oil
 - Lubricate control/meter cables
 - Lubricate throttle grip/housing
 - Check brake fluid
 - Replace oil filter
(6,400 km or 4,000 miles)
 - Lubricate speedometer gear bearing
 - Lubricate rear arm pivot shaft

D. Routine lubrication intervals

1. Every 1,600 km (1,000 miles):
 - Lubricate drive chain
(Every 400 km or 250 miles)
 - Lubricate brake pedal shaft
 - Lubricate change pedal shaft
 - Check brake fluid
2. Every 3,200 km (2,000 miles):

- Lubricate throttle grip/housing
 - Lubricate point cam lubrication wicks
3. Every 6,400 km (4,000 miles):
- Replace oil filter
 - Replace front fork oil
(12,800 km or 8,000 miles)
 - Replace steering bearing grease
(12,800 km or 8,000 miles)
 - Replace rear arm pivot shaft grease
 - Lubricate speedometer gear bearing
 - Replace wheel bearing grease
(12,800 km or 8,000 miles)

E. Recommended lubricants

Engine/Transmission oil:

- At ambient temperature above 5°C (41°F), use YAMALUBE 4-cycle oil, or SAE 20W/40 type "SE" motor oil.
- At ambient temperature below 15°C (59°F), use SAE 10W/30 type "SE" motor oil.
- Do not use "additives" in oil.

Wheel, steering, rear arm pivot shaft:

- Medium weight wheel bearing grease, preferably waterproof.

Front forks:

- Yamaha Fork Oil 20 Wt.

Brake fluid:

- DOT No. 3

Control/Meter cables:

- Yamaha chain and cable lubricant.
- SAE 10W/30 type "SE" motor oil.

Throttle grip/housing:

- Lithium base grease.

Speedometer gear housing:

- Lithium base grease.

Point cam lubrication wicks:

- Lightweight machine oil.

NOTE:

Brake fluid replacement:

- 1) When disassembling the master cylinder or caliper cylinder, replace and bleed the air from the brake fluid. Normally check the brake fluid level and add the fluid as required.
- 2) Replace the master cylinder and caliper cylinder internal seals every two years.
- 3) Replace the brake hoses every four years, or if cracked or damaged.

(PAGE 11)

2-2. ENGINE

A. Carburetor

2. Idle speed adjustment

Specification should be read as follow:

Pilot screw:

Back out $1\frac{1}{4} \pm \frac{1}{2}$ turns

Idle speed: $1,200 \pm 50$ rpm


(PAGE 16, 17)

C. Rear brake

1. Brake adjustment


CAUTION: Proper pedal free play is essential to avoid excessive brake drag.

- 1) Loosen the adjuster locknut (for pedal height).
- 2) By turning the adjuster bolt clockwise or counterclockwise, adjust the brake pedal position so that its top end is approx. 12 ~ 18 mm (0.5 ~ 0.7 in) below the footrest top end.



- | | |
|--|---|
| 1. Brake rod | 6. Joint |
| 2. Adjuster bolt
(for pedal height) | 7. Locknut |
| 3. Locknut | 8. Pedal height
(12 ~ 18 mm or 0.5 ~ 0.7 in) |
| 4. Footrest | 9. Free play
(13 ~ 15 mm or 0.5 ~ 0.6 in) |
| 5. Brake pedal | |

- 3) Secure the adjuster locknut.
- 4) Loosen the brake rod adjuster locknut and screw brake rod downward until there is noticeable freeplay between rod and master cylinder.






1. Brake rod

2. Locknut

- 5) Turn in the brake rod until it lightly touches the master cylinder, then turn it out by approx. 1-1/2 turns (for proper freeplay).
- 6) Tighten the brake rod adjuster locknut.

CAUTION: The pin hole mark on brake rod must not show above locknut.

	Piston size	Cylinder size
A	69 -0.020 mm or less -0.031 mm or more (2.716 -0.00079 in or less -0.00122 in or more)	69 +0.020 mm or less +0.011 mm or more (2.716 +0.00079 in or less +0.00043 in or more)
B	69 -0.030 mm or less -0.040 mm or more (2.716 -0.00118 in or less -0.00157 in or more)	69 +0.010 mm or less 0 (2.716 +0.00039 in or less 0)



2. Brake pad check

See "Brake pad check" for the front brake.

3. Brake fluid level check

See "Brake fluid level check" for the front brake.

(PAGE 21)

B. Spark plug

Specifications should be read as follows:

Standard spark plug	Tightening torque
NGK BP-7ES Champion N-7Y DENSO W22EP	2.0 m·kg (14 ft·lb)

(PAGE 37)

E. Cylinder

3. Types of cylinder

Specifications should be read as


	Standard
Cylinder bore	69.00 ~ 69.02 mm (2.716 ~ 2.717 in)
Cylinder taper	0.05 mm (0.002 in)

F. Piston and piston rings

1. Piston

Specifications should be read as follows:

	Size
Standard	69.00 mm (2.716 in)
Oversize 1	69.25 mm (2.727 in)
Oversize 2	69.50 mm (2.736 in)
Oversize 3	69.75 mm (2.746 in)
Oversize 4	70.00 mm (2.756 in)



2. Piston ring

Specifications should be read as follows:

	Oversize Dia.	Stamped Mark
Oversize 1	69.25 mm (2.727 in)	25
Oversize 2	69.50 mm (2.736 in)	50
Oversize 3	69.75 mm (2.746 in)	75
Oversize 4	70.00 mm (2.756 in)	100

(PAGE 58, 59)



4-1. CARBURETOR

A. Disassembly

1. Prepare to separate carburetor (separation not necessary if only float level adjustment or throttle slide inspection is to be done). Remove the two screws holding the starter shaft to the

NOTE:


- 1) While pulling out the starter shaft, take care that the shaft positioning balls on the left and right do not pop out.
- 2) As illustrated, reassembly the starter shaft so that the holding screws fit in the shaft dents.




2. Remove upper and lower brackets. Note position of synchronizing screws for guidance in reassembly. Separate carburetors.
3. Remove vacuum chamber cover. Remove the spring, needle fitting plate, jet needle and diaphragm (vacuum piston).




4. Note that there is tab on the rubber diaphragm. There is matching recesses in the carburetor body for the diaphragm tab.




5. To inspect starter jet, remove the starter assembly to the left side of the carburetor.



6. Remove the four screws holding the float bowl cover. Remove the float bowl cover. The main jet is located under a cover in the float bowl.




7. Pull out float pivot pin. Remove the float assembly. Be careful to not lose the float valve needle located under the float level adjustment tang. Remove




8. Reassemble in reverse order. Pay close attention to the installation of the vacuum position diaphragm.

B. Inspection

1. Examine carburetor body and fuel passages. If contaminated, wash carburetor in petroleum-based solvent. Blow out all passages and jets with compressed air.
2. Examine condition of floats. If floats are leaking or damaged, they should be replaced.
3. Inspect inlet needle valve and seat for wear or contamination. Replace these components as a set.



4. Inspect vacuum piston and rubber diaphragm. If the piston is scratched or the diaphragm is torn, the assembly must be replaced.



C. Adjustment (Float level)

Refer to CHAPTER 2, Section 2-2, C for "Float Level" adjustment procedure.


Two-position starter jet (Choke)

With a conventional one-position starter jet, the air-fuel ratio remains the same as that required to start the engine (despite that the engine temperature rises gradually) until the engine operating temperature rises to the point at which use of the starter jet is no longer necessary. In other words, the air-fuel mixture is too rich until the engine operating temperature rises to a certain point.

The newly-adopted two-position type starter jet is designed to supply a mixture of proper strength by switching one jet to another.

Routes of Fuel and Air

The fuel supplied from the float chamber ① passes through ② and metered by ③. Air is supplied from the air chamber in the float chamber and flows through ⑤ and ⑥, then it is mixed with the metered fuel. The resultant mixture passes through ④ and ⑥ and flows into the two-position starter jet ⑦ where it is further mixed with air supplied from the diaphragm lower chamber. The mixture passes through ⑧ and streams into the throttle bore out of ⑨.



Operation of two-position starter jet

Full-open:


To start a cold engine, a rich mixture is required. To supply a rich mixture, pull the starter knob all the way out so that the needle regulating the fuel from is set free and the flow rate of incoming fuel is increased to a maximum. The fuel is mixed with the air supplied from the diaphragm lower chamber, and thus a rich mixture is produced.

Half-open:


When warming up the engine, a slightly rich mixture is required. Pull out the starter jet a half-way so that the fuel flow is reduced by the needle. The fuel is mixed with the air from the diaphragm lower chamber, and thus a slightly rich mixture is produced.

Full-closed:

When the engine fully warms up, no mixture from the starter circuit is necessary. Push the starter knob all the way in so that the flow of incoming fuel is stopped by the needle. At the same time, the flow of incoming air is also stopped by the plunger, and thus no mixture enters the throttle bore.



Holder nut torque:
2.0 m-kg (14.7 ft-lb)



c. Install a new cotter pin.

(PAGE 62, 63)

5-1. FRONT WHEEL

D. Front wheel installation

When installing front wheel, reverse the removal procedure taking care of the following points:

1. Lightly grease lips of front wheel oil seals and gear teeth of speedometer drive and driven gears. Use lightweight lithium soap base grease.
2. Make sure there is an enough gap between disc pads.
3. Check for proper engagement of the boss on the outer fork tube with the locating slot on speedometer gear unit housing.
4. Always secure the front wheel axle as follows:
 - a. Torque the front axle nut.

Axle nut torque:
10.7 m-kg (77.4 ft-lb)

- b. Torque axle holder nuts. First tighten nut on front end of axle holder, and tighten nut on rear end.

E. Front wheel inspection

1. Check for cracks, bends or warpage of wheels. If a wheel is deformed or cracked, it must be replaced.

NOTE:

These aluminum wheels are not designed for use with tubeless tires.



2. Check wheel run-out
If deflection exceeds tolerance, check wheel bearing or replace wheel as required.

Rim run-out limits:
Vertical: 2 mm (0.08 in)
Lateral: 1 mm (0.04 in)

3. Check wheel balance
Rotate wheel lightly several times and observe resting position.
If wheel is not statically balanced, wheel will come to rest at the same position.
Install balance weight at lighter position (at top) as illustrated.

NOTE:


The wheel should be balanced with brake disc installed.



5-2. REAR WHEEL

A. Rear wheel removal

1. Support machine on the side stand.
2. Hook one end of the wire tool (contained in the owner's tool kit) to the hook attached to the frame.



3. Apply your weight to the rear part of the seat, and compress the rear shock absorbers by pulling up the right side of the swing arm with your hand, then hook the other end of the wire tool to the swing arm.
4. With the wire tool in this position, place the machine on the center stand.
5. Disconnect the drive chain. Using drive chain cutter (special tool).

NOTE:

The chain joint should be replaced each time the chain is cut.

6. Remove the axle nut cotter pin and axle nut.
7. While supporting the brake caliper, pull out the rear axle.
8. Remove the rear wheel assembly.

B. Checking brake shoe wear

Delete this section.

C. Brake drum

Delete this section.

D. Brake shoe plate

Delete this section.

F. Rear wheel installation

When installing rear wheel, reverse removal procedure taking care of following points:

1. Lightly grease lip of rear wheel oil seals.
2. Make sure the brake pads are installed properly and that there is an enough gap to install the rear disc.
3. Install wheel assembly and axle. Always use a new cotter pin on the axle nut.

Axle nut torque:
10.7 m·kg (77.4 ft·lb)

4. Connect drive chain.
5. Adjust drive chain.

G. Rear wheel inspection

See "E. Front wheel inspection" for the front wheel.

5-3. DISC BRAKES

Except for the following, the same procedure can be performed for Assembly, Disassembly and Inspection of XS400D front and rear brake and XS360C front brake.

B. Disc brake inspection

The shim in the caliper is no longer used, and a set of two pad springs has been changed into one piece type.

C. Disc brake assembly**d. Caliper installation**

- 2) Install the brake hoses (front and rear).

Specification should be read as follow:

Tightening torque:

Union bolt: 2.6 m·kg
(18.8 ft·lb)

NOTE:

If you are changing the tire itself, then finish the removal by working the second bead off the rim.

B. Installation

Reinstall the tire and tube by reversing the disassembly procedure. After the tube has been installed, but before the tire has been completely slipped onto the rim, inflate the tube. This removes any creases that might exist. Release the air continue with reassembly. After the tire has been completely slipped onto the rim, make sure the stem comes out of the hole in the rim at a right angle to the rim. Finally, inflate the tire.

	Front	Rear
Normal riding	1.8 kg/cm ²	2.0 kg/cm ²
Continued high riding or with passenger	2.0 kg/cm ²	2.3 kg/cm ²

NOTE:

Make sure the wheel is balance every time the tire replaced.

5-4. RIMS AND SPOKES**(FRONT AND REAR WHEELS)****A. Checking for loose spokes**

Delete this section.


5-5. TIRES AND TUBES**A. Removal**

1. Remove valve cap, valve core and valve stem locknut.
2. When all air is out of tube, separate tire bead from rim (both sides) by stepping on tire with your foot.
3. Use two tire irons (with rounded edges) to work the tire bead over the edge of the rim, starting 180° opposite the tube stem. Be careful not to pinch the tube as you do this.
4. After you have worked one side of the tire completely off the rim, slip the tube out. Be very careful not to damage the stem while pushing it back out of the rim hole.

6-4. STARTER MOTOR**A. Servicing and troubleshooting****1. Armature**

- a. Check the outer surface of the commutator. If it's surface is dirty, clean with No. 600 grit sand paper.
- b. The mica insulation between commutator segments should be 0.5 ~ 0.8 mm (0.02 ~ 0.03 in) below the segment level. If not, scrape to proper limits with appropriately shaped tool. (A hack saw blade can be ground to fit.)

Mica undercut
0.5 ~ 0.8 mm
(0.02 ~ 0.03 in)



- c. Check the armature and field coil for shorting and insulation. Replace armature as required.

- d. Check the front and rear cover bearings for damage. If damaged, the starter assembly must be replaced.

	Coil resistance
Armature coil	0.005Ω at 20°C (68°F)
Field coil	0.011Ω at 20°C (68°F)

(PAGE 92 ~ 104)

7-2. SPECIFICATION

A. General

1. MODEL	
1) Model (I.B.M. No.)	XS400D(2A2)
2) Frame I.D. and starting number	2A2-000101
3) Engine I.D. and starting number	2A2-000101
2. DIMENSION	
1) Overall length	2,025 mm (79.7 in)
2) Overall width	845 mm (33.3 in)
3) Overall height	1,100 mm (43.3 in)
4) Seat height	815 mm (32.1 in)
5) Wheelbase	1,335 mm (52.6 in)
6) Minimum ground clearance	150 mm (5.9 in)
3. WEIGHT	
1) Net weight (Dry)	164 kg (367 lb)
4. PERFORMANCE	
1) Climbing ability	28°
2) Minimum turning radius	2,200 mm (86.6 in)
3) Braking distance	14 m @50 km/h (45.9 ft @31 mi/h)

B. Engine

1. DESCRIPTION	
1) Engine type	Air cooled, 4-stroke, SOHC twin, parallel forward incline
2) Engine model	2A2
3) Displacement	392 cc (23.92 cu.in)
4) Bore × stroke	69.0 × 52.4 mm (2.717 × 2.063 in)
5) Compression ratio	9.2 : 1
6) Starting system	Kick and electric starter
7) Ignition system	Battery ignition
8) Lubrication system	Wet sump
2. CYLINDER HEAD	
1) Combustion chamber volume	24.0 cc (1.464 cu.in) BP7ES
2) Combustion chamber type	Dome + Squish
3) Head gasket thickness	1.0 mm (0.04 in)
4) Tightening torque	
Cylinder head holding nut (M10 P1.25)	3.3 m·kg (23.9 ft·lb)
Cylinder head holding bolt (M6 P1.0)	1.0 m·kg (7.2 ft·lb)
Spark plug (M14 P1.25)	2.0 m·kg (14.5 ft·lb)

3. CYLINDER 1) Material 2) Bore size 3) Taper limit 4) Out of round limit	Aluminum alloy with cast iron sleeve $69.0^{+0.02}_0$ mm ($2.72^{+0.0008}_0$ in) 0.05 mm (0.002 in) 0.01 mm (0.0004 in)
--	---

4. PISTON				
1) Piston skirt clearance	0.030 ~ 0.050 mm (0.0012 ~ 0.0019 in)			
2) Piston oversize	69.25 mm (2.727 in)	69.50 mm (2.736 in)	69.75 mm (2.746 in)	70.00 mm (2.756 in)
3) Piston pin outside diameter × length	16.0 ⁰ _{-0.005} mm × 58.5 ⁰ _{-0.3} mm (0.63 ⁰ _{-0.0002} in × 2.303 ⁰ _{-0.0116} in)			


5. PISTON RING 1) Piston ring design 2) Ring end gap 3) Ring groove side clearance	(Top) (2nd) (Oil ring) (Installed, top) (Installed, 2nd) (Installed, oil) (Top) (2nd) (Oil) Plain ring 1.0 mm (0.039 in) Plain ring 1.5 mm (0.059 in) With expander 2.45 mm (0.096 in) $0.2 \sim 0.4$ mm ($0.008 \sim 0.016$ in) $0.2 \sim 0.4$ mm ($0.008 \sim 0.016$ in) $0.2 \sim 0.9$ mm ($0.008 \sim 0.035$ in) $0.04 \sim 0.08$ mm ($0.0016 \sim 0.0032$ in) $0.03 \sim 0.07$ mm ($0.0012 \sim 0.0028$ in)
--	---

6. BIG END BEARING 1) Type 2) Oil clearance 3) Bearing size	Plain bearing $0.021 \sim 0.045$ mm ($0.0008 \sim 0.0018$ in) <table border="1" data-bbox="474 696 898 871"> <tr> <td>1. (Blue)</td><td>$15.0^{+0.004}_0$ mm $\varnothing 59.1^{+0.00016}_0$ in)</td></tr> <tr> <td>2. (Black)</td><td>$15.0^{0}_{-0.004}$ mm $\varnothing 59.1^{0}_{-0.00016}$ in)</td></tr> <tr> <td>3. (Brown)</td><td>$15.0^{0}_{-0.008}$ mm $\varnothing 59.1^{0}_{-0.00031}$ in)</td></tr> <tr> <td>4. (Green)</td><td>$15.0^{0}_{-0.012}$ mm $\varnothing 59.1^{0}_{-0.00047}$ in)</td></tr> </table>	1. (Blue)	$15.0^{+0.004}_0$ mm $\varnothing 59.1^{+0.00016}_0$ in)	2. (Black)	$15.0^{0}_{-0.004}$ mm $\varnothing 59.1^{0}_{-0.00016}$ in)	3. (Brown)	$15.0^{0}_{-0.008}$ mm $\varnothing 59.1^{0}_{-0.00031}$ in)	4. (Green)	$15.0^{0}_{-0.012}$ mm $\varnothing 59.1^{0}_{-0.00047}$ in)
1. (Blue)	$15.0^{+0.004}_0$ mm $\varnothing 59.1^{+0.00016}_0$ in)								
2. (Black)	$15.0^{0}_{-0.004}$ mm $\varnothing 59.1^{0}_{-0.00016}$ in)								
3. (Brown)	$15.0^{0}_{-0.008}$ mm $\varnothing 59.1^{0}_{-0.00031}$ in)								
4. (Green)	$15.0^{0}_{-0.012}$ mm $\varnothing 59.1^{0}_{-0.00047}$ in)								

7. CAMSHAFT		Chain (Center side)		
1) Can drive type		3 bearings, cylinder head direct support		
2) Number and type of bearing				
3) Bearing dimensions				
	Cap I.D.	Shaft O.D.	Clearance	
IN and EX	23.0 ^{+0.021} ₀ mm	23.0 ^{-0.020} _{-0.033} mm	0.020 ~ 0.054 mm	
1, 2, 3	∅90.6 ^{+0.0082} ₀ (in)	∅90.6 ^{-0.00079} _{-0.00130} (in)	(0.00079 ~ 0.00213 in)	

4) Cam dimensions

	Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"
IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)
EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)




5) Valve timing

	OPEN	CLOSE	DURATION	OVERLAP
IN	BTDC 30°	ABDC 70°	280°	60°
EX	BBDC 70°	ATDC 30°	280°	

6) Camshaft deflection limit

0.03 mm (0.0012 in)

<p>7) Cam chain</p> <p>Type</p> <p>Pitch/Number of links</p> <p>Sprocket ratio (Teeth)</p>	<p>TSUBAKIMOTO BF05M</p> <p>7.774 mm (0.3060 in) /92L</p> <p>34/17 (2.000)</p>
<p>8. ROCKER ARM AND ROCKER SHAFT</p> <p>1) Rocker arm inner diameter</p> <p>2) Rocker arm shaft diameter</p> <p>3) Clearance</p> <p>4) Lift ratio</p>	<p>$13.0^{+0.018}_0$ mm ($0.512^{+0.0007}_0$ in)</p> <p>$13.0^{-0.016}_{-0.036}$ mm ($0.512^{-0.00063}_{-0.00141}$ in)</p> <p>0.016 ~ 0.054 mm (0.00053 ~ 0.00122 in)</p> <p>X : Y = 32.05 : 33.62 mm (1.262 : 1.324 in)</p>
<p>9. VALVE, VALVE SEAT AND VALVE GUIDE</p> <p>1) Valve per cylinder</p> <p>2) Valve clearance (In cold engine)</p> <p>3) Dimensions</p> <p>Valve head diameter "A"</p> <p>Valve face width "B"</p> <p>Valve seat width "C"</p> <p>Valve margin thickness "D"</p>  <p>Valve stem diameter</p> <p>Valve guide diameter</p> <p>Valve stem to stem clearance</p> <p>4) Valve face runout limit</p>	<p>2 pcs.</p> <p>IN: 0.08 ~ 0.12 mm (0.0031 ~ 0.0047 in)</p> <p>EX: 0.16 ~ 0.20 mm (0.0063 ~ 0.0078 in)</p> <p>IN: 35.5 ± 0.1 mm (1.398 ± 0.004 in)</p> <p>EX: 30.0 ± 0.1 mm (1.181 ± 0.004 in)</p> <p>IN: 2.3 mm (0.091 in)</p> <p>EX: 2.3 mm (0.091 in)</p> <p>IN: 1.0 ± 0.1 mm (0.039 ± 0.004 in)</p> <p>EX: 1.0 ± 0.1 mm (0.039 ± 0.004 in)</p> <p>IN: 1.0 ± 0.2 mm (0.039 ± 0.008 in)</p> <p>EX: 1.0 ± 0.2 mm (0.039 ± 0.008 in)</p> <p>IN: $7.0^{-0.010}_{-0.025}$ mm ($0.275^{-0.0004}_{-0.0009}$ in)</p> <p>EX: $7.0^{-0.030}_{-0.045}$ mm ($0.275^{-0.0012}_{-0.0018}$ in)</p> <p>IN: $7.0^{+0.012}_0$ mm ($0.275^{+0.0005}_0$ in)</p> <p>EX: $7.0^{+0.012}_0$ mm ($0.275^{+0.0005}_0$ in)</p> <p>IN: 0.010 ~ 0.037 mm (0.00039 ~ 0.00145 in)</p> <p>EX: 0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)</p> <p>IN & EX: 0.03 mm (0.0012 in) or less</p>
<p>10. VALVE SPRING</p> <p>1) Free length</p> <p>2) Spring rate (kg/mm)</p> <p>3) Installed length (Valve closed)</p> <p>4) Installed pressure (Valve closed)</p> <p>5) Compressed length (Valve open)</p> <p>6) Compressed pressure (Valve open)</p>	<p>INNER (IN/EX): 39.3 mm (1.547 in)</p> <p>OUTER (IN/EX): 42.8 mm (1.685 in)</p> <p>INNER (IN/EX): $k_1 = 1.93$</p> <p>$k_2 = 2.47$</p> <p>OUTER (IN/EX): $k_1 = 4.19$</p> <p>$k_2 = 5.49$</p> <p>INNER (IN/EX): 33.0 mm (1.299 in)</p> <p>OUTER (IN/EX): 37.0 mm (1.457 in)</p> <p>INNER (IN/EX): 12.1 ± 1.2 kg (26.7 ± 2.6 lb)</p> <p>OUTER (IN/EX): 24.4 ± 1.7 kg (53.8 ± 3.8 lb)</p> <p>INNER (IN/EX): 25.0 mm (0.984 in)</p> <p>OUTER (IN/EX): 29.0 mm (1.142 in)</p> <p>INNER (IN/EX): 31.4 kg (69.2 lb)</p> <p>OUTER (IN/EX): 68.3 kg (151 lb)</p>

7) Wire diameter (Valve open)	INNER (IN/EX): 3.0 mm (0.118 in) OUTER (IN/EX): 4.4 mm (0.173 in)								
8) Winding O.D. (Valve open)	INNER (IN/EX): 22.4 mm (0.882 in) OUTER (IN/EX): 32.0 mm (1.260 in)								
9) Number of windings (Valve open)	INNER (IN/EX): 7.75 turns OUTER (IN/EX): 6.25 turns								
10) Tilt limit (Valve open)	INNER (IN/EX): 1.7 mm (0.067 in) or 2.5° OUTER (IN/EX): 1.9 mm (0.075 in) or 2.5°								
11. CRANKSHAFT									
1) Crankshaft deflection	0.02 mm (0.0008 in)								
2) Con-rod large end clearance	0.160 ~ 0.264 mm (0.0063 ~ 0.0104 in)								
3) Clearance between crank and crankcase	0.05 ~ 0.25 mm (0.002 ~ 0.010 in)								
12. CONNECTING ROD									
1) Big end I.D.	$41.0^{+0.024}_0$ mm ($1.614^{+0.0009}_0$ in)								
2) Small end I.D.	$16.0^{+0.028}_{+0.015}$ mm ($0.630^{+0.0011}_{+0.0028}$ in)								
3) Difference of each rod weight	5 g or less								
13. CRANK BEARING									
1) Oil clearance	0.020 ~ 0.044 mm (0.00079 ~ 0.00157 in)								
2) Bearing size	<table border="1"> <tr> <td>1. (Blue)</td><td>$15.0^{+0.012}_{+0.008}$ mm ($0.591^{+0.00047}_{+0.00031}$ in)</td></tr> <tr> <td>2. (Black)</td><td>$15.0^{+0.008}_{+0.004}$ mm ($0.591^{+0.00031}_{+0.00016}$ in)</td></tr> <tr> <td>3. (Brown)</td><td>$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)</td></tr> <tr> <td>4. (Green)</td><td>$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)</td></tr> </table>	1. (Blue)	$15.0^{+0.012}_{+0.008}$ mm ($0.591^{+0.00047}_{+0.00031}$ in)	2. (Black)	$15.0^{+0.008}_{+0.004}$ mm ($0.591^{+0.00031}_{+0.00016}$ in)	3. (Brown)	$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)	4. (Green)	$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)
1. (Blue)	$15.0^{+0.012}_{+0.008}$ mm ($0.591^{+0.00047}_{+0.00031}$ in)								
2. (Black)	$15.0^{+0.008}_{+0.004}$ mm ($0.591^{+0.00031}_{+0.00016}$ in)								
3. (Brown)	$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)								
4. (Green)	$15.0^{+0.004}_0$ mm ($0.591^{+0.00016}_0$ in)								
14. CLUTCH									
1) Clutch type	Wet, multiple type								
2) Clutch operating mechanism	Inner push type, screw push system								
3) Primary reduction ratio and method	78/24 (3.250), spur gear								
4) Primary reduction gear back lash Tolerance	A—C, B—D, C—E, D—F								
5) Friction plate Thickness/Quantity Wear limit	3 mm (0.12 in) / 7 pcs. 2.7 mm (0.11 in)								
6) Clutch plate Thickness/Quantity Warp limit	1.6 mm (0.063 in) / 6 pcs. 0.05 mm (0.002 in)								
7) Clutch spring Free length/Quantity Minimum length	34.6 mm (1.362 in) / 4 pcs. 33.6 mm (1.323 in)								
8) Clutch housing radial play (Wear limit)	0.009 ~ 0.043 mm (0.00035 ~ 0.00169 in)								
9) Push rod bending limit	0.2 mm (0.008 in)								
10) Tightening torque Primary drive gear (M10 P1.25) Clutch spring screw (M6 P1.0)	4.3 m·kg (31.1 ft·lb) 1.0 m·kg (7.2 ft·lb)								
15. TRANSMISSION									
1) Type	Constant mesh, 6-speed forward								
2) Gear ratio:									
1st	35/14 (2.500)								
2nd	32/18 (1.777)								
3rd	29/21 (1.380)								
4th	27/24 (1.125)								
5th	25/26 (0.961)								
6th	26/30 (0.866)								

<p>3) Bearing type: Main axle (Left) Main axle (Right) Drive axle (Left) Drive axle (Right)</p> <p>4) Oil seal type Drive axle (Left)</p> <p>5) Secondary reduction ratio and method</p> <p>6) Tightening torque Drive sprocket</p>	<p>Needle bearing ($\phi 20-\phi 30-15$) Ball bearing (5205) Ball bearing (6305 special) Needle bearing ($\phi 20-\phi 33-15$) SD-35-62-6 37/16 (2.312)</p> <p>7.0 m·kg (50.6 ft·lb)</p>
<p>16. SHIFTING MECHANISM</p> <p>1) Type</p> <p>2) Oil seal type (Change lever)</p> <p>3) Tightening torque Change pedal (M6 P1.0)</p>	<p>Cam drum, return type SD-12-22-5</p> <p>1.0 m·kg (7.2 ft·lb)</p>
<p>17. KICK STARTER</p> <p>1) Type</p> <p>2) Oil seal type (Kick axle)</p> <p>3) Kick clip friction tension</p> <p>4) Tightening torque Kick crank (M8 P1.25)</p>	<p>Bendix type SD-20-30-7 1.0 m·kg (7.2 ft·lb)</p> <p>2.0 m·kg (14.5 ft·lb)</p>
<p>18. CRANKCASE</p> <p>1) Tightening torque Bolt (M8 P1.25) Bolt (M6 P1.0)</p>	<p>2.2 m·kg (15.9 ft·lb) 1.0 m·kg (7.2 ft·lb)</p>
<p>19. INTAKE</p> <p>1) Air cleaner: Type/Quantity</p> <p>2) Cleaner cleaning interval</p> <p>3) Valve clearance</p>	<p>Dry, foam rubber/2 pcs. Every 3,200 km (2,000 mile). See No. 10-2) Valve, valve seat and valve guide</p>
<p>20. CARBURETOR</p> <p>1) Type and manufacturer/Quantity</p> <p>2) I.D. mark</p> <p>3) Main jet (MJ)</p> <p>4) Air jet (AJ)</p> <p>5) Jet needle-clip position (JN)</p> <p>6) Needle jet (NJ)</p> <p>7) Throttle valve (Th.V)</p> <p>8) Pilot jet (PJ)</p> <p>9) Air screw (Turns out) (AS)</p> <p>10) Starter jet (GS)</p> <p>11) Fuel level (FL)</p> <p>12) Vacuum synchronization</p> <p>13) Idling engine speed</p>	<p>BS34 MIKUNI/2 pcs. 2A2-60 #142.5 #45 5Z1-4 X-4 #135 #42.5 1-1/4 \pm 1/2 GS₁: #30, GS₂: —, AB₁: $\phi 0.7$ 32 \pm 1 mm (1.26 \pm 0.04 in) 5 mmHg or less 1,200 \pm 50 rpm</p>
<p>21. LUBRICATION</p> <p>1) Engine sump oil Quantity</p> <p>2) Oil grade</p> <p>3) Oil type</p> <p>4) Oil pump type</p> <p>5) Trochoid pump specifications Top clearance Tip clearance Side clearance Oil pump volume</p> <p>6) Relief valve operating pressure</p> <p>7) Bypass valve setting pressure</p>	<p>Oil exchange: 2.0 lit (2.1 qt) Filter and oil exchange: 2.3 lit (2.4 qt) Total amount: 2.6 lit (2.7 qt) Shell X-100 or Yamalube 4-cycle oil SAE 20W/40 (more than 5°C (32°F)) SAE 10W/30 (below 15°C (59°F)) Trochoid pump</p> <p>0.10 \sim 0.18 mm (0.0039 \sim 0.0071 in) 0.03 \sim 0.09 mm (0.0012 \sim 0.0035 in) 0.03 \sim 0.09 mm (0.0012 \sim 0.0035 in) 1.2 lit/min at 500 rpm 5 \pm 0.5 kg/cm² (71 \pm 7 psi). 1.0 \pm 0.2 kg/cm² (14 \pm 3 psi)</p>

The diagram illustrates the oil system components and their interconnections. The engine oil system includes the Camshaft, Con-rod big end, Crankshaft, Oil main gallery, Bypass valve, Oil filter, Oil pump, and Relief valve. The transmission oil system includes the Main axle, Clutch, Drive axle, and Collection of splashes. Solid lines represent the main oil flow, while dashed lines represent the splash oil flow from the transmission to the drive axle.

1. FRAME 1) Frame design 2) Tightening torque Engine mounting bolt (M8 P1.25) Engine mounting bolt (M10 P1.25)	Semi double cradle, high tensile frame 1.8 m-kg (13.0 ft-lb) 3.1 m-kg (22.4 ft-lb)
2. STEERING SYSTEM 1) Caster 2) Trail 3) Number and size of balls in steering head Upper race Lower race 4) Steering lock to lock 5) Tightening torque Steering shaft fitting nut (M14 P1.25) Steering shaft fitting nut (M25 P1.0) Stem pinch bolt (M8 P1.25) Handle bar mounting bolt (M10 P1.25)	26°30' 85 mm (3.35 in) 19 pcs. 1/4 in 19 pcs. 1/4 in 43° each (L and R) 5.4 m-kg (39.1 ft-lb) 3.8 m-kg (27.5 ft-lb) 1.2 m-kg (8.7 ft-lb) 2.3 m-kg (16.6 ft-lb)
3. FRONT SUSPENSION 1) Type 2) Damper type 3) Front fork spring Free length Wire diameter × winding diameter Spring constant 4) Front fork travel 5) Inner tube O.D. 6) Front fork oil quantity and type	Telescopic fork Oil damper, coil spring 484 mm (19.05 in) 3.8 mm × 23 mm (0.15 × 0.91 in) $k_1 = 0.4 \text{ kg/mm (0 ~ 100 mm)}$ $k_2 = 0.475 \text{ kg/mm (100 ~ 140 mm)}$ 140 mm (5.5 in) 44 mm (1.30 in) 130 cc (4.4 oz) each leg Yamaha fork oil or SAE 10W/30 motor oil

7) Oil seal type	SD-33-46-10.5
8) Tightening torque Under bracket and inner tube (M10 P1.25) Handle crown and inner tube (M8 P1.25)	3.5 m·kg (25.3 ft·lb) 1.2 m·kg (8.7 ft·lb)
4. REAR SUSPENSION	
1) Type	Swing arm
2) Damper type	Oil damper, coil spring
3) Shock absorber travel	80 mm (3.15 in)
4) Shock absorber spring	
Set length	193 mm (7.6 in)
Free length	205 mm (8.1 in)
Wire diameter × winding diameter	7.0 mm × 56.5 mm (0.27 × 2.22 in)
Spring constant	k = 1.6 kg/mm
5) Swing arm free play (Limit)	1.0 mm (0.04 in)
6) Pivot shaft — Outside diameter	16 mm (0.63 in)
7) Tightening torque:	
Rear shock absorber (Upper) (M10 P1.25)	3.0 m·kg (21.7 ft·lb)
Rear shock absorber (Upper) (M10 P1.25)	3.0 m·kg (21.7 ft·lb)
Pivot shaft (M14 P1.5)	6.5 m·kg (47.0 ft·lb)
5. FUEL TANK	
1) Capacity	11.0 lit (2.9 US.gal)
2) Fuel grade	Regular gasoline (90 octane)
6. WHEEL	
1) Type (Front and rear)	Cast wheel
2) Tire size (Front)	3.50S18-4PR
(Rear)	3.50S18-4PR
3) Tire pressure:	
Normal riding (Front)	1.8 kg/cm ² (26 psi)
(Rear)	2.0 kg/cm ² (28 psi)
High speed riding or with passenger (Front)	2.0 kg/cm ² (28 psi)
(Rear)	2.3 kg/cm ² (33 psi)
4) Rim run out limit (Front and rear)	
Vertical	2.0 mm (0.08 in)
Lateral	2.0 mm (0.08 in)
5) Rim size (Front)	1.85 × 18
(Rear)	2.15 × 18
6) Bearing type	
Front wheel (Left)	6302ZZ
Front wheel (Right)	6302ZZ
Rear wheel (Left)	6304ZZ
Rear wheel (Right)	6304ZZ
7) Oil seal type	
Front wheel (Left)	SDD-45-56-6
Front wheel (Right)	SD-22-42-7
Rear wheel (Left)	SD-27-52-5
Rear wheel (Right)	SD-23-47-7
8) Secondary drive chain type	
Type	DK530DS
Number of links	97L + Joint
Chain pitch	15.875 mm (5/8 in)
Chain free play	10 ~ 20 mm (0.4 ~ 0.8 in)
9) Tightening torque	
Front wheel axle (M14 P1.5)	10.7 m·kg (77.4 ft·lb)
Front axle holder (M8 P1.25)	2.0 m·kg (14.5 ft·lb)
Rear wheel axle (M14 P1.5)	10.7 m·kg (77.4 ft·lb)

7. BRAKE

1) Front and rear brake

Type

Disc size (Outside dia. × thickness)

Disc wear limit

Disc pad thickness

Pad wear limit (Minimum thickness)

Master cylinder inside dia.

Front

Rear

Caliper cylinder inside dia.

Brake fluid type/quantity

2) Tightening torque

Brake disc and hub (M8 P1.25)

Caliper and support bracket (M8 P1.25)

Caliper and pad (M5 P0.8)

Caliper and bleed screw (M8 P1.25)

Support bracket and front fork (M10 P1.25)

Caliper and brake hose (M10 P1.25)

Master cylinder and cylinder bracket (M6 P1.0)

Hydraulic disc type

257 mm × 5.0 mm (10.5 × 0.2 in)

4.5 mm (0.18 in)

6.5 mm (0.26 in)

1.5 mm (0.06 in)

14.0 mm (0.55 in)

15.8 mm (0.62 in)

38.1 mm (1.5 in)

DOT #3/34 cc (0.8 oz)

2.0 m·kg (14.5 ft·lb)

1.8 m·kg (13.0 ft·lb)

0.3 m·kg (2.2 ft·lb)

0.6 m·kg (4.3 ft·lb)

3.5 m·kg (25.3 ft·lb)

2.6 m·kg (18.8 ft·lb)

0.6 m·kg (4.3 ft·lb)

D. Electrical

1. IGNITION SYSTEM

1) Battery (AC generator)

Model/Manufacturer

Voltage

Taper dia. at large end

Rotor tightening torque (M10 P1.25)

2) Ignition timing (B.T.D.C.)

3) Ignition coil

Model/Manufacturer

Spark gap

Primary winding resistance

Secondary winding resistance

4) Spark plug

Type

Spark plug gap

5) Contact breaker

Manufacture/Quantity

Point gap

Point spring pressure

Cam closing angle

6) Condenser

Capacity

Insulation resistance

Quantity

021000-5840/NIPPON DENSO

12V

25 mm (0.98 in)

3.3 m·kg (23.9 ft·lb)

10° ~ 36°

029700-4130/NIPPON DENSO

6 mm (0.24 in) or more/500 rpm

4.0Ω ± 10% at 20°C (68°F)

9.5 kΩ ± 20% at 20°C (68°F)

NGK BP-7ES, CHAMPION N-7Y,

NIPPON DENSO W22EP

0.7 ~ 0.8 mm (0.027 ~ 0.031 in)

NIPPON DENSO/2 pcs.

0.30 ~ 0.40 mm (0.012 ~ 0.016 in)

800 ± 100 g

105°

0.24μF

10 MΩ (500V megger used)

2 pcs.

2. CHARGING SYSTEM

1) AC generator

Charging output

Rotor coil resistance (Field coil)

Stator coil resistance

14.5V 13A/5,000 rpm

4.04Ω ± 10% at 20°C (68°F)

0.72Ω ± 10% at 20°C (68°F)

<p>2) Rectifier Type Model/Manufacturer Capacity Withstand voltage</p> <p>3) Regulator Type Model/Manufacturer Regulating voltage</p> <p>4) Voltage regulator Core gap Yoke gap Point gap Voltage coil Resistor</p> <p>5) Battery Model/Manufacturer/Quantity Capacity Charging rate Specific gravity/Quantity</p>	<p>6-Element type (Full wave) DS10TEY/MITSUBISHI 12A 400V</p> <p>Tillil type 026000-2790/NIPPON DENSO 14.5 ± 0.5V</p> <p>MIN. 0.2 mm (0.008 in) MIN. 0.1 mm (0.004 in) 0.25 ~ 0.5 mm (0.01 ~ 0.02 in) 10.5 $\pm \frac{2}{-1} \Omega$ at 20°C (68°F) 140 ± 10Ω at 20°C (68°F)</p> <p>12N12-4A-1/F.B. or YUASA/1 pc. 12V, 12A 1.2A 10 hours 1.28 at 20°C (68°F), Total 800 cc (27 oz)</p>
<p>3. STARTER</p> <p>1) Starter motor Type Manufacturer Model Output Armature coil resistance Field coil resistance Brush size/Quantity Wear limit Spring pressure Commutator O.D./Wear limit</p> <p>Mica undercut Reduction system/Ratio</p> <p>2) Starter switch Manufacturer Model Ampage rating Cut-in voltage Winding resistance</p>	<p>Constant mesh type MITSUBA ELEC. SM223B 0.5 kW 0.005 ± 10% at 20°C (68°F) 0.011 ± 10% at 20°C (68°F) 11 $\pm \frac{1.5}{0}$ mm (0.43 $\pm \frac{0.06}{0}$ in)/2 pcs. 6.0 mm (0.24 in) 550 ± 55 g (19.4 ± 1.9 oz)</p> <p>0.7 mm (0.027 in) Planetary gear/6.45</p> <p>HITACHI A104-70 100A 6.5V or less 3.5Ω ± 10%</p>
<p>4. LIGHTING SYSTEM</p> <p>1) Head light type</p> <p>2) Bulb wattage/Quantity Head light wattage Tail/Stoplight wattage Flasher light wattage Meter light wattage Neutral light wattage Flasher pilot light wattage Oil pressure light wattage High beam indicator light wattage</p> <p>3) Horn Model/Manufacturer Maximum ampage</p>	<p>Sealed beam</p> <p>12V, 40/30W × 1 pc. 12V, 8/27W × 2 pcs. 12V, 27W × 2 pcs. 12V, 3.4W × 4 pcs. 12V, 3.4W × 1 pc. 12V, 3.4W × 2 pcs. 12V, 3.4W × 1 pc. 12V, 3.4W × 1 pc.</p> <p>SF-12/NIKKO 2.5A</p>

4) Flasher relay

Type

Model/Manufacturer

Flasher frequency

Capacity

5) Flasher canceling unit

Model

Voltage

6) Fuse

Rating/Quantity

Condenser type

061300-4810/NIPPON DENSO

85 ± 10 cycle/min.

$27W \times 2 + 3.4W$

EVH-AC518

DC 9V \sim 16V


Main (Red): 20A

Headlight (Red/Yellow): 10A

Signal (Brown): 10A

Ignition (Red/White): 10A

S400D CIRCUIT DIAGRAM



COLOR CODE

B	Black	B/R	Black/Red
Ch	Chocolate	G/R	Green/Red
G	Green	G/Y	Green/Yellow
L	Blue	L/W	Blue/White
O	Orange	L/Y	Blue/Yellow
P	Pink	R/L	Red/Blue
R	Red	R/W	Red/White
Br	Brown	R/Y	Red/Yellow
W	White	W/G	White/Green
Y	Yellow	Y/B	Yellow/Black
Dg	Dark green	Y/G	Yellow/Green
Gv	Gray	Y/R	Yellow/Red
Lg	Light green		
Sb	Sky blue		

XS400E

SUPPLEMENT

10

FOREWORD

This Supplementary Service Manual for XS400E has been published to supplement the Service Manual for XS360C and the Supplementary Service Manual for the XS400D. For complete information on service procedures, it is necessary to use this Supplementary Service Manual with Service Manual for XS360C (1L9-28197-10) and the Supplementary Service Manual for the XS400D (2A2-28197-10).

NOTICE

The service specifications given in this Service Manual are based on the model as manufactured. When this model may require improvements, the service specifications may be subject to change in the future. If any change is introduced into the specifications or service procedure, Yamaha dealers will be notified through technical service information to be published by Yamaha.

The Service procedure is described in the order that mechanic should follow, and the correct service procedure is described in the order that mechanic should follow, and the correct service tools should be used in the correct manner. Failure to do this may result in poor performance and danger to the rider.

Particularly important information is distinguished in this manual by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the machine.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury to machine operator or person inspecting or repairing the machine.

Page numbers shown in brackets correspond to page numbers of the XS360C Service Manual (1L9-28197-10)

(PAGE 5)

1-1. MACHINE IDENTIFICATION

Specification should be read as follows:

Starting Serial Number	
XS400E	2L0-000101

(PAGE 9 ~ 10)

2-1. MAINTENANCE AND LUBRICATION CHART

PERIODIC MAINTENANCE

Unit: km (miles)

Item	Remarks	Initial				Thereafter every			
		400 (250)	800 (500)	1,600 (1,000)	3,200 (2,000)	1,600 (1,000)	3,200 (2,000)	6,400 (4,000)	
Cylinder(s)	Check compression				○			○	
Valves	Check/Adjust valve clearance			○	○			○	
Spark plugs	Inspect/Clean or replace as required	○			○		○		
Air filter	Dry type — Clean/Replace as required			○			○		
Carburetor	Check operation/Adjust as required		○		○		○		
Brake system (complete)	Check/Adjust as required — Repair as required	○	○	○	○	○			
Clutch	Check/Adjust as required		○		○		○		
Drive chain	Check tension, alignment/Adjust as required	Every 400 (250)							
Wheel and tires	Check pressure/Wear/Balance/Damage	○	○	○		○			
Fuel petcocks	Clean/Flush tank as required	○		○			○		
Battery	Top-up/Check specific gravity and breather pipe	○	○	○	○	○			
Ignition timing	Adjust/Clean or replace parts as required		○	○	○		○		
Lights/Signals	Check operation/Replace as required	○	○	○	○	○			
Fittings/Fasteners	Tighten before each trip and/or ...	○	○	○	○	○			

LUBRICATION INTERVALS

Unit: km (miles)

Item	Remarks	Type	Initial				Thereafter every		
			400 (250)	800 (500)	1,600 (1,000)	3,200 (2,000)	1,600 (1,000)	3,200 (2,000)	6,400 (4,000)
Engine oil	Replace/Warm engine before draining	See note	○			○		○	
Drive chain	Clean/Lube	Yamaha chain and cable lube or SAE 10W/30 motor oil	Every 400 (250)						
Brake pedal shaft	Light application	Lithium base grease			○		○		
Change pedal shaft	Light application	Lithium base grease			○		○		
Control/Meter cables	Apply thoroughly	Yamaha chain and cable lube or SAE 10W/30 motor oil			○	○		○	
Throttle grip/Housing	Apply tightly	Lithium base grease				○		○	
Hydraulic brake fluid reserve	Use new fluid only	DOT NO. 3 Brake fluid	check	check	check	check	check		
Oil filter element	—	—	○			6,400 (4,000)			○
Front forks	Drain completely — Check specifications	Yamaha Fork Oil 20 wt.							12,800 (8,000)
Steering bearings	Inspect thoroughly/ Yearly or	Medium-weight wheel bearing grease							12,800 (8,000)
Speedometer gear housing	Inspect thoroughly/ Pack moderately	Lithium base grease				○			○
Rear arm pivot shafts	Apply grease fully	Medium-weight wheel bearing grease				○			○
Wheel bearings	Do not over/ Yearly or	Medium-weight wheel bearing grease							12,800 (8,000)
Point cam lubrication wicks	Apply very tightly	Light-weight machine oil			○			○	

NOTE:

Engine oil type :

- Yamalube 20W/40 motor oil or equivalent (if temperature does not go below 5°C (40°F).
- 10W/30 type "SE" motor oil (if temperature does not go above 15°C (60°F).

Brake fluid replacement:

- When disassembling the master cylinder or caliper cylinder, replace and bleed the air from the brake fluid level and add the fluid as required.
- Replace the master cylinder and caliper cylinder internal seals every two years.
- Replace the brake hoses every four years, or if cracked or damaged.

(PAGE 21)

B. Spark plug

Specification should be read as follows:

Standard spark plug	Tightening torque
NGK BP-7ES CHAMPION N-7Y	2.0 m·kg (14 ft·lb)

(PAGE 70)

5-5. TIRES AND TUBES

B. Installation

Specification should be changed as follow.

Tires

Check the tire pressure and check the tires for wear.

IMPORTANT NOTICE

Proper loading of your motorcycle is important for the handling, braking, and other performance and safety characteristics of your machine.

NEVER OVERLOAD YOUR MOTORCYCLE. Consider your riding skill, road and weather conditions, and correct weight distribution when loading your motorcycle. Securely pack your heaviest items close to the center of the machine. Always check the condition and inflation pressure of your tires.

WARNING:

Never overload your motorcycles beyond specified tire limits. Operation of an overloaded tire could cause tire damage, an accident and injury.

	FRONT	REAR
XS400E BASIC WEIGHT with oil and full fuel tank	82 kg (181 lb)	97 kg (214 lb)
Standard tire	Bridgestone 3.00S-18-4PR	Bridgestone 3.50S-18-4PR
Maximum load limit	118 kg (260 lb)	225 kg (495 lb)
Cold tire pressure: Up to 90 kg (198 lb) load	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) load ~ 115 kg (254 lb) load	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
(Maximum load) High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

Make sure the total weight of the motorcycle with accessories, rider(s), etc., does not ex-


(PAGE 81 ~ 82)

B. I.C. voltage regulator

The regulator has been changed from a mechanical-point type to an IC (Integrated Circuit) type. The IC Voltage Regulator is a small and normally very reliable component. Due to its construction, it is light-weight and free from the wear and misadjustment associated with mechanical voltage regulators. If the following inspection reveals that the regulator is faulty, it cannot be adjusted and must be replaced.

1. Checking method

- Connect D.C. voltmeter to the battery terminals.



1. D.C. voltmeter

- Start engine.
- Accelerate engine to approximately 3,000 r/min or more and check regulated voltage.

Regulated voltage: 14.0 ~ 14.7V

- If voltage is off, check battery, generator and rectifier. If generator, battery and rectifier are good, then IC regulator is broken and it should be replaced.

NOTE:

- Never disconnect wires from the battery while the generator is in operation. If the battery is disconnected, the voltage across the generator terminals will increase, damaging the semiconductors.
- When checking the regulator being installed on a machine, the battery should not be removed, and it should be fully charged.
- Never use a high voltage insulation ohmmeter such as a megaohmmeter for such a test. If high voltage is applied to the regulator terminals, the regulator will be damaged.


7-2. SPECIFICATION

A. General

1. MODEL	
1) Model (I.B.M. No.)	XS400E (2L0)
2) Frame I.D. and starting number	2L0-000101
3) Engine I.D. and starting number	2L0-000101
2. DIMENSION	
1) Overall length	2,065 mm (81.3 in)
2) Overall width	865 mm (34.1 in)
3) Overall height	1,140 mm (44.9 in)
4) Seat height	780 mm (30.7 in)
5) Wheelbase	1,365 mm (53.7 in)
6) Minimum ground clearance	150 mm (5.9 in)
3. WEIGHT	
1) Net weight (Dry)	168 kg (370 lb)
4. PERFORMANCE	
1) Climbing ability	28°
2) Minimum turning radius	2,300 mm (86.6 in)
3) Braking distance	14 m @ 50 km/h (45.9 ft @ 31 mi/h)

B. Engine

1. DESCRIPTION				
1) Engine type	Air cooled, 4-stroke, SOHC twin, parallel forward incline			
2) Engine model	2L0			
3) Displacement	391 cc (23.92 cu.in)			
4) Bore x stroke	69.0 x 52.4 mm (2.717 x 2.063 in)			
5) Compression ratio	9.3 : 1			
6) Starting system	Kick and electric starter			
7) Ignition system	Battery ignition			
8) Lubrication system	Wet sump			
2. CYLINDER HEAD				
1) Combustion chamber volume	23.6 cc (1.440 cu.in) BP7ES			
2) Combustion chamber type	Dome + Squish			
3) Head gasket thickness	1.0 mm (0.04 in)			
4) Tightening torque				
Cylinder head holding nut (M10 P1.25)	3.3 m·kg (24.0 ft·lb)			
Cylinder head holding bolt (M6 P1.0)	1.0 m·kg (7.0 ft·lb)			
Spark plug (M14 P1.25)	2.0 m·kg (14.5 ft·lb)			
3. CYLINDER				
1) Material	Aluminum alloy with cast iron sleeve			
2) Bore size	$69.0^{+0.02}_0$ mm ($2.72^{+0.0008}_0$ in)			
3) Taper limit	0.05 mm (0.002 in)			
4) Out of round limit	0.01 mm (0.0004 in)			
4. PISTON				
1) Piston skirt clearance	0.030 ~ 0.050 mm (0.0012 ~ 0.0019 in)			
2) Piston oversize				
	69.25 mm (2.727 in)	69.50 mm (2.736 in)	69.75 mm (2.746 in)	70.00 mm (2.756 in)
3) Piston pin outside diameter x length	$16.0^{+0.005}_0$ mm x $58.5^{+0.3}_0$ mm			
	$(0.63^{+0.0002}_0$ in x $2.303^{+0.0116}_0$ in)			

5. PISTON RING		Plain ring 1.0 mm (0.039 in) Plain ring 1.5 mm (0.059 in) With expander 2.45 mm (0.096 in) 0.2 ~ 0.4 mm (0.008 ~ 0.016 in) 0.2 ~ 0.4 mm (0.008 ~ 0.016 in) 0.2 ~ 0.9 mm (0.008 ~ 0.035 in) 0.04 ~ 0.08 mm (0.0016 ~ 0.0032 in) 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)																			
1) Piston ring design	(Top) (2nd) (Oil ring)																				
2) Ring end gap	(Installed, top) (Installed, 2nd) (Installed, oil)																				
3) Ring groove side clearance	(Top) (2nd) (Oil)																				
6. BIG END BEARING		Plain bearing 0.021 ~ 0.045 mm (0.0008 ~ 0.0018 in)																			
1) Type																					
2) Oil clearance																					
3) Bearing size		<table><tr><td>1. (Blue)</td><td>15.0 $+0.004$ 0 mm (0.591 $+0.00016$ 0 in)</td></tr><tr><td>2. (Black)</td><td>15.0 -0.004 0 mm (0.591 -0.00016 0 in)</td></tr><tr><td>3. (Brown)</td><td>15.0 -0.004 -0.008 mm (0.591 -0.00016 -0.00031 in)</td></tr><tr><td>4. (Green)</td><td>15.0 -0.008 -0.012 mm (0.591 -0.00031 -0.00047 in)</td></tr></table>		1. (Blue)	15.0 $+0.004$ 0 mm (0.591 $+0.00016$ 0 in)	2. (Black)	15.0 -0.004 0 mm (0.591 -0.00016 0 in)	3. (Brown)	15.0 -0.004 -0.008 mm (0.591 -0.00016 -0.00031 in)	4. (Green)	15.0 -0.008 -0.012 mm (0.591 -0.00031 -0.00047 in)										
1. (Blue)	15.0 $+0.004$ 0 mm (0.591 $+0.00016$ 0 in)																				
2. (Black)	15.0 -0.004 0 mm (0.591 -0.00016 0 in)																				
3. (Brown)	15.0 -0.004 -0.008 mm (0.591 -0.00016 -0.00031 in)																				
4. (Green)	15.0 -0.008 -0.012 mm (0.591 -0.00031 -0.00047 in)																				
7. CAMSHAFT		Chain (Center side) 3 bearings, cylinder head direct support																			
1) Can drive type																					
2) Number and type of bearing																					
3) Bearing dimensions		<table><tr><td></td><td>Cap I.D.</td><td>Shaft O.D.</td><td>Clearance</td></tr><tr><td>IN and EX</td><td>23.0 $+0.021$ 0 mm</td><td>23.0 -0.020 -0.033 mm</td><td>0.020 ~ 0.054 mm</td></tr><tr><td>1, 2, 3</td><td>(0.906 $+0.0082$ 0 in)</td><td>(0.906 -0.00079 -0.00136 in)</td><td>(0.00079 ~ 0.000213 in)</td></tr></table>			Cap I.D.	Shaft O.D.	Clearance	IN and EX	23.0 $+0.021$ 0 mm	23.0 -0.020 -0.033 mm	0.020 ~ 0.054 mm	1, 2, 3	(0.906 $+0.0082$ 0 in)	(0.906 -0.00079 -0.00136 in)	(0.00079 ~ 0.000213 in)						
	Cap I.D.	Shaft O.D.	Clearance																		
IN and EX	23.0 $+0.021$ 0 mm	23.0 -0.020 -0.033 mm	0.020 ~ 0.054 mm																		
1, 2, 3	(0.906 $+0.0082$ 0 in)	(0.906 -0.00079 -0.00136 in)	(0.00079 ~ 0.000213 in)																		
4) Cam dimensions		<table><tr><td></td><td>Cam height "A"</td><td>Limit</td><td>Base circle "B"</td><td>Limit</td><td>Lift "C"</td></tr><tr><td>IN</td><td>39.53 ± 0.05 mm (1.556 ± 0.0019 in)</td><td>39.38 mm (1.550 in)</td><td>32.27 ± 0.05 mm (1.270 ± 0.0019 in)</td><td>32.12 mm (1.265 in)</td><td>7.53 mm (0.296 in)</td></tr><tr><td>EX</td><td>39.57 ± 0.05 mm (1.558 ± 0.0019 in)</td><td>39.42 mm (1.552 in)</td><td>32.12 ± 0.05 mm (1.265 ± 0.0019 in)</td><td>31.97 mm (1.259 in)</td><td>7.57 mm (0.298 in)</td></tr></table> 			Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"	IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)	EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)
	Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"																
IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)																
EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)																
5) Valve timing		<table><tr><td></td><td>OPEN</td><td>CLOSE</td><td>DURATION</td><td>OVERLAP</td></tr><tr><td>IN</td><td>BTDC 30°</td><td>ABDC 70°</td><td>280°</td><td rowspan="2">60°</td></tr><tr><td>EX</td><td>BBDC 70°</td><td>ATDC 30°</td><td>280°</td></tr></table>			OPEN	CLOSE	DURATION	OVERLAP	IN	BTDC 30°	ABDC 70°	280°	60°	EX	BBDC 70°	ATDC 30°	280°				
	OPEN	CLOSE	DURATION	OVERLAP																	
IN	BTDC 30°	ABDC 70°	280°	60°																	
EX	BBDC 70°	ATDC 30°	280°																		
6) Camshaft deflection limit		0.03 mm (0.0012 in)																			
7) Cam chain		TSUBAKIMOTO BF05M 7.774 mm (0.3060 in)/92L 34/17 (2.000)																			
8. ROCKER ARM AND ROCKER SHAFT		13.0 $+0.018$ 0 mm (0.512 $+0.0007$ 0 in)																			
1) Rocker arm inner diameter																					
2) Rocker arm shaft diameter		13.0 -0.016 -0.036 mm (0.512 -0.00063 -0.00141 in)																			
3) Clearance		0.016 ~ 0.054 mm (0.00053 ~ 0.00122 in)																			
4) Lift ratio		X : Y = 32.05 : 33.62 mm (1.262 : 1.324 in)																			

9. VALVE, VALVE SEAT AND VALVE GUIDE

- 1) Valve per cylinder
- 2) Valve clearance (In cold engine)


3) Dimensions

Valve head diameter "A"

Valve face width "B"

Valve seat width "C"

Valve margin thickness "D"



Valve stem diameter

Valve guide diameter

Valve stem to stem clearance

4) Valve face runout limit

10. VALVE SPRING

1) Free length

2) Spring rate (kg/mm)

3) Installed length (Valve closed)

4) Installed pressure (Valve closed)

5) Compressed length (Valve open)

6) Compressed pressure (Valve open)

7) Wire diameter (Valve open)

8) Winding O.D. (Valve open)

9) Number of windings (Valve open)

10) Tilt limit (Valve open)

2 pcs.

IN: 0.08 ~ 0.12 mm (0.0031 ~ 0.0047 in)

EX: 0.16 ~ 0.20 mm (0.0063 ~ 0.0078 in)

IN: 35.5 ± 0.1 mm (1.398 ± 0.004 in)

EX: 30.0 ± 0.1 mm (1.181 ± 0.004 in)

IN: 2.3 mm (0.091 in)

EX: 2.3 mm (0.091 in)

IN: 1.0 ± 0.1 mm (0.039 ± 0.004 in)

EX: 1.0 ± 0.1 mm (0.039 ± 0.004 in)

IN: 1.0 ± 0.2 mm (0.039 ± 0.008 in)

EX: 1.0 ± 0.2 mm (0.039 ± 0.008 in)

IN: 7.0 $\begin{smallmatrix} -0.010 \\ -0.025 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} -0.0004 \\ -0.0009 \end{smallmatrix}$ in)

EX: 7.0 $\begin{smallmatrix} -0.030 \\ -0.045 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} -0.0012 \\ -0.0018 \end{smallmatrix}$ in)

IN; 7.0 $\begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} +0.0005 \\ 0 \end{smallmatrix}$ in)

EX: 7.0 $\begin{smallmatrix} +0.012 \\ 0 \end{smallmatrix}$ mm (0.275 $\begin{smallmatrix} +0.0005 \\ 0 \end{smallmatrix}$ in)

IN: 0.010 ~ 0.037 mm (0.00039 ~ 0.00145 in)

EX: 0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)

IN & EX: 0.03 mm (0.0012 in) or less

INNER (IN/EX): 39.3 mm (1.547 in)

OUTER (IN/EX): 42.8 mm (1.685 in)

INNER (IN/EX): $k_1 = 1.93$

$k_2 = 2.47$

OUTER (IN/EX): $k_1 = 4.19$

$k_2 = 5.49$

INNER(IN/EX): 33.0 mm (1.299 in)

OUTER(IN/EX): 37.0 mm (1.457 in)

INNER (IN/EX): 12.1 ± 1.2 kg (26.7 ± 2.6 lb)

OUTER (IN/EX): 24.4 ± 1.7 kg (53.8 ± 3.8 lb)

INNER (IN/EX): 25.0 mm (0.984 in)

OUTER (IN/EX): 29.0 mm (1.142 in)

INNER (IN/EX): 31.9 kg (69.2 lb)

OUTER (IN/EX): 68.3 kg (151 lb)

INNER (IN/EX): 3.0 mm (0.118 in)

OUTER (IN/EX): 4.4 mm (0.173 in)

INNER (IN/EX): 22.4 mm (0.882 in)

OUTER (IN/EX): 32.0 mm (1.260 in)

INNER (IN/EX): 7.75 turns

OUTER (IN/EX): 6.25 turns


INNER (IN/EX): 1.7 mm (0.067 in) or 2.5°

OUTER (IN/EX): 1.9 mm (0.075 in) or 2.5°

11. CRANKSHAFT 1) Crankshaft deflection 2) Con-rod large end clearance 3) Clearance between crank and crankcase	0.02 mm (0.0008 in) 0.160 ~ 0.264 mm (0.0063 ~ 0.0104 in) 0.05 ~ 0.25 mm (0.002 ~ 0.010 in)								
12. CONNECTING ROD 1) Big end I.D. 2) Small end I.D. 3) Difference of each rod weight	41.0 $\begin{smallmatrix} +0.024 \\ 0 \end{smallmatrix}$ mm (1.614 $\begin{smallmatrix} +0.0009 \\ 0 \end{smallmatrix}$ in) 16.0 $\begin{smallmatrix} +0.028 \\ +0.015 \end{smallmatrix}$ mm (0.630 $\begin{smallmatrix} +0.0011 \\ +0.0028 \end{smallmatrix}$ in) 5 g or less								
13. CRANK BEARING 1) Oil clearance 2) Bearing size	0.020 ~ 0.044 mm (0.00079 ~ 0.00157 in) <table border="1" data-bbox="524 375 909 518"> <tr> <td>1. (Blue)</td><td>15.0 $\begin{smallmatrix} +0.012 \\ +0.008 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00047 \\ +0.00031 \end{smallmatrix}$ in)</td></tr> <tr> <td>2. (Black)</td><td>15.0 $\begin{smallmatrix} +0.008 \\ +0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00031 \\ +0.00016 \end{smallmatrix}$ in)</td></tr> <tr> <td>3. (Brown)</td><td>15.0 $\begin{smallmatrix} +0.004 \\ 0 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00016 \\ 0 \end{smallmatrix}$ in)</td></tr> <tr> <td>4. (Green)</td><td>15.0 $\begin{smallmatrix} 0 \\ -0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} 0 \\ -0.00016 \end{smallmatrix}$ in)</td></tr> </table>	1. (Blue)	15.0 $\begin{smallmatrix} +0.012 \\ +0.008 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00047 \\ +0.00031 \end{smallmatrix}$ in)	2. (Black)	15.0 $\begin{smallmatrix} +0.008 \\ +0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00031 \\ +0.00016 \end{smallmatrix}$ in)	3. (Brown)	15.0 $\begin{smallmatrix} +0.004 \\ 0 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00016 \\ 0 \end{smallmatrix}$ in)	4. (Green)	15.0 $\begin{smallmatrix} 0 \\ -0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} 0 \\ -0.00016 \end{smallmatrix}$ in)
1. (Blue)	15.0 $\begin{smallmatrix} +0.012 \\ +0.008 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00047 \\ +0.00031 \end{smallmatrix}$ in)								
2. (Black)	15.0 $\begin{smallmatrix} +0.008 \\ +0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00031 \\ +0.00016 \end{smallmatrix}$ in)								
3. (Brown)	15.0 $\begin{smallmatrix} +0.004 \\ 0 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} +0.00016 \\ 0 \end{smallmatrix}$ in)								
4. (Green)	15.0 $\begin{smallmatrix} 0 \\ -0.004 \end{smallmatrix}$ mm (0.591 $\begin{smallmatrix} 0 \\ -0.00016 \end{smallmatrix}$ in)								
14. CLUTCH 1) Clutch type 2) Clutch operating mechanism 3) Primary reduction ratio and method 4) Friction plate Thickness/Quantity Wear limit 5) Clutch plate Thickness/Quantity Warp limit 6) Clutch spring Free length/Quantity Minimum length 7) Clutch housing radial play (Wear limit) 8) Push rod bending limit 9) Tightening torque Primary drive gear (M10 P1.25) Clutch spring screw (M6 P1.0)	Wet, multiple type Inner push type, screw push system 78/24 (3.250), spar gear 3 mm (0.12 in)/7 pcs. 2.7 mm (0.11 in) 1.6 mm (0.063 in)/6 pcs. 0.05 mm (0.002 in) 34.6 mm (1.362 in)/4 pcs. 33.6 mm (1.323 in) 0.009 ~ 0.043 mm (0.00035 ~ 0.00169 in) 0.2 mm (0.008 in) 4.8 m·kg (34.5 ft·lb) 1.0 m·kg (7.2 ft·lb)								
15. TRANSMISSION 1) Type 2) Gear ratio: 1st 2nd 3rd 4th 5th 6th 3) Bearing type: Main axle (Left) Main axle (Right) Drive axle (Left) Drive axle (Right) 4) Oil seal type Drive axle (Left) 5) Secondary reduction ratio and method 6) Tightening torque Drive sprocket (M18 P1.0)	Constant mesh, 6-speed forward 35/14 (2.500) 32/18 (1.777) 29/21 (1.380) 27/24 (1.125) 25/26 (0.961) 26/30 (0.866) Needle bearing (φ 20-φ 30-15) Ball bearing (5205) Ball bearing (6305 special) Needle bearing (φ 20-φ 33-15) SD-35-62-6 39/16 (2.437) Chain 6.5 m·kg (47.0 ft·lb)								

16. SHIFTING MECHANISM 1) Type 2) Oil seal type (Change lever) 3) Tightening torque Change pedal (M6 P1.0)	Cam drum, return type SD-12-22-5 1.0 m·kg (7.2 ft·lb)
17. KICK STARTER 1) Type 2) Oil seal type (Kick axle) 3) Kick clip friction tension 4) Tightening torque Kick crank (M8 P1.25)	Kick and mesh SD-20-30-7 1.0 m·kg (7.0 ft·lb) 2.0 m·kg (14.5 ft·lb)
18. CRANKCASE 1) Tightening torque Bolt (M8 P1.25) Bolt (M6 P1.0)	2.2 m·kg (16.0 ft·lb) 1.0 m·kg (7.0 ft·lb)
19. INTAKE 1) Air cleaner: Type/Quantity 2) Cleaner cleaning interval 3) Valve clearance	Dry, foam rubber/2 pcs. Every 3,200 km (2,000 mile) See No. 9-2) Valve, valve seat and valve guide
20. CARBURETOR 1) Type and manufacturer/Quantity 2) I.D. mark 3) Main jet (MJ) 4) Air jet (AJ) 5) Jet needle-clip position (JN) 6) Needle jet (NJ) 7) Throttle valve (Th.V) 8) Pilot jet (PJ) 9) Air screw (Turns out) (AS) 10) Starter jet (GS) 11) Fuel level (FL) 12) Vacuum synchronization 13) Idling engine speed	BS34 MIKUNI/2 pcs. 2L0-60 # 132.5 # 45 5Z1-3 X-6 # 135 # 42.5 1-1/4 ± 1/2 # 30 32 ± 1 mm (1.26 ± 0.04 in) 5 mmHg or less 1,200 ± 50 r/min
21. LUBRICATION 1) Engine sump oil quantity 2) Oil type 3) Oil pump type 4) Trochoid pump specifications Top clearance Tip clearance Side clearance Oil pump volume 5) Relief valve operating pressure 6) Bypass valve setting pressure	Oil exchange: 2.0 lit (2.1 qt) Filter and oil exchange: 2.3 lit (2.4 qt) Total amount: 2.6 lit (2.7 qt) Yamalube 4-cycle oil or SAE 20W/40"SE" motor oil (more than 5°C (32°F)) SAE 10W/30"SE" motor oil (below 15°C (59°F)) Trochoid pump 0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 1.2 lit/min at 500 r/min 5 ± 0.5 kg/cm ² (71 ± 7 psi) 1.0 ± 0.2 kg/cm ² (14 ± 3 psi)

8) Lubrication chart



C. Chassis

1. FRAME 1) Frame design 2) Tightening torque Engine mounting bolt (M8 P1.25) Engine mounting bolt (M10 P1.25)	Semi double cradle, high tensile frame 1.8 m-kg (13.0 ft-lb) 3.1 m-kg (22.5 ft-lb)
2. STEERING SYSTEM 1) Caster 2) Trail 3) Number and size of balls in steering head Upper race Lower race 4) Steering lock to lock 5) Tightening torque Steering shaft fitting nut (M14 P1.25) Steering shaft fitting nut (M25 P1.0) Stem pinch bolt (M8 P1.25) Handle bar mounting bolt (M10 P1.25)	27° 84 mm (3.31 in) 19 pcs. 1/4 in 19 pcs. 1/4 in 42° each (L and R) 5.4 m-kg (39.0 ft-lb) 3.8 m-kg (27.5 ft-lb) 1.2 m-kg (8.5 ft-lb) 2.3 m-kg (16.5 ft-lb)
3. FRONT SUSPENSION 1) Type 2) Damper type 3) Front fork spring Free length Wire diameter x winding diameter Spring constant 4) Front fork travel 5) Inner tube O.D. 6) Front fork oil quantity and type	Telescopic fork Oil damper, coil spring 484 mm (19.05 in) 3.8 mm x 23 mm (0.15 x 0.91 in) $k_1 = 0.4 \text{ kg/mm (0 ~ 100 mm)}$ $k_2 = 0.575 \text{ kg/mm (100 ~ 140 mm)}$ 140 mm (5.5 in) 33 mm (1.30 in) 142 cc (4.8 oz) each leg Yamaha fork oil or SAE 10W/30 motor oil

7) Oil seal type	SD-33-46-10.5
8) Tightening torque Under bracket and inner tube (M10 P1.25) Handle crown and inner tube (M8 P1.25)	3.5 m·kg (25.0 ft·lb) 1.1 m·kg (8.0 ft·lb)
4. REAR SUSPENSION	
1) Type	Swing arm
2) Damper type	Oil damper, coil spring
3) Shock absorber travel	80 mm (3.15 in)
4) Shock absorber spring	
Set length	216 mm (8.50 in)
Free length	205 mm (8.07 in)
Wire diameter x winding diameter	7.0 mm x 54.0 mm (0.27 x 2.13 in)
Spring constant	$k_1 = 1.7 \text{ kg/mm}$ (0 ~ 55 mm) $k_2 = 2.1 \text{ kg/mm}$ (55 ~ 80 mm)
5) Swing arm free play (Limit)	1.0 mm (0.04 in)
6) Pivot shaft — Outside diameter	16 mm (0.63 in)
7) Tightening torque:	
Rear shock absorber (Upper) (M10 P1.25)	3.0 m·kg (21.5 ft·lb)
Rear shock absorber (Upper) (M10 P1.25)	3.0 m·kg (21.5 ft·lb)
Pivot shaft (M14 P1.5)	6.5 m·kg (47.0 ft·lb)
5. FUEL TANK	
1) Capacity	14.0 lit (3.7 US. gal)
2) Fuel grade	Regulator gasoline (90 octane)
6. WHEEL	
1) Type (Front and rear)	Cast wheel
2) Tire size (Front)	3.00S18-4PR
(Rear)	3.50S18-4PR
3) Tire pressure:	
Normal riding: (Front)	1.8 kg/cm ² (26 psi)
(Rear)	2.0 kg/cm ² (28 psi)
High speed riding or with passenger (Front)	2.0 kg/cm ² (28 psi)
(Rear)	2.3 kg/cm ² (33 psi)
4) Rim run out limit (Front and rear)	
Vertical	2.0 mm (0.08 in)
Lateral	2.0 mm (0.08 in)
5) Rim size (Front)	1.85 x 18
(Rear)	2.15 x 18
6) Bearing type	
Front wheel (Left)	6302ZZ
Front wheel (Right)	6302ZZ
Rear wheel (Left)	6304ZZ
Rear wheel (Right)	6304ZZ
7) Oil seal type	
Front wheel (Left)	SDD-45-56-6
Front wheel (Right)	SD-22-42-7
Rear wheel (Left)	SD-27-52-5
Rear wheel (Right)	SD-23-47-7
8) Secondary drive chain type	
Type	DK530DS
Number of links	97L + Joint
Chain pitch	15.875 mm (5/8 in)
Chain free play	10 ~ 20 mm (0.4 ~ 0.8 in)
9) Tightening torque	
Front wheel axle (M14 P1.5)	10.7 m·kg (77.5 ft·lb)
Front axle holder (M8 P1.25)	2.0 m·kg (14.5 ft·lb)
Rear wheel axle (M14 P1.5)	10.7 m·kg (77.5 ft·lb)

7. BRAKE	
1) Front and rear brake	
Type	Hydraulic disc type
Disc size (Outside dia. x thickness)	257 mm x 5.0 mm (10.5 x 0.2 in)
Disc wear limit	4.5 mm (0.18 in)
Disc pad thickness	6.5 mm (0.26 in)
Pad wear limit (Minimum thickness)	1.5 mm (0.06 in)
Master cylinder inside dia.	
Front	14.0 mm (0.55 in)
Rear	15.8 mm (0.62 in)
Caliper cylinder inside dia.	38.1 mm (1.5 in)
Brake fluid type/quantity	DOT #3/34 cc (0.8 oz)
2) Tightening torque	
Brake disc and hub (M8 P1.25)	2.0 m·kg (14.5 ft·lb)
Caliper and support bracket (M8 P1.25)	1.8 m·kg (13.0 ft·lb)
Caliper and pad (M5 P0.8)	0.3 m·kg (2.0 ft·lb)
Caliper and bleed screw (M8 P1.25)	0.6 m·kg (4.5 ft·lb)
Support bracket and front fork (M10 P1.25)	3.5 m·kg (25.5 ft·lb)
Caliper and brake hose (M10 P1.25)	2.6 m·kg (19.0 ft·lb)
Master cylinder and cylinder bracket (M6 P1.0)	0.6 m·kg (4.5 ft·lb)

D. Electrical

1. IGNITION SYSTEM	
1) Battery (AC generator)	
Model/Manufacturer	021000-5840/NIPPON DENSO
Voltage	12V
Taper dia. at large end	25 mm (0.98 in)
Rotor tightening torque (M10 P1.25)	3.3 m·kg (24.0 ft·lb)
2) Ignition timing (B.T.D.C.)	10° / 1,200 r/min
3) Ignition coil	
Model/Manufacturer	029700-4130/NIPPON DENSO
Spark gap	6 mm (0.24 in) or more/500 r/min.
Primary winding resistance	4.0 Ω \pm 10% at 20°C (68°F)
Secondary winding resistance	9.5K Ω \pm 20% at 20°C (68°F)
4) Spark plug	
Type	NGK BP-7ES, CHAMPION N-7Y.
Spark plug gap	0.7 ~ 0.8 mm (0.027 ~ 0.031 in)
5) Contact breaker	
Manufacture/Quantity	NIPPON DENSO/2 pcs.
Point gap	0.30 ~ 0.40 mm (0.012 ~ 0.016 in)
Point spring pressure	800 \pm 100 g
Cam closing angle	105°
6) Condenser	
Capacity	0.24 μ F \pm 15%
Insulation resistance	10M Ω (500V-megger used) or more
Quantity	2 pcs.
2. CHARGING SYSTEM	
1) AC generator	
Charging output	14.5V 13A/5,000 r/min
Rotor coil resistance (Field coil)	4.04 Ω \pm 10% at 20°C (68°F)
Stator coil resistance	0.72 Ω \pm 10% at 20°C (68°F)

<p>2) Rectifier</p> <p>Type Model/Manufacturer Capacity Withstand voltage</p> <p>3) Regulator</p> <p>Type Model/Manufacturer Regulating voltage</p> <p>4) Battery</p> <p>Model/Manufacturer/Quantity Capacity Charging rate Specific gravity/Quantity</p>	<p>6-Element type (Full wave) DS10TEY/MITSUBISHI or DE3804-1/STANLEY 12V 400V</p> <p>I.C. type 026000-3280 NIPPON DENSO 14.0 ~ 14.7V</p> <p>12N12-4A-1 12V, 12AH 1.2A 10 hours 1.28 at 20°C (68°F), Total 800 cc (27 oz)</p>
<p>3. STARTER</p> <p>1) Starter motor</p> <p>Type Manufacturer Model Output Armature coil resistance Field coil resistance Brush size/Quantity</p> <p>Wear limit Spring pressure Commutator O.D./Wear limit Mica undercut Reduction system/Ratio</p> <p>2) Starter switch</p> <p>Manufacturer Model Amperage rating Cut-in voltage Winding resistance</p>	<p>Constant mesh type MITSUBA ELEC. SM223B 0.5kW 0.005Ω±10% at 20°C (68°F) 0.011Ω±10% at 20°C (68°F) 11 ^{+1.5}₀ mm (0.43 ^{+0.06}₀ in)/2 pcs. 6.0 mm (0.24 in) 550 ± 55 g (19.4 ± 1.9 oz) 28 mm (1.102 in)/27 mm (1.063 in) 0.7 mm (0.027 in) Chain / 6.45</p> <p>HITACHI A104-70 100A 6.5V or less 3.5Ω ± 10%</p>
<p>4. LIGHTING SYSTEM</p> <p>1) Head light type</p> <p>2) Bulb wattage/Quantity</p> <p>Head light wattage Tail/brake light wattage Flasher light wattage Meter light wattage Neutral light wattage Flasher pilot light wattage Oil pressure light wattage High beam indicator light wattage</p> <p>3) Horn</p> <p>Model/Manufacturer Maximum amperage</p>	<p>Semi-sealed beam</p> <p>12V, 40/30W 12V, 8/27W (3/32 cp) x 2 pcs. 12V, 27W (32 cp) x 4 pcs. 12V, 3.4W x 4 pcs. 12V, 3.4W 12V, 3.4W 12V, 3.4W 12V, 3.4W</p> <p>SF-12/NIKKO 2.5A</p>

4) Flasher relay

Type

Model/Manufacturer

Flasher frequency

Capacity

5) Flasher cancelling unit

Model

Voltage

6) Fuse

Rating/Quantity

Condenser type

061300-4810/NIPPON DENSO

85 \pm 10 cycle/min.

27W x 2 +3.4W

EVH-AC518

DC9V ~ 16V

Main (Red): 20 A

Headlight (Red/Yellow): 10A

Signal (Brown): 10A

Ignition (Red/White): 10A

XS400-2E

SUPPLEMENT

FOREWORD

This Supplementary Service Manual for XS400-2E has been published to supplement the Service Manual for the XS360C (1L9-28197-10) and includes changes in specifications and addition to the data.

For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with the Service Manual for the XS360C (1L9-28197-10).

NOTICE

This manual has been written by Yamaha Motor Company for use by Authorized Yamaha Dealers and their qualified mechanics. In light of this purpose it has been assumed that certain basic mechanical precepts and procedures inherent to basic knowledge, repairs or service to this model may render the machine unsafe, and for this reason we must advise that all repairs and/or service be performed by an Authorized Yamaha Dealer who is in possession of the requisite basic product knowledge.

The Research, Engineering and Overseas Service Department of Yamaha are continually striving to further improve all models manufactured by the company. Modifications are therefore inevitable and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha Dealers and will, where applicable, appear in future editions of this manual.

Particularly important information is distinguished in this manual by the following notations:

- NOTE:** A NOTE provides key information to make procedures easier or clearer.
- CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the machine.
- WARNING:** A WARNING indicates special procedures that must be followed to avoid injury to a machine operator or person inspecting or repairing the machine.

Pages numbers shown in brackets correspond to page numbers of the XS360C (1L9-28197-10) Service Manual.

(PAGE 5)

H. MACHINE IDENTIFICATION

Specification should be read as follow:

Starting Serial Number	
XS400-2E	2G5-000101

(PAGE 9, 10)

2-1. MAINTENANCE AND LUBRICATION CHART

Periodic Maintenance

Unit: km (mile)

Item	Remarks	Initial				Thereafter every		
		400 (250)	800 (500)	1,600 (1,000)	3,200 (2,000)	1,600 (1,000)	3,200 (2,000)	6,400 (4,000)
Cylinder	Check compression				○			○
Valves	Check/Adjust valve clearance			○	○			○
Spark plugs	Inspect/Clean or replace as required	○			○		○	
Air filter	Dry type-Clean/Replace as required			○			○	
Carburetor	Check operation/Adjust as required		○		○		○	
Brake system (complete)	Check/Adjust as required- Repair as required		○	○		○		
Wheel and tires	Check pressure/ Wear/Balance	○	○	○		○		
Fuel petcock	Clean/Flush tank as required	○		○			○	
Battery	Top-up/Check specific gravity and breather pipe	○	○	○	○	○		
Ignition timing	Adjust/Clean or replace parts as required		○	○	○		○	
Lights/Signals	Check operation/Replace as required	○	○	○	○	○		
Fittings/Fasteners	Tighten before each trip and/or	○	○	○	○	○		

Lubrication Intervals

Item	Remarks	Type	Initial				Thereafter every		
			400 (250)	800 (500)	1,600 (1,000)	3,200 (2,000)	1,600 (1,000)	3,200 (2,000)	6,400 (4,000)
Engine/Transmission oil	Replace/Warm engine before draining	See Note	○			○		○	
Drive chain	Lube/Adjust as required	Yamaha chain and cable lube or	Every 400 (250)						
	Remove/Clean/Lube	SAE 10W/30 motor oil			○		○		
Brake pedal shaft	Light application	Yamaha chain and cable lube or SAE 10W/30 motor oil			○		○		
Change pedal shaft	Light application	Yamaha chain and cable lube or SAE 10W/30 motor oil			○		○		
Control/Meter	Apply thoroughly	Yamaha chain and cable lube or SAE 10W/30 motor oil			○	○		○	
Throttle grip/Housing	Apply lightly	Lithium base grease				○		○	
Oil filter element	Replace	—	○			6,400 (4,000)			○
Front forks	Drain completely—Check specifications	Yamaha Fork Oil 20Wt.							12,800 (8,000)
Steering bearing	Inspect thoroughly/Yearly or	Medium-weight wheel bearing grease							12,800 (8,000)
Speedometer gear housing	Inspect thoroughly/Pack moderately	Lithium base grease				○			○
Point cam lubrication wicks	Apply very lightly	Light-weight machine oil			○			○	

NOTE:

Engine/Transmission oil type:

- Yamalube 20W/40 motor oil or equivalent (if temperature does not go below 5°C (41°F)).
- 10W/30 type "SE" motor oil (if temperature does not go above 15°C (59°F)).

2-2. ENGINE

A. Carburetor

1. Idle mixture

The idle mixture is set at the factory by the use of special equipment. No attempt should be made to change this adjustment by the dealer.




2. Idle speed adjustment

NOTE:

Carburetors must be synchronized before setting final idle speed. The idle speed adjustment is made by turning only one throttle stop screw.

- The engine must be warmed up before setting idle speed.
- Set engine idle speed by turning the throttle stop screw in (to increase engine speed) or out (to decrease engine speed).

Standard idle r/min:
1,150 ~ 1,250 r/min



3. Throttle cable adjustment

NOTE:

Idle speed should be set before making this adjustment.

The throttle grip should have a play of 3 ~ 7mm (0.12 ~ 0.28 in) in the turning direction at the grip flange. If the play is not this range, take the following steps for adjustment:

Loosen the lock nut on the throttle cable, and turn the adjuster in or out so the play is correct. After the adjustment, tighten the lock nut.


4. Synchronization

NOTE:

Ignition timing and valve clearance must be set properly before synchronizing carburetors.

Procedure:

- Turn petcock to "PRI" position. Remove vacuum pipe and blind plug from carburetor joints.
- Connect vacuum gauge pipes on carburetor joints.
- Start engine and allow it to warm-up for a few minutes. The warm-up is complete when engine responds normally to throttle opening.
- Adjust damping valve on vacuum gauge until the needle flutters only slightly. The gauge needle must respond quickly to rapid opening of the throttle.
- Both gauge reading will indicate the same reading if the carburetors are synchronized.
- If not, turn the synchronizing screw until the gauge reading is the same.



1. Synchronizing screw

(PAGE 13)

C. Float Level

Specification should be read as follow:

Float height:

$25.7 \pm 1.0\text{mm}$ (1.012 ± 0.039 in)

D. Engine Oil

1. Oil level measurement

- a. Place machine is positioned straight up and on both wheels. Warm up engine for a few minutes. With the engine stopped, screw the dip stick completely out and then reset the stick in the hole.

NOTE:

When checking engine oil level with the dip stick, let the unscrews dip stick rest on the case threads. Also, be sure the engine is stopped and the machine is positioned straight up and both wheels.

- b. The dip stick has a Minimum and a Maximum mark. The oil level should be between the two. If the level is lower, add sufficient oil to raise it to the proper level.

Oil Capacity:

Periodic oil change

2.0 lit (2.1 US qt)

With oil filter replacement

2.3 lit (2.4 US qt)

Total amount

2.6 lit (2.7 US qt)

Recommended Oil:

- a. Yamalube 20W/40 motor oil or equivalent (if temperature does not go below 5°C (41°F)).
- b. 10W/30 type "SE" motor oil (if temperature does not go above 15°C (59°F)).

(PAGE 15)

G. Valve Clearance Adjustment

Specifications should be read as follows:

Valve clearance (cold):

Intake 0.10mm (0.004 in)

Exhaust 0.18mm (0.007 in)


(PAGE 16)

B. Front Brake

1. Brake adjustment


The front brake should be adjusted to suit rider preference with a minimum cable slack of 5 ~ 8mm (0.2 ~ 0.3 in) play at the brake lever pivot point. Adjustment is accomplished at one of two places; either the handlebar lever holder of the front brake hub.

- a. Loosen the lock nut.
- b. Turn the cable length adjuster in or out until adjustment is suitable.




1. Maximum level 2. Minimum level

- c. Tighten the lock nut.



1. Adjuster 2. Lock nut



1. Adjuster 2. Lock nut

2. Brake pad check
Delete the whole paragraph.
3. Brake fluid level check
Delete the whole paragraph.

(PAGE 17)

D. Drive Chain Tension Check


Inspect the drive chain with both tires touching the ground and machine is positioned straight up. Check the tension at the halfway between the drive and driven sprockets. The normal vertical deflection is approximately 30 ~ 35mm (1.2 ~ 1.4 in). If the deflection exceeds 35mm (1.4 in) adjust the chain tension.

NOTE:

Before checking and/or adjusting, rotate rear wheel through several revolutions and check tension several times to find the tightest point on the chain. Check and/or adjust chain tension with rear wheel in the "tight chain" position.

E. Drive Chain Tension Adjustment

1. Loosen the rear brake adjuster.
2. Remove the cotter pin of the rear wheel axle nut.
3. Loosen the axle nut.
4. To tighten chain, turn chain puller adjuster clockwise. To loosen chain, turn adjuster counterclockwise. To each adjuster exactly the same amount to maintain correct axle alignment.



1. Rear wheel axle nut 4. Adjuster
2. Cotter pin 5. Marks for align
3. Lock nut

5. After adjusting, be sure to tighten the lock nuts and the rear wheel axle nut.
6. Install the new cotter pin.
7. In the final step, adjust the play in the brake pedal.

(PAGE 19)

2-4. ELECTRICAL

A. Contact Breaker

1. The contact breaker should be checked for the following:
 - a. Wear of the bakelite cam heel.
 - b. Damage of contact point surfaces.
 - c. Rust or wear on the breaker arm or arm shaft.
 - d. Faulty insulation of the contact breaker assembly.
 - e. Oil or dirt on the assembly.
2. To clean the points, run a point file between the points until grey deposits and pits have been removed. Spray the points with ignition cleaner or lacquer thinner, then snap the points shut on a bit of wire.

through until no more carbon or metal particles come off on the card. (The card may be clipped in lacquer or other cleaner to facilitate this procedure.)

- Point replacement should be necessary when the points become severely pitted, or if the heel is broken or worn unevenly, or if the points become shorted or show faulty operation.


NOTE:

New points must be cleaned and adjusted.

- Adjust point gap (at widest opening) by moving the contact breaker assembly. Use filler gauge for this adjustment.

Point gap:

0.3 ~ 0.4 mm (0.012 ~ 0.015 in)



- Add a few drops of light-weight machine oil onto the felt rubbing pad after each point adjustment to lubricate the point cam surface. Do not over oil.


B. Ignition Timing

NOTE:


Point gap must be set before setting ignition timing.

- Ignition timing is checked with a timing light by observing the position of the stationary pointer on the crankcase cover and the marks stamped on the generator rotor.

"LF"	Retarded firing point for L.H. cylinder
"RF"	Retarded firing point for R.H. cylinder
"LT"	Top Dead Center for L.H. cylinder
"RT"	Top Dead Center for R.H. cylinder



1. "LF" mark 2. "LT" mark 3. Pointer



1. "RF" mark 2. "RT" mark 3. Pointer

- Connect timing light to left cylinder spark lead wire. Ignition timing of left cylinder must be set first.

NOTE:


Install a suitable rubber cap on to the crankcase cover lower hole.

- Start the engine and keep the engine speed as specified. Use a tachometer for checking.


Engine idling speed:
1,200 r/min

- The "LF" mark stamped on the rotor should line up pointer on the crankcase cover at a specified engine speed. If it does not align, loosen two breaker


5. To inspect starter jet, remove the starter assembly to the left side of the carburetor.



6. Remove the four screws holding the float bowl cover. Remove the float bowl cover. The main jet is located under a cover in the float bowl.




7. Pull out float pivot pin. Remove the float assembly. Be careful to not lose the float valve needle located under the float level adjustment tang. Remove the needle jet.




8. Reassemble in reverse order. Pay close attention to the installation of the vacuum position diaphragm.

B. Inspection

1. Examine carburetor body and fuel passages. If contaminated, wash carburetor in petroleum-based solvent. Blow out all passages and jets with compressed air.
2. Examine condition of floats. If floats are leaking or damaged, they should be replaced.
3. Inspect inlet needle valve and seat for wear or contamination. Replace these components as a set.



4. Inspect vacuum piston and rubber diaphragm. If the piston is scratched or the diaphragm is torn, the assembly must be replaced.



C. Adjustment (Float level)

Refer to CHAPTER 2, Section 2-2, C for "Float Level" adjustment procedure.

Tightening point	Stud dia. (mm)	Q'ty	Torque m·kg (ft·lb)	Remarks
Oil filter	20	1	1.5 (11.0)	
Oil strainer	5	6	0.7 (5.0)	
Oil pressure switch	1/8 in	1	1.8 (13.0)	Apply Lock Tite
Crankcase	8	7	2.2 (16.0)	
	6	14	1.0 (7.0)	
Clutch spring screw	6	4	1.0 (7.0)	
Primary drive gear	10	1	4.8 (35.0)	
Drive sprocket	18	1	6.5 (47.0)	
Kick crank	8	1	2.0 (14.5)	
Change pedal	6	1	1.0 (7.0)	
Neutral switch	5	3	0.4 (3.0)	
Exhaust pipe	8	4	2.2 (16.0)	

3-3. INSPECTION AND REPAIRING

C. Valves, Valve Springs, Valve Guides and Valve Seats

2. Checking the valve springs

	Outer (IN & EX)	Inner (IN & EX)
Free length	42.8 mm (1.685 in)	39.3 mm (1.547 in)
Installed length (Valve closed)	37.0 mm (1.457 in)	33.0 mm (1.299 in)
Installed pressure	24.4 ± 1.7 kg (53.8 ± 3.8 lb)	12.1 ± 1.2 kg (26.7 ± 2.6 lb)
Compressed length (Valve open)	29.0 mm (1.142 in)	25.0 mm (0.984 in)
Compressed pressure	68.3 ± 4.5 kg (150.6 ± 9.9 lb)	31.4 ± 2.2 kg (69.2 ± 4.8 lb)

E. Cylinder

3. Types of cylinder

	Piston size	Cylinder size
A	69 $\begin{matrix} -0.020 \text{ or less} \\ -0.030 \text{ or more} \end{matrix}$ mm (2.7165 $\begin{matrix} -0.00079 \text{ or less} \\ -0.00118 \text{ or more} \end{matrix}$ in)	69 $\begin{matrix} +0.020 \text{ or less} \\ +0.010 \text{ or more} \end{matrix}$ mm (2.7165 $\begin{matrix} +0.00039 \text{ or less} \\ +0.00039 \text{ or more} \end{matrix}$ in)
B	69 $\begin{matrix} -0.030 \text{ or less} \\ -0.040 \text{ or more} \end{matrix}$ mm (2.7165 $\begin{matrix} -0.00118 \text{ or more} \\ -0.00157 \text{ or less} \end{matrix}$ in)	69 $\begin{matrix} +0.010 \text{ or less} \\ +0 \text{ or more} \end{matrix}$ mm (2.7165 $\begin{matrix} +0.00039 \text{ or less} \\ +0 \text{ or more} \end{matrix}$ in)

	Standard
Cylinder bore	69.00 ~ 69.02 mm (2.7165 ~ 2.7173 in)
Cylinder taper	0.05 mm (0.002 in)

F. Piston and Piston Rings

1. Piston

	Size
Standard	69.00 mm (2.716 in)
Overize 1	69.25 mm (2.726 in)
Overize 2	69.50 mm (2.736 in)
Overize 3	69.75 mm (2.746 in)
Overize 4	70.00 mm (2.756 in)

2. Piston ring

	Oversize Dia.	Stamped Mark
Oversize 1	69.25 mm (2.726 in)	25
Oversize 2	69.50 mm (2.736 in)	50
Oversize 3	69.75 mm (2.746 in)	75
Oversize 4	70.00 mm (2.756 in)	100

(PAGE 58, 59)

4-1. CARBURETOR



This model is furnished with the two-position starter jet of carburetor.

A. Disassembly


1. Prepare to separate carburetor (separation not necessary if only float level adjustment or throttle slide inspection is to be done). Remove the two screws holding the starter shaft to the carburetor.

NOTE:


- 1) While pulling out the starter shaft, take care that the shaft positioning balls on the left and right do not pop out.
- 2) As illustrated, reassembly the starter shaft so that the holding screws fit in the shaft dents.




2. Remove upper and lower brackets. Note position of synchronizing screws for guidance in reassembly. Separate carburetors.
3. Remove vacuum chamber cover. Remove the spring, needle fitting plate, jet needle and diaphragm (vacuum piston).



4. Note that there is tab on the rubber diaphragm. There is matching recesses in the carburetor body for the diaphragm tab.



backing plate screws and move the complete backing plate until the pointer marks align.



1. Left cylinder timing adjustment
2. Right cylinder timing adjustment

5. Retighten screws. Check timing again for left cylinder.

6. Repeat procedure (steps 1-5) for right cylinder.

(PAGE 20)

B. Spark Plug

Specifications should be read as follows:

Standard spark plug	Tightening torque
N-7Y (CHAMPION) or BP7ES (N.G.K.)	2.0 m-kG (14.5 ft-lb)

(PAGE 25-56)

This model is not furnished with a starter motor. Please delete the items concerning the starter motor from these pages.

This model (XS400-2E) is different from XS360C in the following items and specifications.

ENGINE SECTION TIGHTENING TORQUE CHART

Tightening point	Stud dia. (mm)	Q'ty	Torque m-kG (ft-lb)	Remarks
Cylinder head cover and cylinder head	8	8	2.2 (16.0)	
	6	6	1.0 (7.0)	
Cylinder head	6	2	1.0 (7.0)	
	10	8	3.3 (24.0)	Apply engine oil
Tappet cover	32	4	1.2 (8.5)	
Rocker plug	16	2	1.6 (11.5)	
Spark plug	14	2	2.0 (14.5)	
Valve clearance adjusting nut	6	4	1.4 (10.0)	
Cam sprocket bolt	7	2	2.0 (14.5)	
Connecting rod	8	4	3.6 (26.0)	Apply molybdenum grease
Rotor bolt	10	1	3.3 (24.0)	
Governor	6	1	1.0 (7.0)	
Drain plug	14	1	3.7 (27.0)	

D. Description


Two-position starter jet (Choke)

With a conventional one-position starter jet, the air-fuel ratio remains the same as that required to start the engine (despite that the engine temperature rises gradually) until the engine operating temperature rises to the point at which use of the starter jet is no longer necessary. In other words, the air-fuel mixture is too rich until the engine operating temperature rises to a certain point.

The newly-adopted two-position type starter jet is designed to supply a mixture of proper strength by switching one jet to another.

Routes of Fuel and Air

The fuel supplied from the float chamber ① passes through ② and metered by ③. Air is supplied from the air chamber in the float chamber and flows through ⑤ and ⑥, then it is mixed with the metered fuel. The resultant mixture passes through ④ and 6 and flows into the two-position starter jet ⑦, where it is further mixed with air supplied from the diaphragm lower chamber. The mixture passes through ⑧ and streams into the throttle bore out of ⑨.



Operation of two-position starter jet

Full-open:


To start a cold engine, a rich mixture is required. To supply a rich mixture, pull the starter knob all the way out so that the needle regulating the fuel from is set free and the flow rate of incoming fuel is increases to a maximum. The fuel is mixed with the air supplied from the diaphragm lower chamber, and thus a rich mixture is produced.

Half-open:

When warming up the engine, a slightly rich mixture is required. Pull out the starter jet a half-way so that the fuel flow is reduced by the needle. The fuel is mixed with the air from the diaphragm lower chamber, and thus a slightly rich mixture is produced.

Full-closed:

When the engine fully warms up, no mixture from the starter circuit is necessary. Push the starter knob all the way in so that the flow of incoming fuel is stopped by the needle. At the same time, the flow of incoming air is also stopped by the plunger, and thus no mixture enters the throttle bore.



(PAGE 62-76)

This model is not furnished with the disc brake. Please delete the items concerning the disc brake from these pages.

This model (XS400-2E) is different from XS360C in the following items and specifications.

CHASSIS SECTION TIGHTENING TORQUE CHART

Tightening point	Stud dia. (mm)	Q'ty	Torque m·kg (ft·lb)	Remarks
Engine mounting	10	4	3.1 (22.5)	
	8	1	1.8 (13.0)	
Handle crown and steering shaft	14	1	5.4 (39.0)	
	25	1	3.8 (27.5)	
Handle crown and inner tube	8	2	1.1 (8.0)	
Handle crown and handle holder	10	2	2.3 (16.5)	
Under bracket and inner tube	10	2	3.5 (25.5)	
Damper unit	8	1	2.0 (14.5)	Apply Lock Tite
Rear shock absorber	10	4	3.0 (21.5)	
Pivot shaft	14	1	6.5 (47.0)	Use lock washer
Front wheel axle	14	1	10.5 (76.0)	
Front wheel axle holder	8	2	2.0 (14.5)	
Engine mounting stay	8	6	1.8 (13.0)	
Rear wheel axle	14	1	10.5 (76.0)	
Tension bar and brake plate	8	1	1.4 (10.0)	
Tension bar and rear arm	8	1	1.4 (10.0)	
Sprocket wheel	12	4	5.5 (40.0)	Use lock washer
Footrest (front)	8	4	1.1 (8.0)	
Footrest (rear)	10	2	1.7 (12.5)	

5-2. REAR WHEEL**B. Checking Brake Shoe Wear**

1. Measure the outside diameter at the brake shoes with slide calipers.

	FRONT	REAR
Brake shoe dia.	180 mm (7.07 in)	160 mm (6.30 in)
Lining thickness/Wear limit	4 mm/2 mm (0.16/0.08 in)	4 mm/2 mm (0.16/0.08 in)
Brake shoe dia. replacement limit	176 mm (6.93 in)	156 mm (6.14 in)

5-5. TIRES AND TUBES**A. Removal**

1. Remove valve cap, valve core and valve stem lock nut.
2. When all air is out of tube, separate tire bead from rim (both sides) by stepping on tire with your foot.
3. Use two tire irons (with rounded edges) to work the tire bead over the edge of the rim, starting 180° opposite the tube stem. Be careful not to pinch the tube as you do this.
4. After you have worked one side of the tire completely off the rim, slip the tube out. Be very careful not to damage the stem while pushing it back out of the rim hole.

NOTE:

If you are changing the tire itself, then finish the removal by working the second bead off the rim.

B. Installation

Please add the following item after "B. Installation".

C. Checking for tire pressure and wear

Check the tire pressure and check the tire for wear.

IMPORTANT NOTICE

Proper loading of XS400-2E is important for the handling, braking, and other performance and safety characteristics of the machine.

NEVER OVERLOAD THE MOTORCYCLE.

Always check the condition and inflation pressure of tires.

WARNING:

Never overload the motorcycle beyond specified tire limits. Operation of an overload tire could cause tire damage, an accident injury.

	FRONT	REAR
XS400-2E BASIC WEIGHT with oil and full fuel tank	78kg (142 lb)	89kg (196 lb)
Standard tire	Bridgestone or Yokohama 3.00S18-4PR	Bridgestone or Yokohama 3.50S18-4PR
Tire load limit	116kg (255 lb)	224kg (495 lb)
Cold tire pressure: Normal riding	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
With passenger or high speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
With passenger and extra load riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

Make sure the total weight of the motorcycle with accessories, rider (s) etc., does not exceed the tire limits.


(PAGE 78-88)

This model is not furnished with starter motor and flasher self cancelling system. Please delete the items concerning the starter motor and flasher self cancelling system from these pages.

This model (XS400-2E) is different from XS360C in the following items and specifications.

6-1. IGNITION SYSTEM**C. Ignition Coil****2. Direct current resistance test**

Use a pocket tester or equivalent ohmmeter to determine resistance and continuity of primary and secondary coil windings.

**E. Spark Plug****2. Inspection**

Standard spark plug	N-7Y (CHAMPION) or BP7ES (N.G.K.)
Spark plug gap	0.7 ~ 0.8 mm (0.028 ~ 0.031 in)

6-3. BATTERY

B. Service Life

Battery	12V, 12AH
Electrolyte	Specific gravity: 1.28 Quantity: 800 cc (27 oz)
Initial charging current	1.20A/10 Hours (New battery)
Recharging current	1.20A/10 Hours (or until specific gravity reached 1.28)
Refill fluid	Distilled water (to maximum level line)
Refill period	Check once per month (or more often, as required)

(PAGE 92-104)


7-2. SPECIFICATION

A. General

1. MODEL	
1) Model (I.B.M. No.)	XS400-2E (2G5)
2) Frame I.D. and starting number	2G5-000101
3) Engine I.D. and starting number	2G5-000101
2. DIMENSION	
1) Overall length	2,025 mm (79.5 in)
2) Overall width	845 mm (33.3 in)
3) Overall height	1,100 mm (43.3 in)
4) Seat height	815 mm (32.1 in)
5) Wheelbase	1,335 mm (52.6 in)
6) Minimum ground clearance	150 mm (5.9 in)
3. WEIGHT	
1) Net weight (Dry)	155 kg (342 lb)
4. PERFORMANCE	
1) Climbing ability	28°
2) Minimum turning radius	2,200 mm (86.6 in)

B. Engine

1. DESCRIPTION	
1) Engine type	Air cooled, 4-stroke, SOHC twin, parallel forward incline
2) Engine model	2G5
3) Displacement	391 cc (23.86 cu.in)
4) Bore x stroke	69.0×52.4 mm (2.717×2.063 in)
5) Compression ratio	9.4 : 1
6) Starting system	Kick Starter
7) Ignition system	Battery ignition
8) Lubrication system	Wet sump
2. CYLINDER HEAD	
1) Combustion chamber volume	23.3 cc (1.422 cu.in) BP7ES
2) Combustion chamber type	Dome + Squish
3) Head gasket thickness	1.0 mm (0.04 in)

4) Tightening torque Cylinder head holding nut (M10 P1.25) Cylinder head holding bolt (M6 P1.0) Spark plug (M14 P1.25)		3.3 m·kg (24.0 ft·lb) 1.0 m·kg (7.5 ft·lb) 2.0 m·kg (14.5 ft·lb)																			
3. CYLINDER 1) Material 2) Bore size 3) Taper limit 4) Out of round limit		Aluminum alloy with cast iron sleeve $69.0^{+0.002}_0$ mm ($2.72^{+0.0008}_0$ in) 0.05 mm (0.002 in) 0.01 mm (0.0004 in)																			
4. PISTON 1) Piston skirt clearance 2) Piston oversize 3) Piston pin outside diameter × length		0.030 ~ 0.050 mm (0.0012 ~ 0.0019 in) <table><tr><td>69.25 mm (2.726 in)</td><td>69.50 mm (2.736 in)</td><td>69.75 mm (2.746 in)</td><td>70.00 mm (2.756 in)</td></tr></table> $16.0^{+0}_{-0.005}$ mm × $58.5^{+0}_{-0.3}$ mm $(0.63^{+0}_{-0.0002}$ in × $2.303^{+0}_{-0.0116}$ in)		69.25 mm (2.726 in)	69.50 mm (2.736 in)	69.75 mm (2.746 in)	70.00 mm (2.756 in)														
69.25 mm (2.726 in)	69.50 mm (2.736 in)	69.75 mm (2.746 in)	70.00 mm (2.756 in)																		
5. PISTON RING 1) Piston ring design (Top) (2nd) (Oil ring) 2) Ring end gap (Installed, top) (Installed, 2nd) (Installed, oil) 3) Ring groove side clearance (Top) (2nd) (Oil)		Plain ring 1.0 mm (0.039 in) Plain ring 1.5 mm (0.059 in) With expander 2.45 mm (0.096 in) 0.2 ~ 0.4 mm (0.008 ~ 0.016 in) 0.2 ~ 0.4 mm (0.008 ~ 0.016 in) 0.2 ~ 0.9 mm (0.008 ~ 0.035 in) 0.04 ~ 0.08 mm (0.0016 ~ 0.0032 in) 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)																			
6. BIG END BEARING 1) Type 2) Oil clearance 3) Bearing size		Plain bearing 0.021 ~ 0.045 mm (0.0008 ~ 0.0018 in) <table><tr><td>1. (Blue)</td><td>$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)</td></tr><tr><td>2. (Black)</td><td>$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)</td></tr><tr><td>3. (Brown)</td><td>$1.50^{+0.004}_{-0.006}$ mm ($0.0591^{+0.00016}_{-0.00031}$ in)</td></tr><tr><td>4. (Green)</td><td>$1.50^{+0.006}_{-0.012}$ mm ($0.0591^{+0.00031}_{-0.00047}$ in)</td></tr></table>		1. (Blue)	$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)	2. (Black)	$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)	3. (Brown)	$1.50^{+0.004}_{-0.006}$ mm ($0.0591^{+0.00016}_{-0.00031}$ in)	4. (Green)	$1.50^{+0.006}_{-0.012}$ mm ($0.0591^{+0.00031}_{-0.00047}$ in)										
1. (Blue)	$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)																				
2. (Black)	$1.50^{+0.004}_0$ mm ($0.0591^{+0.00016}_0$ in)																				
3. (Brown)	$1.50^{+0.004}_{-0.006}$ mm ($0.0591^{+0.00016}_{-0.00031}$ in)																				
4. (Green)	$1.50^{+0.006}_{-0.012}$ mm ($0.0591^{+0.00031}_{-0.00047}$ in)																				
7. CAMSHAFT 1) Can drive type 2) Number and type of bearing 3) Bearing dimensions		Chain (Center side) 3 bearings, cylinder head direct support <table><tr><td></td><td>Cap I.D.</td><td>Shaft O.D.</td><td>Clearance</td></tr><tr><td>IN and EX</td><td>$23.0^{+0.021}_0$ mm</td><td>$23.0^{+0.020}_{-0.033}$ mm</td><td>0.020 ~ 0.054 mm</td></tr><tr><td>1, 2, 3</td><td>($0.906^{+0.0082}_0$ in)</td><td>($0.906^{+0.00079}_{-0.00130}$ in)</td><td>(0.00079 ~ 0.00213 in)</td></tr></table>			Cap I.D.	Shaft O.D.	Clearance	IN and EX	$23.0^{+0.021}_0$ mm	$23.0^{+0.020}_{-0.033}$ mm	0.020 ~ 0.054 mm	1, 2, 3	($0.906^{+0.0082}_0$ in)	($0.906^{+0.00079}_{-0.00130}$ in)	(0.00079 ~ 0.00213 in)						
	Cap I.D.	Shaft O.D.	Clearance																		
IN and EX	$23.0^{+0.021}_0$ mm	$23.0^{+0.020}_{-0.033}$ mm	0.020 ~ 0.054 mm																		
1, 2, 3	($0.906^{+0.0082}_0$ in)	($0.906^{+0.00079}_{-0.00130}$ in)	(0.00079 ~ 0.00213 in)																		
4) Cam dimensions		<table><tr><td></td><td>Cam height "A"</td><td>Limit</td><td>Base circle "B"</td><td>Limit</td><td>Lift "C"</td></tr><tr><td>IN</td><td>39.53 ± 0.05 mm (1.556 ± 0.0019 in)</td><td>39.38 mm (1.550 in)</td><td>32.27 ± 0.05 mm (1.270 ± 0.0019 in)</td><td>32.12 mm (1.265 in)</td><td>7.53 mm (0.296 in)</td></tr><tr><td>EX</td><td>39.57 ± 0.05 mm (1.558 ± 0.0019 in)</td><td>39.42 mm (1.552 in)</td><td>32.12 ± 0.05 mm (1.265 ± 0.0019 in)</td><td>31.97 mm (1.259 in)</td><td>7.57 mm (0.298 in)</td></tr></table> 			Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"	IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)	EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)
	Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"																
IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)																
EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)																

5) Valve timing

	OPEN	CLOSE	DURATION	OVERLAP
IN	BTDC 30°	ABDC 70°	280°	60°
EX	BBDC 70°	ATDC 30°	280°	

6) Camshaft deflection limit

0.03 mm (0.0012 in)

7) Cam chain

Type

TSUBAKIMOTO BF05M

Pitch/Number of links

7.774 mm (0.3060 in)/92L

Sprocket ratio

34/17 (2.000)

8. ROCKER ARM AND ROCKER SHAFT

1) Rocker arm inner diameter

13.0 $^{+0.018}_{0}$ mm (0.512 $^{+0.0007}_{0}$ in)

2) Rocker arm shaft diameter

13.0 $^{-0.016}_{-0.036}$ mm (0.512 $^{-0.00063}_{-0.00141}$ in)

3) Clearance

0.016 ~ 0.054 mm (0.00053 ~ 0.00122 in)

4) Lift ratio

X : Y = 32.05 : 33.62 mm (1.262 : 1.324 in)

9. VALVE, VALVE SEAT AND VALVE GUIDE

1) Valve per cylinder

2 pcs.

2) Valve clearance (In cold engine)

IN: 0.10 mm (0.004 in)

EX: 0.18 mm (0.007 in)

3) Dimensions

Valve head diameter "A"

IN: 35.5±0.1 mm (1.398±0.004 in)

EX: 30.0±0.1 mm (1.181±0.004 in)

Valve face width "B"

IN: 2.3 mm (0.091 in)

EX: 2.3 mm (0.091 in)

Valve seat width "C"


IN: 1.0±0.1 mm (0.039±0.004 in)

EX: 1.0±0.1 mm (0.039±0.004 in)

Valve margin thickness "D"

IN: 1.0±0.2 mm (0.039±0.008 in)

EX: 1.0±0.2 mm (0.039±0.008 in)



Valve stem diameter

IN: 7.0 $^{-0.010}_{-0.025}$ mm (0.275 $^{-0.0004}_{-0.0009}$ in)

EX: 7.0 $^{-0.030}_{-0.045}$ mm (0.275 $^{-0.0012}_{-0.0018}$ in)

Valve guide diameter

IN: 7.0 $^{+0.012}_{0}$ mm (0.275 $^{+0.0005}_{0}$ in)

EX: 7.0 $^{+0.012}_{0}$ mm (0.275 $^{+0.0005}_{0}$ in)

Valve stem to stem clearance

IN: 0.010 ~ 0.037 mm (0.00039 ~ 0.00145 in)

EX: 0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)

4) Valve face runout limit

IN & EX: 0.03 mm (0.0012 in) or less

10. VALVE SPRING

1) Free length

INNER (IN/EX): 39.3 mm (1.547 in)

OUTER (IN/EX): 42.8 mm (1.685 in)

2) Spring rate

INNER (IN/EX): $k_1 = 1.93 \text{ kg/mm (108 lb/in)}$

$k_2 = 2.47 \text{ kg/mm (138 lb/in)}$

OUTER (IN/EX): $k_1 = 4.19 \text{ kg/mm (235 lb/in)}$

$k_2 = 5.49 \text{ kg/mm (307 lb/in)}$

3) Installed length (Valve closed)

INNER (IN/EX): 33.0 mm (1.299 in)

OUTER (IN/EX): 37.0 mm (1.457 in)

4) Installed pressure (Valve closed)

INNER (IN/EX): 12.1±1.2 kg (26.7±2.6 lb)

OUTER (IN/EX): 24.4±1.7 kg (53.8±3.8 lb)

5) Compressed length (Valve open)

INNER (IN/EX): 25.0 mm (0.984 in)


OUTER (IN/EX): 29.0 mm (1.142 in)

6) Compressed pressure (Valve open)	INNER (IN/EX): 31.4 kg (69.2 lb) OUTER (IN/EX): 68.3 kg (151 lb)								
7) Wire diameter (Valve open)	INNER (IN/EX): 3.0 mm (0.118 in) OUTER (IN/EX): 4.4 mm (0.173 in)								
8) Winding O.D. (Valve open)	INNER (IN/EX): 22.4 mm (0.882 in) OUTER (IN/EX): 32.0 mm (1.260 in)								
9) Number of windings (Valve open)	INNER (IN/EX): 7.75 turns OUTER (IN/EX): 6.25 turns								
10) Tilt limit (Valve open)	INNER (IN/EX): 1.7 mm (0.067 in) or 2.5° OUTER (IN/EX): 1.9 mm (0.075 in) or 2.5°								
11. CRANKSHAFT									
1) Crankshaft deflection	0.02 mm (0.0008 in)								
2) Con-rod large end clearance	0.160 ~ 0.264 mm (0.0063 ~ 0.0104 in)								
3) Clearance between crank and crankcase	0.05 ~ 0.25 mm (0.002 ~ 0.010 in)								
12. CONNTING ROD									
1) Big end I.D.	41.0 $^{+0.024}_0$ mm (1.614 $^{+0.0009}_0$ in)								
2) Small end I.D.	16.0 $^{+0.028}_{-0.015}$ mm (0.630 $^{+0.0011}_{+0.0028}$ in)								
3) Difference of each rod weight	5 g or less								
13. CRANK BEARING									
1) Oil clearance	0.020 ~ 0.044 mm (0.00079 ~ 0.00157 in)								
2) Bearing size	<table border="1"> <tr> <td>1. (Blue)</td><td>1.50 $^{+0.012}_{+0.008}$ mm (0.0591 $^{+0.00047}_{+0.00031}$ in)</td></tr> <tr> <td>2. (Black)</td><td>1.50 $^{+0.008}_{+0.004}$ mm (0.0591 $^{+0.00031}_{+0.00018}$ in)</td></tr> <tr> <td>3. (Brown)</td><td>1.50 $^{+0.004}_0$ mm (0.0591 $^{+0.00018}_0$ in)</td></tr> <tr> <td>4. (Green)</td><td>1.50 $^{0}_{-0.004}$ mm (0.0591 $^{0}_{-0.00018}$ in)</td></tr> </table>	1. (Blue)	1.50 $^{+0.012}_{+0.008}$ mm (0.0591 $^{+0.00047}_{+0.00031}$ in)	2. (Black)	1.50 $^{+0.008}_{+0.004}$ mm (0.0591 $^{+0.00031}_{+0.00018}$ in)	3. (Brown)	1.50 $^{+0.004}_0$ mm (0.0591 $^{+0.00018}_0$ in)	4. (Green)	1.50 $^{0}_{-0.004}$ mm (0.0591 $^{0}_{-0.00018}$ in)
1. (Blue)	1.50 $^{+0.012}_{+0.008}$ mm (0.0591 $^{+0.00047}_{+0.00031}$ in)								
2. (Black)	1.50 $^{+0.008}_{+0.004}$ mm (0.0591 $^{+0.00031}_{+0.00018}$ in)								
3. (Brown)	1.50 $^{+0.004}_0$ mm (0.0591 $^{+0.00018}_0$ in)								
4. (Green)	1.50 $^{0}_{-0.004}$ mm (0.0591 $^{0}_{-0.00018}$ in)								
14. CLUTCH									
1) Clutch type	Wet, multiple type								
2) Clutch operating mechanism	Inner push type, screw push system								
3) Primary reduction ratio and method	78/24 (3.250), spar gear								
4) Primary reductin gear back lash Tolerance	A—C, B—D, C—E, D—F								
5) Friction plate Thickness/Quantity Wear limit	3 mm (0.12 in)/7 pcs. 2.7 mm (0.11 in)								
6) Clutch plate Thickness/Quantity Warp limit	1.6 mm (0.063 in)/6 pcs. 0.05 mm (0.002 in)								
7) Clutch spring Free length/Quantity Minimum length	34.6 mm (1.362 in)/4 pcs. 33.6 mm (1.323 in)								
8) Clutch housing radial play (Wear limit)	0.009 ~ 0.043 mm (0.00035 ~ 0.00169 in)								
9) Push rod bending limit	0.2 mm (0.008 in)								
10) Tightening torque Primary drive gear (M10 P1.25) Clutch spring screw (M6 P1.0)	4.8 m·kg (35.0 ft·lb) 1.0 m·kg (7.0 ft·lb)								
15. TRANSMISSION									
1) Type	Constant mesh, 6-speed forward								
2) Gear ratio: 1st	35/14 (2.500)								
2nd	32/18 (1.777)								
3rd	29/21 (1.380)								
4th	27/24 (1.125)								

<p>3) Bearing type:</p> <p>5th 6th</p> <p>Main axle (Left) Main axle (Right) Drive axle (Left) Drive axle (Right)</p> <p>4) Oil seal type Drive axle (Left)</p> <p>5) Secondary reduction ratio and method</p> <p>6) Tightening torque Drive sprocket (M18 P1.0)</p>	<p>25/26 (0.961) 26/30 (0.866)</p> <p>Needle bearing ($\phi 20-\phi 30-15$) Ball bearing (5205) Ball bearing (6305 special) Needle bearing ($\phi 20-\phi 33-15$) SD-35-62-6 37/16 (2.312)/Chain</p> <p>6.5 m·kg (47.0 ft·lb)</p>
<p>16. SHIFTING MECHANISM</p> <p>1) Type</p> <p>2) Oil seal type (Change lever)</p> <p>3) Tightening torque Change pedal (M6 P1.0)</p>	<p>Guide bar, return type SD-12-22-5</p> <p>1.0 m·kg (7.0 ft·lb)</p>
<p>17. KICK STARTER</p> <p>1) Type</p> <p>2) Oil seal type (Kick axle)</p> <p>3) Kick clip friction tension</p> <p>4) Tightening torque Kick crank (M8 P1.25)</p>	<p>Bendix type SD-20-30-7 1.0 m·kg (7.0 ft·lb)</p> <p>2.0 m·kg (14.5 ft·lb)</p>
<p>18. CRANKCASE</p> <p>1) Tightening torque Bolt (M8 P1.25) Bolt (M6 P1.0)</p>	<p>2.2 m·kg (16.0 ft·lb) 1.0 m·kg (7.0 ft·lb)</p>
<p>19. INTAKE</p> <p>1) Air cleaner: Type/Quantity</p> <p>2) Cleaner cleaning interval</p> <p>3) Valve clearance</p>	<p>Dry, foam rubber/2 pcs. Every 3,200 km (2,000 mile) See No. 9-2) Valve, valve seat and valve guide</p>
<p>20. CARBURETOR</p> <p>1) Type and manufacturer/Quantity</p> <p>2) I.D. mark</p> <p>3) Main jet (MJ)</p> <p>4) Air jet (AJ)</p> <p>5) Jet needle-clip position (JN)</p> <p>6) Needle jet (NJ)</p> <p>7) Throttle valve (Th.V)</p> <p>8) Pilot jet (PJ)</p> <p>9) Air screw (Turns out) (AS)</p> <p>10) Starter jet (GS)</p> <p>11) Fuel height (FL)</p> <p>12) Vacuum synchronization</p> <p>13) Idling engine speed</p>	<p>BS34 MIKUNI/2 pcs. 2G5-60 #137.5 #45 5Z1-3 X-6 #135 #42.5 Preset GS₁: #30, GS₂: —, 25.7 ± 1.0 mm (1.012 ± 0.039 in) 5 mmHg or less 1,200 ± 50 r/min</p>
<p>21. LUBRICATION</p> <p>1) Engine sump oil Quantity</p> <p>2) Oil grade</p> <p>3) Oil type</p> <p>4) Oil pump type</p> <p>5) Trochoid pump specifications Top clearance Tip clearance Side clearance Oil pump volume</p>	<p>Periodic oil charge: 2.0 lit (2.1 qt) With oil filter replacement: 2.3 lit (2.4 qt) Total amount: 2.6 lit (2.7 qt) Shell X-100 or Yamalube 4-cycle oil SAE 20W/40 (more than 5 °C (41 °F)) SAE 10W/30 (below 15 °C (59 °F)) Trochoid pump 0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in) 1.2 lit/min at 500 r/min</p>

- 6) Relief valve operating pressure
- 7) Bypass valve setting pressure
- 8) Lubrication chart

$5 \pm 0.5 \text{ kg/cm}^2$ ($71 \pm 7 \text{ psi}$)
 $1.0 \pm 0.2 \text{ kg/cm}^2$ ($14 \pm 3 \text{ psi}$)



C. Chassis

1. FRAME <ol style="list-style-type: none"> 1) Frame design 2) Tightening torque <ul style="list-style-type: none"> Engine mounting bolt (M8 P1.25) Engine mounting bolt (M10 P1.25) 	Semi double cradle, high tensile frame 1.8 m-kg (13.0 ft-lb) 3.1 m-kg (22.5 ft-lb)
2. STEERING SYSTEM <ol style="list-style-type: none"> 1) Caster 2) Trail 3) Number and size of balls in steering head <ul style="list-style-type: none"> Upper race Lower race 4) Steering lock to lock 5) Tightening torque <ul style="list-style-type: none"> Steering shaft fitting nut (M14 P1.25) Steering shaft fitting nut (M25 P1.0) Stem pinch bolt (M8 P1.25) Handlebar mounting bolt (M10 P1.25) 	26°30' 81 mm (3.19 in) 19 pcs. 1/4 in 19 pcs. 1/4 in 43° each (L and R) 5.4 m-kg (39.0 ft-lb) 3.8 m-kg (27.5 ft-lb) 1.1 m-kg (8.0 ft-lb) 2.3 m-kg (16.5 ft-lb)
3. FRONT SUSPENSION <ol style="list-style-type: none"> 1) Type 2) Damper type 3) Front fork spring <ul style="list-style-type: none"> Free length Wire diameter × winding diameter Spring constant 4) Front fork travel 5) Inner tube O.D. 6) Front fork oil quantity and type 7) Oil seal type 	Telescopic fork Oil damper, coil spring 484 mm (19.05 in) 3.8 mm × 23 mm (0.15 × 0.91 in) $k_1 = 0.4 \text{ kg/mm}$ (22.4 lb/in)/10 ~ 100 mm (0 ~ 3.94 in) $k_2 = 0.475 \text{ kg/mm}$ (26.6 lb/in)/ 100 ~ 140 mm (3.94 ~ 5.51 in) 140 mm (5.5 in) 33 mm (1.30 in) 130 cc (4.4 oz) each leg Yamaha Fork Oil 20Wt. or SAE 20W motor oil SD-33-46-10.5

8) Tightening torque Under bracket and inner tube (M10 P1.25) Handle crown and inner tube (M8 P1.25)	3.5 m·kg (25.5 ft·lb) 1.1 m·kg (8.0 ft·lb)
4. REAR SUSPENSION 1) Type 2) Damper type 3) Shock absorber travel 4) Shock absorber spring Set length Free length Wire diameter × winding diameter Spring constant 5) Swing arm free play (Limit) 6) Pivot shaft — Outside diameter 7) Tightening torque: Rear shock absorber (Upper) (M10 P1.25) Rear shock absorber (Under) (M10 P1.25) Pivot shaft (M14 P1.5)	Swing arm Oil damper, coil spring 80 mm (3.15 in) 193 mm (7.6 in) 205 mm (8.1 in) 7.0 mm × 56.5 mm (0.27 × 2.22 in) k = 1.6 kg/m (89.6 lb/in) 1.0 mm (0.04 in) 16 mm (0.63 in) 3.0 m·kg (21.5 ft·lb) 3.0 m·kg (21.5 ft·lb) 6.5 m·kg (47.0 ft·lb)
5. FUEL TANK 1) Capacity 2) Fuel grade	11.0 lit (2.9 US.gal) Regular gasoline
6. WHEEL 1) Type (Front and rear) 2) Tire size (Front) Tire size (Rear) 3) Tire pressure: Normal riding (Front) Normal riding (Rear) High speed riding or with passenger (Front) High speed riding or with passenger (Rear) With passenger and extra load riding (Front) With passenger and extra load riding (Rear) 4) Rim run out limit (Front and Rear) Vertical Lateral 5) Rim size (Front) (Rear) 6) Spoke O.D. Length/Quantity (Front) Inner Outer Length/Quantity (Rear) Inner Outer 7) Bearing type Front wheel (Left) Front wheel (Right) Rear wheel (Left) Rear wheel (Right) 8) Oil seal type Front wheel (Left) Front wheel (Right) Rear wheel (Left) 9) Secondary drive chain type Type Number of links Chain pitch Chain free play	Spoke wheel 3.00S18-4PR 3.50S18-4PR 1.8 kg/cm ² (26 psi) 2.0 kg/cm ² (28 psi) 2.0 kg/cm ² (28 psi) 2.3 kg/cm ² (32 psi) 2.0 kg/cm ² (28 psi) 2.3 kg/cm ² (32 psi) 2.0 mm (0.08 in) 2.0 mm (0.08 in) 1.60 × 18 1.85 × 18 3.5 × 153.0/18 pcs. 3.5 × 152.5/18 pcs. 3.2-3.5 × 157.5/18 pcs. 3.2-3.5 × 157.0/18 pcs. 6302RS 6302RS 6304RS (6304 LU/3A) 6303 LUC3/3A SDD-53-65-7 SD-22-42-7-1 SD-27-52-5 DK50DS (DK530DS) 97L + Joint 15.875 mm (5/8 in) 30 ~ 35 mm (1.2 ~ 1.4 in)

10) Tightening torque	
Front wheel axle (M14 P1.5)	10.5 m·kg (76.0 ft·lb)
Front axle holder (M8 P1.25)	2.0 m·kg (14.5 ft·lb)
Rear wheel axle (M14 P1.5)	10.5 m·kg (76.0 ft·lb)
7. BRAKE	
1) Front and rear brake	
Type Front	Drum brake
Rear	Drum brake
Actuating method Front	Two leading
Rear	Leading trailing
Brake drum I.D. Front	180 mm (7.1 in)
Rear	160 mm (6.3 in)
Brake shoe dia. X width Front	180 X 30 mm (7.1 X 1.2 in)
Rear	160 X 30 mm (6.3 X 1.2 in)
Lining thickness/Wear limit Front	4.0/2.0 mm (0.16/0.08 in)
Rear	4.0/2.0 mm (0.16/0.08 in)
Shoe spring free length Front	68 mm (2.68 in)
Rear	68 mm (2.68 in)

1. IGNITION SYSTEM	
1) Battery (AC generator)	
Model/Manufacturer	021000-5840/NIPPON DENSO
Voltage	12V
Taper dia. at large end	25 mm (0.98 in)
Rotor tightening torque (M10 P1.25)	3.3 m·kg (24.0 ft·lb)
2) Ignition timing (B.T.D.C.)	10° ~ 36°
3) Ignition coil	
Model/Manufacturer	029700-4130/NIPPON DENSO
Spark gap	6 mm (0.24 in) or more/500 r/min
Primary winding resistance	4.0Ω ± 10% at 20°C (68°F)
Secondary winding resistance	9.5 kΩ ± 20% at 20°C (68°F)
4) Spark plug	
Type	N-7Y (CHAMPION) or BP7ES (NGK)
Spark plug gap	0.7 ~ 0.8 mm (0.027 ~ 0.031 in)
5) Contact breaker	
Manufacture/Quantity	NIPPON DENSO/2 pcs.
Point gap	0.30 ~ 0.40 mm (0.012 ~ 0.016 in)
Point spring pressure	800 ± 100 g
Cam closing angle	105°
6) Condenser	
Capacity	0.24 μF
Insulation resistance	10 MΩ or more
Quantity	2 pcs.
2. CHARGING SYSTEM	
1) AC generator	
Charging output	14.5V 13A/5,000 r/min
Rotor coil resistance (Field coil)	4.04Ω ± 10% at 20°C (68°F)
Stator coil resistance	0.72Ω ± 10% at 20°C (68°F)
2) Rectifier	
Type	6-Element type (Full wave)
Model/Manufacturer	DS10TEY/MITSUBISHI
Capacity	12A
Withstand voltage	400V


3) Regulator Type Model/Manufacturer Regulating voltage	Tillil type 026000-2790/NIPPON DENSO 14.5 ± 0.5V
4) Voltage regulator Core gap Yoke gap Point gap Voltage coil Resistor	MIN. 0.2 mm (0.008 in) MIN. 0.1 mm (0.004 in) 0.25 ~ 0.5 mm (0.01 ~ 0.02 in) 10.5 ± 1 Ω at 20°C (68°F) 140 ± 10 Ω at 20°C (68°F)
5) Battery Model/Manufacturer/Quantity Capacity Charging rate Specific gravity/Quantity	12N12-4A-1/G.S./1 pc. 12V, 12A 1.2A 10 hours 1.28 at 20°C (68°F), Total 800 cc (27 oz)
3. LIGHTING SYSTEM 1) Head light type 2) Bulb wattage/Quantity Head light Tail/Brake light Flasher light Meter light Neutral indicator light Turn indicator light Oil pressure indicator light High beam indicator light 3) Horn Model/Manufacturer Maximum amperage 4) Flasher relay Type Model/manufacturer Flasher frequency Capacity 5) Fuse Rating/Quantity	Sealed beam 12V, 40/30W × 1 pc. 12V, 8/27W × 2 pcs. 12V, 27W × 2 pcs. 12V, 3.4W × 4 pcs. 12V, 3.4W × 1 pc. 12V, 3.4W × 2 pcs. 12V, 3.4W × 1 pc. 12V, 3.4W × 1 pc. CF3-12/NIKKO 2.5A or less Condenser type 061300-3572/NIPPON DENSO 85 ± 10 cycle/min. 27W × 2 + 3.4W Main (Red): 20A Headlight (Red/Yellow): 10A Signal (Brown): 10A Ignition (Red/White): 10A

XS400-2E WIRING DIAGRAM

* The key can be removed in this position

COLOR CODE-

B	Black	B/R	Black/Red
Ch	Chocolate	G/R	Green/Red
G	Green	G/Y	Green/Yellow
L	Blue	L/G	Blue/Green
O	Orange	L/W	Blue/White
P	Pink	L/Y	Blue/Yellow
R	Red	R/L	Red/Blue
R	Brown	R/W	Red/White
W	White	R/Y	Red/Yellow
Y	Yellow	W/G	White/Green
Dg	Dark green	Y/B	Yellow/Black
Gy	Grey	Y/G	Yellow/Green
Lg	Light green	Y/R	Yellow/Red
Sb	Sky blue	Br/W	Brown/White



XS400F/2F

SUPPLEMENT

FOREWORD

This Supplementary Service Manual for XS400F/XS400-2F has been published to supplement the Service Manual for the XS360C models and provides updated information for the XS360C models as well as new data concerning the XS400F/XS400-2F. For complete information on service procedures it is necessary to use this Supplementary Service Manual together with the Service Manual for XS360C (LIT-11616-00-49).

NOTE:

This Supplementary Manual contains special information regarding periodic maintenance to the emissions control system for the XS400F/XS400-2F. Please read this material carefully.

**SERVICE DEPT.
INTERNATIONAL DIVISION
YAMAHA MOTOR CO., LTD.**

NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical precepts and procedures inherent to motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit for use and/or unsafe.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the machine will operate as designed. If there is any question about a service procedure it is imperative that you contact a Yamaha dealer before continuing. Before attempting any service, check with your Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his machine and to conform with federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to further improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

Particularly important information is distinguished in this manual by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: . . . A CAUTION indicates special procedures that must be followed to avoid damage to the machine.

WARNING: . . . A WARNING indicates special procedures that must be followed to avoid injury to a machine operator or person inspecting or repairing the machine.

Page number shown in brackets correspond to page numbers of the XS360C Service Manual (LIT-11616-00-49).

(PAGE 5)

1-1. MACHINE IDENTIFICATION

Specification should read as follows:

Starting Serial Number	
XS400F	2L0-100101
XS400-2F	2V6-000101

(PAGE 9 – 10)

2-1. MAINTENANCE AND LUBRICATION CHART (XS400F/XS400-2F)

A. PERIODIC MAINTENANCE EMISSION CONTROL SYSTEM

No.	ITEM	REMARKS	INITIAL BREAK-IN		THEREAFTER EVERY	
			1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)
1.	Valve Clearance	Check and adjust valve clearance when engine is cold.	○	○		○
2.	Contact Breaker Points	Check condition. Adjust point gap. Replace if necessary.	○	○	○	
3.	Ignition Timing	Check and adjust ignition timing.	○	○	○	
4.	Spark Plugs	Check condition. Adjust gap. Replace if necessary.		○		○
5.	Crankcase Ventilation System	Check ventilation hose for cracks or damage. Replace if necessary.		○		○
6.	Fuel Hose	Check fuel hose for cracks or damage. Replace if necessary.		○		○
7.	Exhaust System	Check for leakage. Retighten as necessary. Replace gasket (s) if necessary.	○	○	○	
8.	Carburetor Synchronization	Adjust synchronization of carburetors.	○	○	○	
9.	Idle Speed	Check and adjust engine idle speed. Adjust cable free play if necessary.	○	○	○	

B. GENERAL MAINTENANCE/LUBRICATION

NO.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY		
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)
1.	Engine Oil	Warm-up engine before draining.	See page 13	○	○	○		
2.	Oil Filter	Replace.	—	○	○		○	
3.	Air Filter	Dry type filter. Clean with compressed air.	—		○		○	
4.	Brake System	Adjust free play. Replace pads (XS400F) or shoes (XS400-2F) if necessary.	—	○	○	○		
5.	Clutch	Adjust free play.	—	○	○	○		

NO.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY			
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)	
6.	Drive Chain	Apply chain lube thoroughly.	Yamaha chain and cable lube or 10W/30 motor oil	CHECK CHAIN TENSION AND LUBE EVERY 500 km (300 mi)					
7.	Control Cables/ Meter Cables	Apply cable lube thoroughly.	Yamaha chain and cable lube or 10W/30 motor oil	○	○	○			
8.	Rear Arm Pivot Shaft	Apply lightly.	Lithium soap base grease		○		○		
9.	Stand Shaft Pivots/ Brake Pedal Shaft/ Change Pedal Shaft/ Kick Crank Boss	Apply lightly.	Yamaha chain and cable lube or 10W/30 motor oil		○	○			
10.	Front Fork oil	Drain completely. Refill to specification.	Yamaha Fork Oil 20Wt or equivalent						○
11.	Steering Ball Bearing and Races	Check bearings assembly for looseness. Moderately repack every 16,000 km (10,000 mi)	Medium weight wheel bearing grease		○	○			repack
12.	Battery	Check specific gravity. Check breather pipe for proper operation.	—		○	○			

2-2. ENGINE (PAGE 11)

A. Carburetor

- Idle speed adjustment
Specification should read as follows:
(XS400F/XS400-2F)

Pilot screw: Preset
Idle speed: 1,200 r/min

"3. Synchronizing carburetors" section should read as follows.


Carburetor Synchronization (XS400F/XS400-2F)

Carburetors must be adjusted to open and close simultaneously at specified intervals. Adjust as follows:

NOTE:

Ignition timing and valve clearances must be set properly before synchronizing carburetors.


- Turn petcock to "PRI" position. Remove vacuum pipe and blind plug from carburetor joints.
- Connect vacuum gauge pipes on carburetor joints.



1. Vacuum gauge pipe

- Start engine and allow it to warm-up for a few minutes. The warm-up is complete when engine responds normally to throttle opening.
- Adjust pumping valve on vacuum gauge until the needle flutters only slightly. The gauge needle must respond quickly to rapid opening of the throttle.

- Both gauge readings will indicate the same reading if the carburetors are synchronized.
- If not, turn the synchronizing screw until the gauge readings the same.



1. Synchronizing screw

(PAGE 15)

The following sections should be added after section "H. Cam Chain Adjustment". (XS400F/XS400-2F)

Crankcase Ventilation System

Check ventilation hose from crankcase to air filter case for cracks or damage. Replace if necessary.

Fuel Hose

Check fuel hose(s) from fuel petcock to carburetor and left and right carburetor joint pipe for crack or damage. Replace if necessary.

Exhaust System

- Tighten the joint bolts and nuts.
- Replace the joint gasket(s) if necessary.

2-3. CHASSIS

(PAGE 16)


"B. Front Brake" section should read as follows.

Front Brake Adjustment (XS400F)

The front brake lever should be adjusted so that it has a free play of 5 ~ 8 mm (0.2 ~ 0.3 in) at the lever end.

- Loosen the lock nut on the brake lever.

- Turn the adjuster so that the brake lever movement at the lever end is 5 ~ 8 mm (0.20 ~ 0.3 in) before the adjuster contacts the master cylinder piston.
- After adjusting, tighten the lock nut.



1. Adjuster 2. Lock nut


NOTE:

Check for correct play and make sure it is working properly.


Front Brake Adjustment (XS400-2F)

The front brake lever should be adjusted so that it has a free play of 5 ~ 8 mm (0.2 ~ 0.3 in) at the lever pivot point.

- Loosen the lock nut of the lever holder, fully turn the adjuster in and tighten the lock nut.
- Loosen the lock nut of the front brake plate and turn the cable length adjuster in or out until adjustment is suitable.
- Tighten the lock nut.
- When adjustment cannot be completed on the brake plate side proceed to adjustment on the brake lever side.



1. Adjuster 2. Lock nut




1. Adjuster 2. Lock nut

(PAGE 16)

"C. Rear Brake" section should read as follows.

Rear Brake Adjustment (XS400F)

The rear brake pedal should be adjusted so that it has a free play of 13 ~ 15 mm (0.5 ~ 0.6 in) from when the brake pedal is trod to when the brake begins to be effected.



- | | |
|-------------------------------------|--|
| 1. Brake rod | 6. Joint |
| 2. Adjuster bolt (for pedal height) | 7. Lock nut |
| 3. Lock nut | 8. Pedal height: 12 ~ 18 mm (0.5 ~ 0.7 in) |
| 4. Footrest | 9. Free play: 13 ~ 15 mm (0.5 ~ 0.6 in) |
| 5. Brake pedal | |

1. Loosen the adjuster lock nut (for pedal height).
2. By turning the adjuster bolt clockwise or counterclockwise, adjust the brake pedal position so that its top end is approx. 12 ~ 18 mm (0.5 ~ 0.7 in) below the footrest top end.
3. Tighten the adjuster lock nut.
4. Loosen the brake rod adjuster lock nut and screw brake rod downward until

there is noticeable free play between rod and master cylinder.

5. Turn in the brake rod until it lightly touches the master cylinder, then turn it out by approx. 1-1/2 turns (for proper free play).
6. Tighten the brake rod adjuster lock nut.

CAUTION:

The pin hole mark on brake rod must not show above lock nut.

Brake Pedal Position Adjustment (XS400-2F)


The position of the rear brake pedal should be adjusted in relation to the footrest. As illustrated, loosen the lock nut and adjust the pedal height by turning the adjuster. After adjusting, check for correct rear brake play and brake light operation. Do not forget to tighten the lock nut.



1. Adjuster 2. Lock nut

Rear Brake Adjustment (XS400-2F)

The rear brake should be adjusted so the end of the brake pedal moves 20~30 mm (0.8 ~ 1.2 in). To adjust, turn the adjuster on the brake rod clockwise to reduce play; turn the adjuster counterclockwise to increase play. Check whether or not the brake light operates correctly after adjusting.



1. Adjuster

(PAGE 17)


"D. Drive Chain Tension Check" section should read as follows.

D. Drive Chain Tension Check (XS400F/XS400-2F)

NOTE:

Before checking and/or adjusting, rotate rear wheel through several revolutions and check tension several times to find the tightest point on the chain. Check and/or adjust chain tension with rear wheel in the "tight chain" position.

Inspect the drive chain with the center stand put up. Check the tension at the position shown in the illustration. The normal vertical deflection is approximately 35 ~ 40 mm (1.4 ~ 1.6 in). If the deflection exceeds 40 mm (1.6 in) adjust the chain tension.




"E. Drive Chain Tension Adjustment" section should read as follows.

E. Drive Chain Tension Adjustment (XS400F/XS400-2F)

1. Loosen the rear brake adjuster.


(XS400-2F only)

2. Remove the cotter pin of the rear wheel axle nut with pliers.
3. Loosen the rear wheel axle nut.
4. Loosen the lock nuts on each side. To tighten chain turn chain puller adjuster bolts clockwise. To loosen chain turn adjuster bolts counterclockwise and push wheel forward. Turn each bolt exactly the same amount to maintain correct axle alignment (There are marks on each side of rear arm and on each chain puller; use them to check for proper axle alignment).



1. Rear wheel axle nut
2. Cotter pin
3. Lock nut
4. Adjuster bolt
5. Marks for align

5. After adjusting, be sure to tighten the lock nuts and the rear wheel axle nut.
6. After adjusting, be sure to tighten the lock nuts and the rear wheel axle nut.
7. Insert a new cotter pin into the rear wheel axle nut and bend the end of the cotter pin as shown in the illustration (if the nut notch and the cotter pin hole do not match, tighten the nut slightly to match).



NOTE:

Excessive chain tension will overload the engine and other vital parts of the machine; keep the tension within the specified limits. Remember to replace the rear axle cotter pin with a new one.

8. In the final step, adjust the play in the brake pedal. (XS400-2F only)

(PAGE 18)

The following sections should be added after section "Drive Chain Lubrication". (XS400F/XS400-2F)

Control Cables/Meter Cables**1. Cable inspection**

Damage to the outer housing of the various cables, may cause corrosion and often free movement will be obstructed. An unsafe condition may result so replace as soon as possible.

2. Cable lubrication

If the inner cables do not operate smoothly, lubricate with Yamaha Chain and Cable Lube or SAE 10W/30 motor oil.

Rear Arm Pivot Shaft

Apply lithium soap base grease to the rear arm pivot shaft.

Stand Shaft/Pivots/Brake Pedal Shaft/Change Pedal Shaft/Kick Crank Boss

Apply Yamaha Chain and Cable Lube or SAE 10W/30 motor oil to the center and side stand, brake pedal and change pedal shafts, and kick crank boss.

(PAGE 18)**G. Front Fork Oil Change**

Specification should read as follows. (XS400F/XS400-2F)

Recommended oil:

Yamaha fork oil 20Wt or equivalent
Quantity per leg: 142 cc (4.8 oz)

The following sections should be added after section "G. Front Fork Oil Change". (XS400F/XS400-2F)

Steering Ball Bearing and Races**1. Steering head inspection:**

With front wheel elevated, grab bottoms of fork legs and gently push and pull to check steering head free play. If any free play can be felt, adjust as follows.

- a. Loosen front fork upper pinch bolts and stem bolt.
- b. Use ring nut wrench to tighten ring nut. Tighten until play is eliminated.

CAUTION:

Forks must swing from lock to lock without binding or catching

- c. After adjusting, tighten fork pinch bolts and stem bolt.
2. Bearing lubrication:
Lubricate the steering ball bearing with bearing grease at specified intervals.

**2-3. ELECTRICAL
(PAGE 19)**

"A. Ignition Timing" section should read as follows. (XS400F/XS400-2F)

Contact Breaker Points

1. The contact breaker should be checked for the following:
 - a. Wear of the bakelite cam heel.
 - b. Damage of contact point surfaces.
 - c. Rust or wear on the breaker arm or arm shaft.
 - d. Faulty insulation of the contact breaker assembly.
 - e. Oil or dirt on the assembly.
2. To clean the points, run a point file between the points until the grey deposits and pits have been removed. Spray the points with ignition point cleaner or lacquer thinner, then snap the points

on a white business card (or paper of hard texture) and repeatedly pull the card through until no more carbon or metal particles come off on the card. (The card may be dipped in lacquer thinner or other cleaner to facilitate this procedure.)

3. Contact point replacement is necessary whenever the contact surface are severely pitted, or the "heel" that rides on the point cam is worn excessively. The latter case becomes evident when it is not possible to properly set the ignition timing after the proper point gap has been set.
4. Adjust point gap (at widest opening) by moving the contact breaker assembly. Use filler gauge for this adjustment.

Point gap: 0.3 ~ 0.4 mm (0.012 ~ 0.016 in)

5. Add a few drops of light-weight machine oil onto the felt rubbing pad after each point adjustment to lubricate the point cam surface. Do not over oil.

Ignition Timing

NOTE:

Point gap must be set before setting timing.

1. Ignition timing is checked with a timing light by observing the position of the stationary pointer on the crankcase cover and the marks stamped on the generator rotor.

Generator rotor is marked as follows:

"LF"	Retarded firing point for L.H cylinder
"RF"	Retarded firing point R.H. cylinder
"LT"	Top Dead Center for L.H. cylinder
"RT"	Top Dead Center for R.H. cylinder

2. Connect timing light to left cylinder spark plug lead wire. Ignition timing of left cylinder must be set first.
3. Start the engine and keep the engine speed as specified in the label. Use a tachometer for checking.
4. The "LF" mark ("RF" for right cylinder) stamped on the rotor should be lined up with the pointer on the crankcase cover at a specified engine speed. If it does not align, loosen two breaker backing plate screws (shift plate screws for right cylinder) and move the complete backing plate (shift plate for right cylinder) until the pointer marks align.
5. Retighten screws. Check timing *again*.
6. Repeat procedure (steps 1 ~ 5) for right cylinder.

(PAGE 20)

"B. Spark Plug" section should read as follows. (XS400F/XS400-2F)

Spark Plugs

1. Check electrode, insulator and electrode gap, condition and wear.
2. Clean the spark plug with spark plug cleaner if necessary. Use a wire gauge to adjust the plug gap to the specification.
3. If the electrodes become too worn, replace the spark plug.
4. When installing the plug, always clean the gasket surface, wipe off any grime that might be present on the surface of the spark plug, and torque the spark plug properly.

Standard spark plug: NGK BP7ES or CHAMPION N-7Y

Spark Plug Gap: 0.7 ~ 0.8 mm
(0.028 ~ 0.031 in)




Spark plug tightening torque:
2.0 m·kg (14.5 ft·lb)

E. Cylinder

3. Types of cylinder

Specifications should read as follows:
(XS400F/XS400-2F)

	Piston size	Cylinder size
A	69 -0.020 mm or less -0.031 mm or more (2.716 ^{-0.00079 in or less} -0.00122 in or more)	69 +0.020 mm or less +0.011 mm or more (2.716 ^{+0.00079 in or less} +0.00043 in or more)
	69 -0.030 mm or less -0.040 mm or more (2.716 ^{-0.00118 in or less} -0.00157 in or more)	69 +0.010 mm or less 0 (2.716 ^{+0.00039 in or less} 0)



	Standard
Cylinder bore	69.00 ~ 69.02 mm (2.716 ~ 2.717 in)
Cylinder taper	0.05 mm (0.002 in)


(PAGE 38)

F. Piston and Piston Rings

1. Piston

Specifications should read as follows:
(XS400F/XS400-2F)

	Size
Standard	69.00 mm (2.716 in)
Oversize 1	69.25 mm (2.727 in)
Oversize 2	69.50 mm (2.736 in)
Oversize 3	69.75 mm (2.746 in)
Oversize 4	70.00 mm (2.756 in)



2. Piston ring

Specifications should read as follows:
(XS400F/XS400-2F)

	Oversize Dia.	Stamped Mark
Oversize 1	69.25 mm (2.727 in)	25
Oversize 2	69.50 mm (2.736 in)	50
Oversize 3	69.75 mm (2.746 in)	75
Oversize 4	70.00 mm (2.756 in)	100

(PAGE 58, 59)



“4-1. CARBURETOR” section should read as follows. (XS400F/XS400-2F)

A. Disassembly


1. Prepare to separate carburetor (separation is not necessary if only float level adjustment or throttle slide inspection is to be done). Remove the two screws holding the starter shaft to the carburetor.

NOTE:


- 1) While pulling out the starter shaft, take care that the shaft positioning balls on the left and right do not pop out.
- 2) As illustrated, reassemble the starter shaft so that the holding screws fit in the shaft dents.




2. Remove upper and lower brackets. Note position of synchronizing screws for guidance in reassembly. Separate carburetors.
3. Remove vacuum chamber cover. Remove the spring, needle fitting plate, jet needle and diaphragm (vacuum piston).




4. Note that there is tab on the rubber diaphragm. There is a matching recess in the carburetor body for the diaphragm tab.




5. To inspect starter jet, remove the starter assembly to the left side of the carburetor.



6. Remove the four screws holding the float bowl cover. Remove the float bowl cover. The main jet is located under a cover in the float bowl.




7. Pull out float pivot pin. Remove the float assembly. Be careful not to lose the float valve needle located under the float level adjustment tang. Remove the needle jet.




8. Reassemble in reverse order. Pay close attention to the installation of the vacuum position diaphragm.

B. Inspection

1. Examine carburetor body and fuel passages. If contaminated, wash carburetor in petroleum-based solvent. Blow out all passages and jets with compressed air.
2. Examine condition of floats. If floats are leaking or damaged, they should be replaced.
3. Inspect inlet needle valve and seat for wear or contamination. Replace these components as a set.



4. Inspect vacuum piston and rubber diaphragm. If the piston is scratched or the diaphragm is torn, the assembly must be replaced.




C. Float Level

1. Using a vernier caliper, measure the distance of float arm from the top of the float chamber gasket seat (gasket removed) to the float.

Float level: 26.6 ± 2.5 mm
(1.047 ± 0.098 in)

NOTE:

The float should be just resting on, but not depressing, the spring loaded inlet needle.




1. Float level

2. To correct float level, bend the tang a slight amount as required.

NOTE:


Both the right and left of the float should measure identically. Correct as required by bending float tang.



D. Two-position Starter Jet (Choke)

1. Routes of Fuel and Air

The fuel supplied from the float chamber ① passes through ② and metered by ③. Air is supplied from the air chamber in the float chamber and flows through ⑤ and ⑥, then it is mixed with the metered fuel. The resultant mixture passes through ④ and ⑥ and flows into the two-position starter jet ⑦, where it is further mixed with air supplied from the diaphragm lower chamber. The mixture passes through ⑧ and streams into the throttle bore out of ⑨.



2. Operation of two-position starter jet

a. Full-open:


To start a cold engine, a rich mixture is required. To supply a rich mixture, pull the starter knob all the way out so that the needle regulating the fuel from is set free and the flow rate of incoming fuel is increases to a maximum. The fuel is mixed with the air supplied from the diaphragm lower chamber, and thus a rich mixture is produced.

b. Half-open:

When warming up the engine, a slightly rich mixture is required. Pull out the starter jet a half-way so that the fuel flow is reduced by the needle. The fuel is mixed with the air from the diaphragm lower chamber, and thus a slightly rich mixture is produced.

C. Full-closed:

When the engine fully warms up, no mixture from the starter circuit is necessary. Push the starter knob all the way in no that the flow of incoming fuel is stopped by the needle. At the same time the flow of incoming air is also stopped by the plunger, and thus no mixture enters the throttle bore.



(PAGE 62)

"5-1. FRONT WHEEL" section should read as follows.

5-1. FRONT WHEEL (XS400F)

A. Removal

1. Remove cotter pin from front axle.
2. Remove the front axle nut.
3. Loosen the two axle holder nuts at the bottom of the right-hand fork leg.
4. Remove the front wheel axle by simultaneously twisting and pulling out on the axle. Then remove the wheel assembly.

NOTE:

Raise the front of the machine by placing a suitable stand under the engine.


B. Front Axle

Remove any corrosion from axle with emery cloth. Then place it on a surface plate and check for bending. If bent, replace.

C. Replacing Wheel Bearings

If the bearings allow play in the wheel hub or if wheel does not turn smoothly, replace the bearings as follows:

1. First clean the outside of the wheel hub.
2. Drive the bearing out by pushing the spacer aside (the spacer "floats" between the bearings) and tapping around the perimeter of the bearing inner race with a soft metal drift pin and hammer. Either or both bearings can be removed in this manner.



3. To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation. Use a socket that matches the outside race of the bearing as a tool to drive in the bearing.

D. Front Wheel Installation

When installing front wheel, reverse the removal procedure taking care of the following points:

1. Lightly grease lips of front wheel oil seals and gear teeth of speedometer drive and driven gears. Use lightweight lithium soap base grease.
2. Make sure there is enough gap between disc pads.
3. Check for proper engagement of the boss on the outer fork tube with the locating slot on speedometer gear unit housing.
4. Always secure the front wheel axle as follows:
 - a. Torque the front axle nut.


Axle nut torque:

10.7 m·kg (77.4 ft·lb)

- b. Torque axle holder nuts. First tighten nut on front end of axle holder, and tighten nut on rear end.

Holder nut torque:

2.0 m·kg (14.5 ft·lb)



Use a new cotter pin.

D. Front Wheel Installation

1. Check for cracks, bends or warpage of wheels. If a wheel is deformed or cracked, it must be replaced.

NOTE:

These aluminum wheels are not designed for use with tubeless tires.

2. Check wheel run-out

If deflection exceeds tolerance, check wheel bearing or replace wheel as required.

Rim run-out limits:

Vertical: 2 mm (0.08 in)

Lateral: 1 mm (0.04 in)


3. Check wheel balance


Rotate wheel lightly several times and observe resting position.

If wheel is not statically balanced, wheel will come to rest at the same position. Install balance weight at lighter position (at top) as illustrated.

NOTE:

The wheel should be balanced with brake disc installed.





5-1. FRONT WHEEL (XS400-2F)

A. Removal


1. Elevate the front wheel by placing a suitable stand under the engine.
2. Remove speedometer cable from front brake shoe plate: First remove clip and then pull cable out.
3. Remove brake cable; loosen all cable adjuster screws and remove cable from handle lever holder. Then remove cable from cam lever at front brake shoe plate.
4. Remove cotter pin from front wheel axle and remove axle nut.
5. Loosen axle holder nuts at other end of axle.
6. Turn and pull out the front wheel axle; the wheel assembly can now be removed.

B. Front Axle

Remove any corrosion from axle with emery cloth. Then place it on a surface plate and check for bending. If bent, replace.

C. Checking Brake Shoe Wear

1. Measure the outside diameter at the brake shoes with slide calipers.



Front brake shoe diameter	
Standard	180 mm (7.1 in)
Wear limit	176 mm (6.9 in)

2. Remove any glazed areas from brake shoes using coarse sand paper.

D. Brake Drum

Oil or scratches on the inner surface or the brake drum will impair braking performance or result in abnormal noises.

Remove oil by wiping with a rag soaked in lacquer thinner or solvent.

Remove scratches by lightly and evenly polishing with emery cloth.

E. Brake Shoe Plate

Remove the camshaft and grease. If the cam face is worn, replace.

NOTE:

Before removing the cam lever, put a match mark (punches) on the cam lever and camshaft to indicate their positions for easy assembly.

F. Replacing Wheel Bearings

If the bearings allow play in the wheel hub or if wheel does not turn smoothly, replace the bearings as follows:

1. First, clean the outside of the wheel hub.
2. Drive the bearing out by pushing the spacer aside (the spacer "floats" between the bearings) and tapping around the perimeter of the bearing inner race with a soft metal drift pin and hammer. Either or both bearings can be removed in this manner.
3. To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation. Use a socket that matches the outside race of the bearing as a tool to drive in the bearing.

G. Front Wheel Installation

When installing front wheel, reverse the removal procedure taking care of the following points:

1. Check for proper engagement of the boss on the outer fork tube with the locating slot on the brake shoe plate.
2. Always secure the front wheel axle as follows:
 - a. Torque the axle nut.

Axle nut torque:
8.5 m·kg (61.5 ft·lb)

- b. Install a new cotter pin; discard old pin.
- c. Install the axle holder as shown.
First tighten the nut on the front end of the axle holder, and tighten the nut on the rear end.

Axle holder nut torque:
1.9 m·kg (13.7 ft·lb)


(PAGE 63)

"5-2. REAR WHEEL" section should read as follows.

5-2. REAR WHEEL (XS400F)

A. Rear Wheel Removal

1. Support machine on the side stand.
2. Hook one end of the wire tool (contained in the owner's tool kit) to the hook attached to the frame.



3. Apply your weight to the rear part of the seat, and compress the rear shock absorbers by pulling up the right side of the swing arm with your hand, then hook the other end of the wire tool to the

swing arm.

4. With the wire tool in this position, place the machine on the center stand.
5. Disconnect the drive chain. Using drive chain cutter (special tool).

NOTE:

The chain joint should be replaced each time the chain is cut.

6. Remove the axle nut cotter pin and axle nut.
7. While supporting the brake caliper, pull out the rear axle.
8. Remove the rear wheel assembly.

B. Checking Brake Shoe Wear

Delete this section.

C. Brake Drum

Delete this section.

D. Brake Shoe Plate

Delete this section.

E. Replacing Wheel Bearings

See front wheel section, "Replacing Wheel Bearings".

F. Rear Wheel Installation

When installing rear wheel, reverse removal procedure taking care of following points:

1. Lightly grease lip of rear wheel oil seals.
2. Make sure the brake pads are installed properly and that there is enough gap to install the rear disc.
3. Install wheel assembly and axle. Always use a new cotter pin on the axle nut.

Axle nut torque:
10.7 m·kg (77.4 ft·lb)

4. Connect drive chain.
5. Adjust drive chain.

G. Rear Wheel Inspection

See "E. Front wheel inspection" for the front wheel.

5-2. REAR WHEEL (XS400-2F)

A. Removing the Rear Wheel

1. Remove the tension bar and the brake rod from the brake shoe plate. The tension bar can be removed by removing the cotter pin and nut from the tension bar bolt. The brake rod can be removed by removing the adjust nut.
2. Loosen the lock nuts of the right and left chain pullers and loosen the adjust bolts.
3. Remove the drive chain.
To remove, use the chain cutter (special tool). See Chapter 3. "Engine Overhaul", page 25.


NOTE:

The chain joint should be replaced each time the chain is cut.

4. Remove the rear wheel axle nut.
5. The rear wheel assembly, the collar, the chain puller (s), etc., can be removed from the motorcycle by pulling the axle.

B. Checking Brake Shoe Wear

1. Measure the outside diameter at the brake shoes with slide calipers.



Rear brake shoe diameter:
160 mm (6.30 in)
Replacement limit:
156 mm (6.14 in) min.

2. Remove any glazed areas from brake shoes using coarse sand paper.

C. Brake Drum

See front wheel section, "5-1-D. Brake Drum".

D. Brake Shoe Plate

See front wheel section, "5-1-E. Brake Shoe Plate".

E. Replacing Wheel Bearings

See front wheel section, "5-1-F. Replacing Wheel Bearing".

F. Installing Rear Wheel

1. Install wheel and axle.

Axle nut torque:
8.5 m·kg (61.5 ft·lb)

2. Connect drive chain, brake rod and tension bar.
3. Adjust drive chain.
(See chapter 2, "Drive chain tension adjustment".)
4. Tighten rear axle nut.
Install a new cotter pin.
5. Adjust rear brake. (See chapter 2, "Rear brake and wheel".)

(PAGE 63~69)

"5-3. DISC BRAKES" section should read as follows.

5-3. DISC BRAKES (XS400F only)

Except for the following, the same procedure can be performed for Assembly, Disassembly and Inspection of XS400F front and rear brake and XS360C front brake.

B. Disc Brake Inspection

The shim in the caliper is no longer used, and a set of two pad springs has been changed into one piece type.

C. Disc Brake Assembly

- d. Caliper installation

- 2) Install the brake hoses (front and rear).
Specification should be read as follows:

Tightening torque:
Union bolt: 2.6 m·kg (18.8 ft·lb)

(PAGE 69)

5-4. RIMS AND SPOKES

(FRONT AND REAR WHEELS)

A. Checking for loose spokes

Delete the whole section. (XS400F only)

(PAGE 70)

5-5. TIRES AND TUBES

Please add the following item after
"B. Installation". (XS400F/XS400-2F)

C. Checking for tire pressure and wear
Check the tire pressure and check the tires for wear.

WARNING:

Never overload the motorcycle beyond specified tire limits. Operation of an overloaded tire could cause tire damage, an accident and injury.

XS400F

	FRONT	REAR
XS400F BASIC WEIGHT with oil and full fuel tank	82 kg (181 lb)	97 kg (214 lb)
Standard tire	Bridgestone 3.00S-18-4PR	Bridgestone 3.50S-18-4PR
Maximum load limit	118 kg (260 lb)	225 kg (495 lb)
Cold tire pressure: Up to 90 kg (198 lb) load	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) load ~115 kg (254 lb) load	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
(Maximum load) High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

XS400-2F

	FRONT	REAR
XS400-2F BASIC WEIGHT with oil and full fuel tank	78 kg (172 lb)	89 kg (196 lb)
Standard tire	Bridgestone or Yokohama 3.00S-18-4PR	Bridgestone or Yokohama 3.50S-18-4PR
Maximum load limit	118 kg (260 lb)	225 kg (495 lb)
Cold tire pressure: Up to 90 kg (198 lb) load	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) load ~115 kg (254 lb) load	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
(Maximum load) High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)

Make sure the total weight of the motorcycle with accessories, rider (s), etc., does not exceed the tire limits.

(PAGE 81~82)


"B. Regulator" section should read as follows. (XS400F/XS400-2F)

B. I.C. voltage regulator

The regulator has been changed from a mechanical-point type to an IC (Integrated Circuit) type. The IC Voltage Regulator is a small and normally very reliable component. Due to its construction, it is light-weight and free from the wear and misadjustment associated with mechanical voltage regulators. If the following inspection reveals that the regulator is faulty, it cannot be adjusted and must be replaced.

1. Checking method

- Connect D.C. voltmeter to the battery terminals.




- b. Start engine.
- c. Accelerate engine to approximately 3,000 r/min or more and check regulated voltage.

Regulated voltage: 14.0 ~ 14.7V

- d. If voltage is off, check battery, generator and rectifier. If generator, battery and rectifier are good, then IC regulator is broken and it should be replaced.

NOTE:

- 1) Never disconnect wires from the battery while the generator is in operation. If the battery is disconnected, the voltage across the generator terminals will increase, damaging the semiconductors.
- 2) When checking the regulator being installed on a machine, the battery should not be removed, and it should be fully charged.
- 3) Never use a high voltage insulation ohmmeter such as a megaohmmeter for such a test. If high voltage is applied to the regulator terminals, the regulator will be damaged.



- c. Check the armature and field coil for shorting and insulation. Replace armature as required.

	Coil resistance
Armature coil	0.005Ω at 20°C (68°F)
Field coil	0.011Ω at 20°C (68°F)

- d. Check the front and rear cover bearings for damage. If damaged, the starter assembly must be replaced.

(PAGE 84)

6-4. STARTER MOTOR (XS400F only)

A. Servicing and troubleshooting

"1. Armature" section should read as follows.

1. Armature
 - a. Check the outer surface of the commutator. If its surface is dirty, clean with No. 600 grit sand paper.
 - b. The mica insulation between commutator segments should be 0.5 ~ 0.8 mm (0.02 ~ 0.03 in) below the segment level. If not, scrape to proper limits with appropriately shaped tool. (A hack saw blade can be ground to fit.)




7-2. SPECIFICATION


A. General

Item	XS400F	XS400-2F
1. MODEL		
1) Model (I.B.M. No.)	XS400F (2L0)	XS400-2F (2V6)
2) Frame I.D. and starting number	2L0-100101	2V6-000101
3) Engine I.D. and starting number	2L0-100101	2V6-000101
2. DIMENSION		
1) Overall length	2,065 mm (81.3 in)	←
2) Overall width	865 mm (34.1 in)	845 mm (33.3 in)
3) Overall height	1,140 mm (44.9 in)	1,130 mm (44.5 in)
4) Seat height	780 mm (30.7 in)	←
5) Wheelbase	1,365 mm (53.7 in)	←
6) Minimum ground clearance	150 mm (5.9 in)	←
3. WEIGHT		
1) Net weight (Dry)	168 kg (370 lb)	159 kg (351 lb)
4. PERFORMANCE		
1) Climbing ability	28°	←
2) Minimum turning radius	2,300 mm (86.6 in)	←
3) Braking distance	14 m @ 50 km/h (46 ft @ 31 mi/h)	←

B. Engine

1. DESCRIPTION		
1) Engine type	Air cooled, 4-stroke, SOHC twin, parallel forward incline	←
2) Engine model	2L0	2V6
3) Displacement	391 cc (23.92 cu.in)	←
4) Bore × stroke	69.0 × 52.4 mm (2.717 × 2.063 in)	←
5) Compression ratio	9.3 : 1	←
6) Starting system	Kick and electric starter	Kick starter
7) Ignition system	Battery ignition	←
8) Lubrication system	Wet sump	←
2. CYLINDER HEAD		
1) Combustion chamber volume	23.6 cc (1.440 cu.in) BP7ES	←
2) Combustion chamber type	Dome + Squish	←
3) Head gasket thickness	1.0 mm (0.04 in)	←
4) Tightening torque		
Cylinder head holding nut (M10 P1.25)	3.3 m·kg (24.0 ft·lb)	←
Cylinder head holding bolt (M6 P1.0)	1.0 m·kg (7.0 ft·lb)	←
Spark plug (M14 P1.25)	2.0 m·kg (14.5 ft·lb)	←
3. CYLINDER		
1) Material	Aluminum alloy with cast iron sleeve	←
2) Bore size	69.0 $^{+0.02}_{0}$ mm (2.72 $^{+0.0008}_{0}$ in)	←
3) Taper limit	0.05 mm (0.002 in)	←
4) Out of round limit	0.01 mm (0.0004 in)	←
4. PISTON		
1) Piston skirt clearance	0.030 ~ 0.050 mm (0.0012 ~ 0.0019 in)	←

Item		XS400F				XS400-2F									
2) Piston oversize		69.25 mm (2.727 in)	69.50 mm (2.736 in)	69.75 mm (2.746 in)	70.00 mm (2.756 in)	←									
3) Piston pin outside diameter × length		16.0 ⁰ _{-0.005} mm × 58.5 ⁰ _{-0.3} mm (0.63 ⁰ _{-0.0002} in × 2.303 ⁰ _{-0.0116} in)				←									
5. PISTON RING															
1) Piston ring design (Top)		Plain ring 1.0 mm (0.039 in)				←									
(2nd)		Plain ring 1.5 mm (0.059 in)				←									
(Oil ring)		With expander 2.45 mm (0.096 in)				←									
2) Ring end gap (Installed top)		0.2 ~ 0.4 mm (0.008 ~ 0.016 in)				←									
(Installed 2nd)		0.2 ~ 0.4 mm (0.008 ~ 0.016 in)				←									
(Installed Oil)		0.2 ~ 0.9 mm (0.008 ~ 0.035 in)				←									
3) Ring groove side clearance (Top)		0.04 ~ 0.08 mm (0.0016 ~ 0.0032 in)				←									
(2nd)		0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)				←									
(Oil)					←									
6. BIG END BEARING															
1) Type		Plain bearing				←									
2) Oil clearance		0.021 ~ 0.045 mm (0.0008 ~ 0.0018 in)				←									
3) Bearing size		<table><tr><td>1. (Blue)</td><td>1.50^{+0.004}₀ mm (0.0591^{+0.00016}₀ in)</td></tr><tr><td>2. (Black)</td><td>1.50⁰_{-0.004} mm (0.0591⁰_{-0.00016} in)</td></tr><tr><td>3. (Brown)</td><td>1.50^{-0.004}_{-0.006} mm (0.0591^{-0.00016}_{-0.00031} in)</td></tr><tr><td>4. (Green)</td><td>1.50^{0.008}_{-0.012} mm (0.0591^{-0.00031}_{-0.00047} in)</td></tr></table>				1. (Blue)	1.50 ^{+0.004} ₀ mm (0.0591 ^{+0.00016} ₀ in)	2. (Black)	1.50 ⁰ _{-0.004} mm (0.0591 ⁰ _{-0.00016} in)	3. (Brown)	1.50 ^{-0.004} _{-0.006} mm (0.0591 ^{-0.00016} _{-0.00031} in)	4. (Green)	1.50 ^{0.008} _{-0.012} mm (0.0591 ^{-0.00031} _{-0.00047} in)	←	
1. (Blue)	1.50 ^{+0.004} ₀ mm (0.0591 ^{+0.00016} ₀ in)														
2. (Black)	1.50 ⁰ _{-0.004} mm (0.0591 ⁰ _{-0.00016} in)														
3. (Brown)	1.50 ^{-0.004} _{-0.006} mm (0.0591 ^{-0.00016} _{-0.00031} in)														
4. (Green)	1.50 ^{0.008} _{-0.012} mm (0.0591 ^{-0.00031} _{-0.00047} in)														
7. CAMSHAFT															
1) Cam drive type		Chain (Center side)				←									
2) Number and type of bearing		3 bearings cylinder head direct support				←									
3) Bearing dimensions															
	Cap I.D.	Shaft O.D.	Clearance												
IN and EX 1,2,3	23.0 ^{+0.021} ₀ mm (0.906 ^{+0.0082} ₀ in)	23.0 ^{-0.020} _{-0.033} mm (0.906 ^{-0.00079} _{-0.00130} in)	0.020 ~ 0.054 mm (0.00079 ~ 0.00213 in)		←										
4) Cam dimensions															
	Cam height "A"	Limit	Base circle "B"	Limit	Lift "C"										
IN	39.53 ± 0.05 mm (1.556 ± 0.0019 in)	39.38 mm (1.550 in)	32.27 ± 0.05 mm (1.270 ± 0.0019 in)	32.12 mm (1.265 in)	7.53 mm (0.296 in)	←									
EX	39.57 ± 0.05 mm (1.558 ± 0.0019 in)	39.42 mm (1.552 in)	32.12 ± 0.05 mm (1.265 ± 0.0019 in)	31.97 mm (1.259 in)	7.57 mm (0.298 in)										
5) Valve timing															
	OPEN	CLOSE	DURATION	OVERLAP											
IN	8TDC 30°	ABDC 70°	280°	60°		←									
EX	8BDC 70°	ATDC 30°	280°			←									
6) Camshaft deflection limit		0.03 mm (0.0012 in)				←									
7) Cam chain															
Type		TSUBAKIMOTO BF05M				←									
Pitch/Number of links		7.774 mm (0.3060 in)/92L				←									
Sprocket ratio (Teeth)		34/17 (2.000)				←									


Item	XS400F	XS400-2F
8. ROCKER ARM AND ROCKER SHAFT		
1) Rocker arm inner diameter	13.0 $^{+0.018}_{-0.016}$ mm (0.512 $^{+0.0007}_{-0.00063}$ in)	←
2) Rocker arm shaft diameter	13.0 $^{+0.018}_{-0.036}$ mm (0.512 $^{+0.0007}_{-0.00141}$ in)	←
3) Clearance	0.016 ~ 0.054 mm (0.00053 ~ 0.00122 in)	←
4) Lift ratio	X : Y = 32.05 : 33.62 mm (1.262 : 1.324 in)	←
9. VALVE, VALVE SEAT AND VALVE GUIDE		
1) Valve per cylinder	2 pcs.	←
2) Valve clearance (In cold engine)	IN: 0.08 ~ 0.12 mm (0.0031 ~ 0.0047 in) EX: 0.16 ~ 0.20 mm (0.0063 ~ 0.0078 in)	←
3) Dimensions		
Valve head diameter "A"	IN: 35.5 ± 0.1 mm (1.398 ± 0.004 in) EX: 30.0 ± 0.1 mm (1.181 ± 0.004 in)	←
Valve face width "B"	IN: 2.3 mm (0.091 in) EX: 2.3 mm (0.091 in)	←
Valve seat width "C"	IN: 1.0 ± 0.1 mm (0.039 ± 0.004 in) EX: 1.0 ± 0.1 mm (0.039 ± 0.004 in)	←
Valve margin thickness "D"	IN: 1.0 ± 0.2 mm (0.039 ± 0.008 in) EX: 1.0 ± 0.2 mm (0.039 ± 0.008 in)	←
		
Valve stem diameter	IN: 7.0 $^{+0.010}_{-0.025}$ mm (0.275 $^{+0.0004}_{-0.0009}$ in) EX: 7.0 $^{+0.030}_{-0.045}$ mm (0.275 $^{+0.0012}_{-0.0018}$ in) IN: 7.0 $^{+0.012}_{0}$ mm (0.275 $^{+0.0005}_{0}$ in) EX: 7.0 $^{+0.012}_{0}$ mm (0.275 $^{+0.0005}_{0}$ in)	←
Valve guide diameter	IN: 0.010 ~ 0.037 mm (0.00039 ~ 0.00145 in)	←
Valve stem to stem clearance	EX: 0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)	←
4) Valve face runout limit	IN & EX: 0.03 mm (0.0012 in) or less	←
10. VALVE SPRING		
1) Free length	INNER (IN/EX): 39.3 mm (1.547 in) OUTER (IN/EX): 42.8 mm (1.685 in)	←
2) Spring rate (kg/mm)	INNER (IN/EX): $k_1 = 1.93$ $K_2 = 2.47$ OUTER (IN/EX): $k_1 = 4.19$ $k_2 = 5.49$	←
3) Installed length (Valve closed)	INNER (IN/EX): 33.0 mm (1.299 in) OUTER (IN/EX): 37.0 mm (1.457 in)	←

Item	XS400F		XS400-2F
4) Installed pressure (Valve closed)	INNER (IN/EX):	12.1 ± 1.2 kg (26.7 ± 2.6 lb)	←
	OUTER (IN/EX):	24.4 ± 1.7 kg (53.8 ± 3.8 lb)	←
5) Compressed length (Valve open)	INNER (IN/EX):	25.0 mm (0.984 in)	←
	OUTER (IN/EX):	29.0 mm (1.142 in)	←
6) Compressed pressure (Valve open)	INNER (IN/EX):	31.9 kg (69.2 lb)	←
	OUTER (IN/EX):	68.3 kg (151 lb)	←
7) Wire diameter (Valve open)	INNER (IN/EX):	3.0 mm (0.118 in)	←
	OUTER (IN/EX):	4.4 mm (0.173 in)	←
8) Winding O.D. (Valve open)	INNER (IN/EX):	22.4 mm (0.882 in)	←
	OUTER (IN/EX):	32.0 mm (1.260 in)	←
9) Number of windings (Valve open)	INNER (IN/EX):	7.75 turns	←
	OUTER (IN/EX):	6.25 turns	←
10) Tilt limit (Valve open)	INNER (IN/EX):	1.7 mm (0.067 in) or 2.5°	←
	OUTER (IN/EX):	1.9 mm (0.075 in) or 2.5°	←
11. CRANKSHAFT			
1) Crankshaft deflection	0.02 mm (0.0008 in)		←
2) Con-rod large end clearance	0.160 ~ 0.264 mm (0.0063 ~ 0.0104 in)		←
3) Clearance between crank and crankcase	0.05 ~ 0.25 mm (0.002 ~ 0.010 in)		←
12. CONNECTING ROD			
1) Big end I.D.	41.0 ^{+0.024} / ₀ mm (1.614 ^{+0.0009} / ₀ in)		←
2) Small end I.D.	16.0 ^{+0.028} / _{+0.015} mm (0.630 ^{+0.0011} / _{+0.0028} in)		←
3) Difference of each rod weight	5 g or less		←
13. CRANK BEARING			
1) Oil clearance	0.020 ~ 0.044 mm (0.00079 ~ 0.00157 in)		←
2) Bearing size	1.(Blue)	1.50 ^{+0.012} / _{+0.008} mm (0.0591 ^{+0.00047} / _{+0.00031} in)	←
	2.(Black)	1.50 ^{+0.008} / _{+0.004} mm (0.0591 ^{+0.00031} / _{+0.00016} in)	
	3.(Brown)	1.50 ^{+0.004} / ₀ mm (0.0591 ^{+0.00016} / ₀ in)	
	4.(Green)	1.50 ⁰ / _{-0.004} mm (0.0591 ⁰ / _{-0.00016} in)	
14. CLUTCH			
1) Clutch type	Wet, multiple type		←
2) Clutch operating mechanism	Inner push type, screw push system		←
3) Primary reduction ratio and method	78/24 (3.250), spar gear		←
4) Friction plate			
Thickness/Quantity	3 mm (0.12 in)/7 pcs.		←
Wear limit	2.7 mm (0.11 in)		←
5) Clutch plate			
Thickness/Quantity	1.6 mm (0.063 in)/6 pcs.		←
Warp limit	0.05 mm (0.002 in)		←
6) Clutch spring			
Free length/Quantity	34.6 mm (1.362 in)/4 pcs.		←
Minimum length	33.6 mm (1.323 in)		←

Item	XS400F	XS400-2F
7) Clutch housing radial play (Wear limit)	0.009 ~ 0.043 mm (0.00035 ~ 0.00169 in)	←
8) Push rod bending limit	0.2 mm (0.008 in)	←
9) Tightening torque		
Primary drive gear (M10 P1.25)	4.8 m·kg (34.5 ft·lb)	←
Clutch spring screw (M6 P1.0)	1.0 m·kg (7.2 ft·lb)	←
15. TRANSMISSION		
1) Type	Constant mesh, 6-speed forward	←
2) Gear ratio: 1st	35/14 (2.500)	←
2nd	32/18 (1.777)	←
3rd	29/21 (1.380)	←
4th	27/24 (1.125)	←
5th	25/26 (0.961)	←
6th	26/30 (0.866)	←
3) Bearing type: Main axle (Left)	Needle bearing (ø20-ø30-15)	←
Main axle (Right)	Ball bearing (5205)	←
Drive axle (Left)	Ball bearing (6305 special)	←
Drive axle (Right)	Needle bearing (ø20-ø33-15)	←
4) Oil seal type Drive axle (Left)	SD-35-62-6	←
5) Secondary reduction ratio and method	39/16 (2.437) Chain	←
6) Tightening torque		
Drive sprocket (M18 P1.0)	6.5 m·kg (47.0 ft·lb)	←
16. SHIFTING MECHANISM		
1) Type	Cam drum, return type	←
2) Oil seal type (Change lever)	SD-12-22-5	←
3) Tightening torque		
Change pedal (M6 P1.0)	1.0 m·kg (7.2 ft·lb)	←
17. KICK STARTER		
1) Type	Kick and mesh	←
2) Oil seal type (Kick axle)	SD-20-30-7	←
3) Kick clip friction tension	1.0 m·kg (7.0 ft·lb)	←
4) Tightening torque		
Kick crank (M8 P1.25)	2.0 m·kg (14.5 ft·lb)	←
18. CRANKCASE		
1) Tightening torque		
Bolt (M8 P1.25)	2.2 m·kg (16.0 ft·lb)	←
Bolt (M6 P1.0)	1.0 m·kg (7.0 ft·lb)	←
19. INTAKE		
1) Air cleaner: Type/Quantity	Dry, foam rubber/2 pcs.	←
2) Cleaner cleaning interval	Every 8,000 km (5,000 mile)	←
3) Valve clearance	See No. 9-2) Valve, valve seat and valve guide	←
20. CARBURETOR		
1) Type and manufacturer/Quantity	BS34 MIKUNI/2 pcs.	←
2) I.D. mark	2L0-60	←
3) Main jet (MJ)	#132.5	←
4) Air jet (AJ)	#45	←
5) Jet needle-clip position (JN)	5Z1-3	←
6) Needle jet (NJ)	X-6	←
7) Throttle valve (Th.V)	#135	←

Item	XS400F	XS400-2F
8) Pilot jet (P.J)	#42.5	←
9) Air screw (Turns out) (AS)	Preset (1-1/4 ± 1/2)	←
10) Starter jet (GS)	#30	←
11) Fuel level (FL)	32 ± 1 mm (1.26 ± 0.04 in)	←
12) Vacuum synchronization	5 mmHg or less	←
13) Idling engine speed	1,200 r/min	←
21. LUBRICATION		
1) Engine sump oil quantity	Oil exchange: 2.0 lit (2.1 qt) Filter and oil exchange: 2.3 lit (2.4 qt) Total amount: 2.6 lit (2.7 qt)	←
2) Oil type	Yamalube 4-cycle oil or SAE 20W/40 "SE" motor oil (more than 5°C (32°F)) SAE 10W/30 "SE" motor oil (below 15°C (59°F))	←
3) Oil pump type	Trochoid pump	←
4) Trochoid pump specifications		
Top clearance	0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in)	←
Tip clearance	0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in)	←
Side clearance	0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in)	←
Oil pump volume	1.2 lit/min at 500 r/min	←
5) Relief valve operating pressure	5 ± 0.5 kg/cm ² (71 ± 7 psi)	←
6) Bypass valve setting pressure	1.0 ± 0.2 kg/cm ² (14 ± 3 psi)	←

Lubrication chart:



C. Chassis

Item	XS400F	XS400-2F
1. FRAME 1) Frame design 2) Tightening torque Engine mounting bolt (M8 P1.25) Engine mounting bolt (M10 P1.25)	Semi double cradle, high tensile frame 1.8 m·kg (13.0 ft-lb) 3.1 m·kg (22.5 ft-lb)	+ + +
2. STEERING SYSTEM 1) Caster 2) Trail 3) Number and size of balls in steering head Upper race Lower race 4) Steering lock to lock 5) Tightening torque Steering shaft fitting nut (M14 P1.25) Steering shaft fitting nut (M25 P1.0) Stem pinch bolt (M8 P1.25) Handle bar mounting bolt (M10 P1.25)	27° 84 mm (3.31 in) 19 pcs. 1/4 in 19 pcs. 1/4 in 42° each (L and R) 5.4 m·kg (39.0 ft-lb) 3.8 m·kg (27.5 ft-lb) 1.2 m·kg (8.5 ft-lb) 2.3 m·kg (16.5 ft-lb)	+ + + + + + + + +
3. FRONT SUSPENSION 1) Type 2) Damper type 3) Front fork spring Free length Wire diameter x winding diameter Spring constant 4) Front fork travel 5) Inner tube O.D. 6) Front fork oil quantity and type 7) Oil seal type 8) Tightening torque Under bracket and inner tube (M10 P1.25) Handle crown and inner tube (M8 P1.25)	Telescopic fork Oil damper, coil spring 502 mm (19.76 in) 3.8 mm × 23 mm (0.15 × 0.91 in) $k_1 = 0.4 \text{ kg/mm}$ (0 ~ 100 mm) $k_2 = 0.575 \text{ kg/mm}$ (100 ~ 140 mm) 140 mm (5.5 in) 33 mm (1.30 in) 142 cc (4.8 oz) each leg Yamaha fork oil or SAE 10W/30 motor oil SD-33-46-10.5 3.5 m·kg (25.0 ft-lb) 1.1 m·kg (8.0 ft-lb)	+ + + + + + + + + +
4. REAR SUSPENSION 1) Type 2) Damper type 3) Shock absorber travel 4) Shock absorber spring Set length Free length Wire diameter × Winding diameter Spring constant 5) Swing arm free play (Limit) 6) Pivot shaft — Outside diameter 7) Tightening torque: Rear shock absorber (Upper) (M10 P1.25)	Swing arm Oil damper, coil spring 80 mm (3.15 in) 204 mm (8.03 in) 216 mm (8.50 in) 7.0 mm × 54.0 mm (0.27 × 2.13 in) $k_1 = 1.7 \text{ kg/mm}$ (0 ~ 55 mm) $k_2 = 2.1 \text{ kg/mm}$ (55 ~ 80 mm) 1.0 mm (0.04 in) 16 mm (0.63 in) 3.0 m·kg (21.5 ft-lb)	+ + + + + + + + +

Item	XS400F	XS400-2F
Rear shock absorber (Upper) (M10 P1.25)	3.0 m-k (21.5 ft-lb)	←
Pivot shaft (M14 P1.5)	6.5 m-k (47.0 ft-lb)	←
5. FUEL TANK		
1) Capacity	14.0 lit (3.7 US. gal)	←
2) Fuel grade	Regulator gasoline (90 octane)	←
6. WHEEL		
1) Type (Front and rear)	Cast wheel	Spoke wheel
2) Tire size (Front)	3.00S18-4PR	←
(Rear)	3.50S18-4PR	←
4) Rim run out limit (Front and rear)		
Vertical	2.0 mm (0.08 in)	←
Lateral	2.0 mm (0.08 in)	←
5) Rim size (Front)	1.85 × 18	1.60 × 18
(Rear)	2.15 × 18	1.85 × 18
6) Bearing type		
Front wheel (Left)	6302ZZ	6302RS
Front wheel (Right)	6302ZZ	6302RS
Rear wheel (Left)	6304ZZ	6304RS (6304 Lu/3A)
Rear wheel (Right)	6303ZZ	6303 Luc3/3A
7) Oil seal type		
Front wheel (Left)	SDD-45-56-6	SDD-53-65-7
Front wheel (Right)	SD-22-42-7	SD-22-42-7-1
Rear wheel (Left)	SO-27-52-5	SD-27-52-5
Rear wheel (Right)	SD-28-47-7	—
8) Secondary drive chain type		
Type	DK530DS	←
Number of links	101L + Joint	←
Chain pitch	15.875 mm (5/8 in)	←
Chain free play	35 ~ 40 mm (13.8 ~ 1.57 in)	←
9) Tightening torque		
Front wheel axle (M14 P1.5)	10.5 m-k (76 ft-lb)	←
Front axle holder (M8 P1.25)	2.0 m-k (14.5 ft-lb)	←
Rear wheel axle (M14 P1.5)	10.5 m-k (76 ft-lb)	←
7. BRAKE		
1) Front and rear brake		
Type	Hydraulic disc type	Drum brake
Disc size (Outside dia. × thickness)	257 mm × 5.0 mm (10.5 × 0.2 in)	—
Disc wear limit	4.5 mm (0.18 in)	—
Disc pad thickness	6.5 mm (0.26 in)	—
Pad wear limit (Minimum thickness)	1.5 mm (0.06 in)	—
Master cylinder inside dia.		
Front	14.0 mm (0.55 in)	—
Rear	15.8 mm (0.62 in)	—
Caliper cylinder inside dia.	38.1 mm (1.5 in)	—
Brake fluid type/quantity	DOT #3/34 cc (0.8 oz)	—
Actuating method Front	—	Two leading
Rear	—	Leading trailing
Brake drum I.D. Front	—	180 mm (7.1 in)
Rear	—	160 mm (6.3 in)
Brake shoe dia × width Front	—	180 mm × 30 mm
		(7.1 in × 1.2 in)
Rear	—	160 mm × 30 mm
		(6.3 in × 1.2 in)

Item		XS400F	XS400-2F
Lining thickness/wear limit	Front	—	4.0/2.0 mm (0.16/0.08 in)
	Rear	—	4.0/2.0 mm (0.16/0.08 in)
Shoe spring free length	Front	—	68 mm (2.68 in)
	Rear	—	68 mm (2.68 in)
2) Tightening torque			
Brake disc and hub (M8 P1.25)		2.0 m·kg (14.5 ft·lb)	—
Caliper and support bracket (M8 P1.25)		1.8 m·kg (13.0 ft·lb)	—
Caliper and pad (M5 P0.8)		0.3 m·kg (2.0 ft·lb)	—
Caliper and bleed screw (M8 P1.25)		0.6 m·kg (4.5 ft·lb)	—
Support bracket and front fork (M10 P1.25)		3.5 m·kg (25.5 ft·lb)	—
Caliper and brake hose (M10 P1.25)		2.6 m·kg (19.0 ft·lb)	—
Master cylinder and cylinder bracket (M6 P1.0)		0.6 m·kg (4.5 ft·lb)	—


D. Electrical

Item		XS400F	XS400-2F
1. IGNITION SYSTEM			
1) Battery (AC generator)			
Model/Manufacturer		021000-5840/NIPPON DENSO	←
Voltage		12V	←
Taper dia. at large end		25 mm (0.98 in)	←
Rotor tightening torque (M10 P1.25)		3.3 m·kg (24.0 ft·lb)	←
2) Ignition timing (B.T.D.C.)		10°/1,200 r/min	←
3) Ignition coil			
Model/Manufacturer		029700-4130/NIPPON DENSO	←
Spark gap		6 mm (0.24 in) or more/500 r/min.	←
Primary winding resistance		4.0 Ω ± 10% at 20°C (68°F)	←
Secondary winding resistance		9.5 kΩ ± 20% at 20°C (68°F)	←
4) Spark plug			
Type		NGK BP 7ES, CHAMPION N-7Y.	←
Spark plug gap		0.7 ~ 0.8 mm (0.027 ~ 0.031 in)	←
5) Contact breaker			
Manufacture/Quantity		NIPPON DENSO/2 pcs.	←
Point gap		0.30 ~ 0.40 mm (0.012 ~ 0.016 in)	←
Point spring pressure		800 ± 100g	←
Cam closing angle		105°	←
6) Condenser			
Capacity		0.24μF ± 15%	←
Insulation resistance		10MΩ (500V megger used) or more	←
Quantity		2 pcs.	←
2. CHARGING SYSTEM			
1) AC generator			
Charging output		14.5V 13A/5,000 r/min	←
Rotor coil resistance (Field coil)		4.04 Ω ± 10% at 20°C (68°F)	←
Stator coil resistance		0.72 Ω ± 10% at 20°C (68°F)	←
2) Rectifier			
Type		6-Element type (Full wave)	←
Model/Manufacturer		DS10TEY/MITSUBISHI or DE3804-1/STANLEY	←

Item	XS400E	XS400-2F
Capacity	12V	←
Withstand voltage	400V	←
3) Regulator		
Type	I.C. type	←
Model/ Manufacturer	026000-3280 NIPPON DENSO	←
Regulating voltage	14.0 ~ 14.7V	←
4) Battery		
Model/ Manufacturer/ Quantity	12N12-4A-1	←
Capacity	12V, 12AH	←
Charging rate	1.2A	←
Specific gravity/ Quantity	1.28 at 20°C (68°F), Total 800 cc (27 oz)	←
3. STARTER		
1) Starter motor		
Type	Constant mesh type	—
Manufacturer	MITSUBA ELEC.	—
Model	SM223B	—
Output	0.5 kW	—
Armature coil resistance	0.005 Ω \pm 10% at 20°C (68°F)	—
Field coil resistance	0.011 Ω \pm 10% at 20°C (68°F)	—
Brush size/ Quantity	11 \times ^{1.5} ₀ mm (0.43 ^{+0.06} ₀ in) 2 pcs.	—
Wear limit	6.0 mm (0.24 in)	—
Spring pressure	550 \pm 55g (19.4 \pm 1.9 oz)	—
Commutator O.D./ Wear limit	28 mm (1.102 in)/ 27 mm (1.063 in)	—
Mica undercut	0.7 mm (0.027 in)	—
Reduction system/ Ratio	Chain/ 6.45	—
2) Starter switch		
Manufacturer	HITACHI	—
Model	A104-70	—
Amperage rating	100A	—
Cut-in voltage	6.5V or less	—
Winding resistance	3.5 Ω \pm 10%	—
4. LIGHTING SYSTEM		
1) Head light type	Semi-sealed beam	←
2) Bulb wattage/ Quantity		
Head light wattage	12V, 40/30W	←
Tail/ Brake light wattage	12V, 8/27W (3/32 cp) \times 2 pcs.	←
Turn light wattage	12V, 27W (32 cp) \times 4 pcs.	←
Meter light wattage	12V, 3.4W \times 4 pcs.	←
Neutral light wattage	12V, 3.4W	←
Turn indicator light wattage	12V, 3.4W	←
Oil pressure light wattage	12V, 3.4W	←
High beam indicator light wattage	12V, 3.4W	←
3) Horn		
Model/ Manufacturer	SF-12/ NIKKO	←
maximum amperage	2.5A	←
4) Flasher relay		
Type	Condenser type	←
Model/ Manufacturer	061300-4810/ NIPPON DENSO	←
Flasher frequency	85 \pm 10 cycle/ min.	←
Capacity	27W \times 2 + 3.4W	←
5) Flasher cancelling unit		
Model	EVH-AC518	←
Voltage	DC9V ~ 16V	←

Item	XS400F	XS400-2F
6) Fuse Rating/Quantity	Main (Red): 20A Headlight (Red/Yellow): 10A Signal (Brown): 10A Ignition (Red/White): 10A	← ← ← ←

G:	Green	G/Y:	Green/Yellow
L:	Blue	L/G:	Blue/Green
O:	Orange	L/W:	Blue/White
P:	Pink	L/Y:	Blue/Yellow
R:	Red	R/L:	Red/Blue
Br:	Brown	R/W:	Red/White
W:	White	R/Y:	Red/Yellow
Y:	Yellow	W/G:	White/Green
Dg:	Dark green	Y/B:	Yellow/Black
Gv:	Grey	Y/G:	Yellow/Green
Lg:	Light green	Y/R:	Yellow/Red
Sb:	Sky blue	Br/W:	Brown/White



XS400G XS400SG

Supplementary

FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and new data for the XS400G/XS400SG.

For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manuals:

XS360C Service Manual (LIT-11616-00-49)

XS400F/XS4002F Supplementary Service Manual (LIT-11616-01-19)

SERVICE DEPT.
INTERNATIONAL DIVISION
YAMAHA MOTOR CO., LTD.

NOTE:

This Supplementary Service Manual contains information regarding periodic maintenance to the emissions control system for the XS400G/-XS400SG. Please read this material carefully.

NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent to motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit for use and/or unsafe.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the motorcycle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his motorcycle and to conform with federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

Particularly important information is distinguished in this manual by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedure that must be followed to avoid damage to the engine.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

Starting Serial Number

XS400G: 3F8-020101



XS400SG: 3F9-000101



MAINTENANCE AND LUBRICATION CHART

Periodic maintenance emission control system

No.	ITEM	REMARKS	INITIAL BREAK-IN		THEREAFTER EVERY	
			1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)
1.*	Valve Clearance	Check and adjust valve clearance when engine is cold.	○	○		○
2.	Spark Plugs	Check condition. Adjust gap. Clean. Replace after initial 13,000 km (8,000 mi).		○	○	Replace every 12,000 km or 18 months (7,500 mi)
3.*	Crankcase Ventilation System	Check ventilation hose for cracks or damage. Replace if necessary.		○		○
4.*	Fuel Hose	Check fuel hose for cracks or damage. Replace if necessary.		○		○
5.*	Exhaust System	Check for leakage. Retighten as necessary. Replace gasket(s) if necessary.		○	○	
6.*	Carburetor Syn-chronization	Adjust synchronization of carburetors.		○	○	
7.*	Idle Speed	Check and adjust engine idle speed. Adjust cable free play if necessary.		○	○	

* It is recommended that these items be inspected and serviced by a Yamaha Dealer or other qualified mechanic.

General maintenance/lubrication

No.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY		
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)
1.	Engine Oil	Warm-up engine before draining	Refer to NOTE	○	○	○		
2.	Oil Filter	Replace	—	○	○		○	
3.*	Air Filter	Dry type filter. Clean with compressed air.	—		○		○	
4.*	Brake system	Adjust free play. Replace pads ** (front brake only) or shoes (rear brake only) if necessary.	—	○	○	○		
5.*	Clutch	Adjust free play	—	○	○	○		
6.	Drive Chain	Check chain condition. Adjust and lubricate chain thoroughly.	Yamaha chain and cable lube or 10W/30 motor oil	CHECK CHAIN TENSION AND LUBE EVERY 500 km (300 mi).				
7.	Control and Meter Cable	Apply cable lube thoroughly.	Yamaha chain and cable lube or 10W/30 motor oil	○	○	○		
8.	Rear Arm Pivot Shaft	Apply lightly.	Lithium soap base grease		○		○	

No.	ITEM	REMARKS	TYPE	INITIAL BREAK-IN		THEREAFTER EVERY		
				1,000 km or 1 month (600 mi)	5,000 km or 7 months (3,000 mi)	4,000 km or 6 months (2,500 mi)	8,000 km or 12 months (5,000 mi)	16,000 km or 24 months (10,000 mi)
9.	Stand Shaft Pivots/ Brake Pedal Shaft/ Charge Pedal Shaft/Kick Crank Boss	Apply lightly	Yamaha chain and cable or 10W/30 motor oil		○	○		
10.*	Front Fork Oil	Drain completely. Refill to specification	Yamaha fork oil 20wt or equivalent					○
11.*	Steering Bearings	Check bearings assembly for looseness. Moderately repack every 16,000 km (10,000 mi)	Medium weight wheel bearing grease.		○	○		Repack
12.*	Wheel Bearings	Check bearings for smooth rotation.	—		○	○		
13.	Battery	Check specific gravity. Check breather pipe for proper operation.	—		○	○		
14.	Brake/ Clutch Lever Pivot Shafts	Apply lightly	Yamaha chain and cable lube or 10W/30 motor oil		○	○		

* It is recommended that these items be inspected and serviced by a Yamaha dealer or other qualified mechanic.

** XS400SG only

NOTE:

Engine oil type:

- If temperature does not go below 5°C (41°F): YAMALUBE 4-cycle oil or SAE 20W/40 type "SE" motor oil.
- If temperature does not go above 15°C (59°F): SAE 10W/30 type "SE" motor oil


NEW SERVICE

* SPECIAL TOOL

Slide hammer

P/N. 90890-01083-00,

90890-01084-00



These tools are used to remove the blind plug from the pick-up coil cover.

* ENGINE

A. ENGINE OIL LEVEL MEASUREMENT

1. Place the motorcycle on the center stand. Warm up the engine for several minutes.


NOTE:

Be sure the motorcycle is positioned straight up when checking the oil level; a slight tilt toward the side can produce false readings.

2. With the engine stopped, check the oil level through the level window located at the lower part of the right side crankcase cover.

NOTE:

Wait a few minutes until the oil level settles before checking



3. The oil level should be between maximum and minimum marks. If the level is lower, add sufficient oil to raise it to the proper level.

B. IGNITION TIMING CHECK

Ignition timing adjustment is required only when the pick-up base is removed from the crankcase.

1. Connect the timing light to the left cylinder spark plug lead wire.
2. Start the engine and keep the engine speed as specified.
Use a tachometer to check the engine speed.

Specified engine speed: 1,200 r/min

3. The stationary pointer should line up with the "LF" timing mark on the rotor. If it does not align or steady, check the relector (rotor) securing bolt for looseness.

C. PICK-UP COIL REMOVAL AND REINSTRATION

The pick-up coil cover is permanently mounted to the cylinder head.


It is necessary to remove the blind plug from the cover when the pick-up coil removal and/or engine overhaul are required.

If the pick-up coil cover is removed and/or pick-up coil is removed or replaced with a new one, the following adjustment and treatment are necessary.

It is mandatory that these procedures be followed carefully and exactly as described. Failure to do so may be a violation of law.


Removal

1. Punch a center mark in the blind plug with a centerpunch.




1. Center punch 2. Blind plug

2. Use a 5 mm drill bit to drill a hole in the blind plug.




1. $\phi 5$ mm drill bit

3. Cut internal threads of 6 mm dia. \times 1.0 mm pitch in the blind plug with a tap drill of proper size.




1. Tap drill (M6 \times 1.0 mm pitch)

4. Remove the blind plug with the slide hammer (special tool) from the pick-up coil cover.




5. Remove the cover holding screws and remove the cover.
6. Remove the reluctor (rotor) holding bolt and remove the reluctor (rotor).



1. Reluctor

7. Remove the pick-up coil holding screws and remove the pick-up coil assembly from the cylinder head.



Reinstallation

1. Install the pick-up coil assembly to the cylinder head.
2. Install the reluctor (rotor).

Reluctor (rotor) holding bolt torque:

3. Check the ignition timing (refer to page 3).
4. If the ignition timing is incorrect, loosen the pick-up coil holding screws and move the pick-up coil base plate until the "LF" and the stationary pointer marks align.
5. After the ignition timing is properly adjusted tighten the screws securely.
6. Install the pick-up coil cover and tighten the screws.
7. Install a new blind plug into the cover hole and tap it in until it tight enough. If the plug will not be tightly fitted or if a crack is developed in the cover while the plug is being installed, be sure to change the cover and repeat the above steps.



1. Pin punch

* CHASSIS

A. TUBELESS TIRES AND ALUMINUM WHEELS (XS400SG only)

This motorcycle is equipped with aluminum wheels designed to be compatible with either tube or tubeless tires. Tubeless tires are installed as standard equipment.


WARNING:

Do not attempt to use tubeless tires on a wheel designed for use only with tube-type tires. Tire failure and personal injury may result from sudden deflation.

Tube-type Wheel — Tube type tires only

Tubeless-type Wheel — Tube-type or Tubeless tires

When using tube-type tires, be sure to install the proper tube plug.



To insure maximum performance, long service, and safe operation, note the following precautions:

1. Check tire pressure, before riding, adjust as necessary.
2. Before operation, always check the tire surfaces for wear and/or damage; look for cracks, glass, nails, metal fragments, stones, etc. Correct any such hazard before riding.
3. Always inspect the aluminum wheels before a ride. Place the motorcycle on the center stand and check for cracks, bends or warpage of the wheels. Do not attempt even small repairs to the wheel. If a wheel is deformed or cracked, it must be replaced.
4. Tires and wheels should be balanced whenever either one is changed or replaced. Failure to have a wheel assembly balanced can result in poor performance, adverse handling characteristics, and shortened tire life.
5. After installing a tire, ride conservatively to allow the tire to seat itself on the rim properly. Failure to allow proper seating may cause tire failure resulting in damage to the motorcycle and injury to the rider.
6. After repairing or replacing a tire, check to be sure the valve stem lock nut is securely fastened. If not, torque it as


Tightening torque: 0.15 m-kg (1.1 ft-lb)

B. TIRE PRESSURE (XS400G/XS400 SG)


Cold tire pressure	Front	Rear
Up to 90 kg (198 lb) load*	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) load ~ 159 kg (351 lb) load* (Maximum load)	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)

* Total weight of accessories, etc. excepting motorcycle.

C. REAR BREKE



1. Adjuster bolt (for pedal height)
2. Lock nut
3. Footrest
4. Pedal height 12 ~ 18 mm (0.47 ~ 0.71 in)
5. Free play 20 ~ 30 mm (0.79 ~ 1.18 in)



1. Adjuster

1. Pedal height
 - a. Loosen the adjuster lock nut (for pedal height).
 - b. By turning the adjuster bolt clockwise or counterclockwise, adjust the breke pedal position so that its top end is approx. 12 ~ 18 mm (0.47 ~ 0.71 in) below the footrest top end.
 - c. Secure the adjuster lock nut.

WARNING:

After adjusting the pedal height, the brake pedal free play should be adjusted.


2. Free play
Turn the adjuster on the brake rod clockwise or counterclockwise to provide the brake pedal end with a free play of 20 ~ 30 mm (0.79. ~ 1.18 in).
3. Brake lining inspection
The specified thickness of the brake lining is 4 mm (0.16 in).
The lining should be replaced when it wears to less than 2 mm (0.079 in). To inspect, remove the plug from the inspection hole on the brake shoe plate and check the thickness of the lining.
Besure to replace the plug carefully so water cannot enter the shoe plate.



* ELECTRICAL

A. IGNITION SYSTEM

1. Block diagram




2. Description

This model is equipped with a battery operated, fully transistorized breakerless ignition system. By using magnetic pick-up coils the need for contact breaker points is eliminated. This adds to the dependability of the system by eliminating frequent cleaning and adjustment of points and ignition timing. This T.C.I. unit incorporates an automatic advance circuit controlled by signals generated by the pick-up coil. This adds to the dependability of the system by eliminating the mechanical advancer. This T.C.I. system consists of two main units; a pick-up unit and an ignitor unit.

3. Operation

The T.C.I. functions on the same principle as a conventional D.C. ignition system with the exception of using magnetic pick-up coils and a transistor control box (T.C.I.) in place of contact breaker points.


a. Pick-up unit



1. Pick-up coil

This unit consists of two pick-up coils and a magneto mounted on the cylinder head. When the reluctor (rotor) projection passes this pick-up coil, the two signals are generated at the pick-up coil and transmitted to the ignitor unit as a signal. The full ignition advance is determined by the width of the reluctor (rotor) projection.

b. Ignitor unit



1. Ignitor unit (T.C.I. unit)

This unit has such functions of wave form, duty control, switching, electrical ignition advance, and etc. The ignition timing is advanced electrically using two signals from the pick-up coil. The duty control circuit is provided to control the on time period of the primary ignition current to reduce the electrical consumption. This unit also incorporates a protective circuit for the ignition coil.

If the ignition switch is turned on and the crankshaft is not turned, the protective circuit stops current flow to the primary coil within a few seconds. When the crankshaft is turned over, the current is turned on again by the signals generated by the pick-up coils.

CAUTION:


Do not run the engine without any spark plug cap(s) in place. Due to the high secondary voltage, it is possible to damage the internal insulation of the secondary coil.

4. Troubleshooting/Inspection

- The entire ignition system can be checked for misfire and weak spark using the Electro Tester. If the ignition system will fire across a sufficient gap, the engine ignition system can be considered good. If not, proceed with individual component tests until the problem is found.

- Warm up engine thoroughly so that all electrical components are at operating temperature.

- Stop the engine and connect the tester as shown.




- Start the engine and increase the spark gap until misfire occurs. (Test at various rpm between idle and red line.)


Minimum spark gap: 6 mm (0.24 in)

CAUTION:

Do not run engine in neutral above 6,000 r/min for more than 1 or 2 seconds.

- If the ignition system should become inoperative, the following troubleshooting aids will be useful.





SPECIFICATIONS

General Specifications

	XS400SG	XS400G
Basic color	BLACK RED or CARDINAL RED	NEW CATALINE BLUE
Dimensions:		
Overall length	2,065 mm (81.3 in)	←
Overall width	870 mm (34.3 in)	860 mm (33.9 in)
Overall height	1,140 mm (44.9 in)	1,105 mm (43.5 in)
Seat height	770 mm (30.3 in)	←
Wheelbase	1,375 mm (54.1 in)	←
Minimum ground clearance	135 mm (5.3 in)	←
Caster (steering head angle)	27°30'	←
Trail	87 mm (3.43 in)	←
Weight:		
Net	169 kg (373 lb)	166 kg (366 lb)
Engine:		
Type	4 stroke air-cooled, gasoline	←
Bore × stroke × cylinders	69 × 52.4 mm × 2 (2.717 × 2.063 in × 2)	←
Displacement	391 cc (23.86 cu. in)	←
Compression ratio	9.3 : 1	←
Lubrication:		
Lubrication system	Pressure lubricated, wet sump	←
Delivery pump type	Trochoid	←
Carburetion:		
Manufacturer	MIKUNI	←
Type	BS34, constant velocity	←
Air filter:	Dry type element	←
Ignition:		
Type	Battery ignition (Full transistor ignition)	←
Spark plug	BP7ES (NGK) or N-7Y (CHAMPION)	←
Charging:		
Type	Three-phase, regulated alternator	←
Manufacturer, I.D. No.	ND 021000-778	←
Maximum output	14.5V, 12A	←
Battery type	12N12A-4A	←
Battery dimensions:	134 × 160 × 80 mm (5.28 × 6.30 × 3.15 in)	←
Rectifier	DE3804-1 or DS10TEY-L full wave	←
Regulator	026000-3280 IC type	←
Regulating voltage (No. load)	14.0 ~ 14.7 V	←
Starting:	Electric and kick starter	←
Primary drive:		
Type	Gear	←
Teeth, ratio	78/24 (3.250)	←
Clutch:	Wet, multiple disc	←
Transmission:	Constant mesh, 6-speed, drum shifter	←


	XS400SG	XS400G
Teeth, ratio 1st	35/14 (2.500)	←
2nd	32/18 (1.777)	←
3rd	29/21 (1.380)	←
4th	27/24 (1.125)	←
5th	25/26 (0.961)	←
6th	26/30 (0.866)	←
Secondary drive:		
Type	Chain DID 50DS-102L	←
Teeth, ratio	37/16 (2.312)	←
Chassis:		
Frame	Tubular steel, semi-double cradle	←
Suspension: Front	Telescopic fork	←
Rear	Swing arm	←
Tires: Front	3.00S 18-4PR (Tubeless)	3.00S 18-4PR
Rear	120/90-16 63S (Tubeless)	120/90-16 63S
Brakes: Front	Hydraulic disc	Drum brake
Rear	Drum brake	←
Fuel tank: Total	14.0 lit (3.67 US. gal)	←
Reserve	3.3 lit (0.87 US. gal)	←
Wheels: Front	Cast wheel	Spoke wheel
Rear	Cast wheel	Spoke wheel

Maintenance Specifications

1. Engine

Engine oil capacity:	
Dry	2.6 lit (2.7 US. qt)
Oil and filter change	2.3 lit (2.4 US. qt)
Oil change	2.0 lit (2.1 US. qt)
Recommended lubricant:	
If temperature does not go below 5°C (40°F)	YAMALUBE 4-cycle oil or SAE 20W/40 SE motor oil
If temperature does not go above 15°C (60°F)	SAE 10W/30 SE motor oil
Cranking pressure (at seal level):	11 kg/cm ² (156 psi)
Maximum difference between cylinders:	1 kg/cm ² (14 psi)

Camshafts:



Camshaft bearing surface diameter:

Camshaft-to-cap clearance:

Standard

Maximum

Camshaft run-out limit:

Dimensions		Standard size	Wear limit
Intake	A	39.53 ± 0.05 mm (1.556 ± 0.002 in)	39.33 mm (1.548 in)
	B	32.27 ± 0.05 mm (1.270 ± 0.002 in)	32.11 mm (1.264 in)
	C	7.53 mm (0.296 in)	—
Exhaust	A	39.57 ± 0.05 mm (1.558 ± 0.002 in)	39.37 mm (1.550 in)
	B	32.12 ± 0.05 mm (1.265 ± 0.002 in)	31.96 mm (1.258 in)
	C	7.53 mm (0.296 in)	—



22.967 ~ 22.980 mm (0.9042 ~ 0.9047 in)

0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in)

0.160 mm (0.006 in)

0.1 mm (0.004 in)

Valves:



Direction of windings
(Top to bottom)


Valve stem run-out maximum

Valve seat width standard/maximum

	Inner Intake/Exhaust	Outer Intake/Exhaust
Free length	39.3 mm (1.547 in)	42.8 mm (1.685 in)
Spring rate	$K_1 = 1.93 \text{ kg/mm}$ (108 lb/in) $K_2 = 2.47 \text{ kg/mm}$ (138 lb/in)	$K_1 = 4.19 \text{ kg/mm}$ (235 lb/in) $K_2 = 5.49 \text{ kg/mm}$ (307 lb/in)
Installed length (valve closed)	33.0 mm (1.299 in)	37.0 mm (1.457 in)
Installed pressure (valve closed)	12.1 ± 1.2 kg (26.7 ± 2.6 lb)	24.4 ± 1.7 kg (53.8 ± 3.7 lb)
Compressed length (valve open)	25.0 mm (0.984 in)	29.0 mm (1.142 in)
Wire diameter	3.0 mm (0.118 in)	4.4 mm (0.173 in)
Number of windings	7.75	6.25
Winding I.D.	22.4 mm (0.882 in)	32.0 mm (1.260 in)


0.03 mm (0.0012 in)

1.1 mm (0.043 in)/2.0 mm (0.080 in)



INTAKE

Clearance (Cold engine)	0.10 mm (0.0039 in)
"A" head diameter	35.5 ± 0.1 mm (1.398 ± 0.0039 in)
"B" face width	2.3 mm (0.091 in)
"C" seat width	1.0 ± 0.1 mm (0.039 ± 0.0039 in)
"D" margin thickness (minimum)	1.0 ± 0.2 mm (0.039 ± 0.0079 in)



Stem diameter (O.D.)	$7 \begin{smallmatrix} -0.010 \\ -0.025 \end{smallmatrix}$ mm (0.276 $\begin{smallmatrix} -0.0004 \\ -0.0010 \end{smallmatrix}$ in)
Guide diameter (I.D.)	$7 \begin{smallmatrix} +0.012 \\ -0 \end{smallmatrix}$ mm (0.276 $\begin{smallmatrix} +0.0005 \\ -0 \end{smallmatrix}$ in)
Stem-to-guide clearance	0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)

EXHAUST

Clearance (Cold engine)	0.18 mm (0.0071 in)
"A" head diameter	30.0 ± 0.1 mm (1.18 ± 0.004 in)
"B" face width	2.3 mm (0.091 in)
"C" seat width	1 ± 0.1 mm (0.039 ± 0.004 in)
"D" margin thickness (minimum)	1 ± 0.2 mm (0.039 ± 0.008 in)
Stem diameter (O.D.)	$7 \begin{smallmatrix} -0.030 \\ -0.045 \end{smallmatrix}$ mm (0.276 $\begin{smallmatrix} -0.0011 \\ -0.0018 \end{smallmatrix}$ in)
Guide diameter (I.D.)	$7 \begin{smallmatrix} +0.012 \\ -0 \end{smallmatrix}$ mm (0.276 $\begin{smallmatrix} +0.0005 \\ -0 \end{smallmatrix}$ in)
Stem-to-guide clearance	0.030 ~ 0.057 mm (0.0012 ~ 0.0022 in)

Cylinder and piston:

Cylinder material
Cylinder liner
Bore size: standard
Wear limit
Cylinder taper limit
Cylinder out-of-round limit
Piston clearance: standard
maximum
Piston weight (include rings, pin and clips)

Aluminum alloy
Pressed in; special cast iron
69.00 mm (2.717 in)
70.10 mm (2.760 in)
0.05 mm (0.0020 in)
0.01 mm (0.0004 in)
0.030 ~ 0.050 mm (0.0012 ~ 0.0020 in)
0.1 mm (0.0039 in)
186.1 g (6.56 oz)

Piston rings:

Design

End gap (installed): standard

limit


Side clearance: standard

limit

Top	2nd	Oil
0.2 ~ 0.4 mm (0.0078 ~ 0.016 in)	0.2 ~ 0.4 mm (0.0078 ~ 0.016 in)	0.2 ~ 0.9 mm (0.0078 ~ 0.035 in)
1.0 mm (0.0394 in)	1.0 mm (0.0394 in)	1.5 mm (0.0591 in)
0.04 ~ 0.08 mm (0.0016 ~ 0.0031 in)	0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)	—
0.15 mm (0.0059 in)	0.15 mm (0.0059 in)	—

Crankshaft:	
Crank journal/bearing oil clearance	0.020 ~ 0.044 mm (0.0008 ~ 0.0017 in)
Main journal run-out (maximum)	0.030 mm (0.0012 in)
Connection rods:	
Rod bearing oil clearance	0.021 ~ 0.045 mm (0.0008 ~ 0.0018 in)
Oil pump:	
Housing-to-outer rotor clearance	0.10 ~ 0.18 mm (0.0039 ~ 0.0071 in)
Outer rotor-to-inner rotor clearance	0.03 ~ 0.09 mm (0.0012 ~ 0.0035 in)
Clutch:	
Friction plate thickness: standard	3.0 mm (0.12 in)
minimum	2.8 mm (0.11 in)
Clutch plate: thickness	1.6 mm (0.06 in)
warp limit	0.05 mm (0.0020 in)
Clutch spring length: standard	34.6 mm (1.362 in)
minimum	33.6 mm (1.323 in)
Spring rate	2.6 kg/mm (146 lb/in)
Clutch lever freeplay (at lever pivot point)	2 ~ 3 mm (0.08 ~ 0.12 in)
Transmission shaft run-out (maximum)	0.08 mm (0.0031 in)

LUBRICATION CHART



2. Carburetion

Manufacturer	MIKUNI BS34	Float height	27.3 ± 0.5 mm (1.075 ± 0.020 in)
Model I.D. No.	3F9-00	Pilot screw	Preset
Main jet	#135	Air jet, Main	#45
Needle jet	Y-2	Air jet, Pilot	#155
Pilot jet	#42.5	Float valve seat	ø2.0
Starter jet	#35	Engine idle speed	1,200 r/min
Jet needle	5GZ9		

*: Total weight of accessories, etc. excepting motorcycle.

** : XS400G only

***: XS400SG only

3. Chassis

Wheels and tires: Rim run-out: vertical horizontal	2.0 mm (0.079 in) 2.0 mm (0.079 in)	
Tire pressure (cold):	Front	Rear
Up to 90 kg (198 lb) load*	1.8 kg/cm ² (26 psi)	2.0 kg/cm ² (28 psi)
90 kg (198 lb) ~ 159 kg (351 lb) load*	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
High speed riding	2.0 kg/cm ² (28 psi)	2.3 kg/cm ² (32 psi)
Minimum tire tread depth	0.8 mm (0.03 in)	0.8 mm (0.03 in)
Brakes		
Front brake ***		
Type	Hydraulic disc type	
Disc size (Outside dia. × thickness)	267 × 5.0 mm (10.51 × 0.20 in)	
Disc wear limit	4.5 mm (0.18 in)	
Pad wear limit	6.5 mm (0.26 in)	
Master cylinder inside dia.	14.00 mm (0.551 in)	
Caliper cylinder inside dia.	42.85 mm (1.687 in)	
Brake fluid type/quantity	DOT #3 Brake fluid/24 cc (0.81 oz)	
Front brake **		
Type	Drum brake (Two leading)	
Actuating method	Wire	
Brake drum I.D.	180 mm (7.09 in)	
Brake shoe dia. × width	180 × 30 mm (7.09 × 1.18 in)	
Lining thickness/wear limit	4 mm/2 mm (0.16 in/0.08 in)	
Shoe spring free length	68 mm (2.68 in)	
Rear brake		
Type	Drum brake (Leading trailing)	
Actuating method	Link rod	
Brake drum I.D.	160 mm (6.30 in)	
Brake shoe dia. × width	160 × 30 mm (6.30 × 1.18 in)	
Lining thickness/wear limit	4 mm/2 mm (0.16 in/0.08 in)	
Shoe spring free length	68 mm (2.68 in)	

Front forks: Travel Spring free length Spring preload length Spring rate 0 ~ 100 mm (0 ~ 3.94 in) 100 ~ 140 mm (3.94 ~ 5.51 in) Fork oil capacity (each side) Oil type	140 mm (5.51 in) 502 mm (19.76 in) 472 mm (18.58 in) 0.4 kg/mm (22.4 lb/in) 0.575 kg/mm (32.2 lb/in) 142 cc (4.80 oz) Yamaha Fork Oil 20 Wt or equivalent
Rear shock absorbers: Spring free length Spring preload length Spring rate 0 ~ 55 mm (0 ~ 2.17 in) 55 ~ 80 mm (2.17 ~ 3.15 in) Travel	216 mm (8.50 in) 204 mm (8.03 in) 1.7 kg/mm (95.2 lb/in) 2.10 kg/mm (117.6 lb/in) 80 mm (3.15 in)

4. Electrical

Ignition timing retarded: Ignition timing advance:	<p>10° at 1,200 r/min</p> <p>(× 1,000 r/min)</p>
Spark plug: Type Electrode gap	BP7ES (NGK) or N-7Y (CHAMPION) 0.7 ~ 0.8 mm (0.023 ~ 0.032 in)
Spark plug cap resistance:	10kΩ
Pick up coil: Resistance	700Ω ± 20% at 20°C (68°F)
Ignition coil type: Spark gap Primary resistance Secondary resistance	HITACHI CM11-54 6 mm (0.24 in) or more at 500 r/min (10 kV/100 r/min, 15 kV/9,500 r/min) 3.0Ω ± 10% at 20°C (68°F) 8.6kΩ ± 20% at 20°C (68°F)
Starter motor type: Armature coil resistance Field coil resistance Brush length: standard minimum Brush spring pressure Armature mica undercut	mitsuba SM-223B 0.005Ω at 20°C (68°F) 0.011Ω at 20°C (68°F) 11.0 mm (0.433 in) 6.0 mm (0.236 in) 550 ± 55g (19.40 ± 1.94 oz) 0.7 mm (0.028 in)
Battery type: Charging rate	GS 12N12A-4A 1.2 Amps for 10 Hours
Generator type: Output Field (inner) coil resistance Stator (outer) coil resistance	ND 021000-778 14.5V 12A at 5,000 r/min 4.0Ω ± 10% at 20°C (68°F) 0.72Ω ± 10% at 20°C (68°F)
Regulator type: Regulated voltage	ND 026000-3280 14.35 ± 0.35V
Starter relay switch: Cut-in voltage Winding resistance	HITACHI A104-70 6.5V 3.5Ω at 20°C (68°F)
Headlight: Tail/brake light: Flasher light: Licence light: Pilot lights: Flasher High beam Neutral	12V, 50W/35W 12V, 8W (3CP1)/27W (32CP) × 2 12V, 27W (32CP) × 4 12V, 3.8W × 2 12V, 3.4W × 1 12V, 3.4W × 1 12V, 3.4W × 1

Oil pressure	12V, 3.4W × 1
Meter light	12V, 3.4W × 2

Torque Specifications


	Tightening torque		Remarks
	m-kg	ft-lb	
Engine:			
Cylinder head cover and cylinder head 8 mm bolt	2.2	15.9	Apply oil
6 mm bolt	1.0	7.2	
Cylinder head 10 mm nut	3.3	23.9	
6 mm bolt	1.0	7.2	
Cylinder head cover (Tappet cover) 32 mm	1.2	8.7	Apply molybdenum disulfide grease
Spark plug	2.0	14.5	
Tappet adjusting screw lock nut 6 mm nut	1.4	10.1	
Cam sprocket 7 mm bolt	2.0	14.5	
Connecting rod 8 mm nut	3.6	26.0	
Generator (rotor) 10 mm bolt	3.3	23.9	Use LOCTITE
Starter clutch 8 mm bolt	3.0	21.7	
Reluctor 6 mm bolt	1.0	7.2	Apply oil
Drain plug (engine oil)	3.8	27.5	
Oil filter	1.5	10.8	
Strainer cover 5 mm bolt	0.7	5.1	
Oil pressure switch	1.8	13.0	Use LOCTITE
Crankcase 8 mm bolt	2.2	16.0	
Crankcase 6 mm bolt	1.0	7.2	
Clutch spring screw 6 mm bolt	1.0	7.2	
Primary drive gear 10 mm bolt	4.8	34.7	
Change pedal 6 mm bolt	1.0	7.2	
Neutral switch	2.0	14.5	
Exhaust pipe 8 mm nut	2.2	16.0	
Chassis:			
Engine mounting Front, under 10 mm bolt/nut	3.0	21.7	
Engine mounting Rear, upper 10 mm bolt/nut	3.0	21.7	
Engine mounting Rear, under 10 mm bolt/nut	3.0	21.7	
Engine mounting Upper 8 mm bolt/nut	1.8	13.0	
Engine mount stay Rear upper 8 mm bolt	1.8	13.0	
Engine mount stay Upper 8 mm bolt/nut	1.8	13.0	
Handle crown and steering shaft 14 mm bolt	5.4	39.1	
Handle crown and inner tube 8 mm bolt/nut	1.1	8.0	
Handle crown and handle holder 10 mm nut	2.3	16.6	
Under bracket and inner tube 10 mm bolt	3.5	25.3	
Rear shock absorber and frame 10 mm bolt	3.0	21.7	
Rear shock absorber and rear arm 10 mm nut	3.0	21.7	
Front wheel axle 14 mm nut	10.7	77.4	
Front fork and axle holder 8 mm nut	2.0	14.5	
Pivot shaft 14 mm nut	6.5	47.0	
Rear wheel axle 14 mm nut	10.7	77.4	
Sprocket wheel 12 mm nut	4.5	32.5	

	Tightening torque		Remarks
	m-kg	ft-lb	
Tension bar and brake plate 8 mm bolt/nut	1.4	10.1	Use lock plate
Tension bar and rear arm 8 mm bolt/nut	1.4	10.1	
Brake cam lever and cam shaft 6 mm bolt	1.0	7.2	
Brake disc and hub (front) 8 mm bolt (XS400SG only)	2.0	14.5	
Caliper and brake hose (XS400SG only)	2.6	18.8	
Caliper and bleed screw (XS400SG only)	0.6	4.3	Use LOCTITE
Master cylinder and brake hose (XS400SG only)	2.6	18.8	
Caliper and caliper bracket 8 mm bolt (XS400SG only)	2.5	18.1	
Handle bar holder 8 mm bolt	1.8	13.0	
Rear stay (Grab bar) and rear shock absorber 10 mm nut	3.0	21.7	
Rear stay (Grab bar) and frame 8 mm bolt	2.3	16.6	

General Torque Specifications

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a

crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.



A (Nut)	B (Bolt)	General torque specifications	
		m-kg	ft-lb
10 mm	6 mm	0.6	4.5
12 mm	8 mm	1.5	11
14 mm	10 mm	3.0	22
17 mm	12 mm	5.5	40
19 mm	14 mm	8.5	61
22 mm	16 mm	13.0	94

CONVERSION TABLES

METRIC TO INCH SYSTEM			
	KNOWN	MULTIPLIER	RESULT
TORQUE	m-kg	7.233	ft-lb
	m-kg	86.80	in-lb
	cm-kg	0.0723	ft-lb
	cm-kg	0.8680	in-lb
WT.	kg	2.205	lb
	g	0.03527	oz
FLOW/DISTANCE	km/lit	2.352	mpg
	km/hr	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
VOL. CAPACITY	cc (cm ³)	0.03382	oz (US liq)
	cc (cm ³)	0.06102	cu. in
	lit (liter)	2.1134	pt (US liq)
	lit (liter)	1.057	qt (US liq)
	lit (liter)	0.2642	gal (US liq)
MISC.	kg/mm	56.007	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade(°C)	9/5(°C)+32	Fahrenheit(°F)

INCH TO METRIC SYSTEM			
	KNOWN	MULTIPLIER	RESULT
TORQUE	ft-lb	0.13826	m-kg
	in-lb	0.01152	m-kg
	ft-lb	13.831	cm-kg
	in-lb	1.1521	cm-kg
WT.	lb	0.4535	kg
	oz	28.352	g
FLOW/DISTANCE	mpg	0.4252	km/lit
	mph	1.609	km/hr
	mi	1.609	km
	ft	0.3048	m
	yd	0.9141	m
	in	2.54	cm
	in	25.4	mm
VOL. CAPACITY	oz (US liq)	29.57	cc (cm ³)
	cu. in	16.387	cc (cm ³)
	pt (US liq)	0.4732	lit (liter)
	qt (US liq)	0.9461	lit (liter)
	gal (US liq)	3.785	lit (liter)
MISC.	lb/in	0.017855	kg/mm
	psi (lb/in ²)	0.07031	kg/cm ²
	Fahrenheit(°C)	5/9(°F-32)	Centigrade(°F)

DEFINITION OF TERMS:

m-kg	=	Meter-kilogram(s) (usually torque)
g	=	Gram(s)
kg	=	Kilogram(s) (1,000 grams)
lit	=	Liter(s)
km/lit	=	Kilometer(s) per liter (fuel consumption)
cc	=	Cubic centimeter(s) (cm ³) (volume or capacity)
kg/mm	=	Kilogram(s) per millimeter (usually spring compression rate)
kg/cm ²	=	Kilogram(s) per square centimeter (pressure)


CONSUMER INFORMATION

Notice

The information presented represents results obtainable by skilled drivers under controlled road and vehicle conditions, and the information may not be correct under other conditions.



STOPPING DISTANCE

This figure indicates braking performance that can be met or exceeded by the vehicles to which it applies, without locking the wheels, under different conditions of loading and with partial failures of the braking system.





ACCELERATION AND PASSING ABILITY



This figure indicates passing times and distances that can be met or exceeded by the vehicles to which it applies, in the situations diagrammed below. The low-speed pass assumes an initial speed of 20 mph. and a limiting speed of 35 mph. This high-speed pass assumes an initial speed of 50 mph. and a limiting speed of 80 mph.





SUMMARY		
Low-speed pass	353.3 feet:	7.2 seconds (XS400G)
	353.0 feet:	7.2 seconds (XS400SG)
High-speed pass	944.0 feet:	9.27 seconds (XS400G)
	1,053.6 feet:	10.6 seconds (XS400SG)


CABLE ROUTING









WIRING DIAGRAM (XS400G /XS400SG)




COLOR CODE



Dg:	Dark green	Ch:	Chocolate	B/W:	Black/White
B:	Black	G:	Green	W/R:	White/Red
Br:	Brown	P:	Pink	W/G:	White/Green
O:	Orange	Gy:	Gray	B/R:	Black/Red
L:	Blue	G/Y:	Green/Yellow	Br/W:	Brown/White
Y:	Yellow	L/W:	Blue/White	Y/R:	Yellow/Red
R:	Red	R/W:	Red/White	Y/G:	Yellow/Green
W:	White	L/B:	Blue/Black		
Sb:	Sky blue	R/Y:	Red/Yellow		

WIRE ROUTING (XS400H/XS400SH)









Viewed B



Viewed C





WIRING DIAGRAM (XS400H/XS400SH)

Front flasher light (right)

Front brake switch "START" switch "ENGINE STOP" switch

