SHOP MANUAL NAVI



A Few Words About Safety

Service information

The service and repair information contained in this manual is intended for use by qualified, professional technicians.

Attempting service or repairs without the proper training, tools, and equipment could cause injury to you or others. It could also damage the vehicle or create an unsafe condition.

This manual describes the proper methods and procedures for performing service, maintenance, and repairs. Some procedures require the use of specially designed tools and dedicated equipment. Any person who intends to use a replacement part, service procedure or a tool that is not recommended by Honda, must determine the risks to their personal safety and the safe operation of the vehicle.

If you need to replace a part, use genuine Honda parts with the correct part number or an equivalent part. We strongly recommended that you do not use replacement parts of inferior quality.

For Your Customer's Safety

Proper service and maintenance are essential to the customer's safety and the reliability of the vehicle. Any error or oversight while servicing a vehicle can result in faulty operation, damage to the vehicle, or injury to others.

For Your Safety

Because this manual is intended for the professional service technician, we do not provide warnings about many basic shop safety practices (e.g., Hot parts – wear gloves). If you have not received shop safety training or do not feel confident about your knowledge of safe servicing practice, we recommended that you do not attempt to perform the procedures described in this manual.

Some of the most important general service safety precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing service and repair procedures. Only you can decide whether or not you should perform a given task.

A WARNING

Improper service or repairs can create an unsafe condition that can cause your customer or others to be seriously hurt or killed.

Follow the procedures and precautions in this manual and other service materials carefully.

A WARNING

Failure to properly follow instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this manual carefully.

Important Safety Precautions

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles or face shields any time you hammer, drill, grind, pry or work around pressurized air or liquids, and springs or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have the vehicle up in the air. Any time you lift the vehicle, either with a hoist or a jack, make sure that it is always securely supported. Use jack stands.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- · Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine.
- · Burns from hot parts or coolant. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers and clothing are out of the way.

Gasoline vapors and hydrogen gases from batteries are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
- Never drain or store gasoline in an open container.
- · Keep all cigarettes sparks and flames away from the battery and all fuel-related parts.

HOW TO USE THIS MANUAL

This service manual describes the service procedures for the NVA110G.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition.

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 and 3 apply to the whole vehicle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections.

Section 4 through 18 describe parts of the vehicle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections start with an assembly or system illustration, service information and troubleshooting for the section. The subsequent pages give detailed procedures.

If you don't know the source of the trouble, go to section 20 Troubleshooting.

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing this vehicle. You must use your own good judgement.

You will find important safety information in a variety of forms including:

- Safety Labels on the vehicle
- Safety Messages preceded by a safety alert symbol /! and one of three signal words, DANGER, WARNING, or CAUTION. These signal words mean:
- A DANGER You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

A WARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

A CAUTION You CAN be HURT if you don't follow instructions.

Instructions- How to service this vehicle correctly and safely.

As you read this manual, you will find information that is preceded by a NOTICE symbol. The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

Some information provided in this manual is applicable for ID type model only.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY **OBLIGATION WHATEVER. NO PART OF THIS** PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC **KNOWLEDGE OF MAINTENANCE ON HONDA** MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

> Honda Motor Co., Ltd. SERVICE PUBLICATION OFFICE

CONTENTS

	GENERAL INFORMATION	1
	FRAME/ BODY PANELS/ EXHAUST SYSTEM	2
	MAINTENANCE	3
	LUBRICATION SYSTEM	4
AIN	FUEL SYSTEM	5
E TR/	ENGINE REMOVAL/ INSTALLATION	6
RIVE	CYLINDER HEAD/VALVES	7
	CYLINDER/ PISTON	8
AE A	KICKSTARTER/ DRIVE AND DRIVEN PULLEY/ CLUTCH	9
	FINAL REDUCTION	10
ш	ALTERNATOR	11
	CRANKCASE/ CRANKSHAFT	12
SSIS	FRONT WHEEL/ BRAKE/ SUSPENSION/ STEERING	13
CHA:	REAR WHEEL/ BRAKE/ SUSPENSION	14
	BATTERY/ CHARGING SYSTEM	15
CAL	IGNITION SYSTEM	16
CTRI	ELECTRIC STARTER	17
ELE(LIGHTS/ METER/ SWITCHES	18
	WIRING DIAGRAM	19
	TROUBLESHOOTING	20
	INDEX	21

SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

B	Replace the part(s) with new one(s) before assembly.
	Use recommended engine oil, unless otherwise specified.
Min OIL	Use molybdenum oil solution (mixture of the engine oil and molybdenum grease in a ratio of 1:1).
GREASE	Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent).
	Use water resistant multi-purpose grease (Shell Alvania EP2 or Excelite EP2 (KYODO YUSHI CO. LTD) or equivalent).
	Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote [®] BR-2 plus manufactured by Dow corning U.S.A. Multi-purpose M-2 manufactured by Mitsubishi Oil, Japan
	Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent). Example: Molykote [®] G-n paste manufactured by Dow Corning, U.S.A. Honda Moly 60 (U.S.A. only) Rocol ASP manufactured by Rocol Limited, U.K. Rocol Paste manufactured by Sumico Lubricant, Japan
	Use silicone grease.
LOCK	Apply a locking agent. Use a middle strength locking agent unless otherwise specified.
SEALS	Apply sealant.
FLUID	Use DOT 3 or DOT 4 brake fluid. Use the recommended brake fluid unless otherwise specified.
FORK	Use Fork or Suspension Fluid.
	Use Lithoplex -2

1. GENERAL INFORMATION

SERVICE RULES	1-1	ELECTRIC STARTER SPECIFICATION	1-6
MODEL IDENTIFICATION	1-2	FRONT WHEEL/ BRAKE/ SUSPENSION/	
SERIAL NUMBERS	1-3	STEERING SPECIFICATIONS	1-7
GENERAL SPECIFICATION	1-4	REAR WHEEL/ BRAKE/ SUSPENSION SPECIFICATIONS	1-7
LUBRICATION SYSTEM SPECIFICATIONS	1-5	BATTERY/ CHARGING SYSTEM SPECIFICATIONS	1-7
FUEL SYSTEM SPECIFICATIONS	1-5	IGNITION SYSTEM SPECIFICATIONS	1-7
CYLINDER HEAD/ VALVES SPECIFICATIONS	1-5	LIGHTS/ METER/ SWITCHES SPECIFICATION	1-7
CYLINDER/PISTON SPECIFICATIONS	1-6	STANDARD TORQUE VALUES	1-8
		ENGINE & FRAME TORQUE VALUES	1-8
PULLEY/CLUTCH SPECIFICATIONS	1-6	TOOLS	1-10
FINAL REDUCTION SPECIFICATIONS	1-6	LUBRICATION & SEAL POINTS	1-11
CRANKCASE/ CRANKSHAFT		CABLE & HARNESS ROUTING	1-13
SPECIFICATION	1-6	EMISSION CONTROL SYSTEMS	1-19

SERVICE RULES

- 1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda's design specifications may cause damage to the vehicle.
- 2. Use the special tools designed for this product to avoid damage and incorrect assembly.
- 3. Use only metric tools when servicing this vehicle. Metric bolts, nuts and screws are not interchangeable with english fasteners.
- 4. Install new gaskets, O-rings, cotter pins, and lock plates while reassembling.
- 5. When tightening bolts or nuts, begin with the larger diameter of inner bolts first. Then tighten to the specified torque diagonally in incremental steps unless a particular sequence is specified.
- 6. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
- 7. After reassembly, check all parts for proper installation and operation.
- 8. Route all cables, electrical wires and wiring harness as shown in pages 1-13 to 1-18, Cable and Harness Routing.

MODEL IDENTIFICATION

This manual covers NVA110G model

Left side view



Right side view



GENERAL INFORMATION

SERIAL NUMBERS

Frame serial number

The Vehicle Identification Number (V.I.N.) is stamped other right side of the steering head.

Vehicle identification number: ME4JF651KFXXXXXXX



Engine serial number

The Engine Serial Number is stamped on the lower left side of the crankcase.

Engine serial number: JF65E – X – XXXXXXX



Carburetor serial number

The carburetor identification number is stamped on the left side of the carburetor body.



GENERAL SPECIFICATIONS

		ITEM	SPECIFICATION	Page NO.
	Overall length		1805 mm (71 in)	-
	Overall width		748 mm (29.4 in)	
	Overall height		1039 mm (40.9 in)	
	Wheelbase		1286 mm (50.6 in)	-
DIMENSIONS	Seat height		765 mm (30.1 in)	-
	Foot peg height		296 mm (11.7 in)	-
	Ground clearance		156 mm (6.1 in)	-
	Dry weight	(STD)	96.4 kg (212.5 lbs)	-
	Curb weight	(STD)	101 kg (222.6 lbs)	-
	Maximum weight ca	pacity	153 kg (337.3 lbs)	-
	Frame type		Under Born Type (Steel)	
	Front suspension		Telescopic fork	Page 3-17
	Front axle travel		89 mm (3.5 in)	
	Rear suspension		Other	Page 3-17
	Rear axle travel		70 mm (2.7 in)	
	Enclose to the second	Size	90/90-12 54J	
	Front tyre	Brand	MRF, TVS,CEAT	-
FRAME	D t	Size	90/100-10 53J	_
	Rear tyre	Brand	MRF, TVS,CEAT	
	Front brake Drum Type		Mechanical Leading Trailing	
	Rear brake	Drum Type	Mechanical Leading Trailing	-
	Caster angle		27º 30	-
	Trail length		81.5 mm (3.2 in)	-
	Fuel tank capacity		3.8 litre (1.0 US gal, 0.84 Imp gal)	-
	Fuel tank reserve capacity		0.9 litre (0.23 US gal, 0.19 Imp gal)	-
	Туре		Gasoline, air-cooled 4-stroke	-
	Cylinder arrangement		Single cylinder inclined 80° from vertical	_
	Bore and stroke		50.0 x 55.609 mm (1.97 x 2.19 in)	_
	Displacement		109.19 cm ³	_
	Compression ratio		9.5 : 1	
	Valve train		Chain driven, SOHC	
	Intake valve	Opens at 1 mm (0.04 in) lift	10° BTDC	_
ENGINE		Closes at 1 mm (0.04 in) lift	35° ABDC	_
	Exhaust valve	Opens at 1 mm (0.04 in) lift	25° BBDC	
		Closes at 1 mm (0.04 in) lift	0° ATDC	
	Lubrication system		Pressing/ Spray	
	Oil pump type		Trochoid	
	Cooling system		Fan cooled	
	Air filtration		Viscous paper filter	
	Engine dry weight		25.7 kg (56.7 lbs)	
CARBURETOR	Carburetor type		Piston type	
	Throttle bore		16 mm (0.63 in)	
	Clutch system		Automatic centrifugal clutch (Dry type)	
DRIVE TRAIN	Final reduction		10.117 (51T/19T x 49T/13T)	
	CVT ratio		2.55:1 ~ 0.8:1	-
	Battery capacity		12V, 3An	Page 15-3
	Ignition system			Page 16-1
ELECTRICAL	Starting system		Self & Kick / Decomp	
	Charging system		Single phase output alternator	Page 15-1
	Regulator/ Rectifier		SCR Shorted, Single phase half wave	Page 15-8

LUBRICATION SYSTEM SPECIFICATIONS

Unit: mm (in) ITEM **STANDARD** SERVICE LIMIT Page NO. At draining 0.7 liters (0.7 US gt, 0.6 Imp gt) Page 3-10 _ Engine oil capacity 0.8 liters (0.8 US gt, 0.7 Imp gt) At disassembly Page 3-10 _ Honda 4-stroke oil or equivalent motor oil Recommended engine oil API service classification: MA Page 3-9 Viscosity: SAE 10W-30 0.15 (0.006) Page 4-3 Tip clearance 0.20 (0.008) Oil pump rotor Body clearance 0.15 - 0.21 (0.006 - 0.008)0.35 (0.014) Page 4-3 Side clearance 0.05 - 0.10 (0.002 - 0.004) 0.12 (0.005) Page 4-3

FUEL SYSTEM SPECIFICATIONS

ITEM **SPECIFICATIONS** Page NO. Carburetor identification number PB5TH Page 1-3 Venturi diameter 16 mm (0.63 in) _ Main jet #85 Page 5-7 Slow jet #35 x #35 Page 5-7 Float level $11.7 \pm 0.5 \text{ mm} (0.46 \pm 0.02 \text{ in})$ Page 5-7 Air screw initial opening 1 3/4 turns out Page 5-9 Engine idle speed 1,700 ± 100 min⁻¹ (RPM) Page 5-10 PAIR control valve specified vacuum 460 mmHg (18.11 in Hg) Page 5-10

CYLINDER HEAD/VALVES SPECIFICATIONS

Unit: mm (in)

Unit: mm (in)

					•
ITEM		STANDARD	SERVICE LIMIT	Page NO.	
Cylinder compre	ession at 600 min ⁻¹ (rpm)		0.98 MPa (9.99 kgf/cm ² , 142 psi)	_	Page 7-3
		IN	0.16 mm (0.006 in)	_	Page 3-8
		EX	0.16 mm (0.006 in)	_	Page 3-8
Comphoft	Hoight	IN	32.1087 - 32.1527	32.084 (1.2631)	Page 7-20
Camsnatt	Height	EX	31.94 - 31.85	31.80 (1.23)	Page 7-20
Cylinder head w	/arpage		-	0.05 (0.002)	Page 7-20
	Arm I.D.	IN/EX	10.000 – 10.015 (0.3937 – 0.3943)	10.10 (0.398)	Page 7-7
Rocker arm	Shaft O.D.	IN/EX	9.972 - 9.987 (0.3926 - 0.3932)	9.91 (0.390)	Page 7-7
	Arm to shaft clearance	IN/EX	0.013 - 0.043 (0.0005 - 0.0017)	0.10 (0.004)	Page 7-9
	Stem O.D.	IN	4.975 - 4.990 (0.1959 - 0.1964)	4.90 (0.193)	Page 7-8
) (alive		EX	4.955 – 4.970 (0.1955 – 0.1956)	4.90 (0.193)	Page 7-8
valve,	Guide I.D.	IN/EX	5.000 - 5.012 (0.1969 - 0.1973)	5.03 (0.198)	Page 7-9
valve guide	Stem-to-guide	IN	0.010 - 0.037 (0.0004 - 0.0015)	0.08 (0.003)	Page 7-9
	clearance	EX	0.030 - 0.057 (0.0012 - 0.0022)	0.10 (0.004)	Page 7-9
Valve spring	Free length		29.78 (1.17)	27.87 (1.1)	Page 7-9
Valve seat width	1	IN/EX	0.7 (0.027)	_	_

CYLINDER/PISTON SPECIFICATIONS

					Unit: mm (in)
ITEM			STANDARD	SERVICE LIMIT	Page NO.
	I.D.		50.005 - 50.015 (1.9686 - 1.9690)	50.1 (1.972)	Page 8-2
Cylinder	Out-of-round		-	0.05 (0.002)	Page 8-3
Cymruer	Taper		-	0.05 (0.002)	Page 8-3
	Warpage		-	0.05 (0.002)	Page 8-3
	Piston O.D. at 5 (0.2) from bottom		49.980 - 49.995 (1.9677 - 1.9683)	49.9 (1.964)	Page 8-4
	Piston pin hole I.D.		12.002 - 12.008 (0.4725 - 0.4727)	12.04 (0.474)	Page 8-4
Piston	Piston pin O.D.		11.994 - 12.000 (0.4722 - 0.4724)	11.98 (0.471)	Page 8-4
piston pin.	Piston-to-piston pin clearance		0.002 - 0.014 (0.0001 - 0.0006)	0.02 (0.001)	Page 8-4
piston ring	Piston ring-to-ring groove clearance	Top Second	0.010 - 0.025 (0.0004 - 0.0010) 0.020 - 0.070 (0.0008 - 0.0028)	0.45 (0.018)	Page 8-3
	Picton ring and gap	Top/ Second	0.15 - 0.45 (0.0006 - 0.0015)	0.08 (0.03)	Page 8-4
	Oil (side rail)			_	_
Cylinder-to-piston clearance		0.010 – 0.035 (0.0004 - 0.0013)	0.10 (0.004)	Page 8-2	
Connecting rod small end I.D.		12.010 - 12.028 (0.4728 - 0.4735)	12.05 (0.474)	Page 8-4	
Connecting rod-to	-piston pin clearance		0.010 - 0.034 (0.0003 - 0.0013)	0.05 (0.002)	Page 8-4

KICKSTARTER/DRIVE & DRIVEN PULLEY/CLUTCH SPECIFICATIONS

					Unit: mm (in)
ITEM		STANDARD		SERVICE LIMIT	Page NO.
Drive belt width		19.5 (0.76)		19.2 (0.75)	Page 9-14
Movable drive	Busing I.D.	22.035 – 22.085 (0.8675 – 0.8695)	22.60 (0.889)	Page 9-11
	Boss O.D.	21.4 – 21.6 (0.866	65 – 0.8671)	21.0 (0.826)	Page 9-11
lace	Weight roller O. D.	19.92 – 20.08 (0.705 – 0.712)		19.40 (0.763)	Page 9-11
Clutch	Outer I.D.	125.0 – 125.2 (4.921 – 4.929)		125.5 (4.941)	Page 9-15
Clutch	Lining thickness	4.0 (0.12)		2.0 (0.08)	Page 9-15
	Ease enring free length	FCC	99.6 (3.921)	85.4 (3.36)	Page 9-15
	Face spring free length	EXEDY 101.3 (3.99)		92.2 (3.62)	Page 9-15
	Driven face O.D.	33.965 – 33.985 (1.3372 – 1.3380)	33.94 (1.336)	Page 9-15
	Movable driven face I.D.	34.000 - 34.025 (1.3386 - 1.3396)		34.06 (1.341)	Page 9-16

FINAL REDUCTION SPECIFICATIONS

ITEM		STANDARD	Page NO.
	At disassembly	0.12 liter (0.13 US qt, 0.11 lmp qt)	Page 10-8
Final reduction oil capacity	At draining	0.10 liter (0.11 US qt, 0.09 lmp qt)	Page 10-8
Recommended final reduction oil		Honda 4-stroke oil or equivalent motor oil API service classification: MA	Page 10-8
		Viscosity: SAE 10W-30	5

CRANKCASE/CRANKSHAFT SPECIFICATIONS

Unit: mm (in)

Unit[·] mm (in)

Crankshaft	ITEM	STANDARD	SERVICE LIMIT	Page NO.
	Connecting rod big end side clearance	0.10 - 0.35 (0.004 - 0.014)	0.55 (0.022)	Page 12-3
	Connecting rod big end radial clearance	0.004 - 0.016 (0.0001 - 0.0006)	0.04 (0.002)	Page 12-4
	Crankshaft runout	_	0.1 (0.04)	Page 12-4

ELECTRIC STARTER SPECIFICATION

Unit: mm (in)

ITEM	STANDARD	SERVICE LIMIT	Page NO.
Starter motor brush length	9.0 (0.35)	3.5 (0.14)	Page 17-3

FRONT WHEEL/BRAKE/SUSPENSION/STEERING SPECIFICATIONS

ITEM		STANDARD	SERVICE LIMIT	Page NO.
Cold tyre pressure	Driver only	150 kPa (1.50 kgf/cm ² , 22 psi)	_	Page 3-18
	Driver and passenger	150 kPa (1.50 kgf/cm ² , 22 psi)	_	Page 3-18
Rim size		12 x 2.15 in		_
Front axle runout		_	0.1 (0.003)	Page 13-5
Front wheel rim runout	Radial	_	1.0 (0.03)	Page 13-5
	Axial	_	1.0 (0.03)	Page 13-5
Front brake drum I.D.		130 (5.12)	131 (5.16)	Page 13-8

REAR WHEEL/BRAKE/SUSPENSION SPECIFICATIONS

Unit: mm (in)

				()
ITEM		STANDARD	SERVICE LIMIT	Page NO.
Cold tyre pressure	Driver only	200 kPa (2.00 kgf/cm ² , 29 psi)	-	Page 3-18
	Driver and passenger	250 kPa (2.50 kgf/cm ² , 36 psi)	-	Page 3-18
Rim size		10 x 2.15 in		
Rear wheel rim runout	Radial	-	1.0 (0.03)	Page 14-3
	Axial	-	1.0 (0.03)	Page 14-3
Rear brake drum I.D.		130 (5.11)	131 (5.16)	Page 14-4

BATTERY/CHARGING SYSTEM SPECIFICATIONS

Unit: mm (in)

ITEM			SPECIFICATION	Page NO.
Detter	Capacity		12 V – 3 Ah	Page 15-3
Battery	Current leakage		0.26 mA max.	Page 15-8
Rectifier comp.	ectifier comp.		13.9 – 14.7 V/5,000 min ⁻¹ (rpm)	_
Regulator		Lighting	12.7 – 13.7 V/5,000 min ⁻¹ (rpm)	_
Alternator coil resistance at 20°C (68°F) Charging coil		Charging coil	0.2 – 1.0 Ω	Page 15-8

IGNITION SYSTEM SPECIFICATIONS

			Unit: mm (in)	
ITEM		SPECIFICATION	Page NO.	
Spark plug Standard		NGK MR7C-9N	Page 3-7	
Spark plug gap		0.8~0.9	Page 3-7	
Ignition primary peak voltage		100 V minimum	Page 16-3	
Ignition pulse generato	or peak voltage	0.7 V minimum	Page 16-4	
Ignition timing ("F" mark)		15° BTDC at 1,700 rpm	_	
Maximum timing (Advance)		34° BTDC at 2,700 rpm	-	

LIGHTS/METER/SWITCHES SPECIFICATIONS

Unit: mm (in) ITEM **SPECIFICATION** Page NO. Hi beam 12 V – 35 W _ Headlight Low beam 12 V – 35 W _ Tail/Brake Light 12 V - 5/21 W _ Front turn signal light 12 V – 10 W x 2 _ 12 V – 10 W x 2 Bulb Rear turn signal light _ Meter light 1.7 W x 1 Position light 5 W x 1 _ High beam indicator 1.7W x 1 _ Turn signal indicator 1.7W x 1 _ Main Fuse 10A Fuse

STANDARD TORQUE VALUES

FASTENER TYPE TORQUE N·m (kgf·m, lbf·ft)		FASTENER TYPE	TORQUE N⋅m (kgf⋅m, lbf⋅ft)	
5 mm bolt and nut	5 (0.5, 3.6)	5 mm screw	4 (0.4, 2.9)	
6 mm bolt and nut	10 (1.0, 7)	6 mm screw	9 (0.9, 6.5)	
8 mm bolt and nut	22 (2.2, 16)	6 mm flange bolt	12 (1.2, 9)	
10 mm bolt and nut	34 (3.5, 25)	8 mm flange bolt and nut	26 (2.7, 19)	
12 mm bolt and nut	54 (5.5, 40)	10 mm flange bolt and nut	39 (4.0, 28)	

FRAME & ENGINE TORQUE VALUES

Torque specifications listed below are for important fasteners.

• Others should be tightened to standard torque values listed above.

FRAME

ITEM	QTY	THREAD DIA. (mm)	TORQUE N⋅m (kgf⋅m, lbf⋅ft)	REMARKS	PAGE NO.	
FRAME/BODY PANELS/EXHAUST SYSTEM						
Muffler mounting bolt	2	10	49 (5.0, 36)		Page 2-10	
Muffler protector mounting bolt	2	6	14 (1.4, 10.3)		Page 2-9	
Exhaust, pipe nut	2	7	29 (2.9, 21.4)		Page 2-10	
Exhaust pipe protector bolt	2	6	14 (1.4, 10.3)		Page 2-9	
Floor set washer-bolt	1	6	10 (1.0, 7.3)		-	
FRONT WHEEL/BRAKE/SUSPENSION	V/STEERI	NG				
Fr. axle nut	1	12	59 (6.0, 43)	PT Nut	Page 13-7	
Fr. hub nut	4	8	23 (2.3, 16.96)	PT Nut	Page 13-6	
Fr. brake arm nut	1	6	10 (1.0, 7.3)		Page 13-13	
Handlebar lower holder nut	2	10	39 (4.0, 29)	PT Nut	Page 13-23	
Handlebar upper holder bolt	4	6	12 (1.2, 8.8)		Page 13-16	
Fork top bridge bolt	2	8	30 (3.0, 22.1)		Page 13-23	
Steering stem nut	1	24	74 (7.5, 55)		Page 13-24	
Nut handle lever	2	6	5.9 (0.6, 4.35)		_	
REAR WHEEL/BRAKE/SUSPENSION						
Rr. axle nut	1	16	118 (12.0, 87)	PT Nut	Page 14-4	
Rr. hub nut	4	10	49 (5.0, 36.1)	PT Nut	Page 14-4	
Rr. brake arm bolt	1	6	10 (1.0, 7.3)		Page 14-6	
Rr. cushion (upper side) bolt	1	10	39 (4.0, 29)		Page 14-7	
Rr. cushion (lower side) bolt	1	8	22 (2.2, 16)		Page 14-7	
FUEL TANK/SIDE STAND						
Fuel cock assy.	1	16	18 (1.8, 13.27)		-	
Tank bolt	4	6	10 (1.0, 7.3)		-	
Side stand pivot bolt	1	10	10 (1.0, 7.3)		-	
Side stand pivot nut	2	10	30 (3.0, 22.1)		-	
ENGINE HANGER						
Frame side - hanger bolt	1	10	-		Page 6-3	
- hanger nut	1	10	69 (7.0, 51)		Page 6-3	
Engine side - hanger bolt	1	10	-		Page 6-4	
- hanger nut	1	10	49 (5.0, 36)		Page 6-4	
LIGHTS						
Light assy. head bolt adjusting	1	4	2 (0.2, 1.5)		_	
Light assy. tail screw	6	4	1 (0.10, 0.73)		_	
Speedometer assy screw	3	4	0.8 (0.08, 0.59)		—	

ENGINE

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.			
MAINTENANCE	MAINTENANCE							
Spark plug	1	10	16 (1.6, 12)		Page 3-7			
Nut, tappet adjusting	2	5	10 (1.0, 7.3)	Apply eng. oil	Page 3-9			
Bolt, plug drain	1	12	24 (2 4 17 7)		Page 3-10			
Can oil filter	1	30	20 (2 0 14 7)		Page 3-11			
Final drive oil bolt	2	8	12 (1 3 9 5)	Mission oil check and	Page 3-13			
	-	Ũ	12 (1.3, 3.5)	drain	i ago o io			
LUBRICATION SYSTEM	I			didin				
Oil pump assy, bolt	2	6	10 (1.0, 7.3)		Page 4-4			
Plate, oil pump screw	1	4	3 (0 3 2 2)		Page 4-4			
Oil nump cover bolt	1	6	10(10,73)		Page 4-5			
	1	6	10 (1.0, 7.3)		Page 4-5			
FUEL SYSTEM		Ū	10 (1.0, 7.0)		1 490 1 0			
Carburetor mounting bolt	2	6	10 (1 0 7 3)		Page 5-8			
	2	0	10 (1.0, 7.0)		i age 5-0			
Bolt head cover	2	6	12 (1 2 8 8)		Page 7-18			
Cyl head comp stud bolt	2	6	6(0644)					
Lifter assy tensioner screw	1	6	4 (0 4 2 9)		Page 7-18			
Sprocket cam bolt	2	5	(0.4, 2.9)	Apply eng. oil	Page 7-17			
Head cylinder put	4	7		Head Side	Page 7-17			
Plate broather separater scrow	2	5	18 (1.6, 13.2)	Tiead Side	Page 7-17			
Shroud exhaust helt	3		3 (0.3, 2.2)		Page 7-13			
			7 (0.7, 5.1)		Page 7-4			
RICKSTARTER/DRIVE AND DRIVE		15/CLUICH						
Plate, L. cover screw	5	4	3 (0.3, 2.2)		Page 9-7			
Kick starter pedal bolt	1	8	29 (2.9, 22)		Page 9-7			
Face comp., drive nut	1	14	93 (9.3, 68.5)	Apply eng. oil	Page 9-19			
Outer comp., clutch nut	1	12	49 (4.9, 36.1)		Page 9-18			
Plate assy., drive nut	1	28	54 (5.4, 39.8)		Page 9-17			
ALTERNATOR								
Fan cover screw	2	5	4 (0.4, 2.9)		-			
Fan cover bolt	2	10	7 (0.7, 5.1)		Page 11-4			
Fan comp., cooling bolt	3	6	10 (1.0, 7.3)		Page 11-4			
Flywheel comp. bolt	1	10	39 (3.9, 28.7)		Page 11-4			
Pulsar coil assy.(stator comp.) bolt	2	5	6 (0.6, 4.4)		Page 11-3			
Stator holding bolt	2	6	10 (1.0, 7.3)		Page 11-3			
Clamper, wire harness bolt	1	6	12 (1.2, 8.8)		Page 11-3			
CRANKCASE								
Pivot cam chain tensioner	1	6	10 (1.0, 7.3)		Page 12-6			
R Crank case stud bolt	2	7	7 (0.7, 5.1)		-			
L Crank case stud bolt	2	7	7 (0.7, 5.1)		_			
Cover crankcase comp. left bolts	7	12	13 (1.3, 9.5)	NOTE 1	Page 10-8			
OTHERS								
Bolt Main stand spring	1	8	22 (2.2, 16)		-			
Stay comp. fuel tank nut	1	8	20 (2.0, 14)		-			

TOOLS

DESCRIPTION	TOOL NUMBER	REFERENCE SECTION
Float level gauge	070MJ – 001 – I110	5
Clutch center holder	070MB – KPL – I200	9
Universal holder	070MB – KPL – 1100	9. 11
Fly wheel puller	070MC – KPL – 1200	11
Bearing remover weight	070MC – KPL – 1300	9.10
Attachment 32 x 35 mm	070GD - 002 - 1140	10 13
Attachment 37 x 40 mm	070GD = 002 = 1150	10
Attachment 42 x 47 mm	070GD - 002 - 1160	10
Attachment 24 x 26 mm	070GD = 002 = 1120	9
Attachment 30 mm LD	070GD = 003 = 1120	13
Pilot 12 mm	070GD = 004 = 1130	10 13
Pilot 17 mm	070GD = 004 = 1150	10
Pilot 20 mm	070GD = 004 = 1160	10
Bearing remover shaft	070GD = 005 = 1100	13
Bearing remover head 12 mm	070MD = 005 = 1130	13
Remover shaft	070 GC = 001 = 1120	13
Adjusting remover head	070GC = 001 = 1120	13
Driver	070GD = 001 = 1100	9 10 13
Valve spring compressor	070GE = 001 = 1100	7
Soot outtor 27.5 mm (45° EX)	070GE - 001 - 1100	7
Seat cutter, 27.5 mm (45° LX)	070MH 003 1150	7
Elet outtor 28 mm (22° EX)	070MH = 003 = 1130	7
Flat cutter, 20 mm (32 EA)		7
Interior outtor, 26 mm (60° IN/EX)	070ME - 002 - 1160	7
Cutter belder	070MH 005 1150	7
Value adjusting wranch	070101 - 005 - 1150	7
		3
	070MA KPL 1200	13
LOCK hul wrench, 45.5 mm	070MA - KPL - 1100	13
Bearing remover head, 12 mm	070MC KPL - 1400	10
Bearing remover shall, 12 mm	070MC - KPL - 1410	10
Bearing remover head, 17 mm	070MC - KPL - 1520	10
Bearing remover nead, 15 mm	070MC - KPL - 1500	10
Bearing remover shaft, 15 mm	070MC - KPL - 1510	10
	070ND - 000 - 1150	1
Attachment, 44 x 49.5 mm	070MD - KPL - 1210	13
Bearing driver	070MD - KPL - 1100	9
Crankcase assembly collar	070MF - KWP - 110	10
Assembly collar attachment	070MF – KWP – 120	10
Crankcase assembly shaft	070MF - KVVP - 130	10
Valve guide reamer	070MH - 001 - 1160	1
Socket wrench, 39 x 41 mm	070MA – KPL – 1300	9
Peak voltage adaptor	070GJ – 002 – 1110	16
Clutch spring compressor	070ME – KWP – 110	9
Bearing remover (Driven face)	070MC – KWP – 410	9
Bearing installer (Driven face)	070NC – KWP – 410	9
Case/driven gear puller	070MC – KPL – 1100	10
Slider base piston	070SRT – KSP – 008	8
Snap ring plier	07914 – SA50 – 001	9
Remover bearing 15 mm shaft	070MC – KPL – 1500	13
Remover bearing 15 mm head	070MC – KPL – I510	13
Rear engine foundation bush remover	07008 – KPL – 900	13
Washer, 10.3 mm	90521 – KSP – 900	13
Drive shaft bearing remover	07008 – DBR – 900	10
Circlip plier	07914 – SA50001	13
Tensioner lifter stopper	070MG – 0010100	7
Pinion Speedometer tool	07000 – PST – 900	13

LUBRICATION AND SEAL POINTS SPECIFICATIONS

ENGINE

LOCATION	MATERIAL	REMARKS
Camshaft cam lobes	Molybdenum oil solution (Mixture	
	of the engine oil and molybdenum	
	grease in a ratio of 1 : 1)	
Oil pump rotor	Engine oil	
Oil pump driven gear teeth		
Stem seal fitting surface		
Cylinder stud bolt threads		
Camshaft holder nut threads and seating surface		
Camshaft bearing rotating area		
Cam sprocket teeth		
Cam sprocket bolt threads and seating surface		
Cam chain		
Rocker arm slipper and sliding surface		
Valve adjusting screw lock nut whole surface		
Rocker arm shaft sliding surface		
Valve stem sliding surface		
Piston outer surface and piston pin hole		
Piston pin outer surface		
Piston ring whole surface		
Drive pulley face nut threads and seating surface		
Connecting rod big end		
Connecting rod small end		
Timing approaches tooth of grankshaft		
Oil pump drive appealet tooth of graphabaft		
Fach bearing rotating area		
Each O ring		
Each oil seal lin and circumference		
Bearing hole in oil nump cover	Multi-purpose grease	
Oil numn driven gear shaft journal		
Kickstarter driven gear shaft journal		Apply $0.2 - 0.3$ g
Kickstarter driven gear friction spring sliding area		, (pp) 0.2 0.0 g
Kickstarter spindle journal		Apply 0.1 – 0.3 a
Starter pinion shaft journal		Apply 0.1 – 0.3 g
Driven face boss inner surface		Apply 5.0 – 5.5 a
Driven face ball bearing cavities		
Driven face needle bearing rollers		

FRAME

LOCATION	MATERIAL	REMARKS
Front wheel dust seal lip	Multi-purpose grease	Do not contaminate the brake lining
Speedometer gear teeth and sliding surface		surfaces.
Front brake cam pivot and shoe contacting area (Drum)		
Front brake panel anchor pin shoe contacting area		
(Drum)		
Front brake cam dust seal sliding surface (Drum)		
Front brake panel dust seal lip (Drum)		
Speedometer pinion teeth and sliding surface		
Speedometer pinion dust seal lip		
Rear brake cam pivot and shoe contacting area		
Rear brake panel anchor pin shoe contacting area		
Rear brake dust seal lip		
Front wheel hub nut thread and seating surface (Drum)		
Rear wheel hub nut thread and seating surface		
Center stand pivot		
Front cushion upper bolt		
Brake master cylinder push rod contacting area		
Brake caliper pin boot inner surface		
Brake caliper pin sliding surface		
Each dust seal lips		
Each O-ring		
Throttle grip		
Front brake lever pivot	Silicone grease	
Rear brake lever pivot		
Inside of front brake cable boot (Drum)		
Inside of rear brake cable boot		
Inside of throttle cable boot		
Inside of speedometer cable		
Seat catch wire and bracket connecting area		
Speedometer cable		
Throttle cable		
Front brake cable (Drum)		
Rear brake cable		
Front wheel hub stud bolt (Drum)	Locking agent	
Rear wheel hub stud bolt		
Fork socket bolt thread		
Rear axle nut threads and seating surface	Engine oil	
Handlebar post threads		
Air cleaner connecting tube seating surface	Cemedine #540 or equivalent	
Handlebar grip inside surface		
Steering head bearing steel ball and race	Use Water resistant multi-purpose	Apply Min 3g
	grease (Shell Alvania EP2 or	
	Excelite EP2	
	(KYODO YUSHI CO. LTD)	
	or equivalent)	

CABLE & HARNESS ROUTING













EMISSION CONTROL SYSTEMS

SOURCE OF EMISSIONS

The combustion process produces carbon monoxide (CO), oxides of nitrogen (NOx) and hydrocarbons (HC). Control of carbon monoxide, oxides of nitrogen and hydrocarbons is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda Motor Co., Ltd. utilizes appropriate carburetor settings as well as other systems, to reduce carbon monoxide and hydrocarbons.

CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow–by gas is returned to the combustion chamber through the air cleaner and carburetor. Residual oil is collected in the breather pipe.



EXHAUST EMISSION CONTROL SYSTEM (PULSE SECONDARY AIR INJECTION SYSTEM)

The exhaust emission control system consists of a pulse secondary air injection system which introduces filtered air into the exhaust gases at the exhaust port. Fresh air is drawn into the exhaust port whenever there is a negative pressure pulse in the exhaust system. This charge of fresh air promotes burning of the unburned exhaust gases and changes a considerable amount of hydrocarbons and carbon monoxide into relatively harmless carbon dioxide and water vapour.

This model has the pulse secondary air injection (PAIR) control valve and PAIR check valve. PAIR check valve prevents reverse air flow through the system. The PAIR control valve reacts to high intake manifold vacuum and will cut off the supply of fresh air during engine deceleration, thereby preventing after burn in the exhaust system.

No adjustment to the pulse secondary air injection system should be made, although periodic inspection of the components is recommended.



MEMO

BODY PARTS LOCATION



2. FRAME/BODY PANELS/EXHAUST SYSTEM

BODY PARTS LOCATION	2-0	FUEL TANK	2-6
SERVICE INFORMATION	2-1	BATTERY COVER	2-6
TROUBLESHOOTING	2-1	FRONT FENDER	2-7
HEADLIGHT ASSEMBLY	2-2	REAR GRIP	2-7
HEADLIGHT COVER DISASSEMBLY	2-2	REAR COWL	2-7
SPEEDOMETER ASSEMBLY	2-2	TAIL LIGHT	2-8
FORK COVER (L SIDE & R SIDE)	2-2	REAR COWL COVER	2-8
COVER CENTER	2-3	BATTERY CASE	2-8
FUEL TANK COVER LOWER	2-3	REAR FENDER	2-9
SEAT	2-3	MUFFLER & EX. PIPE PROTECTOR	2-9
FUEL TANK COVER	2-3	EXHAUST PIPE/ MUFFLER	2-10
RIGHT SIDE COVER	2-4	FLOOR SET	2-11
LEFT SIDE COVER	2-5	SIDE STAND	2-11
TANK COVER CENTER	2-6		

SERVICE INFORMATION

GENERAL

- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.
- This section covers removal and installation of the body panels, fuel tank and exhaust system.
- Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.
- Always replace the exhaust pipe gasket with a new one after loosening or removing the exhaust pipe joint nuts.
- When installing the exhaust system, loosely install all of the exhaust pipe/muffler fasteners, always tighten the exhaust pipe joint nuts first, then tighten the mounting bolt and nut, if you tighten the mounting bolt and nut first, the exhaust pipe may not seat properly.
- Always inspect the exhaust system for leaks after installation.

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS	PAGE NO.
Muffler mounting bolt	2	10	49 (5.0, 36)		Page 2-10
Muffler protector mounting bolt	2	6	14 (1.4, 10.3)		Page 2-9
Exhaust, pipe nut	2	7	29 (2.9, 21.4)		Page 2-10
Exhaust pipe protector bolt	2	6	14 (1.4, 10.3)		Page 2-9
Floor set washer-bolt	1	6	10 (1.0, 7.3)		_

TROUBLESHOOTING

Excessive exhaust noise

- Broken exhaust system
- Exhaust gas leak

Poor performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler

2

HEADLIGHT ASSEMBLY

REMOVAL/INSTALLATION

Remove the pan screws (4 nos.).

Remove the headlight by holding it and carefully disengage the headlight lug from the slot provided in meter cover set.

Disconnect 3P black connector (Headlight) and 2P black coupler (Position light).

Installation is in the reverse order of removal.

NOTICE

While removing: Be careful while removing the headlight assy. from the upper side to avoid any damage to the lugs.

HEADLIGHT COVER DISASSEMBLY

REMOVAL/INSTALLATION

Remove the headlight assy. (page 2-2).

Remove the headlight bulb (page 18-2).

Remove the position light bulb by pulling it.

Remove the headlight aim adjusting bolt (1 no.) and headlight mounting clips (2 nos.) and remove the headlight cover.

Installation is in the reverse order of removal.







REMOVAL/INSTALLATION

Remove the headlight assy. (page 2-2).

Disconnect all connectors from the wiring harness and speedometer cable from combination meter assembly. Remove the plug blind.

Remove the pan screw (1 no.) from the meter cover set. Release the combination meter assembly snap clip (4 nos.) from mounting poins



Snap clips provided on lugs, so carefully remove combination meter assembly to avoid any damage.

Installation is in the reverse order of removal.

FORK COVER (L SIDE & R SIDE)

REMOVAL/INSTALLATION

Remove the speedometer assembly (page 2-2).

Disconnect the front L & R winker connectors.

Remove the fork cover bolt (1 no.) and screws (2 nos.).

Remove the left fork cover first then right fork cover carefully.

Installation is in the reverse order of removal.





Both fork cover are engaged with front no. plate stay, so disengage left fork cover first.

FRAME/BODY PANELS/EXHAUST SYSTEM

COVER CENTER

REMOVAL/INSTALLATION

Remove the pan screws (3 nos.) from the cover center.

Carefully release cover center from the body frame locking tabs.

Installation is in the reverse order of removal.



FUEL TANK COVER LOWER REMOVAL/INSTALLATION

Remove the cover center (page 2-3).

Remove the trim clip A (2 nos.) and trim clip B (2 nos.) from fuel tank cover lower.

Remove the pan screws (6 nos.) from fuel tank cover lower.

Carefully remove the fuel tank cover lower from the body frame.

Installation is in the reverse order of removal.



SEAT

REMOVAL/INSTALLATION

Insert the ignition key into the seat lock and turn it clockwise.

Slide seat backward and remove the seat.

Install the seat, while aligning its hook with the bracket on the frame and press it to lock.



FUEL TANK COVER

REMOVAL/INSTALLATION

Remove the seat (page 2-3).

Remove the pan screws (2 nos.) from front side and pan screws (2 nos.) from rear side.

Insert the ignition key into the fuel tank lid and turn it clockwise to open it.

Remove the screws (2 nos.) from inside of the fuel tank cover and release the fuel tank cover.

Remove the fuel tank cover.

Installation is in the reverse order of removal.



RIGHT SIDE COVER



REMOVAL/INSTALLATION

Remove the fuel tank cover (page 2-3).

Remove the trim clip (A) from top of fuel tank area and trim clip (B) from the right rear side of fuel tank lower cover.

Remove the screws A (2 nos.) from fuel tank center cover, pan screws B (3 nos.) from fuel tank lower cover, special screw C from rear upper side, pan screw D from the body cover under right side.

Be careful not to damage the side cover lugs.

Disengage the right side cover lugs (4 nos.) from the grommets carefully.

Remove the right side cover.

Installation can be done in the reverse order of removal.



REMOVAL/INSTALLATION

Remove the fuel tank cover (page 2-3).

Remove the trim clip (A) from top of fuel tank area and trim clip (B) from the left rear side of fuel tank lower cover.

Remove the screws A (2 nos.) from fuel tank center cover, pan screws B (3 nos.) from fuel tank lower cover, special screw C from rear upper side, pan screw D from the body cover under left side.

Be careful not to damage the side cover lugs. Installation can be done in the reverse order of removal.

TANK COVER CENTER

REMOVAL/INSTALLATION

Remove the fuel tank cover (page 2-3)

Remove the tapping screws (4 nos.) from the both side (left and right side) covers.

Remove the pan screw (1 no.).

Remove the trim clips (2 nos.) installed in front of fuel tank cover lower left and right side.

Remove the tank cover center.

Installation can be done in the reverse order of removal.

FUEL TANK

REMOVAL/INSTALLATION

Remove the following:

- Right side cover (page 2-4)
- Left side cover (page 2-5)
- Tank cover center (page 2-6)

Disconnect the fuel tube from fuel cock.

Remove the fuel cock lever by removing the pan screw.

Disengage the fuel drain tube from fuel tray.

Remove the bolts (4 nos.) from the pipe comp.

Remove the pipe comp. first then remove fuel tank from the body frame.

Installation is in the reverse order of removal.





BATTERY COVER

REMOVAL/INSTALLATION

Remove the seat (page 2-3)

Remove the special screw (1 no.).

Remove the battery cover.

Installation can be done in the reverse order of removal.



FRAME/BODY PANELS/EXHAUST SYSTEM

FRONT FENDER

REMOVAL/INSTALLATION

Remove the front wheel (page 13-3).

Disengage the front brake and speedometer cable from the front fendor.

Remove the bolts (6 nos.) from the front fender mounted on the forks.

Remove the front fender carefully.

Remove the inner screws (2 nos.) to remove the front fender stay from front fender.

Installation is in the reverse order of removal.

REAR GRIP

REMOVAL/INSTALLATION

Remove the seat (page 2-3).

Remove the mounting bolts (4 nos.).

Remove the rear grip.

Installation is in the reverse order of removal.





REAR COWL

REMOVAL/INSTALLATION

Remove the rear grip (page 2-7).

Remove the mounting special screws (4 nos.) from the rear cowl upper side.

Remove the pan screws (2 nos.) from the bottom side of the rear cowl.

Carefully disconnect the rear tail/ brake light 3P coupler (page 18-3).

Remove the rear cowl assembly.

Installation is in the reverse order of removal.

DISASSEMBLY/ASSEMBLY

While installing the rear cowl route the wire harness properly (page 1-13). Remove pan screws (4 nos.) from the inside of the rear cowl and carefully separate the rear cowl upper and rear cowl set lower.

Assembly is in the reverse order of disassembly.





TAIL LIGHT

REMOVAL/INSTALLATION

Remove the rear cowl (page 2-7).

Disassemble the rear cowl (page 2-7).

Remove the screws & washers (2 nos.) from the upper mounting of tail light and screws (2 nos.) from the lower mounting of the tail light.

Installation is in the reverse order of removal.



REAR COWL COVER

REMOVAL/INSTALLATION

Remove the right side cover (page 2-4).

Remove the left side cover (page 2-5).

Disengage the seat lock cable from the seat lock.

Remove the pan screws (2 nos.) from the under side of rear cowl cover and special screws (4 nos.) from left and right side.

Remove the rear cowl cover.

Installation is in the reverse order of removal.



REMOVAL/INSTALLATION

Remove the following:

- Right side cover (page 2-4)
- Left side cover (page 2-5)
- Rear cowl (page 2-7)
- Rear cowl cover (page 2-8)
- Battery (page 3-13)

Disengage the wire harness, fuel tube and lugs from the battery case.

Release the CDI, Starter relay, Turn signal relay and fuse box from the battery case.

Remove the special screws (2 nos.).

Loosen the bolt A.

Remove the bolts B (2 nos.), slightly move upward fuel tank stay and remove the battery case.

Installation is in the reverse order of removal.





FRAME/BODY PANELS/EXHAUST SYSTEM

REAR FENDER

REMOVAL/INSTALLATION

Remove the bolts (4 nos.) from rear fender.

Remove the rear fender.

Installation is in the reverse order of removal.



MUFFLER & EX. PIPE PROTECTOR

REMOVAL/INSTALLATION

The muffler protector can be serviced with the muffler installed on the engine.

Alwavs check

grommets on the muffler protector.

for the condition of the rubber

Remove the bolts A (2 nos.) of muffler protector and slide muffler protector towards engine to take it out.

Remove the bolts B (2 nos.) of ex. pipe protector and remove it.

Installation is in the reverse order of removal.

Tighten the Muffler protector bolts A (2 nos.) and bolts B (2 no.) of ex. pipe protector to the specified torque.

TORQUE: 14 N·m (1.4 kgf·m, 10.3 lbf·ft)

ASSEMBLY OF MUFFLER

Installation is in the reverse order of removal.





EXHAUST PIPE /MUFFLER

Remove the following:

- Exhaust pipe cap nuts
- Muffler mounting bolts and washers
- Exhaust pipe/muffler
- Gasket

Always replace the exhaust pipe gasket with a new one when remove the exhaust pipe from the engine.

Install a new gasket into the exhaust port.

Install the exhaust pipe/muffler, then temporarily install the exhaust pipe cap nuts, muffler mounting washers and bolts.

Tighten the muffler mounting bolt to the specified torque.

TORQUE: 49 N·m (5.0 kgf·m, 36 lbf·ft)

Tighten the exhaust pipe cap nuts securely to the specified torque.

TORQUE: 29 N·m (2.9 kgf·m, 21.4 lbf·ft)



STUD BOLT REPLACEMENT

Thread two nuts onto the stud, and tighten them together, then use a wrench on them to turn the stud bolt out.

Install new stud bolts into the cylinder head as shown.

TORQUE: 11 N·m (1.1 kgf·m, 8 lbf·ft)

After installing the stud bolts, check that the length from the bolt head to the cylinder head surface is within specification.


FRAME/BODY PANELS/EXHAUST SYSTEM

FLOOR SET

REMOVAL/INSTALLATION

Remove the following :

- Remove right side cover (page 2-4)
- Remove left side cover (page 2-5)
- Remove the cover center (page 2-3)
- Remove the fuel tank cover lower (page 2-3).

Remove the pan screws (4 nos.).

Remove the bolt/washer (1 no.) and flange bolts (4 nos.) from upper floor set.

Carefully disengage the floor set from the lugs and remove it. Remove the bolts (2 nos.) from lower floor set and remove it. Installation can be done in the reverse order of removal.



SIDE STAND

Remove the bolt (1 no.) and screw (2 nos.) one from floor lower and other from floor set.



Remove the screw (1 no.) from floor lower lid which is installed in floor lower and remove the floor lower lid.



Remove the floor set bolts (4 nos.).



Tilt the floor lower cover down ward and floor set upward. Align and install the side stand cover.



Align the side stand bracket along with mounting bolts and collars with the holes in the frame.

Tighten the bracket bolts (2 nos.) to the specified torque.

TORQUE: 39 N·m (4.0 kgf·m, 28 lbf·ft)



BOLTS

FRAME/BODY PANELS/EXHAUST SYSTEM

Install the bolt (1 no.) and screw (2 nos.) from floor lower and floor set.



Install and tighten the floor set bolts (4 nos.).



COMPONENT LOCATION



COMPONENT LOCATION	3-0	SECONDARY AIR SUPPLY SYSTEM	3-12
SERVICE INFORMATION	3-1	DRIVE BELT	3-13
MAINTENANCE SCHEDULE	3-3	FINAL DRIVE OIL	3-13
FUEL LINE	3-4	BATTERY	3-13
FUEL STRAINER SCREEN	3-4	FUSE BOX	3-14
THROTTLE OPERATION	3-5	BRAKE SHOES WEAR	3-14
CHOKE OPERATION	3-5	BRAKE SYSTEM	3-15
AIR CLEANER	3-6	BRAKE LIGHT SWITCH	3-16
CRANKCASE BREATHER	3-6	HEADLIGHT AIM	3-16
SPARK PLUG	3-7	CLUTCH SHOES WEAR	3-16
VALVE CLEARANCE	3-8	SUSPENSION	3-17
ENGINE OIL	3-9	NUTS, BOLTS, FASTENERS	3-18
ENGINE OIL STRAINER SCREEN	3-11	WHEELS/TYRES	3-18
ENGINE IDLE SPEED	3-11	STEERING HEAD BEARINGS	3-18

SERVICE INFORMATION

GENERAL

- Support the vehicle on a level surface before starting any work.
- Gasoline is extremely flammable and is explosive under certain conditions.
- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.
- If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in an enclosed area.
- The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and may lead to death.Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

3

SPECIFIC	ATIONS			Unit: mm (in)
	ITEM		SPECIFICATIONS	PAGE NO.
Throttle grip f	ree play		2 – 6 mm (1/12 – 1/4 in)	Page 3-5
Spark plug Standard		Standard	NGK MR7C-9N	Page 3-7
Spark plug ga	ар		0.8 – 0.9 mm (0.031 – 0.035)	Page 3-7
Valve clearan	се	INTAKE/ EXHAUST	0.16 mm (0.006 ± 0.001 in)	Page 3-8
	•.	At draining	0.7 liter (0.7 US qt, 0.6 Imp qt)	Page 3-10
Engine oil capacity At disassembly		At disassembly	0.8 liter (0.8 US qt, 0.7 Imp qt)	Page 3-10
			Honda 4-stroke oil or equivalent motor oil	Page 3-9
Recommende	ed engine oil		API service classification: MA	-
			Viscosity: SAE 10W-30	
Engine Idle speed			1,700 ± 100 min ⁻¹ (rpm)	Page 3-11
Drive belt width			19.5 mm (0.76 in)	Page 3-13
			Honda 4-stroke oil or equivalent motor oil	Page 3-13
Recommende	ed final reduction	oil	API service classification: MA	
			Viscosity: SAE 10W-30	
Final raduatio		At draining	0.10 liter (0.11 US qt, 0.09 Imp qt)	Page 3-13
	n oil capacity	At disassembly	0.12 liter (0.13 US qt, 0.11 Imp qt)	Page 3-13
Front brake le	ever free play	· ·	10 – 20 mm (3/8 – 3/4 in)	Page 3-15
Rear brake le	ver free play		10 – 20 mm (3/8 – 3/4 in)	Page 3-15
	Driversen	Front	150 kPa (1.50 kgf/cm ² , 22 psi)	Page 3-18
Cold tyre	Driver only	Rear	200 kPa (2.00 kgf/cm ² , 29 psi)	Page 3-18
pressure Driver and Front		Front	150 kPa (1.50 kgf/cm ² , 22 psi)	Page 3-18
	passenger	Rear	250 kPa (2.50 kgf/cm ² , 36 psi)	Page 3-18
- .		Front	90/90 – 12 54J	-
Tyre size		Rear	90/100 – 10 53J	_
		Front	NYLOGRIP ZAPPER (MRF, TVS, CEAT)	_
lyre brand	Tyre brand Rear		NYLOGRIP ZAPPER (MRF, TVS, CEAT)	-

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N⋅m (kgf⋅m, lbf⋅ft)	REMARKS	PAGE NO.
Spark Plug	1	10	16 (1.6, 12)		Page 3-7
Nut, Tappet Adjusting	2	5	10 (1.0, 7.3)	Apply eng. oil	Page 3-9
Bolt, Plug Drain 12 mm	1	12	24 (2.4, 17.7)		Page 3-10
Cap, Oil Filter	1	30	20 (2.0, 14.7)		Page 3-11
Final Drive Oil Bolt	1	8	12 (1.2, 8.8)	Mission oil check and drain	Page 3-13

TOOLS

Valve adjusting wrench

070MA – 001I110

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult your Honda dealer.

				ODOM	DOMETER READING (NOTE 1))				
	FREQUENCI	NOTE	PRE-RIDE	X1000KM	1	4	8	12	16	20	24	ANNUAL	REGULAR	REFER
		NOTE	CHECK	X1000MI	0.6	2.5	5	7.5	10	12.5	15	CHECK	REPLACE	PAGE
	ITEM			MONTHS	1	4	8	12	16	20	24			
*	FUEL LINE					I	Ι	I	Ι	I	1	I		3-4
	FUELLEVEL		I											-
*	FUEL STRAINER SCREEN					С	С	С	С	С	С			-
*	THROTTLE OPERATION		I			I	Ι	Ι	Ι	-	Ι	I		3-5
*	CHOKE OPERATION					I	Ι	Ι	Ι	Ι	Ι	I		3-5
*	AIR CLEANER	NOTE (2)							R					3-6
	CRANKCASE BREATHER	NOTE (3)				С	С	С	С	С	С	С		3-6
	SPARK PLUG					I	R	Ι	R	Ι	R			3-7
*	VALVE CLEARANCE				Ι	I	Ι	Ι	Ι	Ι	Ι			3-8
	ENGINE OIL		I		R	R	R	R	R	R	R	R		3-9
	ENGINE OIL STRAINER SCREEN				С			С			С			3-11
*	ENGINE IDLE SPEED				Ι	I	Ι	Ι	Ι	I	1	I		3-11
*	SECONDARY AIR SUPPLY SYSTEM							Ι			Ι	I		3-12
*	SECONDARY AIR SUPPLY SYSTEM AIR FILTER	NOTE (2)						С			С			3-12
*	DRIVE BELT						Ι		I		R			3-13
*	FINAL DRIVE OIL	NOTE (4)			_								2 YEARS	3-13
	BRAKE SHOES WEAR		I			Ι	Ι	Ι	I	Ι	Т	I		3-14
	BRAKE SYSTEM		I		Ι	I	Ι	Ι	I	Ι	Ι	I		3-15
*	BRAKE LOCK OPERATION				Ι	I	Ι	Ι	Ι	Ι	Ι			3-16
	BATTERY VOLTAGE		I		Ι	Ι	I	Ι	Ι	Ι	Ι	I		3-13
	HEAD LIGHT AIM					Ι	I	Ι	Ι	Ι	Ι	I		3-16
	LIGHTS/HORN		I											-
**	CLUTCH SHOES WEAR						Ι		Ι		Ι			3-16
*	SUSPENSION					Ι	Ι	Ι	Ι	Ι	Ι	I		3-17
*	NUTS, BOLTS, FASTENERS				Ι		Ι		Ι		Ι	I		3-18
**	WHEELS/TYRES		I			Ι	Ι	Ι	Ι	Ι	Ι	I		3-18
**	STEERING HEAD BEARINGS				Ι			Ι			Ι	I		3-18

* Should be serviced by an authorized Honda dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to the official Honda Shop Manual

** In the interest of safety, we recommended these items be serviced only by your Honda dealer.

Notes:

- 1. At higher odometer readings, repeat at the frequency interval established here.
- 2. Service more frequently if the vehicle is ridden in unusually wet or dusty areas.
- 3. Service more frequently when riding in rain or at full throttle.
- 4. Replacement requires mechanical skills.

FUEL LINE

Remove the fuel cover lower (page 2-3).

Replace the fuel tube if it is cracked, damaged or leaking. Inspect the fuel tube routing, kinks and bends which can restrict the fuel flow. Also inspect the position of clips used for locking. Check fuel tube and fuel strainer for blockage.

Install the fuel tank cover lower (page 2-3).

Install the cover center (page 2-3).



FUEL STRAINER SCREEN

Wipe the spilled gasoline off at once Remove the fuel tank cover lower (page 2-3).

Turn the fuel lever "OFF".

Remove the fuel strainer cup and drain the contents of the cup into a suitable container.



Remove the O-ring and strainer screen.

Wash the strainer screen and cup in clean non-flammable high flash point solvent.

Carefully install the strainer screen, new O-ring and fuel strainer cup in the fuel cock body, making sure that the O-ring is in place.



Tighten the fuel strainer cup.

Turn the fuel lever "ON" and be sure there are no fuel leaks. Install the fuel tank cover lower (page 2-3). Install the cover center (page 2–3).



THROTTLE OPERATION

Check for any deterioration or damage to the throttle cable. Check the throttle grip for smooth operation. Check that the throttle opens and automatically closes in all steering positions.

If the throttle grip does not return properly, change the throttle cable.





Reusing a damaged or abnormally bent or kinked throttle cable can prevent proper throttle slide operation and may lead to a loss of throttle control while riding.

With the engine idling, turn the handlebar all the way to the right and left to ensure that the idle speed does not change. If idle speed increases, check the throttle grip free play and the throttle cable connection.

Measure the free play at the throttle grip flange.

FREE PLAY: 2 - 6 mm (0.08 - 0.24 in)

Adjustments are made with the upper adjuster.

Slide the boot off the upper adjuster.

Loosen the lock nut and turn the adjuster as required.

After adjustment, tighten the lock nut and install the boot over the adjuster properly.

Recheck the throttle operation.

Replace any damage parts, if necessary.



CHOKE OPERATION

Check for smooth operation of the choke lever.

Lubricate the choke cable if the operation is not smooth.

Inspect the cable casing for cracks which could allow moisture to enter.

Replace the cable if necessary.



AIR CLEANER

Support the vehicle on its center stand.

Remove the screws (6 nos.) and the air cleaner cover.

NOTE:

Clean the air cleaner cover surrounding area with compressed air or soft cloth before removing the air cleaner, If the vehicle is used in wet or dusty areas, more frequent inspections are required.

Remove the air cleaner element assembly from the air cleaner housing. Replace the air cleaner element as per maintenance schedule.

Do not clean with solvent to remove dust and also do not use forced air on it. The special oil will be lost and filter becomes dry. As the base filter paper is coarse, it cannot block fine dust when it becomes dry.

NOTICE

Replace the air cleaner if it is excessively dirty, torn or damage.

Do not place filter horizontally on any surface as dust can stick to the filter due to oil present. If necessary place vertically. Install immediately after inspection.

CRANKCASE BREATHER

Remove the clamp from the drain tube and drain the deposits into a suitable container, then install the clamp securely.

Inspect the breather hose and transmission breather tube for any damage.

NOTE:

Service more frequently when ridden in rain, at full throttle, or after the vehicle is overturned. Service if the deposits level can be seen in the drain tube.









SPARK PLUG

Support the vehicle on its center stand.

Remove the cover center (page 2-3).

Remove the spark plug cap and clean around the spark plug base.

NOTE:

Clean around the spark plug base with compressed air before removing the plug, and be sure that no debris is allowed to enter the combustion chamber.

Remove the spark plug.

Check the insulator for cracks or damage and the electrodes for wear, fouling or discoloration.

If the electrode is corroded with carbon deposits, clean the electrode using the wire brush or spark plug cleaner.

NGK MR7C-9N

Replace the plug if necessary.

Standard





RECOMMENDED SPARK PLUG:

Measure the spark plug gap between the center and ground electrodes with a wire gauge.

SPARK PLUG GAP: 0.8 - 0.9 mm (0.031 - 0.035 in)

If necessary, adjust the gap by carefully bending the ground electrode.

Thread the spark plug in by hand to prevent cross-threading then tighten it to the specified torque.

TORQUE: 16 N·m (1.6 kgf·m, 12 lbf·ft)

Install the spark plug cap.

Install the cover center (page 2-3).



VALVE CLEARANCE

NOTE:

Inspect and adjust the valve clearance when the engine is cold (below $35^{\circ}C/95^{\circ}F$).

Remove the cover center (page 2-3).

Disconnect the breather tube from the cylinder head cover.

Release throttle cable and choke cable from the head cover clamp.

Remove the spark plug (page 3-7).

Remove the bolts (2 nos.) and cylinder head cover.





Turn the crankshaft clockwise and align the "T" mark on the cooling fan with the index mark on the right crankcase.

Make sure that the piston is at TDC (Top Dead Center) on the compression stroke.

Rocker arms should be slightly loose. If the rocker arms are tight, turn the crankshaft clockwise 360° (one full turn) and align the "T" mark with the index mark.



Check the valve clearance by inserting a feeler gauge between the valve adjusting screw and valve stem.

VALVE CLEARANCE:

IN/EX: 0.16 mm (0.006 ± 0.001 in)



If the valve clearance is incorrect, loosen the valve adjusting screw lock nut and adjust the valve clearance by turning the adjusting screw until there is a slight drag on the feeler gauge.

Hold the adjusting screw and tighten the lock nut.

TOOLS:

Valve adjusting wrench 070MA - 001I110

TORQUE: 10 N·m (1.0 kgf·m, 7.3 lbf·ft) Recheck the valve clearance.



Check that the cylinder head cover gasket is in good condition and replace it with a new one if necessary.

Install the cylinder head cover and two bolts.

Connect the crankcase breather tube to the cylinder head cover.

Install the removed parts in the reverse order of removal.



ENGINE OIL

ENGINE OIL LEVEL CHECK

Place the vehicle on its center stand on level ground. Start the engine, let it idle for 2 - 3 minutes. Stop the engine and wait for 2 - 3 minutes. Remove the oil filler cap/dipstick, wipe it and insert it without screwing it in.



Remove the oil filler cap/dipstick and check the oil level.

The oil level should be between the upper and lower level marks on the dipstick.

If the oil level is below or near the lower level mark, add the recommended engine oil to the upper level mark.

RECOMMENDED ENGINE OIL:

Honda 4-stroke oil or equivalent motor oil API service classification: MA Viscosity: SAE 10W-30



NOTE:

Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.

Reinstall and tighten the oil filler cap/dipstick securely.



ENGINE OIL CHANGE

Place the vehicle on its main stand.

ne Remove the oil filler cap/dipstick.

Drain the engine oil while the engine is warm. This ensures complete and rapid draining.

Place oil drain pan under the engine to collect the oil, then remove the oil drain bolt.

After draining the oil completely check that the sealing washer on the drain bolt is in good condition and replace if necessary.



Install and tighten the drain bolt.

TORQUE: 24 N·m (2.4 kgf·m, 18 lbf·ft)

NOTE:

If the maintenance for the engine oil strainer screen is scheduled, perform it before filling the crankcase with engine oil (page 3-10).

Fill the crankcase with the recommended engine oil (page 3-9).

ENGINE OIL CAPACITY:

0.7 liter (0.7 US qt, 0.6 Imp qt) at oil change

0.8 liter (0.8 US qt, 0.7 Imp qt) at disassembly

Install the oil filler cap/dipstick.

Check the oil level.

Make sure that there are no oil leaks.



ENGINE OIL STRAINER SCREEN

Drain the engine oil (page 3-10).

Remove the oil strainer screen cap, spring and oil strainer screen.

Clean the oil strainer screen thoroughly.

Check the screen for damage and the O-ring for damage or deterioration.

Replace the oil strainer screen if necessary.

Install the oil strainer screen, spring, new O-ring and cap.

Tighten the oil strainer screen cap.

TORQUE: 20 N·m (2.0 kgf·m, 14 lbf·ft)

Fill the crankcase with the recommended engine oil (page 3-9).





ENGINE IDLE SPEED

NOTE:

- Inspect and adjust the idle speed after all other engine adjustments are within specifications.
- The engine must be warm for accurate inspection and adjustment.

Warm up the engine to normal operating temperature. Stop the engine and place the vehicle on its center stand on level ground.

Connect a tachometer with spark plug cable.

Start the engine, check the idle speed and adjust by turning the throttle stop screw if necessary.

IDLE SPEED: 1,700 ± 100 min⁻¹ (rpm)





SECONDARY AIR SUPPLY SYSTEM

NOTE:

The secondary air supply system introduces fresh filtered air into the exhaust port. The secondary air is drawn into the exhaust port whenever there is negative pressure pulse in the exhaust system. This charged secondary air promotes burning of the unburned exhaust gases and changes a considerable amount of hydrocarbons and carbon monoxide into relatively harmless water and carbon dioxide respectively.

Remove the right side cover (page 2-4).

Check the air injection hoses between the pulse secondary air injection PAIR control valve and cylinder head cover for deterioration, damage or loose connections. Make sure that the hoses are not cracked.

NOTE:

If the hoses show any signs of heat damage, inspect the PAIR check valve in the PAIR control valve for damage.

Check the air suction hose between the air filter and PAIR control valve for deterioration, damage or loose connections. Make sure that the hoses are not kinked, pinched or cracked.



SECONDARY AIR SUPPLY SYSTEM (AIR CLEANER)

REMOVAL/INSTALLATION

Remove the right side cover (page 2-4).

Remove the screw and housing cover from the secondary air cleaner.

Remove and clean the secondary air cleaner element as per maintenance schedule.



Wash the element in non-flammable or high flash point solvent and let it dry thoroughly.

Never use gasoline or low flash point solvent for cleaning the element. A fire or explosion could result.

Soak the element in engine oil (SAE 10W–30) equivalent and squeeze out any excess oil.

Installation is in the reverse order of removal.





DRIVE BELT

Remove the left crankcase cover (page 9-3).

Remove the drive belt (page 9-10).

Check the drive belt for cracks, separation or abnormal or excessive wear.

Measure the drive belt width.

SERVICE LIMIT: 19.2 mm (0.76 in)

Install the drive belt (page 9-18).

Install the crankcase cover (page 9-8).

FINAL DRIVE OIL

Remove the oil level check bolt.

Remove the oil drain bolt, slowly turn the rear wheel and drain the oil.

NOTE:

Replace the final drive oil as per maintenance schedule.

After the oil is completely drained, install the oil drain bolt with a new sealing washer and tighten it.

TORQUE: 12 N·m (1.2 kgf·m, 8.8 lbf·ft)

Fill the transmission case with recommended oil through the check bolt hole up to the bottom edge of the check bolt hole.

RECOMMENDED OIL:

Honda 4-stroke oil or equivalent motor oil API service classification: MA Viscosity: SAE 10W-30

OIL CAPACITY:

0.10 liter (0.11 US qt, 0.09 Imp qt) at oil change

0.12 liter (0.13 US qt, 0.11 Imp qt) at disassembly

Install the oil level check bolt with a new sealing washer and tighten it.

TORQUE: 12 N·m (1.2 kgf·m, 8.8 lbf·ft)

BATTERY

Battery is maintenance free battery means can be permanently damaged if the cap strip is removed Place the vehicle on its center stand on level ground. Remove the seat (page 2-3). Remove the screw (1 no.) and battery cover. Remove the battery from battery case (page 15-3).

Check for the rusting to the terminals and physical damage of terminals and battery.

Check the battery voltage (page 15-3).

Install the battery and battery cover (page 15-3).







FUSE BOX

REMOVAL

Remove the battery cover (page 2-6).

Unlock the fuse box by pulling the fuse box lock in upward direction and pull it outside.



Don't pull the fuse box lock with excessive force, it may damage the lock permanently.



INSTALLATION

Insert the fuse box into the fuse box installation stay.

Make sure that top of fuse box installation stay is aligned with top surface of fuse box.

Install the battery cover (page 2-6).

Install the seat (page 2-3).



Ensure the proper fitment of fuse box by slightly pulling it upwards from center.



BRAKE SHOES WEAR

FRONT BRAKE

Replace the front brake shoes if the indicator arrow on the brake arm aligns with the reference mark "D" on the brake panel when the front brake is fully applied.

Refer to (page 13-8) for front brake shoe replacement and brake drum inspection.



REAR BRAKE

Replace the rear brake shoes if the indicator of the brake arm aligns with the reference mark on the transmission case when the rear brake is fully applied.

Refer to (page 14-4) for rear brake shoe replacement and brake drum inspection.



BRAKE SYSTEM

Check the cable and brake lever for loose connections, excessive play, or other damage.

Replace or repair if necessary.

Inspect the brake cable for kinks or damage, and lubricate the cable.

FRONT BRAKE

Measure the front brake lever free play at the tip of the brake lever.

FREE PLAY: 10 - 20 mm (0.4 - 0.8 in)

Push the brake arm by hand, turn the adjusting nut in clockwise direction till you cannot turn by hand.

Check that free play of right lever is 10-20 mm. If required than further turn adjuster nut.

Again check the free play and confirm the value within the specified limit.

Check the front wheel for the free movement.





REAR BRAKE

Measure the rear brake lever free play at the tip of the brake lever.

FREE PLAY: 10 - 20 mm (0.4 - 0.8 in)



If adjustment is necessary, turn the rear brake adjusting nut.

Check the brake cable for kinks or other damage.

Check that the brake arm, spring and fasteners are in good condition.

Check the rear wheel for the free movement.



BRAKE LOCK OPERATION

NOTE:

Check the brake lock operation after the rear brake lever free play check and adjusted.

Squeeze the rear brake lever and set the lock lever.

Check that the rear wheel is locked completely.

Again press the brake lever to release the lock lever.



BRAKE LIGHT SWITCH

NOTICE

The brake light switch at the brake lever cannot be adjusted. If the brake light switch actuation and brake engagement are off, either replace the switch unit or the malfunctioning parts of the system.

Check that the brake light comes on when the brake lever (left, right or both) is pressed and the front-rear brake engagement begins.



HEAD LIGHT AIM

NOTE:

Adjust headlight beam as specified by local laws and regulations.

Support the vehicle on its center stand.

Adjust the head light beam vertically by loosening the headlight adjusting bolt.



CLUTCH SHOES WEAR

Remove the clutch shoes (page 9-12). Check the clutch shoe for wear or damage. Refer to (page 9-15), for clutch shoe lining inspection. Installation is in the reverse order of removal.



SUSPENSION

A WARNING

Loose, worn or damaged suspension parts impair vehicle stability and control. Repair or replace any damaged components before riding. Riding a vehicle with faulty suspension increases your risk of an accident and possible injury.

FRONT

NOTE:

Remove the vehicle from the main/side stand.

Check the action of the front suspension by applying the front brake and compressing the forks several times.

Check the entire assembly for signs of leaks, damage or loose fasteners.

Replace damaged components which cannot be repaired. Tighten all nuts and bolts.

Refer section 13 for fork service.



REAR

NOTE:

Remove the vehicle from the main/side stand.

Check the action of the rear shock absorber by compressing it several times.

Check the entire shock absorber assembly for signs of leaks, damage or loose fasteners.

Replace damaged components which cannot be repaired. Tighten all nuts and bolts.

Refer section 14 for shock absorber service.

Raise the rear wheel off the ground by placing the vehicle on its center stand.

Check for worn engine mounting bushings by grabbing the rear wheel and attempting to move the wheel side to side. Replace the bushings if any looseness is noted (section 14).





NUTS, BOLTS, FASTENERS

Check that all chassis nuts and bolts are tightened to the specified torque values (page 1-8).

Check that all cotter pin, safety clips, hose clamps and cable stays are in place and properly secured.

WHEELS/TYRES

NOTE:

Tyre pressure should be checked when the tyres are COLD.

Check the tyre pressure with the tyre pressure gauge.

RECOMMENDED TYRE PRESSURE:

Driver only:

,	
Front:	150 kPa (1.50 kgf/cm ² , 22 psi)
Rear:	200 kPa (2.00 kgf/cm ² , 29 psi)
Driver and passenge	r:

 Front:
 150 kPa (1.50 kgf/cm², 22 psi)

 Rear:
 250 kPa (2.50 kgf/cm², 36 psi)

Check the tyres for cuts, embedded nails or other damage.

Check the front and rear wheels for trueness.

Check the tread wear indicator for insufficient tread depth.

If the tread wear indicator is invisible, the tyre should be replaced.





STEERING HEAD BEARINGS

Support the vehicle on its center stand, and raise the front wheel off the ground.

Check that the control cables do not interfere with the handlebar rotation.

Check that the handlebar moves freely from side to side. If the handlebar moves unevenly, binds, or has vertical movement, inspect the steering head bearings (section 13).



MEMO

LUBRICATION SYSTEM DIAGRAM



4. LUBRICATION SYSTEM

LUBRICATION SYSTEM DIAGRAM

4-0 TROUBLESHOOTING 4-1

SERVICE INFORMATION

OIL PUMP 4-1

4-2

SERVICE INFORMATION

GENERAL

WARNING

Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. KEEP OUT OF REACH OF CHILDREN.

When removing and installing the oil pump, use care not to allow dust or dirt to enter the engine.

SPECIFICATIONS

SPECIFICATION	S			Unit: mm (in)
ITEM		STANDARD	SERVICE LIMIT	Page NO.
Engine oil capacityAt draining0.7 liters (0.7 US of At disassemblyAt disassembly0.8 liters (0.8 US of 0.8 liters (0.8 US of		0.7 liters (0.7 US qt, 0.6 lmp qt)	_	Page 3-10
		0.8 liters (0.8 US qt, 0.7 lmp qt)	_	Page 3-10
Recommended engine oil		Honda 4-stroke oil or equivalent motor oil API service classification: MA Viscosity: SAE 10W-30	_	Page 3-9
	Tip clearance	0.15 (0.006)	0.20 (0.008)	Page 4-3
Oil pump rotor Body clearance		0.15 - 0.21 (0.006 - 0.008)	0.35 (0.014)	Page 4-3
	Side clearance	0.05 - 0.10 (0.002 - 0.004)	0.12 (0.005)	Page 4-3

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Oil pump assy. bolt	2	6	10 (1.0, 7.3)		Page 4-4
Plate, oil pump screw	1	4	3 (0.3, 2.2)		Page 4-4
Oil pump cover bolt	1	6	10 (1.0, 7.3)		Page 4-5
	1	6	10 (1.0, 7.3)		Page 4-5

TROUBLESHOOTING

Oil level too low

- External oil leaks
- Worn valve guide or seal
- Worn piston rings or incorrect piston ring installation •
- Worn cylinder
- ٠ Oil not added frequently enough

Oil contamination

- Oil not changed often enough
- Worn piston rings

OIL PUMP

REMOVAL

Drain the engine oil (page 3-10). Remove the alternator assembly (page 11-2). Remove the oil pump cover bolts (2 nos.).

Screw the (5 mm thread dia) bolt into the threaded hole in the oil pump cover and pull the cover out by the help of plier from the right crankcase.

Remove the oil pump gear shaft and gear.







Remove the oil pump mounting bolts (2 nos.) and the oil pump assembly.



LUBRICATION SYSTEM

DISASSEMBLY

Remove the dowel pins (2 nos.).

Remove the oil pump plate attaching screw (1 no.) and pump plate.



INSPECTION

outer rotor.

Check oil pump body for any damage/worn-out teeth. Measure the outer rotor-to-body clearance. SERVICE LIMIT: 0.35 mm (0.014 in)





Measure the pump end clearance.

SERVICE LIMIT: 0.20 mm (0.008 in)

SERVICE LIMIT: 0.12 mm (0.005 in)

Remove the inner and outer rotors from the pump body. Clean the all disassembled parts thoroughly.



OIL PUMP ASSEMBLY



Install the outer and inner rotors into the pump body.

Install the two dowel pins.

Install the pump plate by aligning the holes in the pump plate with the two dowel pins.

Install and tighten the pump plate attaching screw.

TORQUE: 3 N·m (0.3 kgf·m, 2.2 lbf·ft)

Check that the oil pump rotates smoothly with the oil pump gear.





Install the oil pump assembly onto the right crankcase and tighten the mounting bolts (2 nos.).

TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)



4-4

LUBRICATION SYSTEM

Install the oil pump gear and gear shaft into the oil pump.

Apply grease to the oil pump gear shaft hole in the oil

Coat a new O-ring with oil and install it onto the oil pump

Install the oil pump cover into the right crankcase.



O-RING O-RING

Install and tighten the oil pump cover bolts (2 nos.).

TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)

pump cover.

cover.

Install the alternator assembly (page 11-3).

Fill the crankcase with recommended engine oil (page 3-9).



COMPONENT LOCATION



5. FUEL SYSTEM

COMPONENT LOCATION	5-0	CARBURETOR INSTALLATION	5-8
SERVICE INFORMATION	5-1	AIR SCREW ADJUSTMENT	5-9
TROUBLESHOOTING	5-2	SECONDARY AIR SUPPLY SYSTEM	5-10
AIR CLEANER HOUSING	5-3	FUEL STRAINER	5-12
CARBURETOR REMOVAL	5-4	FUEL TANK	5-13

SERVICE INFORMATION

GENERAL

A WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.
- If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.
- Bending or twisting the control cables will impair smooth operation and could cause the cables to stick or bind, resulting in loss of vehicle control.
- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- If the vehicle is to be stored for more than one month, drain the float bowl. Fuel left in the float bowl may cause clogged jets
 resulting in hard starting or poor drive ability.
- Before removing the carburetor, place an approved fuel container under the carburetor drain tube, loosen the drain screw and drain the carburetor.
- · When disassembling fuel system parts, note the locations of the O-rings. Replace them with new ones on reassembly.
- After removing the carburetor, wrap the intake port of the engine with a shop towel or cover it with a piece of tape to prevent any foreign material from dropping into the engine.

SPECIFICATIONS

ITEM	SPECIFICATIONS	Page NO.
Carburetor identification number	PB5TH	Page 1-3
Venturi diameter	16 mm (0.63 in)	-
Main jet	#85	Page 5-7
Slow jet	#35 x #35	Page 5-7
Float level	11.7 ± 0.5 mm (0.46 ± 0.02 in)	Page 5-7
Air screw initial opening	1 3/4 turns out	Page 5-9
Engine Idle speed	1,700 ± 100 min ⁻¹ (RPM)	Page 5-10
PAIR control valve specified vacuum	460 mmHg (18.11 in Hg)	Page 5-10

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N⋅m (kgf⋅m, lbf⋅ft)	REMARKS	PAGE NO.
Carburetor mounting bolts	2	6	10(1.0, 7.3)		Page 5-8

TOOLS

Carburetor float level gauge 070MJ-001-I110

TROUBLESHOOTING

Engine won't start

- No fuel in fuel tank
- No fuel to carburetor
 - Fuel stainer clogged
 - Fuel tube clogged
 - Fuel valve vacuum tube clogged
 - Float valve stuck
 - Float level miss adjusted
 - Fuel tank cap breather hole clogged

Poor performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler
- Too much fuel getting into the carburettor
 - Air cleaner clogged
 - Flooded carburetor
 - Float valve worn out
 - Deposition on float valve seat
 - Fuel tank cap breather hole block
- Intake air leak
- Fuel cock stuck
- Bad fuel quality
- Fuel jet clogged
- Fuel contaminated/deteriorated
- By-starter valve faulty
- Ignition system faulty (section 15)

Engine stalls, hard to start, rough idling

- Fuel mixture too lean/rich
- Fuel contaminated/deteriorated
- Intake air leak
- Idle speed misadjusted
- Air screw misadjusted
- Float level misadjusted
- Carburetor clogged
- Compression too low
- Ignition system faulty (section 16)
- Flooded carburetor
- Improper carburetor tuning
- Bad quality of fuel
- Fuel tank cap breather hole block
- Air filter chocked
- Fuel line restricted

Backfiring or misfiring during acceleration

- Fuel mixture too lean
- Ignition system faulty (section 16)
- Lean mixture in slow circuit
- Faulty PAIR control valve
- Faulty PAIR check valve
- Clogged hose of the PAIR system

Lean mixture

- Fuel jets clogged
- Float valve faulty
- Float level too low
- Fuel tank cap breather hole clogged
- Fuel strainer clogged
- Fuel tube restricted
- Intake air leak
- Throttle valve faulty
- Carburetor tuning

Rich mixture

- Float valve faulty
- Choke valve in close position
- Float level too high
- Air passage clogged
- Air jets clogged
- Air cleaner contaminated
- Choke valve faulty
- Ignition timing improper

AIR CLEANER HOUSING

For air cleaner housing cover removal and element replacement (page 3-6).

REMOVAL

Remove the cover centre (page 2-3).

Disconnect the engine breather hose from the cylinder head cover and release the hose from clamp.

Loosen the air cleaner connecting guide band screw.

Disconnect the transmission case breather tube from the air cleaner housing.





Remove the mounting bolt (2 nos.) and air cleaner housing.



INSTALLATION

Install the air cleaner housing in the reverse order of removal.

Route the breather tubes properly (page 1-13).

Install the cover centre (page 2-3).

CARBURETOR REMOVAL

THROTTLE VALVE

A CAUTION

Fuel knob should be in OFF position.

Remove the cover centre (page 2-3).

Loosen the carburetor top.

Remove the carburetor top and throttle valve from the carburetor.

Remove the throttle cable from the throttle valve while compressing the throttle valve spring.





Remove the valve plate set and jet needle.

Check the throttle valve and jet needle for scratch, wear or damage.



Remove the choke cable.

Disconnect the fuel tube from the carburetor.

Loosen the air cleaner connection guide band screw.



CARBURETOR BODY

A WARNING

Gasoline is extremely flammable and explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.

Remove the carburetor mounting bolts (2 nos.), insulator, gasket and carburetor.



DISASSEMBLY

Remove the drain tube.

Remove the float chamber screws (2 nos.) and float chamber.



Pull out the float pin and remove the float and float valve. Inspect the float valve and float for wear or damage.



Replace the float valve if it is damaged.

If the seat is damaged, replace the carburetor body.



FUEL SYSTEM

Remove the following:

- Main jet
- Needle jet holder
- Slow jet
- Air screw/ Spring/ Washer
- Throttle stop screw/ spring

NOTE:

Handle the jets with care. They can easily be scored or scratched.

Turn the air screw in and carefully count the number of turns until it seats lightly. Make a note of this to use as a reference when reinstalling the air screw.

NOTICE

If the air screw is over tightened against the seat, air screw seat will get damaged.

Blow open each air and fuel passages in the carburetor body with compressed air.

Check each part for wear or damage and replace them if necessary.





CARBURETOR ASSEMBLY


FUEL SYSTEM

Install the following:

- Throttle stop screw & spring
- Air screw, Spring & washer
- Slow jet
- Needle jet holder
- Main jet

NOTICE

Handle all jets with care. They can easily be scored or scratched.

Install the air screw/ spring/ washer/ O-ring and return it to its original position as noted during removal.

Perform the air screw adjustment procedure if a new air screw is installed (page 5-10).

Install the float and float valve in the carburetor body, then install the float pin through the body and float.





FLOAT LEVEL INSPECTION

With the float valve seated and the float gauge arm just touching the valve, measure the float level with the special tool as shown.

FLOAT LEVEL: 11.7 ± 0.5 mm (0.46 ± 0.02 in)

TOOL:

CARBURETOR FLOAT LEVEL GAUGE 070MJ – 001-I110

The float cannot be adjusted.

Replace the float assembly if it the float level is out of specification.

Install a new O-ring into the float chamber groove.





FUEL SYSTEM

Install the float chamber.

Install and tighten the screws (2 nos.) securely.



CARBURETOR INSTALLATION CARBURETOR BODY

Install the carburetor body with insulator, new gasket between air cleaner connecting housing.

Tighten the carburetor mounting bolts and air cleaner connecting tube band screw.

Install the fuel tube and drain tube.

Install the choke cable.

TORQUE: 10 N·m (1.0 kgf·m, 7.3 lbf-ft)

THROTTLE VALVE

Install the needle clip into the jet needle.





Install the jet needle into the throttle valve. Install the valve plate set.



Connect the fuel tube to the carburetor. Install the choke cable and tighten the mounting screw.



Image: Contract of the second seco



Install the throttle valve spring onto the throttle cable.

Connect the throttle cable to the throttle valve while compressing the throttle spring.

Install the throttle valve into the carburetor body.

Tighten the carburetor top securely.

After installation check that there is no fuel leaks.

Perform the following adjustment:

- Throttle grip free play (page 3-5)
- Idle speed adjustment

IDLE SPEED: 1,700 ± 100 min⁻¹ (rpm)

AIR SCREW ADJUSTMENT

NOTE:

- The air screw is factory preset and no adjustment is necessary unless the carburetor is overhauled or the air screw is replaced.
- Use a tachometer with graduations of 50 min⁻¹ (rpm) or smaller that will accurately indicate a 50 min⁻¹ (rpm) change.



FUEL SYSTEM

1. Turn the air screw until it seats lightly, then back it out to the specification given.

This is an initial setting prior to the final air screw adjustment.

NOTICE

Damage to the air screw seat will occur if the pilot screw is over tighten against the seat.

INITIAL OPENING: 1 3/4 turns out

- 2. Warm up the engine to operating temperature. Stop and go riding for 10 minutes is sufficient.
- 3. Stop the engine and connect the tachometer, according to the manufacturer's instructions.
- 4. Disconnect the PAIR control valve vacuum tube and plug the vacuum port.
- 5. Start the engine and adjust the idle speed with the throttle stop screw.

IDLE SPEED: 1,700 ± 100 min⁻¹ (rpm)

- 6. Turn the air screw in or out slowly to obtain the highest engine speed.
- 7. Lightly open the throttle 2 or 3 times, then adjust the idle speed with the throttle stop screw.
- 8. Turn the air screw in until the engine speed drops by 50 min⁻¹ (rpm).

FINAL OPENING: 1/2 more turn out

- Disconnect the plug from the vacuum tube and connect the PAIR control valve vacuum tube.
- 10. Readjust the idle speed with the throttle stop screw.

IDLE SPEED: 1,700 ± 100 min⁻¹ (rpm)

SECONDARY AIR SUPPLY SYSTEM PAIR CONTROL VALVE REMOVAL/ INSTALLATION

Remove the right side cover (page 2-4).

Remove the bolts (2 nos.) of PAIR control valve body from the body frame.







Remove the screws (2 nos.) from one way valve.

Inspect the one way valve for damage or fatigue. Replace if necessary.

Replace the one way valve if the seat rubber is cracked, Deteriorated or damaged, or if there is clearance between the reed and seat.

Install the one way valve and cover.

Install and tighten the screws (2 nos.) securely.

Install the bolts (2 nos.) and tighten it.



PAIR CHECK VALVE REMOVAL/ INSTALLATION

Disconnect the vacuum tube from the PAIR check valve.

Remove the screws (2 nos.) from PAIR check valve.

Disconnect the PAIR air cleaner hose.

Installation is in the reverse order of removal.



SYSTEM INSPECTION

Start the engine, and warm it up to normal operating temperature, then stop the engine.

Disconnect the air suction hose from the secondary air cleaner housing.

Check the air suction hose port is clean and free carbon deposits.

Check the PAIR check valve if the port is carbon fouled

Disconnect the vacuum hose from the intake pipe, and connect it to the vacuum pump.

Install the plug to the intake pipe.

Start the engine, and open the throttle slightly to be certain that air is sucked in through the air suction hose .

If the air is not drawn in, check the air suction hose for clogging.

With the engine running, gradually apply vacuum to the PAIR control valve vacuum hose.

Check that the air suction hose stop drawing air, and that the vacuum does not bleed.

SPECIFIED VACUUM: 66.7 kPa (500 mmHg)

If the air is drawn in or if the specified vacuum is not maintained, install a new PAIR control valve.

Remove the plug from the intake pipe.

Disconnect the vacuum hose from the vacuum pump, and connect it to the intake pipe.



FUEL STRAINER

REMOVAL

Remove the fuel tank cover lower (page 2-3).

Drain the fuel from the fuel tank into the approved gasoline container.

Disconnect the fuel tube from fuel lever.

Remove the screw and fuel lever.



Make sure not to damage painted surface of fuel tank Loosen the fuel cock lock nut.

Remove the fuel strainer and fuel cock assembly from the fuel tank.

Remove the fuel strainer and O-ring from the fuel cock.



CLEANING

Clean the fuel strainer with compressed air.



INSTALLATION

Install a new O-ring onto the fuel strainer, and install the fuel strainer into the fuel cock.

Install the fuel strainer and fuel cock assembly into the fuel tank.

Tighten the fuel cock lock nut.



Install the fuel lever while aligning the fuel cock tab with the fuel cock assy. hole.

Connect the fuel tube to the fuel lever.

Install and tighten the screw.

Install the fuel tank cover lower (page 2-3).



FUEL TANK

REMOVAL/INSTALLATION

A WARNING

Gasoline is extremely flammable and is explosive under certain condition. KEEP OUT OF REACH OF CHILDREN.

Remove the L & R side covers (page 2-5).

Remove bolts (4 nos.) to release tank stay.

Disconnect the fuel tube (page 3-4).

Disconnect the fuel drain tube.

Installation is in the reverse order of removal.

NOTE:

- · After installation, check that there are no fuel leaks
- Route the cable, wire and tubes properly (page 1-13).





6. ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION

6-1 ENGINE INSTALLATION

ENGINE REMOVAL

6-2

SERVICE INFORMATION

GENERAL

- The following components can be serviced with the engine installed in the frame:
 - Oil pump (section 4)
 - Carburetor (section 5)
 - Drive and driven pulleys/clutch (section 9)
 - Final reduction (section 10)
 - Alternator (section 11)
- The following components require engine removal for servicing:
 - Cylinder head/valves (section 7)
 - Cylinder/piston (section 8)
 - Crankcase/crankshaft (section 12)

SPECIFICATIONS

ITEM		SPECIFICATIONS	
Engine dry weight		25.7 kg (56.7 lbs)	_
	At draining	0.7 liter (0.7 US qt, 0.6 lmp qt)	Page 3-10
Engine on capacity	At disassembly	0.8 liter (0.8 US qt, 0.7 lmp qt)	Page 3-10

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Frame side - hanger bolt	1	10	-		Page 6-3
- hanger nut	1	10	69 (7.0, 51)		Page 6-3
Engine side - hanger bolt	1	10	_		Page 6-4
- hanger nut	1	10	49 (5.0, 36)		Page 6-4
Rr. cushion (upper side) bolt	1	10	39 (4.0, 29)		Page 6-4

6-4

ENGINE REMOVAL

Place the vehicle on its centre stand and support the frame securely.

Drain the engine oil if the crankcase is to be serviced (page 3-10).

Remove the throttle cable before removing the shock absorber mounting bolt.

- Disconnect the following: – Throttle cable (page 5-4)
- Choke cable (page 5-5)
- Spark plug cap (page 3-7)
- Opain plug cap (page 3-7)

Disconnect the air suction tube.

Disconnect the following:

- Starter motor 2P coupler
- Alternator wire 2P coupler
- Ignition pulse generator wire connector

Disconnect the starter motor ground wire from the frame by removing bolt (1 no.).

Release the starter motor and ACG harness lugs from the frame.

Disconnect the secondary air supply hose.

Disconnect the air duct from the crankcase cover by removing the band screw (1 no).







Remove the rear brake adjusting nut, disconnect the brake cable from the brake arm and remove the brake arm joint.

Remove the bolt (1 no.) from cable clamp and release the cable from the crankcase.



Remove the rear shock absorber upper mounting bolt (page 14-7).



Remove the engine mounting nut and pull out the mounting bolt from the left side.



Remove the engine from the frame.



Support the frame securely to prevent it from turning over.



Check the engine mounting bracket for damage or deterioration and replace if necessary.

If you want to remove the engine mounting bracket, remove the engine mounting bracket nut and pull out the mounting bolt from the left side.

Install the engine mounting bracket and mounting bolt.

Install and tighten the nut.

TORQUE: 69 N·m (7.0 kgf·m, 51 lbf·ft)



ENGINE INSTALLATION

NOTICE

Route the wires, tubes and cables properly (page 1-13). Install the engine into the frame. Insert the engine mounting bolt from the left side.

Install and tighten the nut.

TORQUE: 49 N·m (5.0 kgf·m, 36 lbf·ft)



Install rear shock absorber upper mount bolt. TORQUE: 39 N·m (4.0 kgf·m, 29 lbf·ft)



Install the brake cable to the crank case and cable clamp and tighten the bolt (1 no.) to the cable clamp.

Install the brake arm joint and connect the brake cable.

Install the rear brake adjusting nut.

Adjust the rear brake lever free play (page 3-15).

BRAKE CABLE ADJUSTING NUT BOLT CABLE CLAMP BRAKE ARM JOINT

Connect the air duct to the crankcase cover.

Clamp the air duct band from the crankcase cover and tighten the band screw.



ENGINE REMOVAL/INSTALLATION

Connect the secondary air supply hose.







Connect the starter motor ground wire from frame.

Connect the following:

- Starter motor 2P coupler
- Alternator wire 2P coupler
- Ignition pulse generator.

Connect the starter motor and ACG harness lugs to the frame.

Connect the vacuum tubes and fuel tube in carburetor (page 5-9).

Connect the air suction tube.

Install the following:

- Throttle valve (page 5-9)
- Choke cable (page 5-9)
- Spark plug cap (page 3-7).

Adjust the throttle lever free play.

COMPONENT LOCATION



COMPONENT LOCATION	7-0	CYLINDER HEAD INSPECTION	7-8
SERVICE INFORMATION	7-1	VALVE GUIDE REPLACEMENT	7-9
TROUBLESHOOTING	7-2	VALVE SEAT INSPECTION/REFACING	7-10
CYLINDER COMPRESSION	7-3	CYLINDER HEAD ASSEMBLY	7-15
INTAKE/EXHAUST SHROUDS	7-4	CYLINDER HEAD INSTALLATION	7-16
CYLINDER HEAD REMOVAL	7-5	CAMSHAFT REMOVAL	7-19
CYLINDER HEAD DISASSEMBLY	7-7	CAMSHAFT INSTALLATION	7-20

SERVICE INFORMATION

GENERAL

- The engine must be removed from the frame to service the rocker arms, camshaft, cylinder head and valves.
- Clean all disassembled parts with cleaning solvent and dry them by blowing them off with compressed air before inspection.
- Camshaft and rocker arm lubricating oil is fed through the oil passages in the cylinder head. Clean the oil passage before as sembling the cylinder head.

SPECIFICATIONS

[1	1 1	()
ITEM		STANDARD	SERVICE LIMIT	Page NO.	
Cylinder compression at 600 min ⁻¹ (rpm)		0.98 MPa (9.99 kgf/cm ² , 142 psi)	-	Page 7-3	
Valve clearance		IN	0.16 mm (0.006 in)	-	Page 3-8
		EX	0.16 mm (0.006 in)	-	Page 3-8
Comphoft	haight	IN	32.1087 - 32.1527	32.08 (1.263)	Page 7-20
Camsnatt neight		EX	31.94 - 31.85	31.80 (1.23)	Page 7-20
Cylinder head warpage			-	0.05 (0.002)	Page 7-20
	Arm I.D.	IN/EX	10.000 - 10.015 (0.3937 - 0.3943)	10.10 (0.398)	Page 7-7
Rocker arm	Shaft O.D.	IN/EX	9.972 - 9.987 (0.3926 - 0.3932)	9.91 (0.390)	Page 7-7
	Arm to shaft clearance	IN/EX	0.013 - 0.043 (0.0005 - 0.0017)	0.10 (0.004)	Page 7-9
Store O.D.		IN	4.975 - 4.990 (0.1959 - 0.1964)	4.90 (0.193)	Page 7-8
Mahua	Stem O.D.		4.955 - 4.970 (0.1955 - 0.1956)	4.90 (0.193)	Page 7-8
valve quide	Guide I.D.	IN/EX	5.000 - 5.012 (0.1969 - 0.1973)	5.03 (0.198)	Page 7-9
valve guide	Stem-to-guide clearance	IN	0.010 - 0.037 (0.0004 - 0.0015)	0.08 (0.003)	Page 7-9
		EX	0.030 - 0.057 (0.0012 - 0.0022)	0.10 (0.004)	Page 7-9
Valve spring Free length			29.78 (1.17)	27.87 (1.1)	Page 7-9
Valve seat width IN/E		IN/EX	0.7 (0.027)	_	_

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Bolt, head cover	2	6	12 (1.2, 8.8)		Page 7-18
Cyl. head comp stud bolt	2	6	6 (0.6, 4.4)		-
Lifter assy., tensioner screw	1	6	4 (0.4, 2.9)	Apply eng. oil	Page 7-18
Sprocket, cam bolt	2	5	9 (0.9, 6.6)	Apply eng. oil	Page 7-17
Head, cylinder nut	4	7	18 (1.8, 13.2)	Head Side	Page 7-17
Plate, breather separator screw	3	5	3 (0.3, 2.2)		Page 7-13
Shroud, exhaust bolt	1	10	7 (0.7, 5.1)		Page 7-4

7

Unit: mm (in)

TOOLS

Valve spring compressor	070GE – 001-l100
Valve guide reamer	070MH – 001-I160
Valve guide driver	070ND – 006-l150
Seat cutter, 22 mm (45° IN)	070MH – 003-I150
Seat cutter, 27.5 mm (45° EX)	070MF – 003-I180
Flat cutter, 24 mm (32° IN)	070MH – 002-I180
Flat cutter, 28 mm (32° EX)	070MH – 002-I120
Interior cutter, 26 mm (60° EX)	070MF – 004-I150
Cutter holder	070MH – 005-I150
Tensioner lifter stopper	070MG – 0010100

TROUBLESHOOTING

Engine top-end problems usually affect engine performance. These can be diagnosed by a compression test, or by tracing top-end noises with a sounding rod or stethoscope.

Compression too low, hard starting or poor performance at low speed.

- Valves
 - Incorrect valve clearance
 - Burned or bent valve
 - Incorrect valve timing
 - Broken valve spring
 - Uneven valve seating
- Cylinder head
 - Leaking or damaged cylinder head gasket
 - Warped or cracked cylinder head
 - Loose spark plug
- Faulty cylinder or piston (section 8)

Compression too high

• Excessive carbon built-up on piston or combustion chamber

Excessive smoke

- Worn valve stem or valve guide
- Damaged stem seal
- Faulty cylinder or piston (section 8)

Excessive noise

- Incorrect valve clearance
- Sticking valve or broken valve spring
- Worn or damaged camshaft
- Worn or damaged rocker arm and/or shaft
- Worn or damaged cam sprocket teeth
- Loose or worn cam chain
- Worn or damaged cam chain tensioner
- Loose spark plug
- Faulty connecting rod or crankshaft (section 12)
- Worn,damaged or pitted ball bearing.

Rough idle

• Low cylinder compression

CYLINDER COMPRESSION

A WARNING

If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area.

Warm up the engine to normal operating temperature.

Stop the engine.

Disconnect the spark plug cap and remove the spark plug.

Install the compression gauge attachment in a spark plug hole.

Connect the compression gauge to the attachment.

Open the throttle all the way and crank the engine with the starter motor or apply kick 5-6 times and check the gauge reading.

NOTICE

Crank the engine until the gauge reading stops rising. The maximum reading is usually reached within 4-7 seconds.

STANDARD: 980 KPa (9.99 kgf/cm², 142 psi) at 600 min⁻¹ (rpm)

If compression is high, it indicates that carbon deposits have accumulated on the combustion chamber and/or the piston crown.

If compression is low, pour 3-5 cc (0.1-0.2 oz) of clean engine oil into the cylinder through the spark plug hole and recheck the compression.

If the compression increases from the previous value, check the cylinder, piston and piston rings.

- Worn piston ring
- Worn cylinder and piston

If compression is the same as the previous valve, check the valves for leakage, cylinder head bolt looseness.



INTAKE/EXHAUST SHROUDS

REMOVAL

Remove the bolts (3 nos.), gasket and ASV hose from the head assembly.

Remove the following:

- Carburetor (page 5-4)
- Cooling fan cover (page 11-2)
- Muffler assembly (page 2-9)

Remove the nuts (2 nos.) and insulator.

Remove the screws (3 nos.), bolt (1 no.), intake shroud and exhaust shroud.





INSTALLATION

Install the intake shroud and exhaust shroud. Install and tighten the screws (3 nos.). Install and tighten the bolt (1 no.) to the specified torque. **TORQUE: 7 N·m (0.7 kgf·m, 5.1 lbf·ft)**



Install the insulator and tighten the nuts.

Install the new gasket, air supply hose and tighten the bolts (3 nos.) securely.

Install the following:

- Muffler assembly (page 2-9)
- Cooling fan cover (page 11-4)
- Carburetor (page 5-8)



CYLINDER HEAD REMOVAL

Remove the following:

- Engine (page 6-2)
- Intake/Exhaust shrouds and seal (page 7-4)
- Cooling fan cover (page 11-2)
- Spark plug (page 3-7)
- Muffler assembly (page 2-9)

Disconnect crankcase breather pipe from cylinder head cover (page 3-6).

Remove the bolts (2 nos.) and cylinder head cover.

Rotate the cooling fan clockwise and align the "T" mark on the cooling fan with the index mark of the right crankcase.

Make sure that the piston is at TDC (Top Dead Center) on the compression stroke.

The rocker arms should be loose.

Remove the cam chain tensioner lifter plug.

Install the stopper tool to the cam chain tensioner lifter.

If the rocker arms are tight, rotate the crankshaft one turn and realign the "T" mark with the index mark.







Turn the tensioner shaft clockwise with the stopper tool to retract the tensioner, then insert the stopper fully to hold the tensioner in the fully retracted position.

TOOL:

Tensioner lifter stopper 070MG-0010100



Remove the cam sprocket bolts (2 nos.) while holding the crankshaft. Remove the cam sprocket from the camshaft and the cam chain from the sprocket.

Suspend the cam chain with a piece of wire to prevent it from falling into the crankcase.

Remove the tensioner shaft stopper tool, O-ring, bolts (2 nos.), tensioner lifter and gasket.





NUTS BOLTS



Remove the nuts (4 nos.). Remove the bolts (2 nos.) and cylinder head.

Remove the cylinder head gasket and dowel pins. Remove the cam chain guide from the cylinder. Check the cam chain guide for excessive wear or damage.

CYLINDER HEAD DISASSEMBLY

Remove the camshaft (page 7-19).

Screw 6 mm screw/bolt (1 no.) into the threaded hole in the rocker arm shaft and pull the shaft out of the camshaft holder.

Remove the rocker arm.

Remove the other rocker arm shaft and rocker arm.

Remove the insulator carburetor.



INSPECTION

Inspect the rocker arms and shafts for wear, damage or clogged oil hole.

Measure the rocker arm I.D.

SERVICE LIMIT: 10.10 mm (0.398 in)

Measure the rocker arm shaft O.D.

SERVICE LIMIT: 9.91 mm (0.390 in)



Compress the valve springs using the valve spring compressor, and remove the valve cotters.

TOOLS:

Valve spring compressor 070GE - 001-I100



To prevent loss of tension, do not compress the valve springs more than necessary to remove the cotters.



VALVE SPRING COMPRESSOR

Remove the valve spring compressor, then remove the retainer, spring and valve.

Remove the stem seals and spring seat. Do not reuse the old stem seals.

NOTICE

Mark all parts during disassembly so they can be placed back in their original locations.



CYLINDER HEAD INSPECTION

Remove the carbon deposits from the combustion chamber and clean off the head gasket surfaces.

Check the spark plug hole and valve areas of the combustion chamber for cracks.



Check the cylinder head for warpage with a straight edge and feeler gauge.

SERVICE LIMIT: 0.05 mm (0.002 in)



Measure the free length of the valve springs.

SERVICE LIMITS: 27.87 mm (1.09 in)

Insert the valve into the guide and check that the valve moves smoothly.

Check each valve for bending, burning, scratches or abnormal stem wear.

Measure and record the valve stem O.D.

SERVICE LIMIT: 4.90 mm (0.193 in)



Ream the valve guide to remove any carbon buildup before measuring the guide.

Insert the reamer from the combustion chamber side of the head and always rotate the reamer clockwise.

TOOL:

Valve guide reamer 070MH – 001I160

Measure and record each valve guide I.D.

SERVICE LIMIT: 5.03 mm (0.198 in)

Calculate the valve stem-to-guide clearance.

SERVICE LIMITS: Intake: 0.08 mm (0.003 in)

Exhaust: 0.10 mm (0.004 in)

If the stem-to-guide clearance exceeds the service limits, determine if a new guide with standard dimensions would bring the clearance within tolerance. If so, replace any guides as necessary and ream to fit.

If the stem-to-guide clearance exceeds the service limits with new guides, also replace the valve.

NOTICE

Inspect and reface the valve seats whenever the valve guide are replaced (page 7-11).





VALVE GUIDE REPLACEMENT

Chill new valve guides in the freezer section of a refrigerator for about an hour.

Heat the cylinder head to $130 - 140^{\circ}$ C (275 - 290°F) with a hot plate or oven.



Using a torch to heat the cylinder head may cause warpage.

A WARNING

Wear heavy gloves to avoid burns when handling the heated cylinder head.

Support the cylinder head and drive the valve guides out of the cylinder head from the combustion chamber side.

TOOL:

Valve guide driver 070ND – 006l150

Install the new clip to the new valve guide. Drive in the valve guide from the camshaft side of the cylinder head while the cylinder head is still heated.

TOOL:

Valve guide driver

070ND - 006l150





NOTE:

Install the valve guide while measuring the valve guide height from the cylinder head.

SPECIFIED HEIGHT:

IN/EX: 9.7 - 9.9 mm (0.382 - 0.389 in)

Let the cylinder head cool to room temperature.



Ream the new valve guides.

Insert the reamer from the combustion chamber side of the head and always rotate the reamer clockwise.

TOOL:

Valve guide reamer 070MH – 001I160

- Take care not to tilt or lean the reamer in the guide while reaming.
- Use cutting oil on the reamer during this operation.

Clean the cylinder head thoroughly to remove any metal particles after reaming and reface the valve seat (page 7-11).



VALVE GUIDE REAMER

VALVE SEAT INSPECTION/ REFACING

INSPECTION

Clean all intake and exhaust valves thoroughly to remove carbon deposits.

Apply a light coating of Prussian Blue to each valve face.

Tap the valve against the valve seat several times using a hand-lapping tool, without rotating the valve, to make a clear pattern.

Remove the valve and inspect the valve seat face.

NOTICE

The valve cannot be ground. If the valve face is burned or badly worn or if it contacts the seat unevenly, replace the valve.

Inspect the valve seat face for:

- Uneven seat width:
 - Bent or collapsed valve stem:

Replace the valve and reface the valve seat

- Damaged face:
 - Replace the valve and reface the valve seat





- Contact area (too high or too low area):
 - Reface the valve seat

•



Inspect the width of valve seat.

The valve seat contact should be within the specified width and even all around the circumference.

STANDARD:	1.0 mm (0.04 in)
-----------	------------------

SERVICE LIMIT: 1.5 mm (0.06 in)

If the valve seat width is not within specification, reface the valve seat (page 7-11).



VALVE SEAT REFACING

NOTICE

- Follow the reface manufacturer's operating instructions.
- Be careful not to grind the seat more than necessary.



If the contact area is too high on the valve, the seat must be lowered using a 32° flat cutter.

If the contact area is too low on the valve, the seat must be raised using a 60° inner cutter. Refinish the seat to specifications, using a 45° finish cutter.



Using a 45° cutter, remove any roughness or irregularities from the seat.

TOOLS:

Valve seat cutter, 22 mm (45° IN)070MH - 003I150

Valve seat cutter, 27.5 mm (45° EX) 070MF – 003l180

Valve seat cutter holder 070MH - 005I150



Using a 32° cutter, remove 1/4 of the existing valve seat material.

TOOLS:

Valve seat cutter, 24 mm (32° IN)	07780 - 0012900
Valve seat cutter, 28 mm (32° EX)	070MH - 002l120
Valve seat cutter holder	070MH - 005l150



Using a 60° cutter, remove 1/4 of the existing valve seat material.

TOOLS:

Valve seat cutter, 30 mm (60° IN/EX) 07780 – 0014000
Valve seat cutter holder	070MH – 005l150



Using a 45° cutter, cut the seat to the proper width. Make sure that all pitting and irregularities are removed.



After cutting the seat, apply lapping compound to the valve face, and lap the valve using light pressure.

NOTICE

- Excessive lapping pressure may deform or damage the seat.
- Change the angle of lapping tool frequently to prevent uneven seat wear.
- Lapping compound can cause damage if it enters between the valve stem and guide.

After lapping, wash any residual compound off the cylinder head and valve and recheck the seat contact.

BREATHER SEPARATOR CLEANING

Bend up the lock tabs of the breather separator plate. Remove the three screws and breather separator plate.





Clean the separator plate and inside of the cylinder head cover thoroughly.

Install the breather separator plate and tighten the screw (3 nos.) to specified torque.

TORQUE: 3 N·m (0.3 kgf·m, 2.2 lbf·ft)

Bend the lock tabs of the plate against the screw heads.

Installation is in the reverse order of removal.



ASSEMBLY



Blow through the oil passage in the cylinder head with compressed air.

Install the spring seats and new stem seals.

Lubricate the valve stems with clean engine oil and insert the valves into the cylinder head.

NOTICE

To avoid damage to the stem seal, turn the valve slowly when inserting.



Install the valve springs with the tightly wound coils facing the cylinder head.

Install the spring retainer.



CYLINDER HEAD ASSEMBLY

Compress the valve springs and install the valve cotters.

TOOL:





Support the cylinder head so that the valve heads will not contact anything that causes damage.

Seat the cotters firmly using two hammers as shown.

Hold one hammer on the valve stem and gently tap in with the other hammer.





Install the rocker arms and shafts into the holder.

Install the insulator carburettor.

NOTICE

Install the rocker arm shaft with the threaded side facing out.



CYLINDER HEAD INSTALLATION

Install the cam chain guide so that its bosses are placed in the grooves in the cylinder.

Install the dowel pins and a new gasket.



Install the cylinder head.

Suspend the cam chain to keep it from falling into the cylinder.

Install the washers and cylinder head nuts (4 nos.), then loosely tighten the nuts in a crisscross pattern in 2 or 3 steps.

Install the cylinder head side bolt (2 nos.) loosely tighten them.



Install the stopper tool to the cam chain tensioner lifter.

Turn the cam chain tensioner lifter shaft clockwise with the stopper tool to retract the cam chain tensioner lifter, then insert the stopper fully to hold the cam chain tensioner lifter.

Install the cam chain tensioner lifter and tighten the bolts securely.



Turn the cooling fan clockwise slowly and align the "T" mark on the cooling fan with the index mark of the right crankcase.



Align the timing mark (index line) on the cam sprocket with the top surface of the cylinder head.

Install the cam chain onto the cam sprocket, then install the cam sprocket onto the camshaft.

Make sure that the timing mark (index line) aligns with the top surface and the "T" mark aligns with the index mark.

Cover the cam chain opening with a shop towel to prevent from the cam sprocket bolts falling into the crankcase.



Align the bolt holes in the camshaft and cam sprocket, and install the cam sprocket bolts.

Tighten the cam sprocket bolts while holding the crankshaft.

TORQUE: 9 N·m (0.9 kgf·m, 6.5 lbf·ft)

Tighten the cylinder head nuts to the specified torque.

TORQUE: 18 N·m (1.8 kgf·m, 13 lbf·ft)





Apply liquid sealant (Three bond 5211C or SHINE SU-SILICON KE45T or Three bond 1215 or equivalent) to

the semicircular area of rubber seal as shown.

Install a new gasket into the groove in the cylinder head cover.

Install the cylinder head cover on the cylinder head.



Install new rubber washer to the cylinder head cover bolts.



BOLTS



LIFTER PLUG

Install and tighten the cylinder head cover bolts. TORQUE: 12 N·m (1.2 kgf·m, 9 lbf·ft)

Remove the stopper tool from the tensioner lifter.

Install the plug with a new O-ring and tighten it. **TORQUE: 4 N·m (0.4 kgf·m, 2.9 lbf·ft)** Install the cam chain tensioner hole cap.

Install the following:

- Spark plug (page 3-7)
- Muffler assembly (page 2-9)
- Intake/exhaust shroud (page 7-4)
- Cooling fan cover (page 11-4)
- Engine (page 6-4)



CAMSHAFT REMOVAL

Remove the following:

- Engine (page 6-2)
- Cooling fan cover (page 11-2)
- Spark plug (page 3-7)
- Cam sprocket (page 7-6)

Remove the camshaft retainer bolt (1no.).



Remove the camshaft.

NOTE:

Do not hammer the camshaft out as it can damage the camshaft as well as the spring used for decompression mechanism.



NOTICE

For camshaft removal no need to open cylinder head nut/ bolts.



INSPECTION

Check each cam lobe for wear, scratches or scoring.

Measure the cam lobe height.

SERVICE LIMITS: Intake: 32.084 mm (1.2631 in) Exhaust: 31.80 mm (1.23 in)

Turn the outer race of each camshaft bearing with your finger.

The bearing should turn smoothly and quietly.

Check that the inner race of each bearing fits tightly on the camshaft.

Replace the camshaft assembly if the bearing does not turn smoothly, quietly, or if it fits loosely on the camshaft.

CAMSHAFT RUNOUT

Support both ends of the camshaft and check the camshaft runout with a dial indicator.

Actual runout is 1/2 the total indicator reading.

SERVICE LIMIT: 0.05 mm (0.002 in)





CAMSHAFT INSTALLATION

NOTICE

Clean each parts of the assembly in solvent and lubricate them with clean engine oil.

Install the camshaft into the cylinder head by aligning the cam lobes with the cutouts in the holder.

Install the retainer bolt (1 no.).

Install the following:

- Cam sprocket (page 7-17).
- Cooling fan cover (page 11-4)
- Engine (page 6-4)



MEMO

COMPONENT LOCATION




8. CYLINDER/PISTON

COMPONENT LOCATION	8-0	PISTON REMOVAL	8-3
SERVICE INFORMATION	8-1	PISTON INSTALLATION	8-5
TROUBLESHOOTING	8-1	CYLINDER INSTALLATION	8-6
CYLINDER REMOVAL	8-2		

SERVICE INFORMATION

GENERAL

- To service the cylinder and piston, the engine must be removed from the frame. ٠
- Take care not to damage the cylinder wall and piston.
- Be careful not to damage the mating surfaces when removing the cylinder. •

SDECIEIC ATIONS

SPECIFIC/	ATIONS				Unit: mm (in)
	ITEM		STANDARD	SERVICE LIMIT	Page NO.
	I.D.		50.005 - 50.015 (1.9686 - 1.9690)	50.1 (1.972)	Page 8-2
Culinder	Out-of-round		-	0.05 (0.002)	Page 8-3
Cylinder	Taper		-	0.05 (0.002)	Page 8-3
	Warpage		-	0.05 (0.002)	Page 8-3
	Piston O.D. at 5 (0.2)	from bottom	49.980 - 49.995 (1.9677 - 1.9683)	49.9 (1.964)	Page 8-4
	Piston pin hole I.D.		12.002 - 12.008 (0.4725 - 0.4727)	12.04 (0.474)	Page 8-4
Piston	Piston pin O.D.		11.994 - 12.000 (0.4722 - 0.4724)	11.98 (0.471)	Page 8-4
piston pin.	Piston pin Piston-to-piston pin clearance		0.002 - 0.014 (0.0001 - 0.0006)	0.02 (0.001)	Page 8-4
piston ring	Piston ring-to-ring groove clearance	Top Second	0.010 - 0.025 (0.0004 - 0.0010) 0.020 - 0.070 (0.0008 - 0.0028)	0.45 (0.018)	Page 8-3
Distanting and gap Top/ Second		Top/ Second	0.15 - 0.45 (0.0006 - 0.0015)	0.08 (0.03)	Page 8-4
		Oil (side rail)		_	_
Cylinder-to-pis	ston clearance		0.010 – 0.035 (0.0004 - 0.0013)	0.10 (0.004)	Page 8-2
Connecting rod small end I.D.		12.010 - 12.028 (0.4728 - 0.4735)	12.05 (0.474)	Page 8-4	
Connecting ro	d-to-piston pin clearand	e .	0.010 - 0.034 (0.0003 - 0.0013)	0.05 (0.002)	Page 8-4

TROUBLESHOOTING

Compression too low, hard starting or poor performance at low speed

- Worn, stuck or broken piston ring .
- Worn or damaged cylinder or piston •

Excessive smoke

- ٠ Worn cylinder, piston or piston rings
- Improper installation of piston rings
- Scored or scratched piston or cylinder wall •

Abnormal noise

- Worn piston pin or piston pin hole •
- Worn connecting rod small end •
- ٠ Worn cylinder, piston or piston rings

TOOLS

Slider base piston

070SRTKSP008

CYLINDER REMOVAL

Remove the following:

- Cylinder head (page 7-5)
- Cam chain guide
- Cam chain tensioner (page 7-6)

Check the cam chain guide and cam chain tensioner for excessive wear or damage, replace them if necessary.

CAUTION

Be careful not to damage the sliding surface of the piston and cylinder.

Lift the cylinder, and remove it, be careful not to damage the piston with the stud bolts.

TOOL:

Slider base piston

070SRTKSP008

Remove the dowel pins.

Clean any gasket material off the mating surface of the cylinder, be careful not to damage the mating surface.





INSPECTION

Inspect the cylinder bore for scratch or wear. Measure the cylinder I.D. at three levels in an X and Y axis.

Take the maximum reading to determine the cylinder wear.

SERVICE LIMIT: 50.10 mm (1.972 in)

Calculate the cylinder-to-piston clearance.

Refer to page 8-4 for measurement of the piston O.D.

SERVICE LIMIT: 0.10 mm (0.004 in)

Calculate the cylinder taper and out-of-round at three levels in an X and Y axis. Take the maximum reading to determine the taper and out-of-round.

SERVICE LIMITS: Taper: 0.05 mm (0.002 in)

Out-of-round: 0.05 mm (0.002 in)

The cylinder must be rebored and an oversize piston fitted if the service limit is exceeded.

The cylinder must be rebored so that the clearance between oversize piston and rebored cylinder should be maintained between 0.010-0.040 mm (0.0004-0016).

NOTE:

In case of cylinder reboring, use 'Ring Set, Piston' & 'Gasket, Cylinder Head' as per the size of piston.





Check the top of the cylinder for warpage with a straight edge and feeler gauge.

SERVICE LIMIT: 0.05 mm (0.002 in)



PISTON REMOVAL

Place a clean shop towel over the crankcase to prevent the clip from falling into the crankcase.

TOOL:

Slider base piston

070SRTKSP008

Remove the piston pin clips with the pliers.

Push the piston pin out of the piston and connecting rod, and remove the piston.



Spread each piston ring and remove it by lifting up at a point opposite the gap.

Clean carbon deposits from the piston.

CAUTION

- Do not damage the piston ring by spreading the ends too far.
- Be careful not to damage the piston when the piston rings are being removed.
- Clean carbon deposits from the ring grooves with a old piston ring. Never use a wire brush; it will scratch the groove.



INSPECTION

Inspect the piston rings and replace them if they are damaged. Inspect the piston rings for movement by rotating the rings. The rings should be able to move in their grooves without catching.

Push the ring until the outer surface of the piston ring is nearly flush with the piston and measure the ring-to-ring groove clearance.

SERVICE LIMITS: Top: 0.08 mm (0.003 in)

Second: 0.08 mm (0.003 in)



CYLINDER/PISTON

Insert each piston ring into the bottom of the cylinder squarely using the piston.

Measure the ring end gap.

SERVICE LIMITS: Top: 0.45 mm (0.018 in)

Second: 0.45 mm (0.018 in)



Measure the piston O.D. 90° to the piston pin hole and at point 10 mm (0.4 in) from bottom of the piston skirt.

SERVICE LIMIT: 49.91 mm (1.966 in)

Compare this measurement against the maximum cylinder I.D. measurement and calculate the cylinder-to-piston clearance (page 8-2).

SERVICE LIMIT: 0.10 mm (0.004 in)



Measure piston pin hole I.D. in an X and Y axis. Take the maximum reading to determine the I.D.

SERVICE LIMIT: 12.04 mm (0.474 in)

Measure the piston pin O.D. at three points.

SERVICE LIMIT: 11.98 mm (0.471 in)

Calculate the piston-to-piston pin clearance.

SERVICE LIMIT: 0.02 mm (0.0007 in)



Measure the connecting rod small end I.D.

SERVICE LIMIT: 12.04 mm (0.474 in)

Calculate the connecting rod-to-piston pin clearance. **SERVICE LIMIT: 0.05 mm (0.001 in)**



8-4

PISTON INSTALLATION

Carefully install the piston rings into the piston ring grooves with the markings facing up.

NOTICE

- Do not damage the piston ring by spreading the ends too far.
- Do not confuse the top and second rings.
- To install the oil ring, install the spacer first, then install the side rails.
- After installing the rings they should rotate freely, without sticking.



Stagger the piston ring end gaps 120° degrees apart from each other.

Stagger the side rail end gaps as shown clamp.





Clean any gasket material from the cylinder mating surface of the crankcase.

When cleaning the cylinder mating surface, place a shop towel over the cylinder opening to prevent dust or dirt enter the engine.

Apply engine oil solution to the connecting rod small end inner surface.



CYLINDER/PISTON

Apply engine oil to the piston pin outer surface.

Install the piston with the "IN" mark toward the intake side and insert the piston pin through the piston and connecting rod.

TOOL:

Slider base piston

070SRTKSP008



Install new piston pin clips into the grooves of the piston pin hole.

NOTICE

Place a shop towel over the crankcase opening to prevent piston pin clips from falling into the crankcase.



- Make sure that the piston pin clips are seated securely.
- Do not align the piston pin clip end gap with the piston cutout.



CYLINDER INSTALLATION

Install the dowel pins and a new gasket.

Apply engine oil to the cylinder wall, piston and piston ring outer surfaces.



Route the cam chain through the cylinder and install the cylinder over the piston while compressing the piston rings with your fingers.

Install the following:

- Cam chain guide
- Cylinder head (page 7-16)
- Cam chain tensioner (page 7-16).



Be careful not to damage the piston rings and cylinder wall.



MEMO

COMPONENT LOCATION



9. KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

COMPONENT LOCATION	9-0	DRIVE PULLEY REMOVAL	9-10
SERVICE INFORMATION	9-1	CLUTCH/DRIVEN PULLEY	
TROUBLESHOOTING	9-2	REMOVAL	9-12
KICKSTARTER	9-3	CLUTCH/DRIVEN PULLEY	9-16
	0.0	INSTALLATION	9-10
STARTER FINION	9-0	DRIVE PULLEY INSTALLATION	9-18

SERVICE INFORMATION

GENERAL

WARNING

Never operate the starter motor with the left crankcase cover removed.

Avoid getting grease and oil on the V-belt and pulley drive faces in order to prevent belt slippage.

Do not apply grease to the movable drive face and weight rollers.

SPECIFICATIONS

SPECIFICA	IUNS		Unit: mm (in)		
	ITEM	STANDARD		SERVICE LIMIT	Page NO.
Drive belt width		19.5 (0.76)		19.2 (0.75)	Page 9-14
	Busing I.D.	22.035 – 22.085 (0.8675 – 0.8695)	22.60 (0.889)	Page 9-11
face	Boss O.D.	21.4 - 21.6 (0.8665 - 0.8671)		21.0 (0.826)	Page 9-11
Weight roller O. D.		19.92 - 20.08 (0.705 - 0.712)		19.40 (0.763)	Page 9-11
Clutch	Outer I.D.	125.0 - 125.2 (4.921 - 4.929)		125.5 (4.941)	Page 9-15
Lining thickness		4.0 (0.12)		2.0 (0.08)	Page 9-15
		FCC	99.6 (3.921)	85.4 (3.36)	Page 9-15
Driven pulley	Face spring nee length	EXEDY	101.3 (3.99)	92.2 (3.62)	Page 9-15
	Driven face O.D.	33.965 - 33.985 (1.3372 - 1.3380)		33.94 (1.336)	Page 9-15
Movable driven face I.D.		34.000 - 34.025 (1.3386 - 1.3396)		34.06 (1.341)	Page 9-16

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Plate, L. cover screw	5	4	3 (0.3, 2.2)		Page 9-7
Kick starter pedal bolt	1	8	29 (2.9, 22)		Page 9-7
Face comp., drive nut	1	14	93 (9.3, 68.5)	Apply eng. oil	Page 9-19
Outer comp., clutch nut	1	12	49 (4.9, 36.1)		Page 9-18
Plate assy., drive nut	1	28	54 (5.4, 39.8)		Page 9-17

MULTIPLE SOURCED COMPONENT: DRIVEN FACE ASSEMBLY

MAKER	F.C.C.	EXEDY
IDENTIFICATION MARKS	F.C.C.	

NOTE: Parts are not interchangeable with other makers.

REFERENCE: For maker wise child part details refer parts catalogue.

TOOLS

Clutch center holder	070MB – KPL – I200
Universal holder	070MB – KPL – I100
Socket wrench, 39 x 41 mm	070MA – KPL – I300
Bearing driver	070MD – KPL – I100
Bearing remover (Driven face)	070MC – KWP – 410
Bearing installer (Driven face)	070NC – KWP – 410
Clutch spring compressor	070ME – KWP – 110

TROUBLESHOOTING

Engine starts but vehicle won't move

Excessive carbon built-up on piston or combustion chamber

Excessive smoke

- Worn drive belt •
- Damaged ramp plate
- Worn or damaged clutch shoe •
- Broken driven face spring •

Engine stalls or vehicle creeps Broken clutch shoe spring

Poor performance at high speed or lack of power Worn drive belt

- Weak driven face spring ٠
- Worn weight rollers ٠
- Contaminated pulley faces ٠

KICKSTARTER

LEFT CRANKCASE COVER REMOVAL

Remove the bolt A and loosen the bolt B from the air filter.



Remove the rear brake cable holder bolts (2 nos.) and remove the cable holder.

Loosen the air duct band screw and disconnect the air duct from the left crankcase cover.

Remove the left crankcase cover bolts (8 nos.).

Remove the left crankcase cover.

Remove the dowel pins (2 nos.).





DISASSEMBLY

Raise the lock tabs of the left crankcase cover plate. Remove the screws (5 nos.) and left crankcase cover plate.



KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

Remove the kickstarter driven gear while turning the kickstarter pedal.

Remove the thrust washer.



Before removing the kickstarter pedal, mark the pedal and spindle for proper installation position.

Remove the bolt (1 no.) and the kickstarter pedal.



Carefully unhook the return spring from the pin on the crankcase cover.

Remove the snap ring and washer.

Remove the kickstarter spindle and return spring.





Remove the spindle bushing and collar.

INSPECTION

Inspect the following:

- Spindle for wear or damage
- Gear teeth for wear or damage
- Return spring for weakness or damage
- Bushing for wear or damage





- Friction spring for weakness or damage
- Starter ratchet teeth of the drive pulley face for wear or damage



- Crankcase cover bearings for wear or damage.



CRANKCASE COVER ASSEMBLY



Install the bushing and collar into the left crankcase cover. Apply grease (0.1 - 0.3 g) to the kickstarter spindle journal.



Install the spindle and return spring into the crankcase cover and hook the short end of the spring to the spindle groove. (Do not hook the long end of the spring.)

Install the washer and snap ring to secure the spindle.

Make sure that the snap ring is seated into the spindle groove securely, then hook the long end of the return spring to the pin on the crankcase cover.



KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

Install the kickstarter pedal in its original position as marked during removal and tighten the bolt (1 no.).

TORQUE: 29 N·m (3.0 kgf·m, 22 lbf·ft)



Install the thrust washer onto the crankcase cover.



tion spring hook return the pedal ar.

Apply grease (0.2 - 0.3 g) to the driven gear shaft and friction spring sliding area.

Turn the kickstarter pedal and hold it.

Install the driven gear while aligning the friction spring hook with the groove in the crankcase cover, and return the pedal to engage the driven gear and spindle gear.

Install the left crankcase cover plate and tighten the screws (5 nos.).

TORQUE: 3 N·m (0.3 kgf·m, 2.2 lbf·ft)

Bend the lock tabs of the cover plate against the screw heads.



GREASE FRICTION SPRING

LEFT CRANKCASE COVER INSTALLATION

Install the dowel pins (2 nos.) in the left crankcase.



Apply liquid gasket only on highlighted surface between mark (A) & (B) on left crankcase cover as shown in below image.



Install the left crankcase cover and cable holder, and tighten the bolts (8 nos.) in a crisscross pattern in 2 or 3 steps.

Install the rear brake cable in to the cable holder.

Connect the air duct to the left crankcase cover and tighten the band screw (1 no.) securely.

After installation, check that the kickstarter pedal operates properly.

Install and tighten the bolt A & bolt B from the air filter.





STARTER PINION

REMOVAL

Remove the left crankcase cover (page 9-3). Remove the starter pinion holder.

Remove the starter pinion.



INSPECTION

Check that the starter pinion operates smoothly.

Check the pinion gear teeth and shaft for wear or damage.

Check the starter driven gear teeth of the drive pulley face for wear of damage.



INSTALLATION

Apply grease (0.1 - 0.3 g) to the starter pinion shaft journal. Install the starter pinion into the left crankcase.



Install the starter pinion holder by aligning its bosses with the grooves in the left crankcase.

Install the left crankcase cover (page 9-8).



DRIVE PULLEY REMOVAL

Remove the left crankcase cover (page 9-3).

Hold the drive pulley face with the special tool, and remove the drive pulley face nut.

TOOL:

Clutch center holder

070MB - KPL- 1200

DRIVE PULLEY FACE NUT

Remove the washer and drive pulley face fin and drive face.

Remove the drive belt from the crankshaft.





Remove the drive face boss and movable drive face assembly while holding the back of the face (ramp plate).



KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

DRIVE PULLEY ASSEMBLY

- Drive face boss
- Ramp plate
- Slide pieces
- Weight rollers



INSPECTION

WEIGHT ROLLER

Check each roller for wear or damage. Measure the weight roller O.D. SERVICE LIMIT: 19.40 mm (0.764 in)



DRIVE FACE BOSS

Check the drive face boss for wear or damage. Measure the boss O.D. SERVICE LIMITS: 21.0 mm (0.826 in)



Measure the drive face bushing I.D.

SERVICE LIMITS:

22.60 mm (0.889 in)



CLUTCH/DRIVEN PULLEY REMOVAL

Remove the drive pulley (page 9-10).

Hold the clutch outer with the special tool and remove the clutch outer nut.

TOOL:

Universal holder

r 070MB – KPL – I100

Remove the clutch outer.

Remove the clutch/driven pulley assembly and drive belt.





Set the clutch spring compressor onto the clutch/driven pulley, aligning the bosses with the holes in the clutch.

TOOL:

Clutch spring compressor 070ME – KWP – 110

Hold the clutch spring compressor in a vice.



Remove the clutch/driven pulley nut using the socket wrench.

TOOL:

Socket wrench, 39 x 41 mm 070MA – KPL– I300

Loosen the spring compressor and remove the following:

- Driven pulley
- Driven face spring
- Spring seat
- Clutch

For clutch outer and clutch shoe lining inspection, refer to (page 9-15).



Remove the E-clips (3 nos.) and plate.



Remove the clutch shoe springs and clutch shoes from the clutch drive plate.

Remove the damper rubbers (3 nos.).



Remove the seal collar.

Pull out the guide roller pins (3 nos.).

Remove the moveable driven face from the driven face.







DRIVEN FACE BEARING

REPLACEMENT

Remove the needle bearing using the special tools.

TOOLS:

Bearing remover (Driven face) 070MC - KWP- 410

NEEDLE BEARING

Remove the snap ring and drive the ball bearing out of the driven face.

Pack new ball bearing cavities with grease.

Drive the ball bearing into the driven face with the sealed side facing down.

TOOL:

Bearing Driver 070MD – KPL– I100

Install the snap ring properly into the driven face groove.



Pack the inside of the driven face with 5.0-5.5 g of grease.

Apply grease to a new needle bearing.

Press the needle bearing into the driven face with the markings facing up.

TOOLS:

Bearing installer (Driven face) 070NC-KWP-410



INSPECTION

DRIVE BELT

Check the drive belt for cracks, separation or abnormal or excessive wear.

Measure the drive belt width.

SERVICE LIMITS: 19.2 mm (0.76 in)



KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

CLUTCH OUTER

Check the clutch outer for wear or damage. Measure the clutch outer I.D. SERVICE LIMITS: 125.5 mm (4.941 in)



CLUTCH SHOE LINING

Check the clutch shoe for wear or damage. Measure the thickness of each shoe. SERVICE LIMIT: 2.0 mm (0.08 in)



DRIVEN FACE SPRING

Measure the driven face spring free length. SERVICE LIMITS: 92.2 mm (3.62 in) (EXEDY) 85.4 mm (3.36 in) (F.C.C)



DRIVEN FACE

Check the driven face for wear or damage. Measure the driven face O.D. SERVICE LIMIT: 33.94 mm (1.336 in)



MOVABLE DRIVEN FACE

Check the movable driven face for wear, scratches or damage.

Measure the movable driven face I.D.

SERVICE LIMIT: 34.06 mm (1.341 in)



CLUTCH/DRIVEN PULLEY INSTALLATION

NOTICE

Clean any oil and grease from the pulley faces and clutch outer. Replace the contaminated clutch shoes and O-rings with the new one.



Clean the pulley faces.

Apply grease to new oil seal lips and install them into the movable driven face.

Coat new O-rings with grease and install them onto the movable driven face.

Apply grease to the inside surface the movable driven face.



Install the movable driven face onto the driven face.

Apply grease to the guide pins and install them into the holes in the driven face.

Fill the movable driven face in side with grease (5.0 - 5.5 g).



Install the seal collar.



Install the damper rubbers onto the clutch drive plate. Install the clutch shoe springs onto the shoes. Install the clutch shoes and springs onto the drive plate. Install the plate and secure them with E-clips.

Assemble the following:

- Driven pulley
- Driven face spring
- Spring seat
- Clutch

Set the clutch spring compressor over the clutch/driven pulley, aligning the bosses with the holes in the clutch.

TOOL:

Clutch spring compressor 070ME – KWP – 110

Hold the spring compressor in a vice.

Install the clutch/driven pulley nut and tighten it with the socket wrench.

TOOL:

Socket wrench, 39 x 41 mm 070MA – KPL – I300

TORQUE: 54 N·m (5.5 kgf·m, 40 lbf·ft)

Remove the spring compressor from the clutch/driven pulley assembly after the fitment complete.





KICKSTARTER/DRIVE AND DRIVEN PULLEYS/CLUTCH

Install the drive belt and clutch/driven pulley assembly.



Install the clutch outer and nut.

Hold the clutch outer with the special tool and tighten the clutch outer nut.

TOOL:

Universal holder 070MB – KPL– I100

TORQUE: 49 N·m (4.9 kgf·m, 36 lbf·ft)

Install the drive pulley (page 9-18).



DRIVE PULLEY INSTALLATION

NOTICE

- Clean any oil and grease from the pulley faces. Replace the contaminated drive belt.
- Do not apply grease to the movable drive face and weight rollers.

Install the weight rollers into the movable drive face.

Install the slide pieces onto the ramp plate.

Install the ramp plate over the moveable drive face.

Install the drive face boss into the movable drive face.





Install the movable drive face assembly onto the crankshaft while holding the ramp plate.

Install the drive belt onto the drive face boss.



Install the drive pulley face, starter ratchet and washer.



Apply oil to the drive pulley face nut threads and seating surface and install it.

Hold the drive pulley face with the special tool and tighten the drive pulley face nut.

TOOL:

Clutch center holder 070MB – KPL– I200

TORQUE: 93 N·m (9.3 kgf·m, 69 lbf·ft)

Install the left crankcase cover (page 9-8).



COMPONENT LOCATION



COMPONENT LOCATION	10-0	DRIVESHAFT REMOVAL	10-3
SERVICE INFORMATION	10-1	BEARING REPLACEMENT	10-4
TROUBLESHOOTING	10-2	DRIVESHAFT INSTALLATION	10-7
FINAL REDUCTION DISASSEMBLY	10-3	FINAL REDUCTION ASSEMBLY	10-7

SERVICE INFORMATION

GENERAL

- The final reduction servicing can be performed with the engine installed in the frame.
- When installing the drive shaft, be sure to use the special tool; position the special tool against the bearing inner race and pull the driveshaft into the bearing.

SPECIFICATIONS

SPECIFICATIONS			Unit: mm (in)
ITEM		STANDARD	Page NO.
	At disassembly	0.12 liter (0.13 US qt, 0.11 lmp qt)	Page 10-8
Final reduction oil capacity	At draining	0.10 liter (0.11 US qt, 0.09 lmp qt)	Page 10-8
Recommended final reduction oil		Honda 4-stroke oil or equivalent motor oil API service classification: MA Viscosity: SAE 10W-30	Page 10-8

TORQUE VALUES

ITEM	QTY	THREAD SIZE & TYPE	TORQUE VALUE (N.m (kgf.m)	REMARKS	PAGE NO.
Cover crankcase comp. left bolts	7	12	13 (1.3, 9.5)	NOTE 1	Page 10-8

MULTIPLE SOURCED COMPONENT: FINAL REDUCTION ASSEMBLY

MAKER	VARROC	MUSASHI
IDENTIFICATION MARKS	VARROC VARROC	MUSASHI MUSASHI

NOTE: Parts are not interchangeable with other makers.

REFERENCE: For maker wise child part details refer parts catalogue.

10

TOOLS

Case/driven gear puller	070MC - KPL-I1001
Bearing remover set, 12 mm	
 Bearing remover head, 12 mm 	070MC – KPL–I400
 Bearing remover shaft, 12 mm 	070MC – KPL–I410
 Bearing remover weight 	070MC – KPL-I300
Bearing remover set, 15 mm	
 Bearing remover head, 15 mm 	070MC – KPL-I500
 Bearing remover shaft, 15 mm 	070MC – KPL-I510
 Bearing remover weight 	070MC – KPL-I300
Bearing remover set, 17 mm	
 Bearing remover head, 17 mm 	070MC – KPL-I520
 Bearing remover shaft, 15 mm 	070MC – KPL-I510
 Bearing remover weight 	070MC – KPL-I300
Crankcase assembly collar	070MF – KWP-110
Assembly collar attachment	070MF – KWP-120
Crankcase assembly shaft	070MF – KWP-130
Attachment, 32 x 35 mm	070GD – 002-l140
Attachment, 37 x 40 mm	070GD – 002-l150
Attachment, 42 x 47 mm	070GD – 002-I160
Pilot, 12 mm	070GD – 004-l130
Pilot, 17 mm	070GD – 004-l150
Pilot, 20 mm	070GD – 004-I160
Driver	070GD – 001-l100
Drive shaft bearing remover	07008 – DBR-900

TROUBLESHOOTING

Engine starts but vehicle won't move

- Damaged transmission
- Seized transmission
- Faulty drive and driven pulleys/clutch

Abnormal noise

- Worn, seized or chipped gears
- Worn or damaged transmission bearing

Oil leaks

- Oil level too high
- Worn or damaged oil seal
- Cracked crankcase

FINAL REDUCTION DISASSEMBLY

Drain the final reduction oil (page 3-9).

Remove the following:

- Rear wheel (page 14-3)
- Rear brake cable (page 14-5)
- Left crankcase cover (page 9-3)
- Clutch/driven pulley (page 9-12)

Disconnect the final reduction breather tube from the air cleaner housing.

Remove the bolts (7 nos.) and the transmission case.

Remove the dowel pins (2 nos.) and gasket.

Remove the counter gear shaft and counter gear.







DRIVESHAFT REMOVAL

Remove the final shaft.

Install the case/driven gear puller onto the left crankcase.

Remove the driveshaft from the crankcase.

TOOL:

Case/driven gear puller 070MC - KPL- 11001



Remove the driveshaft oil seal.



BEARING REPLACEMENT BEARING INSPECTION

Turn the bearings with your finger. The bearings should turn smoothly and quietly. Also check that the inner race fits tightly on the crankcase.



LEFT CRANKCASE

Remove the muffler (page 2-9)

Remove the final shaft bearing, counter gear shaft bearing and drive shaft bearing using the special tools.

TOOLS:

Counter gear shaft bearing:

Bearing remover head, 12 mm070MC - KPL-I400Bearing remover shaft, 12 mm070MC - KPL-I410

Final shaft bearing:

Bearing remover head, 15 mm 070MC – KPL-I500 Bearing remover shaft, 15 mm 070MC – KPL-I510

Remove the drive shaft from crankcase (page 10-3).

Remove the drive shaft bearing from drive shaft using the special tool.

Drive shaft bearing remover 07008 – DBR – 900



Be careful not to damage the left crankcase and transmission case mating surfaces.





Apply engine oil to new bearing rotating areas.

Drive new bearings into the left crankcase.

TOOLS:

Counter gear shaft bearin Driver Attachment, 32 x 35 mm Pilot ,12 mm	ng: 070GD – 001-l100 070GD – 002-l140 070GD – 004-l130
Final shaft bearing: Driver Attachment, 37 x 40 mm Pilot, 15 mm	070GD – 001-l100 070GD – 002-l150 070GD – 004-l140
Driveshaft bearing: Driver Attachment, 42 x 47 mm Pilot, 20 mm	070GD – 001-l100 070GD – 002-l160 070GD – 004-l160

TRANSMISSION INSPECTION

Check the transmission case bearings for wear or damage.





Check the final shaft for excessive wear, damage or signs of seizure.

Check the counter gear shaft and counter gear for excessive wear, damage or signs of seizure.



Remove the final shaft oil seal from the transmission case. Remove the final shaft bearing from the transmission case.



Remove the driveshaft bearing and counter gear shaft bearing using the special tools.

TOOLS:

Bearing remover head, 12 mm 070MC – KPL-I400 Bearing remover shaft, 12 mm 070MC – KPL-I410

Apply engine oil to new bearing rotating areas.



Drive new bearings into the transmission case.

TOOLS:

Driveshaft bearing:		
Driver	070GD - 001-l100	
Attachment, 37 x 40 mm	070GD - 002-I150	
Pilot, 12 mm	070GD - 004-l130	
Counter gear shaft bearing:		
Driver	070GD - 001-I100	
Attachment, 32 x 35 mm	070GD - 002-l140	
Pilot, 12 mm	070GD - 004-l130	
Final shaft bearing:		
Driver	070GD - 001-I100	
Attachment, 42 x 47 mm	070GD - 002-l160	
Pilot, 20 mm	070GD - 004-l160	

Coat the circumference and lip of a new final shaft oil seal with engine oil.

Install a new final shaft oil seal.





DRIVESHAFT INSTALLATION

Install the driveshaft into the transmission cover.

Position the assembly collar against the driveshaft bearing inner race.

Thread the assembly shaft onto the driveshaft.

Hold the shaft and draw the driveshaft into the bearing inner race by turning the nut.

TOOLS:

Crankcase assembly collar	070MF – KWP-110
Assembly collar attachment	070MF – KWP-120
Crankcase assembly shaft	070MF – KWP-130

Coat the circumference and lip of a new oil seal with engine oil.

Install the oil seal into the left crankcase until the depth from the crankcase end surface is 0 - 0.5 mm (0 - 0.02 in), using the special tools.

TOOLS:

Crankcase assembly collar	070
Assembly collar attachment	070
Crankcase assembly shaft	070

070MF – KWP-110 070MF – KWP-120 070MF – KWP-130





FINAL REDUCTION ASSEMBLY

Install the counter gear shaft and counter gear into the transmission case.

Install the final shaft.



COUNTER GEAR

Install a new gasket and the dowel pins.

Install the transmission case onto the left crankcase.



Tighten the bolts (7 nos.).

Connect the final reduction breather tube.

Install the following:

- Clutch/driven pulley (9-16)
- Left crankcase cover (9-6)
- Rear wheel (page 14-4)
- Rear brake adjusting nut and brake arm joint (page 14-6).

Fill the transmission case with the recommended oil (page 3-9).

RECOMMENDED OIL:

Honda 4-stroke oil or equivalent motor oil API service classification: MA Viscosity: SAE 10W-30

OIL CAPACITY:

0.10 liter (0.11 US qt, 0.09 lmp qt) at oil change 0.12 liter (0.13 US qt, 0.11 lmp qt) at disassembly

Install the oil level check bolt with a new sealing washer and tighten it.

TORQUE: 13 N·m (1.3 kgf·m, 9 lbf·ft)


MEMO

COMPONENT LOCATION



COMPONENT LOCATION

11-0 ALTERNATOR REMOVAL

11-2

SERVICE INFORMATION

11-1 ALTERNATOR INSTALLATION

11-3

SERVICE INFORMATION

GENERAL

- Some electrical components may be damaged if terminals or connectors are connected or disconnected while the ignition switch is ON and current is present.
- This section covers service of the alternator stator, flywheel and the cooling fan. These parts can be removed with the engine installed in the frame.
- Refer to section 15 for alternator stator inspection.

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Fan cover screw	2	5	4 (0.4, 2.9)		-
Fan cover bolt	2	10	7 (0.7, 5.1)		Page 11-4
Fan comp., cooling bolt	3	6	10 (1.0, 7.3)		Page 11-4
Flywheel comp. bolt	1	10	39 (3.9, 28.7)		Page 11-4
Pulsar coil assy.(stator comp.) bolt	2	5	6 (0.6, 4.4)		Page 11-3
Stator holding bolt	2	6	10 (1.0, 7.3)		Page 11-3
Clamper, wire harness bolt	1	6	12 (1.2, 8.8)		Page 11-3

TOOLS

Universal holder	070MB - KPL - I100
Flywheel puller	070MC - KPL - 1200

ALTERNATOR REMOVAL

Remove the right side cover (Page 2-4).

Disconnect the alternator and pulsar wire connectors.

Release the wire lugs from body clamp and cable tie.



Remove the two screws (2 nos.), bolts (2 nos.) and the cooling fan cover.

Remove the bolts (3 nos.) and cooling fan.





Hold the flywheel with the universal holder and remove the flywheel nut (1 no.).

TOOL:

Universal holder

070MB - KPL-I100



11-2

ALTERNATOR

Remove the flywheel with the flywheel puller. TOOL:

Flywheel puller 070MC - KPL- 1200

Remove the woodruff key from the crankshaft.





ALTERNATOR INSTALLATION

from the crankcase.

generator.

Install the stator and tighten the bolts C (2 nos.).

Remove the bolts C (2 nos.) and alternator stator.

TORQUE: 10 N·m (1.0 kgf·m, 7.3 lbf·ft)

Install the wire clamp and tighten the bolt A (1 no.).

TORQUE: 12 N·m (1.2 kgf·m, 8.8 lbf·ft)

Install the grommet into the right crankcase.

Install the ignition pulse generator and holder, and tighten the mounting bolts B (2 nos.).

TORQUE: 6 N·m (0.6 kgf·m, 4.3 lbf·ft)

Install the woodruff key into the crankshaft groove.





ALTERNATOR

Clean any oil or grease from the tapered portion of the crankshaft and the tapered hole in the flywheel.

Install the flywheel on the crankshaft by aligning its groove with the woodruff key.

Install the flywheel nut (1 no.).

Hold the flywheel with the universal holder and tighten the nut.

TOOL:

Universal holder 070MB – KPL– I100

TORQUE: 39 N·m (4.0 kgf·m, 29 lbf·ft)



Align the "T" mark on the cooling fan with the "T" mark on the flywheel and Install the cooling fan.

Tighten the bolts (3 nos.) with the specified torque.

TORQUE:10 N·m (1.0 kgf·m, 7.3 lbf·ft)

NOTE:

Use specified bolts otherwise it may damage the stator coil winding.

Install the fan cover and tighten the screws (2 nos.). Install the fan cover bolts (2 nos.) and tighten them. **TORQUE: 7 N·m (0.7 kgf·m, 5.1 lbf·ft)**





Route the wire properly (page 1-13). Install the wire lugs to the body clamp and tie the cable with the cable tie at its location. Connect the alternator and pulsar wire connectors. Install the right side cover (page 2-4).

Install the fuel tank cover (page 2-3).

Install the seat (page 2-3).



MEMO

COMPONENT LOCATION



12. CRANKCASE/CRANKSHAFT

COMPONENT LOCATION	12-0	CRANKSHAFT INSPECTION	12-3
SERVICE INFORMATION	12-1	CRANKCASE/CRANKSHAFT	
TROUBLESHOOTING	12-1	ASSEMBLY	12-4
CRANKCASE/CRANKSHAFT			
DISASSEMBLY	12-2		

SERVICE INFORMATION

GENERAL

- This section covers the crankcase separation to service the crankshaft.
- The engine must be removed from the frame to separate the crankcase.
- The following parts must be removed before separating the crankcase:
- air cleaner housing, carburetor (section 5)
- alternator (section 11)
- drive pulley, clutch/driven pulley (section 9)
- cylinder head (section 7)
- cylinder, piston (section 8)
- In addition to the parts listed above, remove the following parts when the left crankcase half must be replaced:
 - final reduction (section 10)
 - rear brake (section 14)
- Be careful not to damage the crankcase mating surfaces when separating and assembling the crankcase halves.
- The crankcase oil seals must be replaced with new ones when assembling the crankcase halves.

SPECIFICATIONS

	ITEM	STANDARD	SERVICE LIMIT	Page NO.
Crankshaft	Connecting rod big end side clearance	0.10 - 0.35 (0.004 - 0.014)	0.55 (0.022)	Page 12-3
Clarikshalt	Connecting rod big end radial clearance	0 - 0.012 (0 - 0.0005)	0.04 (0.002)	Page 12-4
	Crankshaft runout	-	0.1 (0.04)	Page 12-4

TORQUE VALUES

ITEM	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Pivot cam chain tensioner	Bolt, Spl. M6x1.0	10 (1.0, 7.3)		Page 12-6
R Crank case stud bolt	Bolt, A Stud 7x200	6.5(0.66, 5.0)		-
L Crank case stud bolt	Bolt, A Stud 7x204.5	6.5(0.66, 5.0)		_

TROUBLESHOOTING

Abnormal engine noise

- Worn or damaged connecting rod bearing
- Worn or damaged crankshaft bearings

Unit: mm (in)

CRANKCASE / CRANKSHAFT DISASSEMBLY

Remove the parts required for crankcase separation (page 12-1).

Remove the center stand return spring.



Remove the cotter pin, washer, center stand pivot bolt and center stand.



Remove bolts (2 nos.) and oil seal stopper plate from the left crankcase.

Remove the cam chain tensioner pivot and cam chain tensioner.



Remove the crankcase bolts (8 nos.).

Place the crankcase with the left crankcase down and remove the right crankcase from the left crankcase.

NOTICE

Separate the right crankcase while tapping it at several locations with a soft hammer.

A CAUTION

Be careful not to damage the crankcase mating surface.



CRANKCASE/CRANKSHAFT

Remove dowel pins. Clean off crankcase mating surface.

DOWEL PINS





Put the right crankcase on the wooden box. Remove the crankshaft from the left crankcase. Remove the cam chain.

Remove the oil seal from the left and right crankcase.

CRANKSHAFT INSPECTION

Set the crankshaft on V-blocks and measure the connecting rod big end side clearance with a feeler gauge. **SERVICE LIMIT: 0.55 mm (0.022 in)**



Set the crankshaft on V-blocks and measure the connecting rod big end radial clearance.

SERVICE LIMIT: 0.04 mm (0.002 in)



Read the runout using dial indicators. Actual runout is 1/2 of total indicator reading.

SERVICE LIMIT: 0.1 mm (0.04 in)



BEARING INSPECTION

Turn the bearings with your finger. The bearings should turn smoothly and quietly. Also check that the inner race fits tightly on the crankshaft.

Replace the crankshaft assembly if the races do not turn smoothly, quietly, or if they fit loosely on the crankshaft.



CRANKSHAFT/CRANKCASE ASSEMBLY

Clean the insides of the crankcases.

Check the crankcases for cracks or other faults.

Coat the lip and circumference of a new oil seal with engine oil.

Install the oil seal into the right crankcase so that the depth from the inside of the case is 0 - 1 mm (0 - 0.04 in).



CRANKCASE/CRANKSHAFT

Coat the lip and circumference of a new oil seal with engine oil.

Install the oil seal into the left crankcase so that the depth from the outside of the case is 0 - 0.5 mm (0 - 0.02 in).





Install the cam chain into the left crankcase.

Install the crankshaft into the left crankcase through the cam chain, being careful not to damage the oil seal lip.

NOTICE

Note the connecting rod location when installing the crankshaft.



DOWEL PINS



Install the dowel pins and a liquid gasket.

Install the crankcase bolts (8 nos.) and tighten them in a crisscross pattern in 2 or 3 steps and specified torque.

TORQUE: 6.5 N·m (0.66 kgf·m, 5.0 lbf·ft)

Check that the crankshaft turns smoothly.Install the center

CRANKCASE/CRANKSHAFT

stand onto the crankcase, insert the pivot bolt and secure it with the washer and a new

cotter pin.

Hook the center stand return spring to the stand and



spring pin. Install the following: COTTER PIN/WASHER

- Cylinder/ Piston (section 8)
- Cylinder head (section 7)
- Drive pulley, Clutch/ Driven pulley (section 9)
- Alternator (section 11)
- Carburetor, Air cleaner housing (section 5)
- Engine in the frame



MEMO

COMPONENT LOCATION



COMPONENT LOCATION	13-0	HANDLEBAR	13-14
SERVICE INFORMATION	13-1	STEERING STEM	13-20
TROUBLESHOOTING	13-2	FORK	13-24
FRONT WHEEL	13-3	STEERING LOCK	13-28
FRONT BRAKE	13-8		

SERVICE INFORMATION

GENERAL

- Riding on damaged rims impairs safe operation of the vehicle. •
- When servicing the front wheel, fork or steering stem, support the vehicle.
- A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes, and clean a contaminated drum with a high quality brake de-greasing agent.
- Raise the front wheel off the ground by supporting the frame securely when servicing the front wheel and suspension.
- After the front wheel installation, check the brake operation by applying the brake lever.
- ٠ Refer to the brake system information (section 13).
- Refer to section 18 for light, meter and switch inspection. ٠

SPECIFICATIONS

SPECIFICATIONS Unit: mm				
ITEM		STANDARD	SERVICE LIMIT	Page NO.
	Driver only	150 kPa (1.50 kgf/cm ² , 22 psi)	-	Page 3-18
Cold tyre pressure	Driver and passenger	150 kPa (1.50 kgf/cm ² , 22 psi)	-	Page 3-18
Rim size		12 x 2.15 in		-
Front axle runout		_	0.1 (0.003)	Page 13-5
	Radial	_	1.0 (0.03)	Page 13-5
Axial		_	1.0 (0.03)	Page 13-5
Front brake drum I.D.		130 (5.12)	131 (5.16)	Page 13-8

TORQUE VALUES

ITEM	QTY	THREAD SIZE & TYPE	TORQUE VALUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Fr. axle nut	1	12	59 (6.0, 43)	PT Nut	Page 13-7
Fr. hub nut	4	8	23 (2.3, 16.96)	PT Nut	Page 13-6
Fr. brake arm nut	1	6	10 (1.0, 7.3)		Page 13-13
Handlebar lower holder nut	2	10	39 (4.0, 29)	PT Nut	Page 13-23
Handlebar upper holder bolt	4	6	12 (1.2, 8.8)		Page 13-16
Fork top bridge bolt	2	8	30 (3.1, 22.1)		Page 13-23
Steering stem nut	1	24	74 (7.5, 55)		Page 13-24
Nut handle lever	2	6	5.9 (0.6, 4.35)		-

NOTE: Parts are not interchangeable with other makers.

REFERENCE: For maker wise child part details refer latest parts catalogue.

TOOLS

Bearing remover head, 12 mm	070MD – 005 – 1130
Bearing remover shaft	070GD – 005 – 1100
Driver	070GD - 001 - 1100
Attachment, 32 x 35 mm	070GD - 002 - 1140
Pilot, 12 mm	070GD - 004 - 1130
Lock nut wrench 45.5 mm	070MA – KPL – 1100
Adjusting remover head	070GC - 001 - 1110
Remover shaft	070GC - 001 - I120
Remover weight	070MC – KPL – 1300
Attachment 42 x 47 mm	070GD - 002 - 1160
Attachment	070MD – KPL – I210
Attachment, 30 mm I.D.	070GD - 003 - 1120
Lock nut wrench 42 mm	070MA – KPL – I200
Steering nut spanner	07000 – SNS – 900
Steering inner cone remover	07000 – SCR – 900
Top and bottom cone race installer	07004 – KPL – 900
Circlip plier	07914 – SA50001
Pinion Speedometer tool	07000 – PST – 900

TROUBLESHOOTING

Hard steering

- Steering top cone race too tight
- Worn or damaged steering bearings
- Worn or damaged steering bearing races
- Bent steering stem
- Insufficient tyre pressure

Steers to one side or does not track straight

- Damaged or loose steering bearings
- Bent fork
- Bent front axle
- Bent frame
- Worn or damaged front wheel bearings
- Front wheel wobbling
- Bent rim
- Worn or damaged front wheel bearings
- Faulty front tyre
- Unbalanced front tyre and wheel

Front wheel turns hard

- Faulty front wheel bearings
- Bent front axle
- Front brake drag

Hard suspension

• High tyre pressure

Soft suspension

- Weak fork spring
- Low tyre pressure

Front suspension noise

• Loose front suspension fasteners

FRONT WHEEL

REMOVAL

Support the vehicle on its centre stand.

Remove the front fork cover L & R screws (1 no.) from each side and front fork covers.



Remove the front brake adjusting nut, brake cable, brake arm joint.

Push the speedometer cable tab and disconnect the cable.



Hold the vehicle from rear side with tie down belt. Loosen the front axle nut.

Support the frame securely and raise the front wheel off the ground.

Remove the axle nut, axle and front wheel.





FRONT WHEEL DISASSEMBLY

Remove the brake panel from the left wheel hub.

Remove the distance collar from the right side of wheel hub.



Remove the dust seal from the right side of wheel.



Insert the bearing remover head into the bearing.

From the opposite side install the bearing remover shaft and drive the bearing out of the wheel from both side (left & right side).

TOOLS:

Bearing remover head, 12 mm 070GD – 005-I130 Bearing remover shaft 070GD – 005-I100

NOTICE

Replace the wheel bearings in pairs.

Remove the nuts (4 nos.) and wheel hub.





INSPECTION

FRONT AXLE

Set the front axle in V-blocks and measure the runout using a dial indicator.

Actual runout is 1/2 of the total indicator reading.

SERVICE LIMIT: 0.20 mm (0.008 in)



WHEEL RIM

Check the rim runout by placing the wheel on a truing stand.

Spin the wheel slowly and read the runout by using a dial indicator.

Actual runout is 1/2 of the total indicator reading.

SERVICE LIMITS:

Radial: 1.0 mm (0.03 in) Axial: 1.0 mm (0.03 in)



WHEEL BEARING

Turn the inner race of each bearing with your finger. The bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the hub.

Remove and discard the bearings if the races do not turn smoothly, quietly, or if they fit loosely in the hub.



NOTE: The rotating direction mark is available on the tyre, during tyre installation always fit the tyre so that the mark face the same direction of rotation.



ASSEMBLY OF DRUM BRAKE



Install the front wheel hub and tighten the nuts to the specified torque.

TORQUE: 23 N·m (2.3 kgf·m, 17 lbf·ft)

Apply grease on all bearing cavities.



Never reinstall an old bearing, once a bearing has been removed, the bearing must be replaced with a new one.



Drive in a new left side bearing squarely with the sealed side facing up until it is fully seated.

Install the distance collar.

Drive in a new right side bearing squarely with the sealed side facing up until it is fully seated.

NOTICE

Do not let the bearings tilt while driving them in.

TOOLS:

 Driver
 070GD - 001-I100

 Attachment, 32 x 35 mm
 070GD - 002-I140

 Pilot, 12 mm
 070GD - 004-I130



Apply grease to a new dust seal lip and install it. Install the side collar from right side of wheel hub.









Install the axle nut and tighten it to the specified torque.

TORQUE: 59 N·m (6.0 kgf·m, 43 lbf·ft)



INSTALLATION

Install the front wheel between the fork legs by aligning the brake panel groove with the boss of the left fork leg.

Install the brake panel assembly from left side of wheel.

Connect the speedometer cable by aligning its tab with the groove of the speedometer gear box.

Install the brake arm joint into the brake arm.

Install the brake cable through the brake panel and to the brake arm.

Install the brake adjusting nut.

Adjust the front brake lever free play (page 3-15).



Install the front fork cover of both sides and tighten the screw (1 no.).



FRONT BRAKE

Remove the front wheel (page 13-3).

Remove the brake panel.

A WARNING

- A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes and clean a contaminated drum with a high quality brake degreasing agent.
- Inhaling of asbestos fibers found to cause respiratory disease and cancer. Never use an air hose or dry brush to clean brake assemblies. Use a vacuum cleaner or alternate method to minimize the hazard caused by air borne asbestos fibers.

INSPECTION

BRAKE DRUM

Measure the brake drum I.D.

SERVICE LIMIT: 131 mm (5.16 in)





BRAKE PANEL DISASSEMBLY

Remove the speedometer drive gear from the brake panel.

Check for any wear and damage.



Remove the brake shoes and springs.

NOTICE

- Replace the brake shoes as a set.
- While removal mark the brake shoes to ensure that they are reinstalled on their original position.







Remove the brake arm bolt (1 no.). Unhook the return spring from the brake arm.

Remove the indicator, return spring and brake cam.

Remove the dust seal.



Remove the pinion gear with the help of flat screw driver by using mallet.



Remove the dust seal and washers (2 nos.).





Apply grease to a new dust seal lip and install it into the brake panel.



NOTE:

Always install new speedometer gear, new speedometer pinion and new bush pinion as in set.

Apply grease on pinion speedometer and speedometer gear before installation.



Be careful, not Insert the bush pinion and speedometer pinion in front brake panel by using special tool.

to damage the Speedo Pinion gear and Bush while pressing.

TOOLS:

Pinion speedometer installer

07000PST900



Insert the bush pinion until it hits with brake panel.



Apply grease to the new dust seal and install it into the brake panel.



Apply grease to the brake cam sliding surface and install it into the brake panel.



Install the return spring, inserting its end into the hole in the brake panel.

Install the indicator on the brake cam, aligning its wide tooth with the cam's wide groove.



Install the brake arm into the brake cam, aligning the punch marks on the arm and cam.

Install the brake arm bolt and nut, and tighten the nut.

TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)



Apply grease to the anchor pin.

NOTICE

- Wipe any excess grease off the brake cam and anchor pin.
- Contaminated brake linings reduce stopping power. Keep grease off the brake linings.

Install the brake shoes and springs.



Apply grease to the speedometer gear and install it with the washer.



Install the brake panel. Install the front wheel (page 13-7).



HANDLEBAR

REMOVAL

of handlebar.

Remove the wire bands and rear-view mirrors.





Disconnect the throttle cable from the throttle grip, then remove the throttle lower housing from the handlebar.



Remove the throttle grip from the handlebar.



Disconnect the front brake light switch connector (page 18-7).

Disconnect the front brake cable, brake lever bracket bolt (1 no.) and remove front brake lever bracket from handlebar.





Remove the screws (2 nos.) and separate the left side of handlebar switch housing.

Pull out the left handlebar grip with twisting movement in outward direction from the handlebar.



Disconnect the rear brake light switch connector (page 18-8).

Disconnect the rear brake cable, brake lever bracket bolt (1 no.) and remove rear brake lever bracket from handlebar.



Remove the bolts (4 nos.), cable stay, handlebar upper holders (2 nos.) and handlebar from the top bridge.



INSTALLATION

Route the cables to the stay.

Place the handlebar onto the handlebar lower holders.

Place the handlebar holders with the punch marks facing forward and install the handlebar upper holder bolts.

Align the end of the handlebar lower holder with the punch mark on the handlebar.

Tighten the front bolts first, then tighten the rear bolts to the specified torque.

TORQUE: 12 N.m (1.2 kgf.m, 8.8 lbf.ft)

Align the end of the rear brake lever bracket with the punch mark (under side) on the left side of handlebar.

Tighten the rear brake lever bracket bolt.





Connect the rear brake light switch connector (page 18-7).

Apply Honda Bond A or its equivalent to the inside surface of the grips and to the clean surface of the left handlebar.

Wait 3-5 minutes and install the grip.

Connect the rear brake cable,



HANDLEBAR GRIP





Install the left handlebar switch housing while aligning the locating pin in the housing with the hole in the handle bar.

Rotate the grips for even application of the adhesive.

Allow the adhesive to dry for 1 hour before using.



Install the screws (2 nos.) and tighten the forward screw first, then the rear screw.



Align the end of the front brake lever bracket with the punch mark (under side) on the right side of handlebar.

Tighten the front brake lever bracket bolt.

Connect the front brake cable (1 no.).



Connect the front brake light switch connector (page 18-7). FRONT BRAKE LEVER FRONT BRAKE CABLE HANDLEBAR BOLT

> THROTTLE GRIP S HANDLEBAR

Apply grease to the throttle pipe rotating area of the handlebar and install the throttle grip on the handle bar.

Apply silicon grease to the throttle cable end. Connect the throttle cable end to the throttle grip.



Install the throttle housing while aligning the locating pin in the housing with the hole in the handle bar.







Install the screw and tighten the forward screw first, then the rear screw.

Route the wires and cables properly (page 1-13). Tighten the rear-view mirrors.

Tie the cables with the wire bands.

STEERING STEM

REMOVAL

Remove the following:

- Fork cover (left and right) (page 2-2)
- Handlebar (page 13-14)

Remove the stay by removing bolts (4 nos.)

Remove the steering stem lock nut, bolts (2 nos.) and remove fork top bridge.





LOCK NUT WRENCH 70SRTKSP004

Loosen the adjusting nut using the special tool.

TOOL:

Socket wrench steering

Hold the steering stem and remove the adjusting nut.



- Top cone race

Be careful not to loose the steel balls.





UPPER STEEL BALL



ADJUSTING NUT
FRONT WHEEL/BRAKE/SUSPENSION/STEERING

BALL RACE REPLACEMENT

Remove the ball races using the special tool.

TOOL:

Ball race remover

070SRTKSP005



Install a new top ball race and new bottom ball race using the special tool.

TOOLS: Steering ball race installer

70SRTKSP006



BOTTOM CONE RACE REPLACEMENT

Avoid damaging the steering stem thread, temporarily install the stem nut.

Remove the dust seal and washer.

Remove the bottom cone race with a T-stem cone remover MC tool, being careful not to damage the stem.

TOOL:

T-stem cone remover MC

07000TCR900



Install the washer and dust seal.

Press a new bottom cone race onto the steering stem using the special tool.

TOOL:

Steering cone installer

070SRTKSP007





Apply water-proof grease to the steering cone races and steering ball races.

Install the steel balls in the bottom cone race and top ball race.

Upper steel ball: 18 Lower steel ball: 18

Install the steering stem and top cone race.



Install the adjusting nut and tighten it to the specified torque.

TORQUE: 27 N.m (2.7 kgf.m, 20 lbf.ft)

TOOL:

Socket wrench steering

070SRTKSP004



FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Turn the steering stem left and right several times and recheck that there is no vertical play and that the steering stem rotates smoothly.



ADJUSTING NUT





Temporarily loosen the adjusting nut completely, then retighten the adjusting nut to the specified torque.

TOOL:

Socket wrench steering 070SRTKSP004

TORQUE: 1.5 N.m (0.15 kgf.m, 1.0 lbf.ft)

Check that there is no vertical play and that the steering stem rotates smoothly.

Install the top bridge on the stem and tighten the bolts (2 nos.) to the specified torque.

TORQUE: 30 N.m (3.1 kgf.m, 22.1 lbf.ft)

Install the washer and steering stem lock nut.

Tighten the steering stem nut to the specified torque.

TORQUE: 74 N.m (7.5 kgf.m, 55 lbf.ft)

Turn the steering stem left and right several times and recheck that there is no vertical play and that the steering stem rotates smoothly.



Install the cover stay and tighten the bolts (4 nos.) to the specified torque.

TORQUE: 10 N.m (1.0 kgf.m, 7 lbf.ft)

Install the following:

- Handlebar (page 13-16)
- Fork cover L & R (page 2-2)
- Meter assembly (page 2-2).

Connect the all connectors and install the front headlight assy.



FORK

REMOVAL

Remove the front wheel (13-3).

Remove the front fender (page 2-7).

Remove the circlip using special tool downward direction.

TOOLS:

Circlip plier

07914-SA50001

Pull the pipe comp. in downward direction to remove it.





Remove the rubber stopper and spring front fork.



DISASSEMBLY

Remove the slide pipe piston by using flat screw driver.







Do not overtighten the vise on the fork slider.

Do not Set the fork slider in a vise with a piece of wood or soft jaws to avoid damage.

Unstuck the rebound stopper with the help of flat screw driver.

Remove the stopper ring.

INSPECTION



INSTALLATION

Install the parts in following sequence:

- _ Pipe comp.
- Boot
- Circlip (chamfered face should be inner side)
- Bush
- Fork spacer
- Rebound spring _
- Rebound stopper

Install and fix the stopper ring to the fork pipe.



FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Move the rebound stopper to upward till it move and tighten the rebound stopper with the help of slip joint plier by pressing the projections (4 nos.) in the rebound stopper.





Install the new slide pipe piston on the top of the fork pipe comp. and press it tightly.

Apply grease on rubber stopper and spring front fork.

Grease Qty: 20 to 25 grms (Each side)

Install the rubber stopper and spring front fork to the stem.

NOTE:

Install the larger pitch of spring towards inner side.





Insert the fork pipe comp. inside the stem to install it.

FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Install the circlip using special tool upward direction.

TOOLS: Circlip plier

07914-SA50001

Install the front fender (page 2-7). Install the front wheel (13-7).



STEERING LOCK

REMOVAL/INSTALLATION

Remove the steering stem (page 13-20).

Remove the screws (2 nos.).

Remove the steering lock.

Installation is in the reverse order of removal.



MEMO

COMPONENT LOCATION



118 N.m (12.0 kgf.m, 87 lbf.ft)

14. REAR WHEEL/BRAKE/SUSPENSION

COMPONENT LOCATION	14-0	REAR WHEEL	14-3
SERVICE INFORMATION	14-1	REAR BRAKE	14-4
TROUBLESHOOTING	14-2	SHOCK ABSORBER	14-7

SERVICE INFORMATION

GENERAL

CAUTION

Frequent inhalation of brake shoe dust, regardless of material composition could be hazardous to your health.

- Avoid breathing dust particles.
- Never use an air hose or brush to clean brake assemblies. Use an OSHA-approved vacuum cleaner.
- Riding on damaged rims impairs safe operation of the vehicle.
- When servicing the rear wheel and suspension, support the vehicle using a center stand or hoist.
- A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes, and clean a contaminated drum with a high quality brake de-greasing agent.
- After the rear wheel installation, check the brake operation by applying the brake lever.
- Use Honda genuine bolts and nuts for all suspension pivots and mounting points. •

NOTICE

A contaminated brake drum or lining reduces stopping power. Discard contaminated linings and clean a contaminated drum with a high quality brake de-greasing agent.

- Always check the brake operation before riding the vehicle.
- Use genuine Honda replacement bolts and nuts for all suspension pivots and mounting points.

SPECIFICATIONS

SPECIFICATIONS				Unit: mm (in)	
ITEM		STANDARD	SERVICE LIMIT	Page NO.	
	Driver only	200 kPa (2.00 kgf/cm ² , 29 psi)	-	Page 3-18	
Cold tyre pressure	Driver and passenger	250 kPa (2.50 kgf/cm ² , 36 psi)	-	Page 3-18	
Rim size		10 x 2.15 in			
	Radial	-	2.0 (0.08)	Page 14-3	
Rear wheel rim runout	Axial	-	2.0 (0.08)	Page 14-3	
Rear brake drum I.D.		130 (5.11)	131 (5.16)	Page 14-4	

TORQUE VALUES

ITEM	THREAD SIZE & TYPE	TORQUE VALUE N.m (kgf.m, lbf.ft)	REMARKS	PAGE NO.
Rr. axle nut	M16x1.5	118 (12.0, 87)	PT Nut Apply Oil	Page 14-4
Rr. hub nut	M10x1.25	49 (5.0, 36.1)	PT Nut Apply Oil	Page 14-4
	M10x1.25	49 (5.0, 36.1)	PT Nut Apply Oil	Page 14-4
Rr. brake arm bolt	M6x1.0	10 (1.0, 7)	Alock Bolt	Page 14-6
Rr. cushion (upper side)	M10x1.25	39 (4.0, 29)		Page 14-7
Rr. cushion (lower side)	M8x1.25	22 (2.2, 16)		Page 14-7

MULTIPLE SOURCED COMPONENT : CUSHION ASSEMBLY

MAKER	MUNJAL SHOWA	GABRIEL	ENDURANCE
IDENTIFICATION MARKS	MSL	GABRIEL	

NOTE: Parts are not interchangeable with other makers.

REFERENCE: For maker wise child part details refer latest parts catalogue.

TROUBLESHOOTING

Rear wheel wobbling

- Bent rim
- Worn or damaged final shaft bearing
- Worn or damaged engine mounting bushings
- Faulty tyre
- Axle nut or engine mounting nut not tightened properly
- Insufficient tyre pressure
- Unbalanced tyre and wheel

Hard suspension

- Bent rear shock absorber damper rod
- High tyre pressure

Poor brake performance

- Improper brake adjustment
- Contaminated brake shoe lining
- Worn brake shoes
- Worn brake cam
- Contaminated brake drum
- Worn brake drum

Soft suspension

- Weak rear shock absorber spring
- Faulty rear shock absorber damper

REAR WHEEL/BRAKE/SUSPENSION

REAR WHEEL

REMOVAL

Remove the rear fender RR inner (page 2-9).

Remove the vehicle from the main stand and apply rear brake.

Remove the axle nut, washer and the rear wheel.







INSPECTION

Check the wheel rim runout using a dial indicator. Actual runout is 1/2 the total indicator reading. SERVICE LIMITS: Radial: 1.0 mm (0.03 in)

Axial: 1.0 mm (0.03 in)



INSTALLATION

Install the wheel hub on the wheel and tighten the nuts (4 nos.) to the specified torque.

TORQUE: 49 N·m (4.9 kgf·m, 36 lbf·ft)



REAR WHEEL/BRAKE/SUSPENSION

NOTE:

Check the rotating direction mark on the tyre (rear wheel) before installation.



Install the rear wheel and washer.

Apply oil to the axle nut threads and seating surface, and install it.

Tighten the axle nut.

TORQUE: 118 N·m (12.0 kgf·m, 87 lbf·ft)

Install the rear fender RR inner (page 2-9).



REAR BRAKE

Remove the rear wheel (page 14-3).

INSPECTION

Measure the rear brake drum I.D. SERVICE LIMIT: 131 mm (5.16 in).



DISASSEMBLY

NOTICE

- Replace the brake shoes as a set.
- Mark the brake shoes to ensure that they are reinstalled on their original position.

Remove the brake shoes and springs.



14-4

Remove the adjusting nut, brake cable and brake arm joint from the brake arm.

Remove the brake arm return spring.

Remove the brake arm bolt, brake arm, brake cam and dust seal from the brake panel (transmission case).



ASSEMBLY DUST SEA **BRAKE ARM** ANCHOR PIN BOLT BRAKE SHOE ADJUSTING NUT OTTIME . BRAKÈ CABLE BRAKE ÁRM PIN **RETURN SPRING** BRAKE CAM SHOE SPRING GREASE Apply grease to a new dust seal lip and install it into the brake panel (transmission case). Apply grease to the brake cam sliding surface and install it into the brake panel.

GREASE BRAKE CAM

REAR WHEEL/BRAKE/SUSPENSION

Install the brake arm onto the brake cam, aligning the punch marks on the arm and cam.



Install and tighten the brake arm bolt (1 no.).

TORQUE: 10 N·m (1.0 kgf·m, 7 lbf·ft)

Install the return spring.

Install the brake arm joint, brake cable and brake adjusting nut (page 3-15).



Apply grease to the brake cam and anchor pin.

ACAUTION

When the brake shoes are reused, install them on their original position.

Install the shoe springs onto the brake shoes.

Install the brake shoes and springs onto the brake cam and anchor pin.

Install the rear wheel (page 14-4).

Adjust the rear brake free play (page 3-15).



SHOCK ABSORBER

REMOVAL

Place the vehicle on its centre stand.

Remove the upper mounting bolt (1 no.) first and then lower mounting bolt (1 no.), then remove shock absorber.



INSPECTION

Visually inspect the shock absorber for oil leaks or other faults.



INSTALLATION

Install the shock absorber and tighten the lower mounting bolt (1 no.) first then tighten the upper mounting bolt (1 no.).

TORQUE: Upper: 39 N·m (4.0 kgf·m, 29 lbf·ft) Lower: 22 N·m (2.2 kgf·m, 16 lbf·ft)



COMPONENT LOCATION



SYSTEM DIAGRAM



15. BATTERY/CHARGING SYSTEM

COMPONENT LOCATION	15-0	BATTERY	15-3
SYSTEM DIAGRAM	15-0	CHARGING SYSTEM INSPECTION	15-6
SERVICE INFORMATION	15-1	ALTERNATOR INSPECTION	15-8
TROUBLESHOOTING	15-2	RECTIFIER COMP. REGULATOR	15-8

SERVICE INFORMATION

GENERAL

A WARNING

- The battery gives off explosive gases, keep sparks, flames and cigarettes away. Provide adequate ventilation when charging.
- The battery contains sulphuric acid (electrolyte). Contact with skin or eyes may cause severe burns. Wear protective clothing and a face shield.
 - If electrolyte gets on your skin, flush with water.
 - If electrolyte gets in your eyes, flush with water for at least 15 minutes and call a physician immediately.
- Electrolyte is poisonous.
 - If swallowed, drink large quantities of water or milk and call your local Poison Control Center or a physician immediately.

NOTICE

- Always turn "OFF" the ignition switch before disconnecting any electrical component.
- Some electrical components may be damaged if terminals or connectors are connected or disconnected when the ignition switch is "ON", and current is present.
- For extended storage, remove the battery, give it a full charge, and store it in a cool, dry space. For maximum service life, charge the stored battery every two weeks.
- For a battery remaining in a stored vehicle, disconnect the negative battery cable from the battery terminal.
- The battery can be damaged if overcharged or undercharged, or if left to discharge for a long period. These same conditions contribute to shortening the "life span" of the battery. Even under normal use, the performance of the battery deteriorates after 2-3 years.
- Battery voltage may recover after battery charging, but under heavy load, battery voltage will drop guickly and eventually die out. For this reason, the charging system is often suspected as the problem. Battery overcharge often results from problems in the battery itself, which may appear to be an overcharging symptom. If one of the battery cells is shorted and battery voltage does not increase, the rectifier comp. regulator supplies excess voltage to the battery. Under these conditions, the electrolyte level goes down quickly.
- The battery will self-discharge when the vehicle is not in use. For this reason, charge the battery every two weeks to prevent • sulfation occurring of.
- When checking the charging system, always follow the steps in the troubleshooting flow chart (page 15-2).
- Refer to the alternator removal and disassembly.

BATTERY TESTING

Refer to instructions in the Operation Manual for the recommended battery tester for details about battery testing. The recommended battery tester puts a "load" on the battery so that the actual battery condition can be measured.

Recommended battery tester: FBT-50

SPECIFICATIONS

SPECIFICATIONS Unit: mm (ir				Unit: mm (in)
	ITEM		SPECIFICATION	Page NO.
Detter	Capacity		12 V – 3 Ah	Page 15-3
Battery	Current leakage		0.26 mA max.	Page 15-8
Rectifier comp.		Charging	13.9 – 14.7 V/ 5,000 min ⁻¹ (rpm)	-
Regulator	Regulated voltage	Lighting	12.7 – 13.7 V/ 5,000 min ⁻¹ (rpm)	_
Alternator coil resista	ance at 20°C (68°F)	Charging coil	0.2 – 1.0 Ω	Page 15-8

TROUBLESHOOTING

BATTERY IS DAMAGED OR WEAK



BATTERY/CHARGING SYSTEM

BATTERY

REMOVAL/INSTALLATION

Remove the battery cover (page 2-6).

Remove the seat (page 2-3).

Always turn the ignition switch OFF before removing the battery.

Do not forget to apply

terminal cover

on (+) positive

terminal.

While Removal : Disconnect the negative (-) terminal first and then positive (+) terminal by removing the screw. Remove the battery.

Install the battery in the reverse order of removal.

While Installation : Connect the positive (+) terminal first and then the negative (-) terminal.

VOLTAGE INSPECTION

Remove the battery cover (page 2-6).

Measure the battery voltage using the FBT-50 battery tester.

VOLTAGE (20°C/68°F):

Fully charged: More than 12.4 V

Under charged: Below 12.4 V

If the battery voltage is below 12.3 V, charge the battery.





BATTERY TESTING PROCEDURE

Check the battery model no. front side of the battery and refer the test instructions mention on back side of the FBT- 50 tester.

ET	Z4	4
Battery Model	Brand	FBT-50 Ref. pin
ETZ4	EXIDE	4



Connect the tester probes to the battery terminal.

NOTICE

Always connect red probe to positive and black probe to negative terminal.



BATTERY/CHARGING SYSTEM

On connecting probes, the screen displays battery pin number.



Use yellow selection arrow button to select the correct pin number. According to the battery reference table.



To check voltage press "V" button.



To load test the battery press "TEST" button. **NOTE:** *Device will take approx 3 seconds to display result.*



BATTERY CHARGING

Connect charger red probe to positive and black to negative terminal.

Select the "New Battery" mode or "Used Battery" mode by the selector switch based on condition of the battery (New or Used) and switch on the charger.



After switching ON the Power, "MAINS LED" will glow instantly.



Green LED indicates, the battery is fully charged.

Again test the battery voltage (page 15-3).

NOTICE

getting charged properly.

Before testing, battery should be kept idle for at least 30 minutes after charging.











INDICATION TABLE FOR MF BATTERY CHARGER

CHARGING SYSTEM INSPECTION

CHARGING VOLTAGE INSPECTION

A WARNING

If the engine is running to do some work, make sure that area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and may lead to death.

Remove the battery cover (page 2-6).

NOTICE

Be sure the battery is in good condition before performing this test. Battery voltage should be more than 12.4 V.

BATTERY/CHARGING SYSTEM

CHARGING OUTPUT:

Warm up the engine to normal operating temperature.

Stop the engine, and connect the multimeter as shown.

ACAUTION

- To prevent short, make absolutely certain which are the positive and negative terminals or cable.
- Do not disconnect the battery or any cable in the charging system without first switching off the ignition switch. Failure to follow this precaution can damage the tester or electrical components.

Connect a tachometer according to the tachometer manufacture instruction.

Restart the engine.

With the headlight high beam ON, measure the voltage on the multimeter when the engine runs at 5,000 min⁻¹ (rpm)

STANDARD

Measured BV < Measured CV = $14.3 \pm 0.4V$

- BV = Battery voltage (page 15-3).
- CV = Charging Voltage



LIGHTING OUTPUT:

Open the headlight assy. (page 2-2).

NOTE : Do not remove headlight assy.

Connect the multimeter positive (+) probe to the headlight Blue terminal, and negative (–) probe to the Green wire terminal.

Start the engine and light switch is "ON" and the dimmer switch is "Hi" position, and read the voltage.

REGULATED VOLTAGE:

13.2 ± 0.5V at 5,000 min⁻¹ (rpm)

NOTICE

• Measure the voltage with the headlight wire connectors connected.

CURRENT LEAKAGE INSPECTION

Remove the battery cover (page 2-6).

Turn the ignition switch off and disconnect the battery negative cable from the battery.

Connect the ammeter (+) probe to the battery negative terminal and the ammeter (-) probe to the harness (-) connector.

With the ignition switch off, check for current leakage.





NOTICE

- When measuring current using a tester, set it to a high range, and then bring the range down to an appropriate level. Current flow higher than the range selected may blow out the fuse in the tester.
- While measuring current, do not turn the ignition on. A sudden surge of current may blow out the fuse in the tester.

SPECIFIED CURRENT LEAKAGE: 0.26 mA max.

If current leakage exceeds the specified value, a shorted circuit is likely.

Locate the short by disconnecting connections one by one and measuring the current.

ALTERNATOR INSPECTION

NOTICE

It is not necessary to remove the stator coil to make this test.

Remove the cover center (page 2-4).

Disconnect the alternator 2P connector (page 11-2).

Check the resistance between following terminals.

STANDARD:

Charging coil { White - Green (Ground)}:

White-Green $0.2 - 1.0 \Omega$ (at 20° C/68°F)

Replace the alternator stator if readings are far beyond the standard.

For stator removal (page 11-2).

Connect the alternator 2P connector.

Install the cover center (page 2-4).





RECTIFIER COMP. REGULATOR

SYSTEM INSPECTION

Remove the right side cover (page 2-4).

Remove the rectifier comp. regulator 4P connector, and check it for loose contact or corroded terminals.

If the regulated voltage reading (page 15-7) is out of the specification, measure the voltage between connector terminals (wire harness side) as follows:



Item	Terminal	Specification
Battery	Red (+) and	Battery voltage
charging line	ground (–)	should register
Charging coil	White and	0.2 – 1.0 Ω
line	ground	(at 20°C/68°F)
Croundling	Green and	Continuity should
Ground line	ground	exist

If all components of the charging system are normal and there are no loose connections at the rectifier comp. regulator connectors, replace the rectifier comp. regulator unit.

REMOVAL/INSTALLATION

Remove the rectifier comp. regulator unit mounting bolt (1 no.).

Disconnect the connector and remove the rectifier comp. regulator unit.

Install the rectifier comp. regulator unit in the reverse order of removal.



COMPONENT LOCATION



SYSTEM DIAGRAM



16. IGNITION SYSTEM

COMPONENT LOCATION	16-0	IGNITION SYSTEM INSPECTION	16-3
SYSTEM DIAGRAM	16-0	IGNITION TIMING	16-5
SERVICE INFORMATION	16-1	IGNITION COIL	16-5
TROUBLESHOOTING	16-2	SPARK UNIT	16-5

SERVICE INFORMATION

GENERAL

- Some electrical components may be damaged if terminals or connectors are connected or disconnected while the ignition • switch is ON and current is present.
- When servicing the ignition system, always follow the steps in the troubleshooting on page 16-2.
- The spark unit ignition system uses an electrically controlled ignition timing system. No adjustments can be made to the ٠ ignition timing.
- The spark unit may be damaged if dropped. Also, if the connector is disconnected when current is flowing, the excessive voltage may damage the spark unit. Always turn off the ignition switch before servicing.
- A faulty ignition system is often related to poor connections. Check those connections before proceeding.
- Make sure the battery is adequately charged. A weak battery may be unable to turn the starter motor quickly enough, or . adequate ignition current may not be supplied.
- Use spark plug of the correct heat range. Using spark plug with an incorrect heat range can damage the engine.
- For ignition switch inspection, see section 18.
- For ignition pulse generator (alternator starter) removal/installation, see section 10.

SPECIFICATIONS			Unit: mm (in)	
ITEM		SPECIFICATION	Page NO.	
Spark plug	Standard	NGK MR7C-9N	Page 3-7	
Spark plug gap		0.8~0.9	Page 3-7	
Ignition primary peak v	oltage	100 V minimum	Page 16-3	
Ignition pulse generato	r peak voltage	0.7 V minimum	Page 16-4	
Ignition timing ("F" mar	k)	15° BTDC at 1,700 rpm	-	
Maximum timing (Adva	ince)	34° BTDC at 2,700 rpm	-	

TOOL



TROUBLESHOOTING

- Inspect the following before diagnosing the system.
 - Faulty spark plug
 - Loose spark plug cap or spark plug wire connections
 - Water got into the spark plug cap (Leaking the ignition coil secondary voltage)
- If there is no spark at cylinder, temporarily exchange the ignition coil with the other good one and perform the spark test. If there is spark, the exchanged ignition coil is faulty.

No spark at spark plug

	Unusual condition	Probable cause (check in numerical order)
Ignition coil primary voltage	Low peak voltage	 Incorrect peak voltage adaptor connections. (System is normal if measured voltage is over the specifications with reverse connections.) The multimeter impedance is too low; below 10 MΩ/DCV. Cranking speed is too low. The sampling timing of the tester and measured pulse were not synchronized. (System is normal if measured voltage is over the standard voltage at least once.) Poorly connected connectors or an open circuit in ignition system. Faulty spark unit (in case when above No.1–5 are normal)
	No peak voltage	 Incorrect peak voltage adaptor connections. Faulty ignition switch or engine stop switch. Loose or poorly connected spark unit connectors. Open circuit or poor connection in ground wire of the spark unit. Faulty peak voltage adaptor. Faulty ignition pulse generator (Measure the peak voltage). Faulty spark unit (in cases when above No. 1–7 are normal).
	Peak voltage is normal. but no spark jumps at the plug.	 Faulty spark plug or leaking ignition coil secondary current ampere. Faulty ignition coil.
Ignition pulse generator	Low peak voltage	 Multimeter impedance is too low; below 10 MΩ/DCV. Cranking speed is too low. Operating force of the kickstarter is weak. The sampling timing of the tester and measured pulse were not synchronized (System is normal if measured voltage is over the specifications at least once). Faulty exciter coil (in cases when above No. 1–3 are normal).
	No peak voltage	1. Faulty peak voltage adaptor
Ignition pulse generator	Low peak voltage	 The multimeter impedance is too low; below 10 MΩ/DCV. Cranking speed is too slow. Operating force of the kickstarter is weak. The sampling timing of the tester and measured pulse were not synchronized (System is normal if measured voltage is over the standard voltage at least once.) Faulty ignition pulse generator (in case when above No. 1–3 are normal)
	No peak voltage	 Faulty peak voltage adaptor. Faulty ignition pulse generator.

IGNITION SYSTEM INSPECTION

NOTICE

- If not spark jumps at the plug, check all connections for loose or poor contact before measuring each peak voltage.
- Use a commercially available digital multimeter (impedance 10 MΩ/DCV minimum).
- The display value differs depending upon the internal impedance of the multimeter.
- If the Imrie diagnostic tester (model 625) is used, follow the manufacturer's instructions.

Connect the peak voltage adaptor to the digital multimeter.

TOOL:

 $\begin{array}{ll} \mbox{Imrie diagnostic tester (model 625) or} \\ \mbox{Peak voltage adaptor} & 07 \mbox{HGJ} - 0020100 \\ \mbox{with commercially available digital multimeter} \\ \mbox{(impedance 10 $M\Omega$/DCV minimum)} \end{array}$

IGNITION COIL PRIMARY PEAK VOLTAGE

NOTICE

- Check all system connections before this inspection. Poor connected connectors can cause incorrect readings
- If the system is disconnected, incorrect peak voltage might be measured.
- Check that the cylinder compression is normal and check that the spark plug is installed correctly in the cylinder head.

Remove the cover center (page 2-3).

Disconnect the spark plug cap from the spark plug.

Connect a good known spark plug to the spark plug cap and ground the spark plug to the cylinder head as done in a spark test.

With the connector connected, connect the peak voltage adaptor probes to the ignition coil primary terminal and ground.

TOOL:

Imrie diagnostic tester (model 625) or Peak voltage adaptor 07HGJ – 0020100 with commercially available digital multimeter (impedance 10 $M\Omega$ /DCV minimum)

Avoid touching the spark plug and tester probes to prevent electric shock.

CONNECTION: Black/yellow (-) - body ground (+)

Turn the ignition switch ON.

Crank the engine with the kickstarter and read the ignition coil primary voltage.

PEAK VOLTAGE: 100 V minimum

If the peak voltage is lower than the standard value, follow the checks described in the troubleshooting on (page 16-2).







IGNITION PULSE GENERATOR PEAK VOLTAGE

NOTICE

- Check that the cylinder compression is normal and the spark plug is installed correctly in the cylinder head.
- If the system is disconnected, incorrect peak voltage might be measured.
- Check all system connections before this inspection. Poor connected connectors can cause incorrect readings

Disconnect the spark unit (6P) connector (page 16-5).

Connect the peak voltage adaptor probes to the ignition pulse generator wire and ground wire terminals of the wire harness side connector.

TOOL:

 $\begin{array}{ll} \mbox{Imrie diagnostic tester (model 625) or} \\ \mbox{Peak voltage adaptor} & 07 \mbox{HGJ} - 0020100 \\ \mbox{with commercially available digital multimeter} \\ \mbox{(impedance 10 $M\Omega$/DCV minimum)} \end{array}$

Avoid touching the spark plug and tester probes to prevent electric shock.

CONNECTION: Blue/Yellow (+) – green (–)

Turn the ignition switch ON.

Crank the engine with the kickstarter and read the peak voltage.

PEAK VOLTAGE: 0.7 V min

If the peak voltage measured at the spark unit connector is abnormal, disconnect the ignition pulse generator connector and connect the adaptor probes to the ignition pulse generator side connector.

In the same manner as the spark unit connector, measure the peak voltage and compare it to the voltage measured at the spark unit connector.

- If the peak voltage measured at the spark unit connector is abnormal and the one measured at the ignition pulse generator connector is normal, the blue/yellow wire has an open or short circuit, or loose connections.
- If both peak voltages are abnormal, follow the checks described in the troubleshooting on (page 16-2).

IGNITION PRIMARY AND SECONDARY COIL RESISTANCE

Disconnect the ignition coil connectors.

Connect the digital multimeter probes to the ignition coil connectors.

PRIMARY COIL RESISTANCE: 2.07 – 2.53 Ω

Disconnect the spark plug suppressor cap and wire.

Connect the digital multimeter probes to the ignition coil connector and spark plug wire.

SECONDARY COIL RESISTANCE: 12.33 – 15.07 k Ω





IGNITION SYSTEM

IGNITION TIMING

A WARNING

When the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.



The ignition timing is factory preset and only needs to be checked when an electrical system component is replaced.

Warm up the engine to the normal operating temperature.

Remove the fan cover.

Connect the timing light and a tachometer.

NOTICE

Read the manufacturer's instructions for the timing light and tachometer.

The ignition timing is correct if the "F" mark on the flywheel aligns with the index mark of the right crankcase at idle.

Install the fan cover.

IGNITION COIL

REMOVAL/INSTALLATION

Remove the cover center (page 2-3).

Disconnect the ignition coil primary wire and connectors.

Remove the spark plug cap (page 3-7).

Remove the bolts (2 nos.) and ignition coil from the frame.

Install the ignition coil in the reverse order of removal.





SPARK UNIT

REMOVAL/INSTALLATION

Remove the battery cover (page 2-6).

Remove the spark unit from the battery stay, disconnect the connectors and remove the spark unit.

Install the spark unit in the reverse order of removal.

Check continuity between green wire and body ground.





SYSTEM DIAGRAM



17. ELECTRIC STARTER

COMPONENT LOCATION

SYSTEM DIAGRAM

SERVICE INFORMATION

17-0 TROUBLESHOOTING 17-2 17-0 STARTER MOTOR 17-3 17-1 STARTER RELAY 17-7

SERVICE INFORMATION

GENERAL

A WARNING

Always turn the ignition switch OFF before servicing the starter motor. The motor could suddenly start, causing serious injury.

- The starter motor can be serviced with the engine installed in the frame.
- When checking the starter system, always follow the steps in the troubleshooting flow chart (page 17-2).
- A weak battery may be unable to turn the starter motor quickly enough, or supply adequate ignition current.
- If the current is kept flowing through the starter motor to turn it while the engine is not cranking over, the starter motor may be damaged.
- See section 18 for starter switch and ignition switch inspections.
- See section 9 for starter pinion inspection.
- The following color codes are used throughout this section.

B = Blue	G = Green	Lg = Light green	R = Red
L = Black	Gr = Gray	O = Orange	W = White
Br = Brown	Lb = Light blue	P = Pink	Y = Yellow

SPECIFICATIONS

ITEM	STANDARD	SERVICE LIMIT	Page NO.
Starter motor brush length	9.0 (0.35)	3.5 (0.14)	Page 17-3

Unit: mm (in)

TROUBLESHOOTING

Starter motor will not turn

- Check for a blown main fuse (10 A)
- Check that the battery is fully charged and in good condition.


ELECTRIC STARTER

STARTER MOTOR

REMOVAL

A WARNING

Always turn the ignition switch OFF before servicing the starter motor. The motor could suddenly start, causing serious injury.

Remove the mounting bolts (2 nos.), ground wire and the starter motor from the crankcase.



Slide the dust cover off the starter motor terminal.

Remove the screw (1 no.) and bolt (1 no.) to release the starter motor wire from the starter motor.





DISASSEMBLY

Remove the bolts (2 nos.) and motor case.

Remove the following:

- Gasket
- Armature
- Front bracket

INSPECTION

Measure the brush length.

SERVICE LIMIT: 3.5 mm (0.14 in)

Springs

ELECTRIC STARTER

Inspect the commutator bars of armature for discoloration.

Bars discolored in pairs indicate shorted coils.

NOTICE

Do not use emery or sand paper on the commutator.



Check for continuity between pairs of commutator bars. There should be continuity.



Check for continuity between each commutator bar and the armature shaft.

There should be no continuity.



STARTER MOTOR ASSEMBLY



Install the springs into the brush holders.



Push and hold the brushes into the brush holders, and insert the armature into the front bracket.



Be careful not to damage the brush and armature.



Install the new gasket onto the front bracket.

Install the armature into the motor case while holding the armature tightly to keep the magnet from pulling the armature against the case.

Install a new O-ring.



Install and tighten the bolts (2 nos.).



INSTALLATION

Tighten the screw (1 no.) and bolt (1 no.) to connect the starter motor wire from the starter motor.

Slide the dust cover on the starter motor wire (Red/White) terminal.



Install the starter motor into the crankcase.

Install the ground wire and mounting bolts (2 nos.), and tighten the bolts securely.

Connect the starter motor wire to the terminal, tighten the screw (1 no.) and install the dust cover over the terminal.



STARTER RELAY

INSPECTION

Remove the battery cover (page 2-6). Remove the starter relay.



STARTER RELAY VOLTAGE

Measure the voltage between the yellow/red wire terminal (+) and ground (–).

If battery voltage appears when the starter switch is pushed with the ignition switch ON, the power source circuit is normal.

Connect the starter relay switch connector.



GROUND LINE AND RELATED CIRCUITS

Disconnect the spark unit connector (page 16-5).

Measure the following between the wire terminals of the wire harness side connectors with the ignition switch ON.

Item	Terminal	Specification
Starter relay	White/green (+)	Battery voltage with
switch ground	and green (–)	the starter switch
line		pushed
Starter switch	Yellow/red (+)	Battery voltage with
line	and green (–)	the starter switch
		pushed
Brake light switch line	Green/yellow (+) and green (–)	Battery voltage with the brake applied



Install the removed parts in the reverse order of removal.

COMPONENT LOCATION



18. LIGHTS/METER/SWITCHES

COMPONENT LOCATION	18-0	IGNITION SWITCH	18-6
SERVICE INFORMATION	18-1	HANDLEBAR SWITCHES	18-7
HEADLIGHT	18-2	BRAKE LIGHT SWITCH	18-7
BRAKE /TAIL LIGHT	18-3	HORN	18-8
TURN SIGNAL LIGHTS	18-3	TURN SIGNAL RELAY	18-9
SPEEDO METER	18-4		

SERVICE INFORMATION

GENERAL

NOTICE

- A halogen headlight bulb become very hot while the headlight is "ON", and remain hot for a while after it is turned "OFF".
 Be sure to let it cool down before servicing.
- Note the following when replacing the halogen headlight bulb.
 - Wear clean gloves by replacing the bulb. Do not put finger prints on the headlight bulb, as they may create hot spots on the bulb and cause is to fail.
 - If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.
 - Be sure to install the dust cover after replacing the bulb.
- Keep all flammable materials away from the electric heating element. Wear protective clothing, insulated gloves and eye
 protection.
- Check the battery condition before performing any inspection that requires proper battery voltage.
- A continuity test can be made with the switches installed on the vehicle.
- All plastic connectors have locking tabs that must be released before disconnecting, and must be aligned when reconnecting.
- To isolate an electrical failure, check the continuity of the electrical path through the part. A continuity check can usually be made without removing the part from the vehicle. Simply disconnect the connectors and connect a continuity tester to the terminals or connections.
- The following color codes are used throughout this section.

Bu = Blue	G = Green	Lg = Light green	R = Red
BI = Black	Gr = Gray	O = Orange	W = White
Br = Brown	Lb = Light blue	P = Pink	Y = Yellow

SPECIFICATIONS

	ITEM		SPECIFICATION	Page NO.
	Hi beam	12 V – 35 W	-	
	Headlight	Low beam	12 V – 35 W	-
	Tail/Brake Light		12 V – 5/21 W	-
	Front turn signal light	ht	12 V – 10 W x 2	-
Bulb Rear turn signal light Meter light Position light High beam indicator	Rear turn signal lig	nt	12 V – 10 W x 2	-
		1.7 W x 1	-	
	Position light		5 W x 1	-
	High beam indicato	r	1.7W x 1	-
Turn signal indicator		r	1.7W x 1	-
Fuse	Ma	in Fuse	10A	-

TORQUE VALUES

ITEM	QTY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS	PAGE NO.
Light assy. head bolt adjusting	1	4	2 (0.2, 1.5)		-
Light assy. tail screw	6	4	1 (0.10, 0.73)		-
Speedometer assy screw	3	4	0.8 (0.08, 0.59)		-

HEADLIGHT

BULB REPLACEMENT

Remove the headlight assy. (page 2-2).

Disconnect the headlight and position light connectors.



Avoid touching halogen headlight bulb. Finger prints can create hot spots that cause a bulb to break. Remove the dust cover. Unhook the bulb retainer. Remove the headlight bulb. Install the new bulb while aligning the tabs of the bulb with the slots of the headlight unit. Hook the bulb retainer into the headlight unit groove.

Install the dust cover with the "TOP " mark facing up.



Connect the headlight and position light connectors. Install the headlight assy. (page 2-2).



LIGHTS/METER/SWITCHES

HEADLIGHT UNIT REMOVAL/INSTALLATION

Remove the headlight adjusting bolt.



Remove the headlight assy (page 2-2). Remove the clips and headlight unit. Installation is in the reverse order of removal. Adjust the headlight aim (page 3-16).



BRAKE/TAIL LIGHT BULB REPLACEMENT

Remove the seat (page 2-3).

Remove the tail light bulb holder by turning counter clockwise.

Remove bulb by pressing in and turning counter clock wise and replace it with a new one.

Installation is in the reverse order of removal.



TURN SIGNAL LIGHTS

BULB REPLACEMENT

Remove the screw and turn signal light lens.

Push the bulb in and turn it counterclockwise to remove.

Replace the bulb with a new one.



REMOVAL/INSTALLATION

FRONT

Route the wires properly (page 1-13).

Route the wires

properly

(page 1-13).

Remove the headlight assy. (page 2-2). Remove the turn signal mounting nut and cut out washer. Install the winker assy, by aligning the cut-out of the cover

headlight RR assy. with cut-out washer.

Installation is in the reverse order of removal.



REAR

plate stay.

Remove the seat (page 2-3). Remove the wire cover boot. Disconnect the turn signal light connectors.



Remove the nuts (1 no.) from each winker assy. TURN SIGNAL LIGHT Install the winker assy. by aligning the cut-out of the licence Installation is in the reverse order of removal.



SPEEDO METER

BULB REPLACEMENT

Remove the headlight assy. (page 2-2).

Remove the meter bulb socket.

Remove the bulb out of the meter bulb socket, and replace it with a new one.



LIGHTS/METER/SWITCHES

REMOVAL/INSTALLATION

Remove the headlight assy. (page 2-2). Disconnect the speedo meter cable.



Disconnect the speedo meter wire connectors.







DISASSEMBLY

Remove the following from speedo meter case under:

Remove the screws (3 nos.) and speedo meter assembly.

Installation is in the reverse order of removal. TORQUE: 1.1 N-m (0.1 kgf-m, 0.8 lbf-ft)

- Screws (3 nos.)
- Clamp (1 no.)
- Bulb sockets (3 nos.)
- Wire harness.



IGNITION SWITCH

INSPECTION

Remove the headlight assy. (page 2-2).

Disconnect the ignition switch 2P (White) connector and red/white connector after removing cover boot.

Check for continuity between the ignition switch connector terminal in each switch position.

Continuity should exist between the color coded wires as follows:

	BAT1	BAT2
LOCK		
OFF		
ON	o	O
COLOR	R/W	В

REMOVAL/INSTALLATION

Remove the headlight assy. (page 2-2).

Disconnect the ignition switch wire connectors.

Carefully release the ignition switch by pressing lugs from the cover meter.





LIGHTS/METER/SWITCHES

HANDLEBAR SWITCHES

LEFT HANDLEBAR SWITCHES

Remove the headlight assy. (page 2-2).

Disconnect the handlebar switches 6P and 3P from left handlebar.

Check for continuity between the terminals in each switch position according to the table.

DIMMER SWITCH

HORN SWITCH

FREE PUSH

WINKER SWITCH

WR

L

R

	HL	LO	HI	
LO	0	0		L
(N)	<u> </u>		_0	(N)
HI	0		0	R
COLOR		W	L/W	COLO

С		L	0	_0	
5	_0	(N)			
	_0	R	0		-0
/	L/W	COLOR	SB	GR	0





COLOR B LC

BAT

0-

LIGHTING SWITCH

НО		HL	C 1	RE	C2	ΗL
	OFF		0	-0		
_0	(N)		0	_0	0	-0
16	PO				0	0
LG	(N)	0	0		0	0
	H/L	0	-0		0—	0
	COLOR	Y	W			



Check for continuity between the terminals in each switch position according to the table.

STARTER SWITCH

	BAT	ST
FREE		
PUSH	0	—0
COLOR	В	Y/R



BRAKE LIGHT SWITCH

FRONT

Remove the headlight assy. (page 2-2).

Disconnect the front brake light connectors.

There should be continuity with the brake lever squeezed, and there should be no continuity when the brake lever is released.

Continuity : Green/Yellow - Black



REAR

Remove the headlight assy. (page 2-2).

Disconnect the rear brake light switch 2P connectors, and check for continuity between the terminals.

There should be continuity with the brake pedal squeezed, and there should be no continuity when the brake pedal is released.

Continuity : Green/Yellow - Black



HORN

INSPECTION

Disconnect the wire connectors from the horn.

Connect the multi-meter to the horn terminals.

The horn is normal if it sounds when the battery voltage is connected across the horn terminals.



REMOVAL/INSTALLATION

Disconnect the wire connectors from the horn.

Remove the bolt and horn.



TURN SIGNAL RELAY

INSPECTION

1. Recommended Inspection

Check the following:

- Battery condition
- Burned out bulb or non-specified wattage
- Burned fuse
- Ignition and turn signal switches function
- Loose connector

Are the above items in good condition?

NO – Replace or repair the malfunction parts. **YES** – GO TO STEP 2.

2. Turn Signal Circuit Inspection

Remove the battery cover (page 2-6).

Disconnect the turn signal relay 2P connector from the turn signal relay.

Short the Black and Gray terminals of the turn signal relay connector with a jumper wire.

Start the engine and check the turn signal light by turning the switch "ON".

Is the light come on?

- YES • Faulty turn signal relay
 Poor connection of the connector
- NO Open circuit in Black or Gray wires

REMOVAL/INSTALLATION

Remove the battery cover (page 2-6).

Disconnect the turn signal relay 2P connector from the relay.

Remove the turn signal relay from the bracket.





MEMO



19-1

В	BLACK/काला	BR	BROWN/ भूरा			
Y	YELLOW/पीला	0	ORANGE/ संतरी			
L	BLUE/ नीला	SB	SKY BLUE/आसमानी			
G	GREEN/हरा	LG	LIGHT GREEN/ हल्का हरा			
R	RED/लाल	P	PINK/ गुलाबी			
W	WHITE/ सफेद	GR	GRAY/ सलेटी			
COI	COLOR COMB GROUND/MARKING					

19-1

20. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START	20-1	POOR PERFORMANCE AT HIGH SPEED	20-4
ENGINE LACKS POWER	20-2	POOR HANDLING	20-4
POOR PERFORMANCE AT LOW AND	20-2		
	20-3		

ENGINE DOES NOT START OR IS HARD TO START



ENGINE LACKS POWER

		Possible cause
1. Raise rear wheel off ground and ——— accelerate lightly Engine speed increase	—— Engine speed does not — increase sufficiently	 Clogged air cleaner Restricted fuel flow Clogged fuel tank cap breather hole Clogged muffler
2. Check ignition timing	Incorrect	 Faulty spark unit Faulty ignition pulse generator
3. Test cylinder compression ————	Low compression	 Valve clearance too small Improper valve and seat contact Worn cylinder, piston and piston rings Valve stuck open
Normal compression		 Improper valve timing Leaking cylinder head gasket Loose spark plug
4. Check carburetor for clogging ——— I Normal	Clogged	 Carburetor not serviced frequently enough
 5. Remove and inspect spark plug Not fouled or discolored 	—— Fouled or discolored ——	 Plug not serviced frequently enough Use of plug with improper heat range
6. Check if engine overheats Not overheating	Overheating	 Lean fuel mixture (section 5) Wrong type of fuel Excessive carbon build-up in combustion chamber Ignition timing too advance (Faulty spark unit or ignition pulse generator) Drive and driven pulleys/ clutch slipping (section 10) Any extra modification
 Try rapid acceleration or run at high speed 	Engine knocks	 Excessive carbon build-up in combustion chamber Wrong type of fuel Lean fuel mixture (section 5) Ignition timing too advance (Faulty spark unit or ignition pulse generator) Throttle position switch faulty

POOR PERFORMANCE AT LOW AND IDLE SPEEDS



POOR PERFORMANCE AT HIGH SPEED

		Possible cause
1. Check fuel flow from fuel tank	- Fuel flow restricted	Clogged fuel stainerClogged fuel tube/vaccum tube
Fuel flows enough		
↓ ↓		
2. Check carburetor for clogging	- Clogged	Carburetor not serviced frequently enough
Normal		
3. Check valve timing	- Incorrect	 Cam sprocket not installed properly
Correct		
4. Check ignition timing	- Incorrect	 Faulty ignition pulse generator
		Faulty spark unit
Correct		
5. Check choke valve	- Abnormal	Choke valve open or broken
Normal		
6. Check valve spring	- Weak	 Faulty valve spring
POOR HANDLING		
		Possible cause
1. If steering is hard		 Steering stem adjusting nut too tight
		 Damaged steering head bearings
2. If either wheel is wobbling	→	 Excessive wheel bearing play Bent rim
		Improper installed wheel hub
		Swingarm pivot bushing excessively wornBent frame
3. If the scooter pulling to one side		 Faulty shock absorber
		 Front and rear wheel not aligned Bont fork
		Bent swingarm
		Bent axle

21. INDEX

AIR CLEANER	3-6
AIR CLEANER HOUSING	5-3
AIR SCREW ADJUSTMENT	5-9
ALTERNATOR INSPECTION	15-8
ALTERNATOR INSTALLATION	11-3
ALTERNATOR REMOVAL	11-2
BATTERY	15-3
BATTERY CASE	2-8
BATTERY COVER	2-6
BEARING REPLACEMENT	10-4
BRAKE /TAIL LIGHT	18-3
BRAKE LIGHT SWITCH	18-7
BRAKE SHOES WEAR	3-14
BRAKE SYSTEM	3-15
CABLE & HARNESS ROUTING	1-13
CAMSHAFT INSTALLATION	7-20
CAMSHAFT REMOVAL	7-19
CARBURETOR INSTALLATION	5-8
	5-4
CHARGING SYSTEM INSPECTION	15-6
CHOKE OPERATION	3-5
CLUTCH SHOES WEAR	3-16
	9-16
	9-12
	1_3
	1-0
	11_0
	15-0
	12-0
	7_0
	8-0
	17-0
	10-0
	2.0
	2-0
	12.0
SUSPENSION/STEERING	5.0
	16.0
	10-0
	0.0
	9-0
	2.0
	3-0
COVED CENTED	14-0
	2-3
	3-0
	12-4
	12-2
	12-3
	7-3
	1-15
	7-1
	7-8
OTLINDER HEAD INSTALLATION	7-16
	7-5
GILINDER INSTALLATION	8-6

CYLINDER REMOVAL	8-2	
DRIVE BELT	3-13	
DRIVE PULLEY INSTALLATION	9-18	
DRIVE PULLEY REMOVAL	9-10	
DRIVESHAFT INSTALLATION	10-7	
DRIVESHAFT REMOVAL	10-3	
EMISSION CONTROL SYSTEMS	1-18	
ENGINE & FRAME TORQUE VALUES	1-8	
ENGINE IDLE SPEED	3-11	
ENGINE INSTALLATION	6-4	
ENGINE OIL	3-9	
ENGINE OIL STRAINER SCREEN	3-11	
ENGINE REMOVAL	6-2	
EXHAUST PIPE/ MUFFLER	2-10	
FINAL DRIVE OIL	3-13	
FINAL REDUCTION ASSEMBLY	10-7	
	10-3	
FLOOR SET	2_11	
FORK	13-24	
	2-2	
EDONIT BDAKE	12.0	
	13-0	
	2-1	
	13-3	
	3-4	
	5-12	
FUEL STRAINER SCREEN	3-4	
	5-13	
FUEL TANK COVER LOWER	2-3	
FUEL TANK COVER	2-3	
FUEL TANK	2-6	
FUSE BOX	3-14	
HANDLEBAR	13-14	
HANDLEBAR SWITCHES	18-7	
HEADLIGHT	18-2	
HEADLIGHT AIM	3-16	
HEADLIGHT ASSEMBLY	2-2	
HEADLIGHT COVER DISASSEMBLY	2-2	
HORN	18-8	
IGNITION COIL	16-5	
IGNITION SWITCH	18-6	
IGNITION SYSTEM INSPECTION	16-3	
IGNITION TIMING	16-5	
INTAKE/EXHAUST SHROUDS	7-4	
KICKSTARTER	9-3	
LEFT SIDE COVER	2-5	
LUBRICATION & SEAL POINTS	1-11	
MAINTENANCE SCHEDULE	3-3	
MODEL IDENTIFICATION	1-2	21
MUFFLER & EX. PIPE PROTECTOR	2-9	
NUTS, BOLTS, FASTENERS	3-18	
OIL PUMP	4-2	
PISTON INSTALLATION	8-5	
PISTON REMOVAL	8-3	
REAR BRAKE	14-4	
REAR COWL COVER	2-8	
· · · · · - · · · · · · · ·		

REAR COWL	2-7
REAR FENDER	
REAR GRIP	2-7
REAR WHEEL	14-3
RECTIFIER COMP. REGULATOR	15-8
RIGHT SIDE COVER	2-4
SEAT	2-3
SECONDARY AIR SUPPLY SYSTEM	5-10
SERIAL NUMBERS	1-3
SERVICE INFORMATION	
ALTERNATOR	11-1
BATTERY/ CHARGING SYSTEM	15-1
CRANKCASE/ CRANKSHAFT	12-1
CYLINDER HEAD/VALVES	7-1
CYLINDER/ PISTON	8-1
ELECTRIC STARTER SYSTEM	17-1
	6-1
	10-1
	2 1
	2-1
	10.1
SUSPENSION/ STEERING	13-1
	1-6
	16-1
DRIVEN PULLEY/ CLUICH	9-1
LIGHTS/ METER/ SWITCHES	18-1
	4-1
MAINTENANCE	3-1
REAR WHEEL/ BRAKE/ SUSPENSION	14-1
SERVICE RULES	1-1
SHOCK ABSORBER	14-7
SIDE STAND	2-11
SPARK PLUG	3-7
SPARK UNIT	16-5
SPECIFICATION	
BATTERY/CHARGING SYSTEM SPECIFICATION	S 1-7
CYLINDER HEAD/VALVES SPECIFICATIONS	1-5
CYLINDER/PISTON SPECIFICATIONS	1-6
FINAL REDUCTION SPECIFICATIONS	1-6
FRONT WHEEL/BRAKE/	
SUSPENSION/STEERING SPECIFICATIONS	1-7
FUEL SYSTEM SPECIFICATIONS	1-5
GENERAL SPECIFICATION	1-4
IGNITION SYSTEM SPECIFICATIONS	1-7
KICKSTARTER/ DRIVE AND DRIVEN PULLEY/	
CLUTCH SPECIFICATIONS	1-6
LIGHTS/METER/SWITCHES SPECIFICATION	1-7
LUBRICATION SYSTEM SPECIFICATIONS	1-5
REAR WHEEL/BRAKE/	
SUSPENSION SPECIFICATIONS	1-7
SPEEDO METER	18-1
SPEEDOMETER ASSEMBLY	2-2
	<u>۲</u> -۲ ۱ ۵
	17 2
	0.0
	9-0

STARTER RELAY	17-7
STEERING HEAD BEARINGS	3-18
STEERING LOCK	13-28
STEERING STEM	13-20
SUSPENSION	3-17
SYSTEM DIAGRAM	
BATTERY/ CHARGING SYSTEM	15-0
ELECTRIC STARTER	17-0
IGNITION SYSTEM	16-0
LUBRICATION	4-0
TAIL LIGHT	2-8
TANK COVER CENTER	2-6
THROTTLE OPERATION	3-5
TOOLS	1-10
TROUBLESHOOTING	
BATTERY/ CHARGING SYSTEM	15-2
CRANKCASE/ CRANKSHAFT	12-1
CYLINDER HEAD/VALVES	7-2
CYLINDER/ PISTON	8-1
ELECTRIC STARTER	17-2
ENGINE DOES NOT START	
OR IS HARD TO START	20-1
ENGINE LACKS POWER	20-2
FRAME/BODY PANELS/EXHAUST SYSTEM	2-1
FRONT WHEEL/ BRAKE/	
SUSPENSION/ STEERING	13-2
FUEL SYSTEM	5-2
IGNITION SYSTEM	16-2
KICKSTARTER/ DRIVE AND	
DRIVEN PULLEY/ CLUTCH	9-2
LUBRICATION SYSTEM	4-1
POOR HANDLING	20-4
POOR PERFORMANCE AT HIGH SPEED	20-4
POOR PERFORMANCE	
AT LOW AND IDLE SPEEDS	20-3
REAR WHEEL/ BRAKE/ SUSPENSION	14-2
TURN SIGNAL LIGHTS	18-3
TURN SIGNAL RELAY	18-9
VALVE CLEARANCE	3-8
VALVE GUIDE REPLACEMENT	7-9
VALVE SEAT INSPECTION/ REFACING	7-10
WHEELS/TYRES	3-18
WIRING DIAGRAM	19-1

